
About this book 1

How this book is organized	1
Related documentation	2
Typographical conventions	3
How can we improve this book?	4

Chapter 1

About UnixWare 7 systems 5

UnixWare 7 licenses	5
Evaluation licenses	6
UnixWare 7 system profiles	7
Media	7
Printed documentation	8
Free* UnixWare 7	8
Accessing SCO Services information online	8
Finding SCO training	9

Chapter 2

Before you install 11

System requirements	12
Verifying supported hardware	13
Installing and configuring hardware devices	13
Installation checklists	14
General installation checklist	15
Installation hardware checklist	19
Network checklists	21
Partitions and filesystems checklists	25

Chapter 3

Installing a UnixWare 7 system 33

Responding to prompts	33
The installation procedure	34
Configuring a TCP network installation	39
Configuring an SPX network installation	40

Manually selecting sets, services, and packages	41
---	----

Chapter 4	
After you install	43

Configuring additional hardware	44
Configuring and administering the system	45
Specifying a desktop to use	47
Configuring and using SCOhelp	48

Chapter 5	
Licensing and registering SCO products	49

The License Manager interface	50
Licensing products	50
Removing product licenses	51
Registering products	51
Troubleshooting license and registration problems	52
License Manager will not accept registration key	53
License Manager will not accept license information	53
Licensing Policy Manager Daemon (ifor_pmd) has terminated	53
UnixWare license has expired	54
No user licenses were found on this machine	54
Policy manager has died	55

Chapter 6	
Creating and using emergency recovery media	59

Keys to recovering your system	59
Creating emergency recovery diskettes	60
Creating emergency recovery tapes	62
Handling tape error messages	64
After creating emergency recovery tapes	65
Recovering an unusable system	65

Chapter 7
Adding or removing hard disks, tapes, and other devices **69**

Starting the DCU	70
Adding hardware controllers	70
Configuring hardware controllers	72
Removing hardware controllers	73
Rebuilding your system	74
Adding hard disks	75
Adding a hard disk — an annotated example	75
Adding tape drives	78

Chapter 8
Configuring video adapters **79**

The Video Configuration Manager interface	80
Understanding video configuration	80
About function keys and video configuration	81
Understanding resolutions	82
Searching for adapters	83
Understanding multi-monitor configuration	83
Modifying monitors, resolutions, and function keys	85
Changing the configured video monitor	85
Changing a configured resolution	86
Adding a resolution	86
Assigning function keys	86
Testing a video adapter configuration	87
Adding a new video adapter	88
Removing a video configuration	89
Configuring unsupported adapters	90

Appendix A
Configuring installation hardware **91**

Viewing hardware device configuration	92
Modifying hardware device configuration	93
Viewing and activating software device drivers	94
Adding a new controller for a device driver	95

Configuring PC Card (PCMCIA) modems	96
Enabling the pcic driver	96
Index	99