

S3 Color Control Help

The S3 Color Control program controls in this dialog box allow you to adjust the Hue, Saturation, Brightness and Contrast for YUV video overlays. YUV video overlays are often used when playing MPG files.

S3 Color

The S3 Color Control program controls in this dialog box allow you to adjust the Hue, Saturation, Brightness and Contrast for YUV video overlays. YUV video overlays are often used when playing MPG files.

Move this slider to adjust the HUE. This changes the color of the video picture.

Move this slider to adjust the HUE. This changes the color of the video picture.

Move this slider to adjust the SATURATION. As saturation is lowered more color is lost and the video picture becomes grayer. When the saturation is increased the color becomes more pronounced.

Move this slider to adjust the SATURATION. As saturation is lowered more color is lost and the video picture becomes grayer. When the saturation is increased the color becomes more pronounced.

Move this slider to adjust the BRIGHTNESS. By changing the brightness you can make the picture appear lighter or darker.

Move this slider to adjust the BRIGHTNESS. By changing the brightness you can make the picture appear lighter or darker.

Move this slider to adjust the CONTRAST. Changing the contrast will accent the difference between lighter and darker parts of the picture.

Move this slider to adjust the CONTRAST. Changing the contrast will accent the difference between lighter and darker parts of the picture.

Press this button to set the color adjustments back to the NORMAL position.

Press this button to save the selected color adjustments.

Press this button to cancel (undo) any color adjustments made. Color adjustments are returned to their starting positions. Pressing this button exits the S3 Color program.

Press this button to cancel (undo) any color adjustments made. Color adjustments are returned to their starting values.

Use the controls in this box to make color adjustments.

Move this slider to adjust the HUE. This changes the color of the video picture.

Move this slider to adjust the SATURATION. As saturation is lowered more color is lost and the video picture becomes grayer. When the saturation is increased the color becomes more pronounced.

Move this slider to adjust the BRIGHTNESS. By changing the brighter you can make the picture appear lighter or darker.

Move this slider to adjust the CONTRAST. Changing the contrast will accent the difference between lighter and darker parts of the picture.

Use these buttons to restore default color settings or to undo color adjustments.

