

## NE2000 Compatible ISA Adapters Setup

Use this dialog box to configure settings for the  
IBM ISA Ethernet Adapter  
D-Link DE-220 Ethernet Adapter  
LinkSys Ether16 Ethernet Adapter

### **IRQ Level**

Select an interrupt level for his adapter. Do not set this to IRQ3 if you have two COM ports COM1=IRQ4 and COM2=IRQ3).

### **I/O Port Address**

Select a number (expressed as a hexadecimal string) to specify the I/O port base address.

