

TV Out Page

Allows you to use a TV to display the video card output.

Enables Windows to automatically switch your display to the TV any time one of your applications switches to 640x480 resolution. It is recommended to enable this only if you have both a TV and a monitor connected to your system.

Allows you to choose which display to use, either TV or monitor.

Allows you to choose which display to use, either TV or monitor.

Selects to display on a connected TV.

Selects to display on a connected monitor.

Set the amount of flicker filtering, High, Low or Off. Use flicker filtering to reduce the amount of flicker visible on your TV display. Turn the flicker filter off for compatibility with some games.

Set the amount of flicker filtering, High, Low or Off. Use flicker filtering to reduce the amount of flicker visible on your TV display. Turn the flicker filter off for compatibility with some games.

Graphically displays your currently selected display, either TV or monitor.

Allows you to move the image on your TV display up, down, left and right. The image is restored to its original position after 10 seconds unless the OK or Apply buttons are selected.

Restores the image on your TV display to the default position.

