

Sheet1

PR_NAME,C,40	PR_SETUP,C,80	PR_RESET,C,80
Alphacom 8125		
Anadex 9620A		
Anadex DP-6500		
Anadex DP-9001/DP-9501		
	LGP	
	LANGUAGE=X630	
	X630.RESET	
	X630.SPACING=STANDARD	
AST TurboLaser	END!	
Blaser	(
Brother DM-40	@	@
Brother HR-1		
Brother HR-15/HR-25		
Brother HR-20	P	
Brother HR-40	P	
C. Itoh 8510A		
C. Itoh CI-400/CI-800	>	
C. Itoh F10		
C. Itoh LIPS 10+	(O) SEM 6; EXIT;E	
Canon BJ-300/BJ-330 (IBM mode)	[K[\ØI	
Canon Bubble Jet BJ-130e	[K	
Canon Control Capsule 48/XL		
Canon LBP-4	; <[0q[?1;5;6;7;32h[?2;4;33l[0;4;10;0;0;0%u	<
	:	
Canon LBP-8 A1/A2	P	
Canon LBP-8 A1/A2(ISO)	c	
Canon LBP-8 II (IBML Graphic Set)	; <('\$2[?1;5;6h[?2;4l	<
Canon LBP-8 IIR/IIT (ISO_UK Graphic Set)	; <[0q(A[?1;5;6h[?2;4l	<
Canon LBP-8 Mark III	; <[0q[?1;5;6;7;32h[?2;4;33l[0;4;10;0;0;0%u	<
Centronics 351/352/353		
Centronics H80-1/H80-2	@	
Citizen MSP-10/MSP-15	@	
Comrex CR-I		
Comrex CR-II	P	
Cordata LP300	@RESET;@FONT MX9M;	
DaisyWriter 1500/2000	S	
Data Products LZR 2655	E	
Datasouth DS 180		
Diablo 620 & 630	P	
Dynax DX-15	P	
Epson EX,FX,JX,LX,RX High-Speed Draft	@	
Epson EX,FX,JX,LX,RX Microspace Draft	@	
Epson EX,FX,JX,LX,RX Microspace NLQ	@x1	
Epson LQ Series Draft Mode	@x0	

Sheet1

Epson LQ Series Letter Quality Mode	@x1	
Epson MX	@	
Fujitsu DL 1200	@	@
Fujitsu DL 3300/3400	I	I
Genicom 4410	c[;13m	
HP DeskJet	E(10U&kG	E
HP DeskJet Plus/DeskJet 500	E(10U&kG	E
HP LaserJet (Original)	&l1H(10U	E
HP LaserJet +	&l1H(10U	E
HP LaserJet 2000	&l1H(10U	E
HP LaserJet 500+	&l1H(10U	E
HP DeskJet Plus/DeskJet 500	E(10U&kG	E
HP LaserJet II D Duplex	&l1H(10U	E
HP LaserJet II D Simplex	&l0S&l1H(10U	E
HP LaserJet III	&l1H(10U	E
HP LaserJet III D Duplex	&l1H(10U	E
HP LaserJet III D Simplex	&l0S&l1H(10U	E
HP LaserJet III Si Simplex	%-12345X@PJL ENTER LANGUAGE = PCL &l0S&l1H(10U	%-12345X
HP LaserJet III Si Standard	%-12345X@PJL ENTER LANGUAGE = PCL &l1H(10U	%-12345X
HP PaintJet	E(10U&v0S	(10U&v0S
HP ThinkJet	E	
IBM 5218	[K	[K
IBM Color Printer	?	
IBM LaserPrinter 4019	[K1";[HØ[I□μ	[K
HP LaserJet II	&l1H(10U	E
IBM LaserPrinter 4029 Series	[K1";[HØ[I□μ	[K
IBM LetterQuality 5218	p5	
IBM Pageprinter 3812		
IBM PPSII 2380/2381 Draft Mode	[K[d@	[K
IBM PPSII 2380/2381 Letter Quality mode	[K[d€	[K
IBM PPSII 2390/2391 Draft Mode	[K[d@	[K
IBM PPSII 2390/2391 Letter Quality Mode	[K[d€	[K
IBM Proprinter II, XL, IIXL, X24, XL24		
IBM Quietwriter 5201		
IBM Quietwriter III		
IBM Wheelprinter 5216		
IDS 460		
IDS Prism 80/132		
Juki 6100	IQ	
Kyocera F-1000A	!R! RES; UNIT D; EXIT;(10U	!R! RES; EXIT;
Kyocera F-1010 (Landscape)	!R! RES; UNIT D; SPO L; EXIT;	
Kyocera F-1010 (Portrait)	!R! RES; UNIT D; SPO P; EXIT;	
Mannesmann MT160/180	[6~	
Mannesmann Spirit-80	@	

Sheet1

NEC Pinwriter P2/P3		
NEC Pinwriter P2200	@	
NEC Pinwriter P5/P6/P7	@	
NEC Pinwriter P5200/P5300	@	
NEC Pinwriter P9XL	((
NEC Silentwriter LC 850	#A	
NEC Silentwriter LC 860	E	
NEC Spinwriter 2000	#A	#A
NEC Spinwriter 3550	=	
NEC Spinwriter 5515/25		
NEC Spinwriter 7710/20	#B	
NEC Spinwriter 7715/25	R	
NEC Spinwriter 7730		
Oki 320/321	@	@
Oki Laser 400	E	
Oki Microline 182/183		
Oki Microline 192/193		
Oki Microline 292/3/4		
Oki Microline 390/391	@t1	
Oki Microline 393/393C	@6	
Oki Microline 82A/83A		
Oki Microline 84/92/93		
Oki Okimate 20		
Oki Pacemark 2350		
Oki Pacemark 2410		
Oki Pacemerk 2410-IBM		
Oki Plug&Play 192/193		
Oki Plug&Play 82A/83A		
Oki Plug&Play 84/92/93		
Olympia NP-80/NP-136	@6	@
Panasonic KX-P1090	@	
Panasonic KX-P1124	@t	@
Panasonic KX-P1091	@	
Panasonic KX-P1180	@t	
Panasonic KX-P1624	@	
Panasonic KX-P3151	I	
Panasonic KX-P4450/4450i Epson Mode	E;@t	@
Panasonic KX-P4450/4450i Panasonic Mode	H,P,X0,Y0;1E(10U	E
Primage I	P	P
Quadram QuadJet		
Quadram QuadLaser	1e 1s 2i	
Qume LetterPro 20	P	P
Qume Sprint 5	I	
Qume Sprint 9/45, 9/55	I	

Sheet1

Sanyo PR-5500	P
Silver Reed 550	
Silver Reed 770	P
Star Gemini 10-X/15-X	@
Star Radix 10/15	@
Tandy DMP 2100P	!:
Tandy DMP 2110	7!
Toshiba P 351 SX	I
Toshiba PageLaser 12	I
Texas Instruments 810 LQ	+X
Xerox 2700 II	
Xerox 4045 - 630 Mode ASCII	P+1Titan10iso-P+2XCP14iso-L

Sheet1

PR_6LPI,C,80

PR_8LPI,C,80

H
H
H

I
I
I

LGP
X630.VERTICAL=51
END!

LGP
X630.VERTICAL=68
END!

2
2
6

0
0

RS
A
?!
L08
&l7.27C
2
2
2
[0 L

RS
B
?!#
L06
&l5.45C
0
0
0
[4 L

>0 B
[0 L
[0 L
[0 L
[1z
2
2
6

>4 B
[4 L
[4 L
[4 L
[2z
0
0

@LH 48;@TBORDER 66;@PHEIGHT 3168;
808
&l6D
[1z

@LH 36;@TBORDER 66;@PHEIGHT 3168;
806
&l8D
[2z

2
2
2
2

0
0
0
0

Sheet1

[illegible]

&l6D

&l6D
&l6D
&l6D

2

3\$
&l6D

3\$

2

2

2

2

2

2

2

2

2

2

B,8,\$

B,8,\$

```
!R! SLPI 6; EXIT, E;  
!R! STM 102; SLPP 51; SLS 46; EXIT;  
!R! STM 132; SLPP 66; SLS 46; EXIT;  
[3z  
2
```

[illegible]

&l8D

&l8D
&l8D
&l8D

0

0

0

&l8D

0

0

0

0

0

0

0

0

0

0

0

B,6,\$

B,6,\$

```
!R! SLPI 8; EXIT, E;  
!R! STM 85; SLPP 68; SLS 35; EXIT;  
!R! STM 110; SLPP 88; SLS 35; EXIT;  
[4z  
0
```

Sheet1

2
2
2
2
2
2
&l7.27C
JW
2
JW
JW
JW
JW
2
&l6D
3\$
6
6
2
2
6
6
2
4
A12
2
2
2
2
2
2
2
2
2
2
2

2
&l6D

F

8

0
0
0
0
0
0
&I5.45C
JU
0
JU
JU
JU
JU
0
&I8D
0
8
8
0
0
8
8
A
5
0
0
0
0
0
0
0
0
0
0
0

0
&l8D

F

6

2	0
2	0
	0
2	0
L8	L6
%	
4	5

Sheet1

PR_10CPI,C,80

PR_12CPI,C,80

PR_COMPR,C,80

U
Q

T
T

R
R

LGP
X630.FONT[1]=PCOURIER12
END!F

LGP
X630.FONT[2]=PCOURIER9
END!F
%

LGP
X630.FONT[3]=PCOURIER7
END!F

P
P

M
E

M
M

US
N
?
E12
(s10H

US
E
?!
E10
(s12H
:
:
:

Q
?#
E08
(s16.6H

[0 K

[1 K

('\$2[?1666 K

>0 K
[0 K
[0 K
[0 K
[1w

>1 K
[1 K
[1 K
[1 K
[2w
M

>2 K
[2 K
[2 K
[?1700 K
[4w

P
P

M
E

M

P
(s10H
[1w

E
(s12H
[2w

M
(s16.6H
[4w

P
P
P

M
M
M
M

Sheet1

P	M	
	M	
P	M	
P	M	
[;72 G	[;60 G	[;43 G
(s10H	(s12H	(s16.67H
(s10H	(s12H	(s16.67H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.67H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
(s10H	(s12H	(s16.66H
&k0S	&k4S	&k2S
&k3S	&k0S	&k2S
>	>	>
	:	
	:	
(s10H	(s12H	(s16.66H
	:	
	:	
X,,	Xž	XÆ
	:	
	:	
!R! SCPI 10; EXIT, E;	!R! SCPI 12; EXIT, E;	(s16.66H
(s10H	(s12H	(s16.6H
(s10H	(s12H	(s16.6H
[4w	[5w	[6w

?1	?3	?7
P	M	
P	M	g
P	M	g
P	M	P
S	I	
(s10H	(s12H	(s16.6H
]L]J]H
S	I	
]L]J]H
]L]J]H
]L]J]H
]L]J]H
P	M	P
(s10H	(s12H	(s16.6H
	:	
P	M	
P	M	g
	:	
6	A	B
6	A	B
	:	
	:	
	:	
P	P	P
P	M	P
P	M	
	M	
P	M	g
P	M	
(s10H	(s12H	(s16.66H
N		

[

B	B	B
B	B	B
	:	
	:	
E12	E10	[
E12	E10	[
6	V	2

Sheet1

PR_PORT,C,80	PR_LAND,C,80	PR_BDON,C,80	PR_BDOFF,C,80	PR_ULON E
		p	q	8
LGP X630.FORMAT=PORTRAIT END!	LGP X630.FORMAT=LANDSCAPE END!	O	&	E
@	?	G E	H F	- -
				E
		F	O	E
		F !	&	E X
		3!	3	2!
		O	&	-
&l0O	&l1O&l14c1E	(s3B	(s0B	&dD
		G	H	-
		G	H	-
		E	F	-
[0p	[1p	[1m	[22m	[4m
		O	&	E
>0%r	>1%r	>1m	>22m	>4m
[0p	[1p	[1m	[22m	[4m
[0p	[1p	[1m	[22m	[4m
[0p	[1p	[1m	[22m	[4m [4m
		G	H	-
		G	H	-
		F	&	E
		@FONT MX9B;	@FONT MX9M;	@ULON;
		O	&	I
&l0O	&l1O	(s3B	(s0B	&d0D \$1
		W	&	E
		F	&	E
		G	H	-1
		G	H	-1
		E	F	-1
		E	F	-1

Sheet1

[illegible]

Sheet1

		G	H	-1
		E	F	-
		G	H	-1
		E	F	!128
		E	F	-
		E	F	-
&l0O	&l1O&l14c1E	(s3B	(s0B	&dD
		*	,	-
		E	F	-
		*	,	-
		O	&	E
		E	F	-
&l0O	&l1O	(s3B	(s0B	&d0D
		G	H	-1
		T	I	C
		T	I	C
		E	F	-1
		G	H	-
		H	I	C
				-
				U
		G	H	-
		G	H	-
		G	H	-
		G	H	-
		G	H	-
		G	H	-1
		E	F	-
		O	&	E
E,P,X50,Y0; &l0O	E,L,X100,Y0; &l1O	E	F	-1
		(s3B	(s0B	&dD
		O	&	E
0m	1m	O	&	I
		Q	R	I
				I
		K	M	I

Sheet1

		O	&	E
		O	&	E
		G	H	-
		G	H	-
		E	F	-
		K3	M	I
		K	M	I
		N	O	-
		b	p	U
F1	F2	W	&	E

PR_ULOFF;PR_PR_ITOFF,C,80

R

9 t u

R

-

-

R

R

R

Y

2 3 3

R

&d@ (s1 (s0S

-

-

-

[24m [3m[23m

R

>24m >3m>22m

[24m [3m[23m

[24m [3m[23m

[24m [3m[23m

[0m

- 4 5

- 4 5

R

@ULOFF; @F@FONT MX9M;

J

&d@ (s1 (s0S

\$2

R

R

-0 4 5

-0 4 5

-0 4 5

-0 4 5

[illegible]

-0
 - 4 5
 -0 4 5
 !0 4 5
 - 4 5
 ,
 &d@ (s1 (s0S
 ,
 ,
 ,
 R
 - 4 5
 &d@ (s1 (s0S
 -0
 D !/ !*
 D !* !/
 -0 4 5
 - 4 5
 D
 - %G%H
 V
 -
 -
 - %G%H
 -
 -0 4 5
 - 4 5
 - 4 5
 - 4 5
 -0 4 5
 - 4 5
 R
 -0 4 5
 &d@ (s1 (s0S
 R
 J W &
 J
 J
 J

R
R
- 4 5
- 4 5

-
J
J
^

W

R