Print Cartridge Maintenance

Click on the desktop printer to which you want to perform print cartridge maintenance.

Cleaning Print Cartridge(s)
To clean your print cartridge(s), choose "Clean Print Cartridge(s)" from the "Printing" menu. Follow the instructions on your screen.

Aligning Print Cartridge(s)
To align your print cartridge(s), choose "Align Print Cartridge(s)" from the "Printing" menu. Follow the instructions on your screen.

Note: Refer to your DeskWriter 600 Series User Guide for more information
          on print cartridge maintenance.