

If you do not have enough memory for the picture

The memory requirement, displayed in KBytes in the status bar across the bottom of HP PictureScan's main screen, is determined by the picture's type, the kind of printer specified, and the size of the picture. Although the picture type and printer type influence the memory required, you may not want to change them to different values. They both affect the quality of the picture.

>>> Suggestions

> You may be able to reduce the size of the final picture, which will decrease the memory requirements. For instructions, see [How to Adjust the Size of a Picture](#).

> If possible, reduce the size of the selected area. Only the area inside the selection border is scanned when you click Accept, so be certain a selection border exists and is adjusted to eliminate any unneeded area. For instructions, see [How to Select Part of a Page or Picture](#).