

SEQUENCIDESC,C,60

400 Admate 100 10 CPI
401 Admate 100 12 CPI
402 Admate 100 12 Lines/Inch
403 Admate 100 15-17 CPI
404 Admate 100 6 Lines/Inch
405 Admate 100 8 Lines/Inch
406 Admate 100 Alt. Var Ln Sp
407 Admate 100 Bldirect'l ON
408 Admate 100 Bold OFF
409 Admate 100 Bold ON
410 Admate 100 Condense Off
411 Admate 100 DblStrike OFF
412 Admate 100 DblStrike ON
413 Admate 100 DblWIDE OFF
414 Admate 100 DdlWIDE ON
415 Admate 100 Draft Mode
416 Admate 100 Emphasize OFF
417 Admate 100 Emphasize ON
418 Admate 100 Initialize
419 Admate 100 Italic OFF
420 Admate 100 Italic ON
421 Admate 100 Mastr Font/Typ
422 Admate 100 NLQ Mode
423 Admate 100 Propor'nl Off
424 Admate 100 Propor'nl On
425 Admate 100 Select Char St
426 Admate 100 Set LFT Margin
427 Admate 100 Set RHT Margin
428 Admate 100 Set Tab Stops
429 Admate 100 Skip Perf OFF
430 Admate 100 Skip Perf ON
431 Admate 100 SUBScript OFF
432 Admate 100 SUBScript ON
433 Admate 100 SUP-Scr OFF
434 Admate 100 SUPERscript ON
435 Admate 100 Underline OFF
436 Admate 100 Underline ON
437 Admate 100 UNldirect'l ON
438 Admate 100 Var. Ln Space
439 Alphacom I 10 CPI
440 Alphacom I 12 CPI
441 Alphacom I 12 Lines/Inch
442 Alphacom I 15-17 CPI
443 Alphacom I 6 Lines/Inch
444 Alphacom I 8 Lines/Inch
445 Alphacom I Bold OFF
446 Alphacom I Bold ON
447 Alphacom I DblStrike OFF

448 Alphacom I DblStrike ON
449 Alphacom I DdlWIDE OFF
450 Alphacom I DdlWIDE ON
451 Alphacom I Emphasize OFF
452 Alphacom I Emphasize ON
453 Alphacom I Initialize
454 Alphacom I Move ABS Horiz
455 Alphacom I Move ABS Vert.
456 Alphacom I NLQ Mode
457 Alphacom I Propor'nl Off
458 Alphacom I Propor'nl On
459 Alphacom I Set BOT Margin
460 Alphacom I Set LFT Margin
461 Alphacom I Set RHT Margin
462 Alphacom I Set Tab Stops
463 Alphacom I Set TOP Margin
464 Alphacom I SUBScript OFF
465 Alphacom I SUBScript ON
466 Alphacom I SUP-Scr OFF
467 Alphacom I SUPERscript ON
468 Alphacom I Underline OFF
469 Alphacom I Underline ON
470 Alps Allegro 24 10 CPI
471 Alps Allegro 24 12 CPI
472 Alps Allegro 24 12 Lines/Inch
473 Alps Allegro 24 15-17 CPI
474 Alps Allegro 24 6 Lines/Inch
475 Alps Allegro 24 8 Lines/Inch
476 Alps Allegro 24 Alt. Var Ln Sp
477 Alps Allegro 24 Bldirect'l ON
478 Alps Allegro 24 Bold OFF
479 Alps Allegro 24 Bold ON
480 Alps Allegro 24 Condense Off
481 Alps Allegro 24 DblHeight OFF
482 Alps Allegro 24 DblHeight ON
483 Alps Allegro 24 DblStrike OFF
484 Alps Allegro 24 DblStrike ON
485 Alps Allegro 24 DblWIDE OFF
486 Alps Allegro 24 DdlWIDE ON
487 Alps Allegro 24 Draft Mode
488 Alps Allegro 24 Emphasize OFF
489 Alps Allegro 24 Emphasize ON
490 Alps Allegro 24 Initialize
491 Alps Allegro 24 Italic OFF
492 Alps Allegro 24 Italic ON
493 Alps Allegro 24 Mastr Font/Typ
494 Alps Allegro 24 Move ABS Horiz
495 Alps Allegro 24 Move REL Horiz
496 Alps Allegro 24 NLQ Mode

497 Alps Allegro 24 Propor'nl Off
498 Alps Allegro 24 Propor'nl On
499 Alps Allegro 24 Sel. Prt Style
500 Alps Allegro 24 Select Char St
501 Alps Allegro 24 Set LFT Margin
502 Alps Allegro 24 Set RHT Margin
503 Alps Allegro 24 Set Tab Stops
504 Alps Allegro 24 Skip Perf OFF
505 Alps Allegro 24 Skip Perf ON
506 Alps Allegro 24 SUBScript OFF
507 Alps Allegro 24 SUBScript ON
508 Alps Allegro 24 Underline OFF
509 Alps Allegro 24 Underline ON
510 Alps Allegro 24 UNIdirect'l ON
511 Alps Allegro 24 UP-Scr OFF
512 Alps Allegro 24 UPERscript ON
513 Alps Allegro 24 Var. Ln Space
514 Alps ALQ 200/300 [Epson FX] NLQ Mode
515 Alps ALQ 200/300 [Epson FX] 10 CPI
516 Alps ALQ 200/300 [Epson FX] 12 CPI
517 Alps ALQ 200/300 [Epson FX] 12 Lines/Inch
518 Alps ALQ 200/300 [Epson FX] 15-17 CPI
519 Alps ALQ 200/300 [Epson FX] 6 Lines/Inch
520 Alps ALQ 200/300 [Epson FX] 8 Lines/Inch
521 Alps ALQ 200/300 [Epson FX] Alt. Var Ln Sp
522 Alps ALQ 200/300 [Epson FX] Bldirect'l ON
523 Alps ALQ 200/300 [Epson FX] Bold OFF
524 Alps ALQ 200/300 [Epson FX] Bold ON
525 Alps ALQ 200/300 [Epson FX] Condense Off
526 Alps ALQ 200/300 [Epson FX] DbIStrike OFF
527 Alps ALQ 200/300 [Epson FX] DbIStrike ON
528 Alps ALQ 200/300 [Epson FX] DbIWIDE OFF
529 Alps ALQ 200/300 [Epson FX] DdIWIDE ON
530 Alps ALQ 200/300 [Epson FX] Draft Mode
531 Alps ALQ 200/300 [Epson FX] Emphasize OFF
532 Alps ALQ 200/300 [Epson FX] Emphasize ON
533 Alps ALQ 200/300 [Epson FX] Initialize
534 Alps ALQ 200/300 [Epson FX] Italic OFF
535 Alps ALQ 200/300 [Epson FX] Italic ON
536 Alps ALQ 200/300 [Epson FX] Mastr Font/Typ
537 Alps ALQ 200/300 [Epson FX] Propor'nl Off
538 Alps ALQ 200/300 [Epson FX] Propor'nl On
539 Alps ALQ 200/300 [Epson FX] Sel. Prt Style
540 Alps ALQ 200/300 [Epson FX] Select Char St
541 Alps ALQ 200/300 [Epson FX] Set LFT Margin
542 Alps ALQ 200/300 [Epson FX] Set RHT Margin
543 Alps ALQ 200/300 [Epson FX] Set Tab Stops
544 Alps ALQ 200/300 [Epson FX] Skip Perf OFF
545 Alps ALQ 200/300 [Epson FX] Skip Perf ON

Sheet1

546 Alps ALQ 200/300 [Epson FX] SUBScript OFF
547 Alps ALQ 200/300 [Epson FX] SUBScript ON
548 Alps ALQ 200/300 [Epson FX] SUP-Scr OFF
549 Alps ALQ 200/300 [Epson FX] SUPERscript ON
550 Alps ALQ 200/300 [Epson FX] Underline OFF
551 Alps ALQ 200/300 [Epson FX] Underline ON
552 Alps ALQ 200/300 [Epson FX] UNIdirect'l ON
553 Alps ALQ 200/300 [Epson FX] Var. Ln Space
554 Alps ALQ 200/300 [Epson LQ] 10 CPI
555 Alps ALQ 200/300 [Epson LQ] 12 CPI
556 Alps ALQ 200/300 [Epson LQ] 12 Lines/Inch
557 Alps ALQ 200/300 [Epson LQ] 15-17 CPI
558 Alps ALQ 200/300 [Epson LQ] 6 Lines/Inch
559 Alps ALQ 200/300 [Epson LQ] 8 Lines/Inch
560 Alps ALQ 200/300 [Epson LQ] Alt. Var Ln Sp
561 Alps ALQ 200/300 [Epson LQ] BIdirect'l ON
562 Alps ALQ 200/300 [Epson LQ] Bold OFF
563 Alps ALQ 200/300 [Epson LQ] Bold ON
564 Alps ALQ 200/300 [Epson LQ] Condense Off
565 Alps ALQ 200/300 [Epson LQ] DbIHeight OFF
566 Alps ALQ 200/300 [Epson LQ] DbIHeight ON
567 Alps ALQ 200/300 [Epson LQ] DbIStrike OFF
568 Alps ALQ 200/300 [Epson LQ] DbIStrike ON
569 Alps ALQ 200/300 [Epson LQ] DbIWIDE OFF
570 Alps ALQ 200/300 [Epson LQ] DdIWIDE ON
571 Alps ALQ 200/300 [Epson LQ] Draft Mode
572 Alps ALQ 200/300 [Epson LQ] Emphasize OFF
573 Alps ALQ 200/300 [Epson LQ] Emphasize ON
574 Alps ALQ 200/300 [Epson LQ] Initialize
575 Alps ALQ 200/300 [Epson LQ] Italic OFF
576 Alps ALQ 200/300 [Epson LQ] Italic ON
577 Alps ALQ 200/300 [Epson LQ] Mastr Font/Typ
578 Alps ALQ 200/300 [Epson LQ] Move ABS Horiz
579 Alps ALQ 200/300 [Epson LQ] Move REL Horiz
580 Alps ALQ 200/300 [Epson LQ] NLQ Mode
581 Alps ALQ 200/300 [Epson LQ] Propor'nI Off
582 Alps ALQ 200/300 [Epson LQ] Propor'nI On
583 Alps ALQ 200/300 [Epson LQ] Sel. Prt Style
584 Alps ALQ 200/300 [Epson LQ] Select Char St
585 Alps ALQ 200/300 [Epson LQ] Set LFT Margin
586 Alps ALQ 200/300 [Epson LQ] Set RHT Margin
587 Alps ALQ 200/300 [Epson LQ] Set Tab Stops
588 Alps ALQ 200/300 [Epson LQ] Skip Perf OFF
589 Alps ALQ 200/300 [Epson LQ] Skip Perf ON
590 Alps ALQ 200/300 [Epson LQ] SUBScript OFF
591 Alps ALQ 200/300 [Epson LQ] SUBScript ON
592 Alps ALQ 200/300 [Epson LQ] SUP-Scr OFF
593 Alps ALQ 200/300 [Epson LQ] SUPERscript ON
594 Alps ALQ 200/300 [Epson LQ] Underline OFF

Sheet1

595 Alps ALQ 200/300 [Epson LQ] Underline ON
596 Alps ALQ 200/300 [Epson LQ] UNIdirect'l ON
597 Alps ALQ 200/300 [Epson LQ] Var. Ln Space
598 Alps P2000 [Epson] 10 CPI
599 Alps P2000 [Epson] 12 CPI
600 Alps P2000 [Epson] 12 Lines/Inch
601 Alps P2000 [Epson] 15-17 CPI
602 Alps P2000 [Epson] 6 Lines/Inch
603 Alps P2000 [Epson] 8 Lines/Inch
604 Alps P2000 [Epson] Alt. Var Ln Sp
605 Alps P2000 [Epson] Bldirect'l ON
606 Alps P2000 [Epson] Bold OFF
607 Alps P2000 [Epson] Bold ON
608 Alps P2000 [Epson] Condense Off
609 Alps P2000 [Epson] DblStrike OFF
610 Alps P2000 [Epson] DblStrike ON
611 Alps P2000 [Epson] DblWIDE OFF
612 Alps P2000 [Epson] DdlWIDE ON
613 Alps P2000 [Epson] Draft Mode
614 Alps P2000 [Epson] Emphasize OFF
615 Alps P2000 [Epson] Emphasize ON
616 Alps P2000 [Epson] Initialize
617 Alps P2000 [Epson] Italic OFF
618 Alps P2000 [Epson] Italic ON
619 Alps P2000 [Epson] Mastr Font/Typ
620 Alps P2000 [Epson] NLQ Mode
621 Alps P2000 [Epson] Propor'nl Off
622 Alps P2000 [Epson] Propor'nl On
623 Alps P2000 [Epson] Select Char St
624 Alps P2000 [Epson] Set LFT Margin
625 Alps P2000 [Epson] Set RHT Margin
626 Alps P2000 [Epson] Set Tab Stops
627 Alps P2000 [Epson] Skip Perf OFF
628 Alps P2000 [Epson] Skip Perf ON
629 Alps P2000 [Epson] SUBScript OFF
630 Alps P2000 [Epson] SUBScript ON
631 Alps P2000 [Epson] SUP-Scr OFF
632 Alps P2000 [Epson] SUPERscript ON
633 Alps P2000 [Epson] Underline OFF
634 Alps P2000 [Epson] Underline ON
635 Alps P2000 [Epson] UNIdirect'l ON
636 Alps P2000 [Epson] Var. Ln Space
637 Alps P200G/2100 10 CPI
638 Alps P200G/2100 12 CPI
639 Alps P200G/2100 12 Lines/Inch
640 Alps P200G/2100 15-17 CPI
641 Alps P200G/2100 6 Lines/Inch
642 Alps P200G/2100 8 Lines/Inch
643 Alps P200G/2100 Alt. Var Ln Sp

644 Alps P200G/2100 Bldirect'l ON
645 Alps P200G/2100 Bold OFF
646 Alps P200G/2100 Bold ON
647 Alps P200G/2100 Condense Off
648 Alps P200G/2100 DbIHeight OFF
649 Alps P200G/2100 DbIHeight ON
650 Alps P200G/2100 DbIStrike OFF
651 Alps P200G/2100 DbIStrike ON
652 Alps P200G/2100 DbIWIDE OFF
653 Alps P200G/2100 DdlWIDE ON
654 Alps P200G/2100 Draft Mode
655 Alps P200G/2100 Emphasize OFF
656 Alps P200G/2100 Emphasize ON
657 Alps P200G/2100 Initialize
658 Alps P200G/2100 Italic OFF
659 Alps P200G/2100 Italic ON
660 Alps P200G/2100 Mastr Font/Typ
661 Alps P200G/2100 Move ABS Horiz
662 Alps P200G/2100 Move REL Horiz
663 Alps P200G/2100 NLQ Mode
664 Alps P200G/2100 Propor'nI Off
665 Alps P200G/2100 Propor'nI On
666 Alps P200G/2100 Sel. Prt Style
667 Alps P200G/2100 Select Char St
668 Alps P200G/2100 Set LFT Margin
669 Alps P200G/2100 Set RHT Margin
670 Alps P200G/2100 Set Tab Stops
671 Alps P200G/2100 Skip Perf OFF
672 Alps P200G/2100 Skip Perf ON
673 Alps P200G/2100 SUBScript OFF
674 Alps P200G/2100 SUBScript ON
675 Alps P200G/2100 SUP-Scr OFF
676 Alps P200G/2100 SUPERscript ON
677 Alps P200G/2100 Underline OFF
678 Alps P200G/2100 Underline ON
679 Alps P200G/2100 UNldirect'l ON
680 Alps P200G/2100 Var. Ln Space
681 Amdek 5040 10 CPI
682 Amdek 5040 12 CPI
683 Amdek 5040 12 Lines/Inch
684 Amdek 5040 15-17 CPI
685 Amdek 5040 6 Lines/Inch
686 Amdek 5040 8 Lines/Inch
687 Amdek 5040 Bold OFF
688 Amdek 5040 Bold ON
689 Amdek 5040 DbIStrike OFF
690 Amdek 5040 DbIStrike ON
691 Amdek 5040 DdlWide OFF
692 Amdek 5040 DdlWIDE ON

693 Amdek 5040 Emphasize OFF
694 Amdek 5040 Emphasize ON
695 Amdek 5040 Initialize
696 Amdek 5040 Move ABS Horiz
697 Amdek 5040 Move ABS Vert.
698 Amdek 5040 NLQ Mode
699 Amdek 5040 Propor'n'l Off
700 Amdek 5040 Propor'n'l On
701 Amdek 5040 Set BOT Margin
702 Amdek 5040 Set LFT Margin
703 Amdek 5040 Set RHT Margin
704 Amdek 5040 Set Tab Stops
705 Amdek 5040 Set TOP Margin
706 Amdek 5040 SUBScript OFF
707 Amdek 5040 SUBScript ON
708 Amdek 5040 SUP-Scr OFF
709 Amdek 5040 SUPERscript ON
710 Amdek 5040 Underline OFF
711 Amdek 5040 Underline ON
712 Amstrad 3000/3160 10 CPI
713 Amstrad 3000/3160 12 CPI
714 Amstrad 3000/3160 12 Lines/Inch
715 Amstrad 3000/3160 15-17 CPI
716 Amstrad 3000/3160 6 Lines/Inch
717 Amstrad 3000/3160 8 Lines/Inch
718 Amstrad 3000/3160 Alt. Var Ln Sp
719 Amstrad 3000/3160 Bldirect'l ON
720 Amstrad 3000/3160 Bold OFF
721 Amstrad 3000/3160 Bold ON
722 Amstrad 3000/3160 Condense Off
723 Amstrad 3000/3160 DblHeight OFF
724 Amstrad 3000/3160 DblHeight ON
725 Amstrad 3000/3160 DblStrike OFF
726 Amstrad 3000/3160 DblStrike ON
727 Amstrad 3000/3160 DblWIDE OFF
728 Amstrad 3000/3160 DdlWIDE ON
729 Amstrad 3000/3160 Draft Mode
730 Amstrad 3000/3160 Emphasize OFF
731 Amstrad 3000/3160 Emphasize ON
732 Amstrad 3000/3160 Initialize
733 Amstrad 3000/3160 Int Chr Spac'g
734 Amstrad 3000/3160 Italic OFF
735 Amstrad 3000/3160 Italic ON
736 Amstrad 3000/3160 Mastr Font/Typ
737 Amstrad 3000/3160 Move ABS Horiz
738 Amstrad 3000/3160 Move REL Horiz
739 Amstrad 3000/3160 NLQ Mode
740 Amstrad 3000/3160 Propor'n'l Off
741 Amstrad 3000/3160 Propor'n'l On

742 Amstrad 3000/3160 Sel. Prt Style
743 Amstrad 3000/3160 Select Char St
744 Amstrad 3000/3160 Set LFT Margin
745 Amstrad 3000/3160 Set RHT Margin
746 Amstrad 3000/3160 Set Tab Stops
747 Amstrad 3000/3160 Skip Perf OFF
748 Amstrad 3000/3160 Skip Perf ON
749 Amstrad 3000/3160 SUBScript OFF
750 Amstrad 3000/3160 SUBScript ON
751 Amstrad 3000/3160 SUP-Scr OFF
752 Amstrad 3000/3160 SUPERscript ON
753 Amstrad 3000/3160 Underline OFF
754 Amstrad 3000/3160 Underline ON
755 Amstrad 3000/3160 UNIdirect'l ON
756 Amstrad 3000/3160 Var. Ln Space
757 Amstrad LQ 3500 10 CPI
758 Amstrad LQ 3500 12 CPI
759 Amstrad LQ 3500 12 Lines/Inch
760 Amstrad LQ 3500 15-17 CPI
761 Amstrad LQ 3500 6 Lines/Inch
762 Amstrad LQ 3500 8 Lines/Inch
763 Amstrad LQ 3500 Alt. Var Ln Sp
764 Amstrad LQ 3500 Bldirect'l ON
765 Amstrad LQ 3500 Bold OFF
766 Amstrad LQ 3500 Bold ON
767 Amstrad LQ 3500 Condense Off
768 Amstrad LQ 3500 DbIHeight OFF
769 Amstrad LQ 3500 DbIHeight ON
770 Amstrad LQ 3500 DbIStrike OFF
771 Amstrad LQ 3500 DbIStrike ON
772 Amstrad LQ 3500 DbIWIDE OFF
773 Amstrad LQ 3500 DdIWIDE ON
774 Amstrad LQ 3500 Draft Mode
775 Amstrad LQ 3500 Emphasize OFF
776 Amstrad LQ 3500 Emphasize ON
777 Amstrad LQ 3500 Initialize
778 Amstrad LQ 3500 Int Chr Spac'g
779 Amstrad LQ 3500 Italic OFF
780 Amstrad LQ 3500 Italic ON
781 Amstrad LQ 3500 Mastr Font/Typ
782 Amstrad LQ 3500 Move ABS Horiz
783 Amstrad LQ 3500 Move REL Horiz
784 Amstrad LQ 3500 NLQ Mode
785 Amstrad LQ 3500 Propor'nI Off
786 Amstrad LQ 3500 Propor'nI On
787 Amstrad LQ 3500 Sel. Prt Style
788 Amstrad LQ 3500 Select Char St
789 Amstrad LQ 3500 Set LFT Margin
790 Amstrad LQ 3500 Set RHT Margin

Sheet1

791 Amstrad LQ 3500 Set Tab Stops
792 Amstrad LQ 3500 Skip Perf OFF
793 Amstrad LQ 3500 Skip Perf ON
794 Amstrad LQ 3500 SUBScript OFF
795 Amstrad LQ 3500 SUBScript ON
796 Amstrad LQ 3500 SUP-Scr OFF
797 Amstrad LQ 3500 SUPERscript ON
798 Amstrad LQ 3500 Underline OFF
799 Amstrad LQ 3500 Underline ON
800 Amstrad LQ 3500 UNIdirect'l ON
801 Amstrad LQ 3500 Var. Ln Space
802 Anadex 9620A 10 CPI.
803 Anadex 9620A 12 CPI.
804 Anadex 9620A 6 lines per inch.
805 Anadex 9620A 8 lines per inch.
806 Anadex 9620A Underline Off.
807 Anadex 9620A Underline On.
808 Anadex DP-6500 10 CPI.
809 Anadex DP-6500 12 CPI.
810 Anadex DP-6500 6 lines per inch.
811 Anadex DP-6500 8 lines per inch.
812 Anadex DP-6500 Double Stike Off.
813 Anadex DP-6500 Double Stike On.
814 Anadex DP-6500 Italics Off.
815 Anadex DP-6500 Italics On.
816 Anadex DP-6500 Underline Off.
817 Anadex DP-6500 Underline On.
818 Anadex DP-9000/DP-9500 10 CPI.
819 Anadex DP-9000/DP-9500 12 CPI.
820 Anadex DP-9000/DP-9500 6 lines per inch.
821 Anadex DP-9000/DP-9500 8 lines per inch.
822 Anadex DP-9000/DP-9500 Underline Off.
823 Anadex DP-9000/DP-9500 Underline On.
824 Anadex DP-9001/DP-9501 10 CPI.
825 Anadex DP-9001/DP-9501 6 lines per inch.
826 Anadex DP-9001/DP-9501 8 lines per inch.
827 Anadex DP-9001/DP-9501 Underline Off.
828 Anadex DP-9001/DP-9501 Underline On.
829 Astrad 4000 10 CPI
830 Astrad 4000 12 CPI
831 Astrad 4000 12 Lines/Inch
832 Astrad 4000 15-17 CPI
833 Astrad 4000 6 Lines/Inch
834 Astrad 4000 8 Lines/Inch
835 Astrad 4000 Alt. Var Ln Sp
836 Astrad 4000 Bldirect'l ON
837 Astrad 4000 Bold OFF
838 Astrad 4000 Bold ON
839 Astrad 4000 Condense Off

840 Astrad 4000 DblHeight OFF
841 Astrad 4000 DblHeight ON
842 Astrad 4000 DblStrike OFF
843 Astrad 4000 DblStrike ON
844 Astrad 4000 DblWIDE OFF
845 Astrad 4000 DdlWIDE ON
846 Astrad 4000 Draft Mode
847 Astrad 4000 Emphasize OFF
848 Astrad 4000 Emphasize ON
849 Astrad 4000 Initialize
850 Astrad 4000 Int Chr Spac'g
851 Astrad 4000 Italic OFF
852 Astrad 4000 Italic ON
853 Astrad 4000 Mastr Font/Typ
854 Astrad 4000 Move ABS Horiz
855 Astrad 4000 Move REL Horiz
856 Astrad 4000 NLQ Mode
857 Astrad 4000 Propor'nl Off
858 Astrad 4000 Propor'nl On
859 Astrad 4000 Sel. Prt Style
860 Astrad 4000 Select Char St
861 Astrad 4000 Set LFT Margin
862 Astrad 4000 Set RHT Margin
863 Astrad 4000 Set Tab Stops
864 Astrad 4000 Skip Perf OFF
865 Astrad 4000 Skip Perf ON
866 Astrad 4000 SUBScript OFF
867 Astrad 4000 SUBScript ON
868 Astrad 4000 SUP-Scr OFF
869 Astrad 4000 SUPERscript ON
870 Astrad 4000 Underline OFF
871 Astrad 4000 Underline ON
872 Astrad 4000 UNIdirect'l ON
873 Astrad 4000 Var. Ln Space
874 AT&T 477 10 CPI
875 AT&T 477 12 CPI
876 AT&T 477 12 Lines/Inch
877 AT&T 477 15-17 CPI
878 AT&T 477 6 Lines/Inch
879 AT&T 477 8 Lines/Inch
880 AT&T 477 Alt. Var Ln Sp
881 AT&T 477 Bldirect'l ON
882 AT&T 477 Bold OFF
883 AT&T 477 Bold ON
884 AT&T 477 Condense Off
885 AT&T 477 DblStrike OFF
886 AT&T 477 DblStrike ON
887 AT&T 477 DblWIDE OFF
888 AT&T 477 DdlWIDE ON

889 AT&T 477 Draft Mode
890 AT&T 477 Emphasize OFF
891 AT&T 477 Emphasize ON
892 AT&T 477 Initialize
893 AT&T 477 Italic OFF
894 AT&T 477 Italic ON
895 AT&T 477 Mastr Font/Typ
896 AT&T 477 NLQ Mode
897 AT&T 477 Propor'nl Off
898 AT&T 477 Propor'nl On
899 AT&T 477 Select Char St
900 AT&T 477 Set LFT Margin
901 AT&T 477 Set RHT Margin
902 AT&T 477 Set Tab Stops
903 AT&T 477 Skip Perf OFF
904 AT&T 477 Skip Perf ON
905 AT&T 477 SUBScript OFF
906 AT&T 477 SUBScript ON
907 AT&T 477 SUP-Scr OFF
908 AT&T 477 SUPERscript ON
909 AT&T 477 Underline OFF
910 AT&T 477 Underline ON
911 AT&T 477 UNldirect'l ON
912 AT&T 477 Var. Ln Space
913 Axiom DX-2500/3500 10 CPI
914 Axiom DX-2500/3500 12 CPI
915 Axiom DX-2500/3500 12 Lines/Inch
916 Axiom DX-2500/3500 15-17 CPI
917 Axiom DX-2500/3500 6 Lines/Inch
918 Axiom DX-2500/3500 8 Lines/Inch
919 Axiom DX-2500/3500 Bold OFF
920 Axiom DX-2500/3500 Bold ON
921 Axiom DX-2500/3500 Condense Off
922 Axiom DX-2500/3500 DbIStrike OFF
923 Axiom DX-2500/3500 DbIStrike ON
924 Axiom DX-2500/3500 DbIWIDE OFF
925 Axiom DX-2500/3500 DdlWIDE ON
926 Axiom DX-2500/3500 Draft Mode
927 Axiom DX-2500/3500 Emphasize OFF
928 Axiom DX-2500/3500 Emphasize ON
929 Axiom DX-2500/3500 Initialize
930 Axiom DX-2500/3500 Move ABS Horiz
931 Axiom DX-2500/3500 Move ABS Vert.
932 Axiom DX-2500/3500 NLQ Mode
933 Axiom DX-2500/3500 Propor'nl Off
934 Axiom DX-2500/3500 Propor'nl On
935 Axiom DX-2500/3500 Set BOT Margin
936 Axiom DX-2500/3500 Set LFT Margin
937 Axiom DX-2500/3500 Set RHT Margin

938 Axiom DX-2500/3500 Set Tab Stops
939 Axiom DX-2500/3500 Set TOP Margin
940 Axiom DX-2500/3500 SUBScript OFF
941 Axiom DX-2500/3500 SUBScript ON
942 Axiom DX-2500/3500 SUP-Scr OFF
943 Axiom DX-2500/3500 SUPERscript ON
944 Axiom DX-2500/3500 Underline OFF
945 Axiom DX-2500/3500 Underline ON
946 Blaser 10 CPI.
947 Blaser 12 CPI.
948 Blaser 6 lines per inch.
949 Blaser 8 lines per inch.
950 Blaser Double Stike Off.
951 Blaser Double Stike On.
952 Blaser Reset
953 Blaser Setup
954 Blaser Underline Off.
955 Blaser Underline On.
956 Brother 2024-L 10 CPI
957 Brother 2024-L 12 CPI
958 Brother 2024-L 12 Lines/Inch
959 Brother 2024-L 15-17 CPI
960 Brother 2024-L 6 Lines/Inch
961 Brother 2024-L 8 Lines/Inch
962 Brother 2024-L Alt. Var Ln Sp
963 Brother 2024-L Bldirect'l ON
964 Brother 2024-L Bold OFF
965 Brother 2024-L Bold ON
966 Brother 2024-L Condense Off
967 Brother 2024-L DbIHeight OFF
968 Brother 2024-L DbIHeight ON
969 Brother 2024-L DbIStrike OFF
970 Brother 2024-L DbIStrike ON
971 Brother 2024-L DbIWIDE OFF
972 Brother 2024-L DdlWIDE ON
973 Brother 2024-L Draft Mode
974 Brother 2024-L Emphasize OFF
975 Brother 2024-L Emphasize ON
976 Brother 2024-L Initialize
977 Brother 2024-L Int Chr Spac'g
978 Brother 2024-L Italic OFF
979 Brother 2024-L Italic ON
980 Brother 2024-L Mastr Font/Typ
981 Brother 2024-L Move ABS Horiz
982 Brother 2024-L Move REL Horiz
983 Brother 2024-L NLQ Mode
984 Brother 2024-L Propor'nl Off
985 Brother 2024-L Propor'nl On
986 Brother 2024-L Sel. Prt Style

987 Brother 2024-L Select Char St
988 Brother 2024-L Set LFT Margin
989 Brother 2024-L Set RHT Margin
990 Brother 2024-L Set Tab Stops
991 Brother 2024-L Skip Perf OFF
992 Brother 2024-L Skip Perf ON
993 Brother 2024-L SUBScript OFF
994 Brother 2024-L SUBScript ON
995 Brother 2024-L SUP-Scr OFF
996 Brother 2024-L SUPERscript ON
997 Brother 2024-L Underline OFF
998 Brother 2024-L Underline ON
999 Brother 2024-L UNIdirect'l ON
1000 Brother 2024-L Var. Ln Space
1001 Brother BP5420 10 CPI
1002 Brother BP5420 12 CPI
1003 Brother BP5420 12 Lines/Inch
1004 Brother BP5420 15-17 CPI
1005 Brother BP5420 6 Lines/Inch
1006 Brother BP5420 8 Lines/Inch
1007 Brother BP5420 Alt. Var Ln Sp
1008 Brother BP5420 Bldirect'l ON
1009 Brother BP5420 Bold OFF
1010 Brother BP5420 Bold ON
1011 Brother BP5420 Condense Off
1012 Brother BP5420 DblStrike OFF
1013 Brother BP5420 DblStrike ON
1014 Brother BP5420 DbIWIDE OFF
1015 Brother BP5420 DdlWIDE ON
1016 Brother BP5420 Draft Mode
1017 Brother BP5420 Emphasize OFF
1018 Brother BP5420 Emphasize ON
1019 Brother BP5420 Initialize
1020 Brother BP5420 Italic OFF
1021 Brother BP5420 Italic ON
1022 Brother BP5420 Mastr Font/Typ
1023 Brother BP5420 NLQ Mode
1024 Brother BP5420 Propor'nl Off
1025 Brother BP5420 Propor'nl On
1026 Brother BP5420 Select Char St
1027 Brother BP5420 Set LFT Margin
1028 Brother BP5420 Set RHT Margin
1029 Brother BP5420 Set Tab Stops
1030 Brother BP5420 Skip Perf OFF
1031 Brother BP5420 Skip Perf ON
1032 Brother BP5420 SUBScript OFF
1033 Brother BP5420 SUBScript ON
1034 Brother BP5420 SUP-Scr OFF
1035 Brother BP5420 SUPERscript ON

Sheet1

1036 Brother BP5420 Underline OFF
1037 Brother BP5420 Underline ON
1038 Brother BP5420 UNIdirect'l ON
1039 Brother BP5420 Var. Ln Space
1040 Brother DM-5 10 CPI
1041 Brother DM-5 12 CPI
1042 Brother DM-5 12 Lines/Inch
1043 Brother DM-5 15-17 CPI
1044 Brother DM-5 6 Lines/Inch
1045 Brother DM-5 8 Lines/Inch
1046 Brother DM-5 Alt. Var Ln Sp
1047 Brother DM-5 Bldirect'l ON
1048 Brother DM-5 Bold OFF
1049 Brother DM-5 Bold ON
1050 Brother DM-5 Condense Off
1051 Brother DM-5 DbStrike OFF
1052 Brother DM-5 DbStrike ON
1053 Brother DM-5 DbWIDE OFF
1054 Brother DM-5 DdWIDE ON
1055 Brother DM-5 Draft Mode
1056 Brother DM-5 Emphasize OFF
1057 Brother DM-5 Emphasize ON
1058 Brother DM-5 Initialize
1059 Brother DM-5 Italic OFF
1060 Brother DM-5 Italic ON
1061 Brother DM-5 Mastr Font/Typ
1062 Brother DM-5 NLQ Mode
1063 Brother DM-5 Propor'nl Off
1064 Brother DM-5 Propor'nl On
1065 Brother DM-5 Select Char St
1066 Brother DM-5 Set LFT Margin
1067 Brother DM-5 Set RHT Margin
1068 Brother DM-5 Set Tab Stops
1069 Brother DM-5 Skip Perf OFF
1070 Brother DM-5 Skip Perf ON
1071 Brother DM-5 SUBScript OFF
1072 Brother DM-5 SUBScript ON
1073 Brother DM-5 SUP-Scr OFF
1074 Brother DM-5 SUPERscript ON
1075 Brother DM-5 Underline OFF
1076 Brother DM-5 Underline ON
1077 Brother DM-5 UNIdirect'l ON
1078 Brother DM-5 Var. Ln Space
1079 Brother HR-10/15/20/25 6 lines per inch.
1080 Brother HR-10/15/20/25 8 lines per inch.
1081 Brother HR-10/15/20/25 Reset
1082 Brother HR-10/15/20/25 Setup
1083 Brother HR-10/15/20/25 Underline Off.
1084 Brother HR-10/15/20/25 Underline On.

1085 Brother HR-35 10 CPI
1086 Brother HR-35 12 CPI
1087 Brother HR-35 12 Lines/Inch
1088 Brother HR-35 15-17 CPI
1089 Brother HR-35 6 Lines/Inch
1090 Brother HR-35 8 Lines/Inch
1091 Brother HR-35 Bold OFF
1092 Brother HR-35 Bold ON
1093 Brother HR-35 DblStrike OFF
1094 Brother HR-35 DblStrike ON
1095 Brother HR-35 DdlWIDE OFF
1096 Brother HR-35 DdlWIDE ON
1097 Brother HR-35 Emphasize OFF
1098 Brother HR-35 Emphasize ON
1099 Brother HR-35 Initialize
1100 Brother HR-35 Move ABS Horiz
1101 Brother HR-35 Move ABS Vert.
1102 Brother HR-35 NLQ Mode
1103 Brother HR-35 Propor'nl Off
1104 Brother HR-35 Propor'nl On
1105 Brother HR-35 Set BOT Margin
1106 Brother HR-35 Set LFT Margin
1107 Brother HR-35 Set RHT Margin
1108 Brother HR-35 Set Tab Stops
1109 Brother HR-35 Set TOP Margin
1110 Brother HR-35 SUBScript OFF
1111 Brother HR-35 SUBScript ON
1112 Brother HR-35 SUP-Scr OFF
1113 Brother HR-35 SUPERscript ON
1114 Brother HR-35 Underline OFF
1115 Brother HR-35 Underline ON
1116 Brother HR-40 12 CPI
1117 Brother HR-40 12 Lines/Inch
1118 Brother HR-40 15-17 CPI
1119 Brother HR-40 6 Lines/Inch
1120 Brother HR-40 8 Lines/Inch
1121 Brother HR-40 Bold OFF
1122 Brother HR-40 Bold ON
1123 Brother HR-40 Condense Off
1124 Brother HR-40 DblStrike OFF
1125 Brother HR-40 DblStrike ON
1126 Brother HR-40 DblWIDE OFF
1127 Brother HR-40 DdlWIDE ON
1128 Brother HR-40 Draft Mode
1129 Brother HR-40 Emphasize OFF
1130 Brother HR-40 Emphasize ON
1131 Brother HR-40 Initialize
1132 Brother HR-40 Move ABS Horiz
1133 Brother HR-40 Move ABS Vert.

1134 Brother HR-40 NLQ Mode
1135 Brother HR-40 Propor'nl Off
1136 Brother HR-40 Propor'nl On
1137 Brother HR-40 Set BOT Margin
1138 Brother HR-40 Set LFT Margin
1139 Brother HR-40 Set RHT Margin
1140 Brother HR-40 Set Tab Stops
1141 Brother HR-40 Set TOP Margin
1142 Brother HR-40 SUBScript OFF
1143 Brother HR-40 SUBScript ON
1144 Brother HR-40 SUP-Scr OFF
1145 Brother HR-40 SUPERscript ON
1146 Brother HR-40 Underline OFF
1147 Brother HR-40 Underline ON
1148 Brother HR1 10 CPI.
1149 Brother HR1 12 CPI.
1150 Brother HR1 6 lines per inch.
1151 Brother HR1 Reset
1152 Brother HR1 Setup
1153 Brother M-1724 [Epson] 10 CPI
1154 Brother M-1724 [Epson] 12 CPI
1155 Brother M-1724 [Epson] 12 Lines/Inch
1156 Brother M-1724 [Epson] 15-17 CPI
1157 Brother M-1724 [Epson] 6 Lines/Inch
1158 Brother M-1724 [Epson] 8 Lines/Inch
1159 Brother M-1724 [Epson] Bold OFF
1160 Brother M-1724 [Epson] Bold ON
1161 Brother M-1724 [Epson] Condense Off
1162 Brother M-1724 [Epson] DblStrike OFF
1163 Brother M-1724 [Epson] DblStrike ON
1164 Brother M-1724 [Epson] DblWIDE OFF
1165 Brother M-1724 [Epson] DdlWIDE ON
1166 Brother M-1724 [Epson] Draft Mode
1167 Brother M-1724 [Epson] Emphasize OFF
1168 Brother M-1724 [Epson] Emphasize ON
1169 Brother M-1724 [Epson] Initialize
1170 Brother M-1724 [Epson] Move ABS Horiz
1171 Brother M-1724 [Epson] Move ABS Vert.
1172 Brother M-1724 [Epson] NLQ Mode
1173 Brother M-1724 [Epson] Propor'nl Off
1174 Brother M-1724 [Epson] Propor'nl On
1175 Brother M-1724 [Epson] Set BOT Margin
1176 Brother M-1724 [Epson] Set LFT Margin
1177 Brother M-1724 [Epson] Set RHT Margin
1178 Brother M-1724 [Epson] Set Tab Stops
1179 Brother M-1724 [Epson] Set TOP Margin
1180 Brother M-1724 [Epson] SUBScript OFF
1181 Brother M-1724 [Epson] SUBScript ON
1182 Brother M-1724 [Epson] SUP-Scr OFF

Sheet1

1183 Brother M-1724 [Epson] SUPERscript ON
1184 Brother M-1724 [Epson] Underline OFF
1185 Brother M-1724 [Epson] Underline ON
1186 Brother Twinwriter 5 10 CPI
1187 Brother Twinwriter 5 12 CPI
1188 Brother Twinwriter 5 12 Lines/Inch
1189 Brother Twinwriter 5 15-17 CPI
1190 Brother Twinwriter 5 6 Lines/Inch
1191 Brother Twinwriter 5 8 Lines/Inch
1192 Brother Twinwriter 5 Alt. Var Ln Sp
1193 Brother Twinwriter 5 Bldirect'l ON
1194 Brother Twinwriter 5 Bold OFF
1195 Brother Twinwriter 5 Bold ON
1196 Brother Twinwriter 5 Condense Off
1197 Brother Twinwriter 5 DblStrike OFF
1198 Brother Twinwriter 5 DblStrike ON
1199 Brother Twinwriter 5 DblWIDE OFF
1200 Brother Twinwriter 5 DdlWIDE ON
1201 Brother Twinwriter 5 Draft Mode
1202 Brother Twinwriter 5 Emphasize OFF
1203 Brother Twinwriter 5 Emphasize ON
1204 Brother Twinwriter 5 Initialize
1205 Brother Twinwriter 5 Italic OFF
1206 Brother Twinwriter 5 Italic ON
1207 Brother Twinwriter 5 Mastr Font/Typ
1208 Brother Twinwriter 5 NLQ Mode
1209 Brother Twinwriter 5 Propor'nl Off
1210 Brother Twinwriter 5 Propor'nl On
1211 Brother Twinwriter 5 Select Char St
1212 Brother Twinwriter 5 Set LFT Margin
1213 Brother Twinwriter 5 Set RHT Margin
1214 Brother Twinwriter 5 Set Tab Stops
1215 Brother Twinwriter 5 Skip Perf OFF
1216 Brother Twinwriter 5 Skip Perf ON
1217 Brother Twinwriter 5 SUBScript OFF
1218 Brother Twinwriter 5 SUBScript ON
1219 Brother Twinwriter 5 SUP-Scr OFF
1220 Brother Twinwriter 5 SUPERscript ON
1221 Brother Twinwriter 5 Underline OFF
1222 Brother Twinwriter 5 Underline ON
1223 Brother Twinwriter 5 UNldirect'l ON
1224 Brother Twinwriter 5 Var. Ln Space
1225 Businessland 45LQ 10 CPI
1226 Businessland 45LQ 12 CPI
1227 Businessland 45LQ 12 Lines/Inch
1228 Businessland 45LQ 15-17 CPI
1229 Businessland 45LQ 6 Lines/Inch
1230 Businessland 45LQ 8 Lines/Inch
1231 Businessland 45LQ Bold OFF

1232 Businessland 45LQ Bold ON
1233 Businessland 45LQ Condense Off
1234 Businessland 45LQ DbIStrike OFF
1235 Businessland 45LQ DbIStrike ON
1236 Businessland 45LQ DbIWIDE OFF
1237 Businessland 45LQ DdIWIDE ON
1238 Businessland 45LQ Draft Mode
1239 Businessland 45LQ Emphasize OFF
1240 Businessland 45LQ Emphasize ON
1241 Businessland 45LQ Initialize
1242 Businessland 45LQ Move ABS Horiz
1243 Businessland 45LQ Move ABS Vert.
1244 Businessland 45LQ NLQ Mode
1245 Businessland 45LQ Propor'nl Off
1246 Businessland 45LQ Propor'nl On
1247 Businessland 45LQ Set BOT Margin
1248 Businessland 45LQ Set LFT Margin
1249 Businessland 45LQ Set RHT Margin
1250 Businessland 45LQ Set Tab Stops
1251 Businessland 45LQ Set TOP Margin
1252 Businessland 45LQ SUBScript OFF
1253 Businessland 45LQ SUBScript ON
1254 Businessland 45LQ SUP-Scr OFF
1255 Businessland 45LQ SUPERscript ON
1256 Businessland 45LQ Underline OFF
1257 Businessland 45LQ Underline ON
1258 C. Itoh 8510A 10 CPI.
1259 C. Itoh 8510A 12 CPI.
1260 C. Itoh 8510A 6 lines per inch.
1261 C. Itoh 8510A 8 lines per inch.
1262 C. Itoh 8510A Double Stike Off.
1263 C. Itoh 8510A Double Stike On.
1264 C. Itoh 8510A Reset
1265 C. Itoh 8510A Setup
1266 C. Itoh 8510A Underline Off.
1267 C. Itoh 8510A Underline On.
1268 C. Itoh C-310/15 X 10 CPI
1269 C. Itoh C-310/15 X 12 CPI
1270 C. Itoh C-310/15 X 12 Lines/Inch
1271 C. Itoh C-310/15 X 15-17 CPI
1272 C. Itoh C-310/15 X 6 Lines/Inch
1273 C. Itoh C-310/15 X 8 Lines/Inch
1274 C. Itoh C-310/15 X Alt. Var Ln Sp
1275 C. Itoh C-310/15 X Bldirect'I ON
1276 C. Itoh C-310/15 X Bold OFF
1277 C. Itoh C-310/15 X Bold ON
1278 C. Itoh C-310/15 X Condense Off
1279 C. Itoh C-310/15 X DbIStrike OFF
1280 C. Itoh C-310/15 X DbIStrike ON

1281 C. Itoh C-310/15 X DbIWIDE OFF
1282 C. Itoh C-310/15 X DdIWIDE ON
1283 C. Itoh C-310/15 X Draft Mode
1284 C. Itoh C-310/15 X Emphasize OFF
1285 C. Itoh C-310/15 X Emphasize ON
1286 C. Itoh C-310/15 X Initialize
1287 C. Itoh C-310/15 X Int Chr Spac'g
1288 C. Itoh C-310/15 X Italic OFF
1289 C. Itoh C-310/15 X Italic ON
1290 C. Itoh C-310/15 X Mastr Font/Typ
1291 C. Itoh C-310/15 X NLQ Mode
1292 C. Itoh C-310/15 X Propor'nl Off
1293 C. Itoh C-310/15 X Propor'nl On
1294 C. Itoh C-310/15 X Sel. Prt Style
1295 C. Itoh C-310/15 X Select Char St
1296 C. Itoh C-310/15 X Set LFT Margin
1297 C. Itoh C-310/15 X Set RHT Margin
1298 C. Itoh C-310/15 X Set Tab Stops
1299 C. Itoh C-310/15 X Skip Perf OFF
1300 C. Itoh C-310/15 X Skip Perf ON
1301 C. Itoh C-310/15 X SUBScript OFF
1302 C. Itoh C-310/15 X SUBScript ON
1303 C. Itoh C-310/15 X SUP-Scr OFF
1304 C. Itoh C-310/15 X SUPERscript ON
1305 C. Itoh C-310/15 X Underline OFF
1306 C. Itoh C-310/15 X Underline ON
1307 C. Itoh C-310/15 X UNIdirect'l ON
1308 C. Itoh C-310/15 X Var. Ln Space
1309 C. Itoh F10 10 CPI.
1310 C. Itoh F10 12 CPI.
1311 C. Itoh F10 6 lines per inch.
1312 C. Itoh F10 8 lines per inch.
1313 C. Itoh F10 Double Stike Off.
1314 C. Itoh F10 Double Stike On.
1315 C. Itoh F10 Underline Off.
1316 C. Itoh F10 Underline On.
1317 C. Itoh LIPS 10+ 10 CPI.
1318 C. Itoh LIPS 10+ 12 CPI.
1319 C. Itoh LIPS 10+ 6 lines per inch.
1320 C. Itoh LIPS 10+ 8 lines per inch.
1321 C. Itoh LIPS 10+ Double Stike Off.
1322 C. Itoh LIPS 10+ Double Stike On.
1323 C. Itoh LIPS 10+ Italics Off.
1324 C. Itoh LIPS 10+ Italics On.
1325 C. Itoh LIPS 10+ Reset
1326 C. Itoh LIPS 10+ Setup
1327 C. Itoh LIPS 10+ Underline Off.
1328 C. Itoh LIPS 10+ Underline On.
1329 Canon A-550 10 CPI

Sheet1

1330 Canon A-550 12 CPI
1331 Canon A-550 12 Lines/Inch
1332 Canon A-550 15-17 CPI
1333 Canon A-550 6 Lines/Inch
1334 Canon A-550 8 Lines/Inch
1335 Canon A-550 Bold OFF
1336 Canon A-550 Bold ON
1337 Canon A-550 Condense Off
1338 Canon A-550 DblStrike OFF
1339 Canon A-550 DblStrike ON
1340 Canon A-550 DdIWIDE OFF
1341 Canon A-550 DdIWIDE ON
1342 Canon A-550 Draft Mode
1343 Canon A-550 Emphasize OFF
1344 Canon A-550 Emphasize ON
1345 Canon A-550 Initialize
1346 Canon A-550 Move ABS Horiz
1347 Canon A-550 Move ABS Vert.
1348 Canon A-550 NLQ Mode
1349 Canon A-550 Propor'nl Off
1350 Canon A-550 Propor'nl On
1351 Canon A-550 Set BOT Margin
1352 Canon A-550 Set LFT Margin
1353 Canon A-550 Set RHT Margin
1354 Canon A-550 Set Tab Stops
1355 Canon A-550 Set TOP Margin
1356 Canon A-550 SUBScript OFF
1357 Canon A-550 SUBScript ON
1358 Canon A-550 SUP-Scr OFF
1359 Canon A-550 SUPERscript ON
1360 Canon A-550 Underline OFF
1361 Canon A-550 Underline ON
1362 Canon A-60 10 CPI
1363 Canon A-60 12 CPI
1364 Canon A-60 12 Lines/Inch
1365 Canon A-60 15-17 CPI
1366 Canon A-60 6 Lines/Inch
1367 Canon A-60 8 Lines/Inch
1368 Canon A-60 Alt. Var Ln Sp
1369 Canon A-60 Bldirect'l ON
1370 Canon A-60 Bold OFF
1371 Canon A-60 Bold ON
1372 Canon A-60 Condense Off
1373 Canon A-60 DblStrike OFF
1374 Canon A-60 DblStrike ON
1375 Canon A-60 DblWIDE OFF
1376 Canon A-60 DdIWIDE ON
1377 Canon A-60 Draft Mode
1378 Canon A-60 Emphasize OFF

1379 Canon A-60 Emphasize ON
1380 Canon A-60 Initialize
1381 Canon A-60 Int Chr Spac'g
1382 Canon A-60 Italic OFF
1383 Canon A-60 Italic ON
1384 Canon A-60 Mastr Font/Typ
1385 Canon A-60 NLQ Mode
1386 Canon A-60 Propor'nl Off
1387 Canon A-60 Propor'nl On
1388 Canon A-60 Sel. Prt Style
1389 Canon A-60 Select Char St
1390 Canon A-60 Set LFT Margin
1391 Canon A-60 Set RHT Margin
1392 Canon A-60 Set Tab Stops
1393 Canon A-60 Skip Perf OFF
1394 Canon A-60 Skip Perf ON
1395 Canon A-60 SUBScript OFF
1396 Canon A-60 SUBScript ON
1397 Canon A-60 SUP-Scr OFF
1398 Canon A-60 SUPERscript ON
1399 Canon A-60 Underline OFF
1400 Canon A-60 Underline ON
1401 Canon A-60 UNIdirect'l ON
1402 Canon A-60 Var. Ln Space
1403 Canon AP-110 10 CPI
1404 Canon AP-110 12 CPI
1405 Canon AP-110 12 Lines/Inch
1406 Canon AP-110 15-17 CPI
1407 Canon AP-110 6 Lines/Inch
1408 Canon AP-110 8 Lines/Inch
1409 Canon AP-110 Bold OFF
1410 Canon AP-110 Bold ON
1411 Canon AP-110 Condense Off
1412 Canon AP-110 DblStrike OFF
1413 Canon AP-110 DblStrike ON
1414 Canon AP-110 DdIWIDE OFF
1415 Canon AP-110 DdIWIDE ON
1416 Canon AP-110 Draft Mode
1417 Canon AP-110 Emphasize OFF
1418 Canon AP-110 Emphasize ON
1419 Canon AP-110 Initialize
1420 Canon AP-110 Move ABS Horiz
1421 Canon AP-110 Move ABS Vert.
1422 Canon AP-110 NLQ Mode
1423 Canon AP-110 Propor'nl Off
1424 Canon AP-110 Propor'nl On
1425 Canon AP-110 Set BOT Margin
1426 Canon AP-110 Set LFT Margin
1427 Canon AP-110 Set RHT Margin

1428 Canon AP-110 Set Tab Stops
1429 Canon AP-110 Set TOP Margin
1430 Canon AP-110 SUBScript OFF
1431 Canon AP-110 SUBScript ON
1432 Canon AP-110 SUP-Scr OFF
1433 Canon AP-110 SUPERscript ON
1434 Canon AP-110 Underline OFF
1435 Canon AP-110 Underline ON
1436 Canon AP-400/92 10 CPI
1437 Canon AP-400/92 12 CPI
1438 Canon AP-400/92 12 Lines/Inch
1439 Canon AP-400/92 15-17 CPI
1440 Canon AP-400/92 6 Lines/Inch
1441 Canon AP-400/92 8 Lines/Inch
1442 Canon AP-400/92 Bold OFF
1443 Canon AP-400/92 Bold ON
1444 Canon AP-400/92 Condense Off
1445 Canon AP-400/92 DblStrike OFF
1446 Canon AP-400/92 DblStrike ON
1447 Canon AP-400/92 DblWIDE OFF
1448 Canon AP-400/92 DdlWIDE ON
1449 Canon AP-400/92 Draft Mode
1450 Canon AP-400/92 Emphasize OFF
1451 Canon AP-400/92 Emphasize ON
1452 Canon AP-400/92 Initialize
1453 Canon AP-400/92 Move ABS Horiz
1454 Canon AP-400/92 Move ABS Vert.
1455 Canon AP-400/92 NLQ Mode
1456 Canon AP-400/92 Propor'nl Off
1457 Canon AP-400/92 Propor'nl On
1458 Canon AP-400/92 Set BOT Margin
1459 Canon AP-400/92 Set LFT Margin
1460 Canon AP-400/92 Set RHT Margin
1461 Canon AP-400/92 Set Tab Stops
1462 Canon AP-400/92 Set TOP Margin
1463 Canon AP-400/92 SUBScript OFF
1464 Canon AP-400/92 SUBScript ON
1465 Canon AP-400/92 SUP-Scr OFF
1466 Canon AP-400/92 SUPERscript ON
1467 Canon AP-400/92 Underline OFF
1468 Canon AP-400/92 Underline ON
1469 Canon AP-550 10 CPI
1470 Canon AP-550 12 CPI
1471 Canon AP-550 12 Lines/Inch
1472 Canon AP-550 15-17 CPI
1473 Canon AP-550 6 Lines/Inch
1474 Canon AP-550 8 Lines/Inch
1475 Canon AP-550 Bold OFF
1476 Canon AP-550 Bold ON

Sheet1

1477 Canon AP-550 Condense Off
1478 Canon AP-550 DblStrike OFF
1479 Canon AP-550 DblStrike ON
1480 Canon AP-550 DblWIDE OFF
1481 Canon AP-550 DdlWIDE ON
1482 Canon AP-550 Draft Mode
1483 Canon AP-550 Emphasize OFF
1484 Canon AP-550 Emphasize ON
1485 Canon AP-550 Initialize
1486 Canon AP-550 Move ABS Horiz
1487 Canon AP-550 Move ABS Vert.
1488 Canon AP-550 NLQ Mode
1489 Canon AP-550 Propor'nl Off
1490 Canon AP-550 Propor'nl On
1491 Canon AP-550 Set BOT Margin
1492 Canon AP-550 Set LFT Margin
1493 Canon AP-550 Set RHT Margin
1494 Canon AP-550 Set Tab Stops
1495 Canon AP-550 Set TOP Margin
1496 Canon AP-550 SUBScript OFF
1497 Canon AP-550 SUBScript ON
1498 Canon AP-550 SUP-Scr OFF
1499 Canon AP-550 SUPERscript ON
1500 Canon AP-550 Underline OFF
1501 Canon AP-550 Underline ON
1502 Canon AP-76 Emphasize OFF
1503 Canon AP-76 SUBScript ON
1504 Canon AP-76 10 CPI
1505 Canon AP-76 12 CPI
1506 Canon AP-76 12 Lines/Inch
1507 Canon AP-76 15-17 CPI
1508 Canon AP-76 6 Lines/Inch
1509 Canon AP-76 8 Lines/Inch
1510 Canon AP-76 Bold OFF
1511 Canon AP-76 Bold ON
1512 Canon AP-76 Condense Off
1513 Canon AP-76 DblStrike OFF
1514 Canon AP-76 DblStrike ON
1515 Canon AP-76 DdlWIDE OFF
1516 Canon AP-76 DdlWIDE ON
1517 Canon AP-76 Draft Mode
1518 Canon AP-76 Emphasize ON
1519 Canon AP-76 Initialize
1520 Canon AP-76 Move ABS Horiz
1521 Canon AP-76 Move ABS Vert.
1522 Canon AP-76 NLQ Mode
1523 Canon AP-76 Propor'nl Off
1524 Canon AP-76 Propor'nl On
1525 Canon AP-76 Set BOT Margin

1526 Canon AP-76 Set LFT Margin
1527 Canon AP-76 Set RHT Margin
1528 Canon AP-76 Set Tab Stops
1529 Canon AP-76 Set TOP Margin
1530 Canon AP-76 SUBScript OFF
1531 Canon AP-76 SUP-Scr OFF
1532 Canon AP-76 SUPERscript ON
1533 Canon AP-76 Underline OFF
1534 Canon AP-76 Underline ON
1535 Canon LBP-8 A1/A2 10 CPI.
1536 Canon LBP-8 A1/A2 12 CPI.
1537 Canon LBP-8 A1/A2 6 lines per inch.
1538 Canon LBP-8 A1/A2 8 lines per inch.
1539 Canon LBP-8 A1/A2 Double Stike Off.
1540 Canon LBP-8 A1/A2 Double Stike On.
1541 Canon LBP-8 A1/A2 Reset
1542 Canon LBP-8 A1/A2 Setup
1543 Canon LBP-8 A1/A2 Underline Off.
1544 Canon LBP-8 A1/A2 Underline On.
1545 Canon LBP-8 A1/A2(ISO) 10 CPI.
1546 Canon LBP-8 A1/A2(ISO) 12 CPI.
1547 Canon LBP-8 A1/A2(ISO) 6 lines per inch.
1548 Canon LBP-8 A1/A2(ISO) 8 lines per inch.
1549 Canon LBP-8 A1/A2(ISO) Double Stike Off.
1550 Canon LBP-8 A1/A2(ISO) Double Stike On.
1551 Canon LBP-8 A1/A2(ISO) Italics Off.
1552 Canon LBP-8 A1/A2(ISO) Italics On.
1553 Canon LBP-8 A1/A2(ISO) Reset
1554 Canon LBP-8 A1/A2(ISO) Setup
1555 Canon LBP-8 A1/A2(ISO) Underline Off.
1556 Canon LBP-8 A1/A2(ISO) Underline On.
1557 Centronics 240 [DP] 10 CPI
1558 Centronics 240 [DP] 12 CPI
1559 Centronics 240 [DP] 12 Lines/Inch
1560 Centronics 240 [DP] 15-17 CPI
1561 Centronics 240 [DP] 6 Lines/Inch
1562 Centronics 240 [DP] 8 Lines/Inch
1563 Centronics 240 [DP] Alt. Var Ln Sp
1564 Centronics 240 [DP] Bldirect'l ON
1565 Centronics 240 [DP] Bold OFF
1566 Centronics 240 [DP] Bold ON
1567 Centronics 240 [DP] Condense Off
1568 Centronics 240 [DP] DbIStrike OFF
1569 Centronics 240 [DP] DbIStrike ON
1570 Centronics 240 [DP] DbIWIDE OFF
1571 Centronics 240 [DP] DdlWIDE ON
1572 Centronics 240 [DP] Draft Mode
1573 Centronics 240 [DP] Emphasize OFF
1574 Centronics 240 [DP] Emphasize ON

1575 Centronics 240 [DP] Initialize
1576 Centronics 240 [DP] Italic OFF
1577 Centronics 240 [DP] Italic ON
1578 Centronics 240 [DP] Mastr Font/Typ
1579 Centronics 240 [DP] NLQ Mode
1580 Centronics 240 [DP] Propor'nl Off
1581 Centronics 240 [DP] Propor'nl On
1582 Centronics 240 [DP] Select Char St
1583 Centronics 240 [DP] Set LFT Margin
1584 Centronics 240 [DP] Set RHT Margin
1585 Centronics 240 [DP] Set Tab Stops
1586 Centronics 240 [DP] Skip Perf OFF
1587 Centronics 240 [DP] Skip Perf ON
1588 Centronics 240 [DP] SUBScript OFF
1589 Centronics 240 [DP] SUBScript ON
1590 Centronics 240 [DP] SUP-Scr OFF
1591 Centronics 240 [DP] SUPERscript ON
1592 Centronics 240 [DP] Underline OFF
1593 Centronics 240 [DP] Underline ON
1594 Centronics 240 [DP] UNIdirect'l ON
1595 Centronics 240 [DP] Var. Ln Space
1596 Centronics 250 10 CPI
1597 Centronics 250 12 CPI
1598 Centronics 250 12 Lines/Inch
1599 Centronics 250 15-17 CPI
1600 Centronics 250 6 Lines/Inch
1601 Centronics 250 8 Lines/Inch
1602 Centronics 250 Alt. Var Ln Sp
1603 Centronics 250 Bldirect'l ON
1604 Centronics 250 Bold OFF
1605 Centronics 250 Bold ON
1606 Centronics 250 Condense Off
1607 Centronics 250 DbIStrike OFF
1608 Centronics 250 DbIStrike ON
1609 Centronics 250 DbIWIDE OFF
1610 Centronics 250 DdlWIDE ON
1611 Centronics 250 Draft Mode
1612 Centronics 250 Emphasize OFF
1613 Centronics 250 Emphasize ON
1614 Centronics 250 Initialize
1615 Centronics 250 Italic OFF
1616 Centronics 250 Italic ON
1617 Centronics 250 Mastr Font/Typ
1618 Centronics 250 NLQ Mode
1619 Centronics 250 Propor'nl Off
1620 Centronics 250 Propor'nl On
1621 Centronics 250 Select Char St
1622 Centronics 250 Set LFT Margin
1623 Centronics 250 Set RHT Margin

Sheet1

1624 Centronics 250 Set Tab Stops
1625 Centronics 250 Skip Perf OFF
1626 Centronics 250 Skip Perf ON
1627 Centronics 250 SUBScript OFF
1628 Centronics 250 SUBScript ON
1629 Centronics 250 SUP-Scr OFF
1630 Centronics 250 SUPERscript ON
1631 Centronics 250 Underline OFF
1632 Centronics 250 Underline ON
1633 Centronics 250 UNIdirect'I ON
1634 Centronics 250 Var. Ln Space
1635 Centronics 351/352/353 10 CPI.
1636 Centronics 351/352/353 12 CPI.
1637 Centronics 351/352/353 6 lines per inch.
1638 Centronics 351/352/353 8 lines per inch.
1639 Centronics 351/352/353 Underline Off.
1640 Centronics 351/352/353 Underline On.
1641 Centronics H136 10 CPI
1642 Centronics H136 12 CPI
1643 Centronics H136 12 Lines/Inch
1644 Centronics H136 15-17 CPI
1645 Centronics H136 6 Lines/Inch
1646 Centronics H136 8 Lines/Inch
1647 Centronics H136 Alt. Var Ln Sp
1648 Centronics H136 BIdirect'I ON
1649 Centronics H136 Bold OFF
1650 Centronics H136 Bold ON
1651 Centronics H136 Condense Off
1652 Centronics H136 DbIStrike OFF
1653 Centronics H136 DbIStrike ON
1654 Centronics H136 DbIWIDE OFF
1655 Centronics H136 DdIWIDE ON
1656 Centronics H136 Draft Mode
1657 Centronics H136 Emphasize OFF
1658 Centronics H136 Emphasize ON
1659 Centronics H136 Initialize
1660 Centronics H136 Italic OFF
1661 Centronics H136 Italic ON
1662 Centronics H136 Mastr Font/Typ
1663 Centronics H136 NLQ Mode
1664 Centronics H136 Propor'nl Off
1665 Centronics H136 Propor'nl On
1666 Centronics H136 Select Char St
1667 Centronics H136 Set LFT Margin
1668 Centronics H136 Set RHT Margin
1669 Centronics H136 Set Tab Stops
1670 Centronics H136 Skip Perf OFF
1671 Centronics H136 Skip Perf ON
1672 Centronics H136 SUBScript OFF

1673 Centronics H136 SUBScript ON
1674 Centronics H136 SUP-Scr OFF
1675 Centronics H136 SUPERscript ON
1676 Centronics H136 Underline OFF
1677 Centronics H136 Underline ON
1678 Centronics H136 UNIdirect'I ON
1679 Centronics H136 Var. Ln Space
1680 Centronics H80-1/2 10 CPI
1681 Centronics H80-1/2 12 CPI
1682 Centronics H80-1/2 12 Lines/Inch
1683 Centronics H80-1/2 15-17 CPI
1684 Centronics H80-1/2 6 Lines/Inch
1685 Centronics H80-1/2 8 Lines/Inch
1686 Centronics H80-1/2 Alt. Var Ln Sp
1687 Centronics H80-1/2 BIdirect'I ON
1688 Centronics H80-1/2 Bold OFF
1689 Centronics H80-1/2 Bold ON
1690 Centronics H80-1/2 Condense Off
1691 Centronics H80-1/2 DbIStrike OFF
1692 Centronics H80-1/2 DbIStrike ON
1693 Centronics H80-1/2 DbIWIDE OFF
1694 Centronics H80-1/2 DdIWIDE ON
1695 Centronics H80-1/2 Draft Mode
1696 Centronics H80-1/2 Emphasize OFF
1697 Centronics H80-1/2 Emphasize ON
1698 Centronics H80-1/2 Initialize
1699 Centronics H80-1/2 Italic OFF
1700 Centronics H80-1/2 Italic ON
1701 Centronics H80-1/2 Mastr Font/Typ
1702 Centronics H80-1/2 NLQ Mode
1703 Centronics H80-1/2 Propor'nI Off
1704 Centronics H80-1/2 Propor'nI On
1705 Centronics H80-1/2 Select Char St
1706 Centronics H80-1/2 Set LFT Margin
1707 Centronics H80-1/2 Set RHT Margin
1708 Centronics H80-1/2 Set Tab Stops
1709 Centronics H80-1/2 Skip Perf OFF
1710 Centronics H80-1/2 Skip Perf ON
1711 Centronics H80-1/2 SUBScript OFF
1712 Centronics H80-1/2 SUBScript ON
1713 Centronics H80-1/2 SUP-Scr OFF
1714 Centronics H80-1/2 SUPERscript ON
1715 Centronics H80-1/2 Underline OFF
1716 Centronics H80-1/2 Underline ON
1717 Centronics H80-1/2 UNIdirect'I ON
1718 Centronics H80-1/2 Var. Ln Space
1719 Centronics H80-1/H80-2 10 CPI.
1720 Centronics H80-1/H80-2 12 CPI.
1721 Centronics H80-1/H80-2 6 lines per inch.

Sheet1

1722 Centronics H80-1/H80-2 8 lines per inch.
1723 Centronics H80-1/H80-2 Double Strike Off.
1724 Centronics H80-1/H80-2 Double Strike On.
1725 Centronics H80-1/H80-2 Italics Off.
1726 Centronics H80-1/H80-2 Italics On.
1727 Centronics H80-1/H80-2 Reset
1728 Centronics H80-1/H80-2 Setup
1729 Centronics H80-1/H80-2 Underline Off.
1730 Centronics H80-1/H80-2 Underline On.
1731 Citizen 120-D/180-D 10 CPI
1732 Citizen 120-D/180-D 12 CPI
1733 Citizen 120-D/180-D 12 Lines/Inch
1734 Citizen 120-D/180-D 15-17 CPI
1735 Citizen 120-D/180-D 6 Lines/Inch
1736 Citizen 120-D/180-D 8 Lines/Inch
1737 Citizen 120-D/180-D Alt. Var Ln Sp
1738 Citizen 120-D/180-D Bldirect'l ON
1739 Citizen 120-D/180-D Bold OFF
1740 Citizen 120-D/180-D Bold ON
1741 Citizen 120-D/180-D Condense Off
1742 Citizen 120-D/180-D DbStrike OFF
1743 Citizen 120-D/180-D DbStrike ON
1744 Citizen 120-D/180-D DbWIDE OFF
1745 Citizen 120-D/180-D DdWIDE ON
1746 Citizen 120-D/180-D Draft Mode
1747 Citizen 120-D/180-D Emphasize OFF
1748 Citizen 120-D/180-D Emphasize ON
1749 Citizen 120-D/180-D Initialize
1750 Citizen 120-D/180-D Int Chr Spac'g
1751 Citizen 120-D/180-D Italic OFF
1752 Citizen 120-D/180-D Italic ON
1753 Citizen 120-D/180-D Mastr Font/Typ
1754 Citizen 120-D/180-D NLQ Mode
1755 Citizen 120-D/180-D Propor'nl Off
1756 Citizen 120-D/180-D Propor'nl On
1757 Citizen 120-D/180-D Sel. Prt Style
1758 Citizen 120-D/180-D Select Char St
1759 Citizen 120-D/180-D Set LFT Margin
1760 Citizen 120-D/180-D Set RHT Margin
1761 Citizen 120-D/180-D Set Tab Stops
1762 Citizen 120-D/180-D Skip Perf OFF
1763 Citizen 120-D/180-D Skip Perf ON
1764 Citizen 120-D/180-D SUBScript OFF
1765 Citizen 120-D/180-D SUBScript ON
1766 Citizen 120-D/180-D SUP-Scr OFF
1767 Citizen 120-D/180-D SUPERscript ON
1768 Citizen 120-D/180-D Underline OFF
1769 Citizen 120-D/180-D Underline ON
1770 Citizen 120-D/180-D UNldirect'l ON

1771 Citizen 120-D/180-D Var. Ln Space
1772 Citizen Compressed Off
1773 Citizen Compressed On
1774 Citizen Eject Page
1775 Citizen Emphasized Print Off
1776 Citizen Emphasized Print On
1777 Citizen Expanded Print Off
1778 Citizen Expanded Print On
1779 Citizen GSX-140 10 CPI
1780 Citizen GSX-140 12 CPI
1781 Citizen GSX-140 12 Lines/Inch
1782 Citizen GSX-140 15-17 CPI
1783 Citizen GSX-140 6 Lines/Inch
1784 Citizen GSX-140 8 Lines/Inch
1785 Citizen GSX-140 Alt. Var Ln Sp
1786 Citizen GSX-140 Bldirect'l ON
1787 Citizen GSX-140 Bold OFF
1788 Citizen GSX-140 Bold ON
1789 Citizen GSX-140 Condense Off
1790 Citizen GSX-140 DbIHeight OFF
1791 Citizen GSX-140 DbIStrike OFF
1792 Citizen GSX-140 DbIStrike ON
1793 Citizen GSX-140 DbIWIDE OFF
1794 Citizen GSX-140 DdIWIDE ON
1795 Citizen GSX-140 Draft Mode
1796 Citizen GSX-140 Emphasize OFF
1797 Citizen GSX-140 Emphasize ON
1798 Citizen GSX-140 Initialize
1799 Citizen GSX-140 Int Chr Spac'g
1800 Citizen GSX-140 Italic OFF
1801 Citizen GSX-140 Italic ON
1802 Citizen GSX-140 Mastr Font/Typ
1803 Citizen GSX-140 Move ABS Horiz
1804 Citizen GSX-140 Move REL Horiz
1805 Citizen GSX-140 NLQ Mode
1806 Citizen GSX-140 Propor'nI Off
1807 Citizen GSX-140 Propor'nI On
1808 Citizen GSX-140 Sel. Prt Style
1809 Citizen GSX-140 Select Char St
1810 Citizen GSX-140 Set LFT Margin
1811 Citizen GSX-140 Set RHT Margin
1812 Citizen GSX-140 Set Tab Stops
1813 Citizen GSX-140 Skip Perf OFF
1814 Citizen GSX-140 Skip Perf ON
1815 Citizen GSX-140 SUBScript OFF
1816 Citizen GSX-140 SUBScript ON
1817 Citizen GSX-140 SUP-Scr OFF
1818 Citizen GSX-140 SUPERscript ON
1819 Citizen GSX-140 Underline OFF

1820 Citizen GSX-140 Underline ON
1821 Citizen GSX-140 UNdirect'l ON
1822 Citizen GSX-140 Var. Ln Space
1823 Citizen Italics Off
1824 Citizen Italics On
1825 Citizen Letter Quality Off
1826 Citizen Letter Quality On
1827 Citizen MSP-10/MSP-15 10 CPI.
1828 Citizen MSP-10/MSP-15 12 CPI.
1829 Citizen MSP-10/MSP-15 6 lines per inch.
1830 Citizen MSP-10/MSP-15 8 lines per inch.
1831 Citizen MSP-10/MSP-15 Double Stike Off.
1832 Citizen MSP-10/MSP-15 Double Stike On.
1833 Citizen MSP-10/MSP-15 Italics Off.
1834 Citizen MSP-10/MSP-15 Italics On.
1835 Citizen MSP-10/MSP-15 Reset
1836 Citizen MSP-10/MSP-15 Setup
1837 Citizen MSP-10/MSP-15 Underline Off.
1838 Citizen MSP-10/MSP-15 Underline On.
1839 Citizen Pitch 10 cpi
1840 Citizen Pitch 12 cpi
1841 Citizen Reset Printer to Defaults
1842 Citizen Underline Off
1843 Citizen Underline On
1844 Comrex CR-I 10 CPI.
1845 Comrex CR-I 12 CPI.
1846 Comrex CR-I 6 lines per inch.
1847 Comrex CR-I Reset
1848 Comrex CR-I Setup
1849 Comrex CR-II 10 CPI.
1850 Comrex CR-II 12 CPI.
1851 Comrex CR-II 6 lines per inch.
1852 Comrex CR-II 8 lines per inch.
1853 Comrex CR-II Double Stike Off.
1854 Comrex CR-II Double Stike On.
1855 Comrex CR-II Reset
1856 Comrex CR-II Setup
1857 Comrex CR-II Underline Off.
1858 Comrex CR-II Underline On.
1859 DaisyWriter 1500/2000 10 CPI.
1860 DaisyWriter 1500/2000 12 CPI.
1861 DaisyWriter 1500/2000 6 lines per inch.
1862 DaisyWriter 1500/2000 8 lines per inch.
1863 DaisyWriter 1500/2000 Double Stike Off.
1864 DaisyWriter 1500/2000 Double Stike On.
1865 DaisyWriter 1500/2000 Reset
1866 DaisyWriter 1500/2000 Setup
1867 DaisyWriter 1500/2000 Underline Off.
1868 DaisyWriter 1500/2000 Underline On.

1869 Data Products SPG-8010 10 CPI.
1870 Data Products SPG-8010 12 CPI.
1871 Data Products SPG-8010 6 lines per inch.
1872 Data Products SPG-8010 8 lines per inch.
1873 Data Products SPG-8010 Double Strike Off.
1874 Data Products SPG-8010 Double Strike On.
1875 Data Products SPG-8010 Reset
1876 Data Products SPG-8010 Setup
1877 Data Products SPG-8010 Underline Off.
1878 Data Products SPG-8010 Underline On.
1879 Dataproducts DP-20/DP-55 10 CPI
1880 Dataproducts DP-20/DP-55 12 CPI
1881 Dataproducts DP-20/DP-55 12 Lines/Inch
1882 Dataproducts DP-20/DP-55 15-17 CPI
1883 Dataproducts DP-20/DP-55 6 Lines/Inch
1884 Dataproducts DP-20/DP-55 8 Lines/Inch
1885 Dataproducts DP-20/DP-55 Bold OFF
1886 Dataproducts DP-20/DP-55 Bold ON
1887 Dataproducts DP-20/DP-55 Condense Off
1888 Dataproducts DP-20/DP-55 DbIStrike OFF
1889 Dataproducts DP-20/DP-55 DbIStrike ON
1890 Dataproducts DP-20/DP-55 DbIWIDE OFF
1891 Dataproducts DP-20/DP-55 DdIWIDE ON
1892 Dataproducts DP-20/DP-55 Draft Mode
1893 Dataproducts DP-20/DP-55 Emphasize OFF
1894 Dataproducts DP-20/DP-55 Emphasize ON
1895 Dataproducts DP-20/DP-55 Initialize
1896 Dataproducts DP-20/DP-55 Move ABS Horiz
1897 Dataproducts DP-20/DP-55 Move ABS Vert.
1898 Dataproducts DP-20/DP-55 NLQ Mode
1899 Dataproducts DP-20/DP-55 Propor'nl Off
1900 Dataproducts DP-20/DP-55 Propor'nl On
1901 Dataproducts DP-20/DP-55 Set BOT Margin
1902 Dataproducts DP-20/DP-55 Set LFT Margin
1903 Dataproducts DP-20/DP-55 Set RHT Margin
1904 Dataproducts DP-20/DP-55 Set Tab Stops
1905 Dataproducts DP-20/DP-55 Set TOP Margin
1906 Dataproducts DP-20/DP-55 SUBScript OFF
1907 Dataproducts DP-20/DP-55 SUBScript ON
1908 Dataproducts DP-20/DP-55 SUP-Scr OFF
1909 Dataproducts DP-20/DP-55 SUPERscript ON
1910 Dataproducts DP-20/DP-55 Underline OFF
1911 Dataproducts DP-20/DP-55 Underline ON
1912 Datasouth DS 180 10 CPI.
1913 Datasouth DS 180 12 CPI.
1914 Datasouth DS 180 6 lines per inch.
1915 Datasouth DS 180 8 lines per inch.
1916 Datasouth DS 180 Underline Off.
1917 Datasouth DS 180 Underline On.

1918 DEC LA210 10 CPI
1919 DEC LA210 12 CPI
1920 DEC LA210 12 Lines/Inch
1921 DEC LA210 15-17 CPI
1922 DEC LA210 6 Lines/Inch
1923 DEC LA210 8 Lines/Inch
1924 DEC LA210 Alt. Var Ln Sp
1925 DEC LA210 Bldirect'l ON
1926 DEC LA210 Bold OFF
1927 DEC LA210 Bold ON
1928 DEC LA210 Condense Off
1929 DEC LA210 DblStrike OFF
1930 DEC LA210 DblStrike ON
1931 DEC LA210 DblWIDE OFF
1932 DEC LA210 DdlWIDE ON
1933 DEC LA210 Draft Mode
1934 DEC LA210 Emphasize OFF
1935 DEC LA210 Emphasize ON
1936 DEC LA210 Initialize
1937 DEC LA210 Italic OFF
1938 DEC LA210 Italic ON
1939 DEC LA210 Mastr Font/Typ
1940 DEC LA210 NLQ Mode
1941 DEC LA210 Propor'nl Off
1942 DEC LA210 Propor'nl On
1943 DEC LA210 Select Char St
1944 DEC LA210 Set LFT Margin
1945 DEC LA210 Set RHT Margin
1946 DEC LA210 Set Tab Stops
1947 DEC LA210 Skip Perf OFF
1948 DEC LA210 Skip Perf ON
1949 DEC LA210 SUBScript OFF
1950 DEC LA210 SUBScript ON
1951 DEC LA210 SUP-Scr OFF
1952 DEC LA210 SUPERscript ON
1953 DEC LA210 Underline OFF
1954 DEC LA210 Underline ON
1955 DEC LA210 UNIdirect'l ON
1956 DEC LA210 Var. Ln Space
1957 DeskJet PLUS Bold OFF
1958 DeskJet PLUS Bold ON
1959 DeskJet PLUS Clear Horizontal Margins
1960 DeskJet PLUS Eject Current Page
1961 DeskJet PLUS End-of-line Wrap OFF
1962 DeskJet PLUS End-of-line Wrap ON
1963 DeskJet PLUS Envelope Feed
1964 DeskJet PLUS Form Feed
1965 DeskJet PLUS Half Line Feed
1966 DeskJet PLUS Italics OFF

Sheet1

1967 DeskJet PLUS Italics ON
1968 DeskJet PLUS Line Feed
1969 DeskJet PLUS lines/inch: 1
1970 DeskJet PLUS lines/inch: 2
1971 DeskJet PLUS lines/inch: 3
1972 DeskJet PLUS lines/inch: 4
1973 DeskJet PLUS lines/inch: 6
1974 DeskJet PLUS lines/inch: 8
1975 DeskJet PLUS lines/inch:12
1976 DeskJet PLUS lines/inch:16
1977 DeskJet PLUS lines/inch:24
1978 DeskJet PLUS lines/inch:48
1979 DeskJet PLUS Perforation Skip OFF
1980 DeskJet PLUS Perforation Skip ON
1981 DeskJet PLUS Print Bidirectional
1982 DeskJet PLUS Print Unidirectional Left to Right
1983 DeskJet PLUS Print Unidirectional Right to Left
1984 DeskJet PLUS Proportional Spacing OFF
1985 DeskJet PLUS Proportional Spacing ON
1986 DeskJet PLUS Reset
1987 DeskJet PLUS Select 10 CPI
1988 DeskJet PLUS Select 12 Point Character Height
1989 DeskJet PLUS Select 16.67 CPI
1990 DeskJet PLUS Select 20 CPI
1991 DeskJet PLUS Select 5 CPI
1992 DeskJet PLUS Select 6 Point Character Height
1993 DeskJet PLUS Select Draft Quality Print
1994 DeskJet PLUS Select Letter Quality Print
1995 DeskJet PLUS Self-Test
1996 DeskJet PLUS Set Landscape Orientation
1997 DeskJet PLUS Set Left Margin: 1 line
1998 DeskJet PLUS Set left margin: 2 Lines
1999 DeskJet PLUS Set Left Margin: 4 lines
2000 DeskJet PLUS Set Left Margin:10 lines
2001 DeskJet PLUS Set Page Length: 56
2002 DeskJet PLUS Set Page length: 60
2003 DeskJet PLUS Set Page Length: 65
2004 DeskJet PLUS Set Paper Size - A4 210mm x 297mm
2005 DeskJet PLUS Set Paper Size - Envelopes 9 1/2 x 4 1/8
2006 DeskJet PLUS Set Paper Size - U.S. Legal 8 1/2' x 14'
2007 DeskJet PLUS Set Paper Size - U.S. Letter 8 1/2' x 11'
2008 DeskJet PLUS Set Portrait Orientation
2009 DeskJet PLUS Set Top Margin: 1 line
2010 DeskJet PLUS Set Top Margin: 2 Lines
2011 DeskJet PLUS Set Top Margin: 4 lines
2012 DeskJet PLUS Set Top Margin:10 lines
2013 DeskJet PLUS Subscript ON
2014 DeskJet PLUS Superscript ON
2015 DeskJet PLUS Superscript/Subscript OFF

Sheet1

2016 DeskJet PLUS Text Scale Mode OFF
2017 DeskJet PLUS Text Scale Mode ON
2018 DeskJet PLUS Tray Feed
2019 DeskJet PLUS Underline OFF
2020 DeskJet PLUS Underline ON: Double fixed
2021 DeskJet PLUS Underline ON: Double floating
2022 DeskJet PLUS Underline ON: Single fixed
2023 DeskJet PLUS Underline ON: Single floating
2024 DeskJet PLUS Underline Until End-of-line
2025 DeskJet PLUS Underline Until Turned Off
2026 Diablo 630API
2027 Diablo 630API 10 CPI
2028 Diablo 630API 12 CPI
2029 Diablo 630API 12 Lines/Inch
2030 Diablo 630API 15-17 CPI
2031 Diablo 630API Alt. Var Ln S
2032 Diablo 630API Bold OFF
2033 Diablo 630API Bold ON
2034 Diablo 630API DbIStrike OFF
2035 Diablo 630API DbIStrike ON
2036 Diablo 630API DbIWIDE OFF
2037 Diablo 630API Draft Mode
2038 Diablo 630API Emphasize OFF
2039 Diablo 630API Emphasize ON
2040 Diablo 630API Initialize
2041 Diablo 630API Mastr Font/Ty
2042 Diablo 630API NLQ Mode
2043 Diablo 630API Sel. Prt Style
2044 Diablo 630API Select Char S
2045 Diablo 630API Set BOT Margin
2046 Diablo 630API Set RHT Margin
2047 Diablo 630API Set Tab Stops
2048 Diablo 630API Set TOP Margin
2049 Diablo 630API SUBScript OFF
2050 Diablo 630API SUBScript ON
2051 Diablo 630API SUP-Scr OFF
2052 Diablo 630API SUPERscript On
2053 Diablo 630API Underline OFF
2054 Diablo 630API Underline ON
2055 Diablo 630API User
2056 Diablo 630API User
2057 Diablo 630API Var. Ln Space
2058 Diablo Activate Auto CR/LF
2059 Diablo Activate Inverted HMI
2060 Diablo Backspace
2061 Diablo Backspace 1/120 inch
2062 Diablo Backward Line feed
2063 Diablo Bold Off
2064 Diablo Bold On

2065 Diablo Carriage Return
2066 Diablo Clear All horizontal and vertical Tabs
2067 Diablo Clear Bold, Shadow, Auto-Underline
2068 Diablo Clear Horizontal Tab at cursor position
2069 Diablo Clear Top & Bottom Margins
2070 Diablo Deactivate Inverted HMI
2071 Diablo Disable Auto CR/LF
2072 Diablo Eject Page
2073 Diablo Form Feed
2074 Diablo Half Line feed
2075 Diablo Horizontal Tab
2076 Diablo Italics Off
2077 Diablo Italics On
2078 Diablo Line Feed
2079 Diablo One-Line Auto justification
2080 Diablo Print Character in control code range
2081 Diablo Print Special Character location 127
2082 Diablo Print Special Character location 32
2083 Diablo Reverse Half Line feed
2084 Diablo Select Auto justification
2085 Diablo Select Primary character set
2086 Diablo Select Primary character set
2087 Diablo Select Printwheel 1: Courier 10
2088 Diablo Select Printwheel 2: Courier Legal 10
2089 Diablo Select Printwheel 3: ECS multipurpose 10
2090 Diablo Select Supplemental character set
2091 Diablo Set Bottom Margin at cursor position
2092 Diablo Set Horizontal Tab at cursor position
2093 Diablo Set Left Margin
2094 Diablo Set page length to 66 lines
2095 Diablo Set Right Margin
2096 Diablo Set Top Margin at cursor position
2097 Diablo Set Vertical tab at cursor position
2098 Diablo Space
2099 Diablo Start Backward printing
2100 Diablo Start shadow (Bold)
2101 Diablo Stop Backward printing
2102 Diablo Suppress Printing until Carriage Return
2103 Diablo Tab to Column 1
2104 Diablo Tab to Column 8
2105 Diablo Underline Off
2106 Diablo Underline On
2107 Diablo Vertical Tab
2108 Diablo-620 & 630 10 CPI.
2109 Diablo-620 & 630 12 CPI.
2110 Diablo-620 & 630 6 lines per inch.
2111 Diablo-620 & 630 8 lines per inch.
2112 Diablo-620 & 630 Double Strike Off.
2113 Diablo-620 & 630 Double Strike On.

2114 Diablo-620 & 630 Reset
2115 Diablo-620 & 630 Setup
2116 Diablo-620 & 630 Underline Off.
2117 Diablo-620 & 630 Underline On.
2118 Diconix 150 plus [IBM] 10 CPI
2119 Diconix 150 plus [IBM] 12 CPI
2120 Diconix 150 plus [IBM] 12 Lines/Inch
2121 Diconix 150 plus [IBM] 15-17 CPI
2122 Diconix 150 plus [IBM] 6 Lines/Inch
2123 Diconix 150 plus [IBM] 8 Lines/Inch
2124 Diconix 150 plus [IBM] Alt. Var Ln Sp
2125 Diconix 150 plus [IBM] Bldirect'l ON
2126 Diconix 150 plus [IBM] Bold OFF
2127 Diconix 150 plus [IBM] Bold ON
2128 Diconix 150 plus [IBM] Condense Off
2129 Diconix 150 plus [IBM] DblStrike OFF
2130 Diconix 150 plus [IBM] DblStrike ON
2131 Diconix 150 plus [IBM] DblWIDE OFF
2132 Diconix 150 plus [IBM] DdlWIDE ON
2133 Diconix 150 plus [IBM] Draft Mode
2134 Diconix 150 plus [IBM] Emphasize OFF
2135 Diconix 150 plus [IBM] Emphasize ON
2136 Diconix 150 plus [IBM] Initialize
2137 Diconix 150 plus [IBM] Italic OFF
2138 Diconix 150 plus [IBM] Italic ON
2139 Diconix 150 plus [IBM] Mastr Font/Typ
2140 Diconix 150 plus [IBM] NLQ Mode
2141 Diconix 150 plus [IBM] Propor'n'l Off
2142 Diconix 150 plus [IBM] Propor'n'l On
2143 Diconix 150 plus [IBM] Select Char St
2144 Diconix 150 plus [IBM] Set LFT Margin
2145 Diconix 150 plus [IBM] Set RHT Margin
2146 Diconix 150 plus [IBM] Set Tab Stops
2147 Diconix 150 plus [IBM] Skip Perf OFF
2148 Diconix 150 plus [IBM] Skip Perf ON
2149 Diconix 150 plus [IBM] SUBScript OFF
2150 Diconix 150 plus [IBM] SUBScript ON
2151 Diconix 150 plus [IBM] SUP-Scr OFF
2152 Diconix 150 plus [IBM] SUPERscript ON
2153 Diconix 150 plus [IBM] Underline OFF
2154 Diconix 150 plus [IBM] Underline ON
2155 Diconix 150 plus [IBM] UNldirect'l ON
2156 Diconix 150 plus [IBM] Var. Ln Space
2157 Diconix 150 [Epson] 10 CPI
2158 Diconix 150 [Epson] 12 CPI
2159 Diconix 150 [Epson] 12 Lines/Inch
2160 Diconix 150 [Epson] 15-17 CPI
2161 Diconix 150 [Epson] 6 Lines/Inch
2162 Diconix 150 [Epson] 8 Lines/Inch

2163 Diconix 150 [Epson] Alt. Var Ln Sp
2164 Diconix 150 [Epson] Bldirect'l ON
2165 Diconix 150 [Epson] Bold OFF
2166 Diconix 150 [Epson] Bold ON
2167 Diconix 150 [Epson] Condense Off
2168 Diconix 150 [Epson] DblStrike OFF
2169 Diconix 150 [Epson] DblStrike ON
2170 Diconix 150 [Epson] DblWIDE OFF
2171 Diconix 150 [Epson] DdlWIDE ON
2172 Diconix 150 [Epson] Draft Mode
2173 Diconix 150 [Epson] Emphasize OFF
2174 Diconix 150 [Epson] Emphasize ON
2175 Diconix 150 [Epson] Initialize
2176 Diconix 150 [Epson] Int Chr Spac'g
2177 Diconix 150 [Epson] Italic OFF
2178 Diconix 150 [Epson] Italic ON
2179 Diconix 150 [Epson] Mastr Font/Typ
2180 Diconix 150 [Epson] NLQ Mode
2181 Diconix 150 [Epson] Propor'nl Off
2182 Diconix 150 [Epson] Propor'nl On
2183 Diconix 150 [Epson] Sel. Prt Style
2184 Diconix 150 [Epson] Select Char St
2185 Diconix 150 [Epson] Set LFT Margin
2186 Diconix 150 [Epson] Set RHT Margin
2187 Diconix 150 [Epson] Set Tab Stops
2188 Diconix 150 [Epson] Skip Perf OFF
2189 Diconix 150 [Epson] Skip Perf ON
2190 Diconix 150 [Epson] SUBScript OFF
2191 Diconix 150 [Epson] SUBScript ON
2192 Diconix 150 [Epson] SUP-Scr OFF
2193 Diconix 150 [Epson] SUPERscript ON
2194 Diconix 150 [Epson] Underline OFF
2195 Diconix 150 [Epson] Underline ON
2196 Diconix 150 [Epson] UNIdirect'l ON
2197 Diconix 150 [Epson] Var. Ln Space
2198 Dynax DX-15 10 CPI.
2199 Dynax DX-15 12 CPI.
2200 Dynax DX-15 6 lines per inch.
2201 Dynax DX-15 8 lines per inch.
2202 Dynax DX-15 Double Stike Off.
2203 Dynax DX-15 Double Stike On.
2204 Dynax DX-15 Reset
2205 Dynax DX-15 Setup
2206 Dynax DX-15 Underline Off.
2207 Dynax DX-15 Underline On.
2208 Epson E/F/J/RX/LQ 10 CPI.
2209 Epson E/F/J/RX/LQ 12 CPI.
2210 Epson E/F/J/RX/LQ 6 lines per inch.
2211 Epson E/F/J/RX/LQ 8 lines per inch.

2212 Epson E/F/J/RX/LQ Double Strike Off.
2213 Epson E/F/J/RX/LQ Double Strike On.
2214 Epson E/F/J/RX/LQ Italics Off.
2215 Epson E/F/J/RX/LQ Italics On.
2216 Epson E/F/J/RX/LQ Reset
2217 Epson E/F/J/RX/LQ Setup
2218 Epson E/F/J/RX/LQ Underline Off.
2219 Epson E/F/J/RX/LQ Underline On.
2220 Epson FX Clear Printer Buffer
2221 Epson FX Compressed OFF
2222 Epson FX Compressed ON
2223 Epson FX Double Height OFF
2224 Epson FX Double Height ON
2225 Epson FX Double Width OFF
2226 Epson FX Double Width ON
2227 Epson FX Emphasized OFF
2228 Epson FX Emphasized ON
2229 Epson FX Enhanced OFF
2230 Epson FX Enhanced ON
2231 Epson FX Form Feed
2232 Epson FX High Speed Draft OFF
2233 Epson FX High Speed Draft ON
2234 Epson FX Italics OFF
2235 Epson FX Italics ON
2236 Epson FX Line Feed
2237 Epson FX Paper-Out Sensor OFF
2238 Epson FX Paper-Out Sensor ON
2239 Epson FX Print Bidirectional
2240 Epson FX Print Courier
2241 Epson FX Print Full Speed
2242 Epson FX Print Half Speed
2243 Epson FX Print Sans Serif
2244 Epson FX Print Suppress Mode OFF
2245 Epson FX Print Suppress Mode ON
2246 Epson FX Print Unidirectional
2247 Epson FX Proportional Spacing OFF
2248 Epson FX Proportional Spacing ON
2249 Epson FX Reset
2250 Epson FX Select 10 CPI
2251 Epson FX Select 12 CPI
2252 Epson FX Select NLQ Print
2253 Epson FX Select Utility Quality Print
2254 Epson FX Set Form Length In Inches: 11
2255 Epson FX Set Form Length In Inches: 14
2256 Epson FX Set Form Length In Lines: 56
2257 Epson FX Set Form Length In Lines: 56
2258 Epson FX Set Justification to center.
2259 Epson FX Set Justification to left & right.
2260 Epson FX Set Justification to left.

2261 Epson FX Set Justification to right.
2262 Epson FX Set Line Spacing 1/6
2263 Epson FX Set Line Spacing 1/8
2264 Epson FX Set Line Spacing 7/72
2265 Epson FX Subscript OFF
2266 Epson FX Subscript ON
2267 Epson FX Superscript OFF
2268 Epson FX Superscript ON
2269 Epson FX Underline OFF
2270 Epson FX Underline ON
2271 Epson FX-800/1000 10 CPI.
2272 Epson FX-800/1000 12 CPI.
2273 Epson FX-800/1000 6 lines per inch.
2274 Epson FX-800/1000 8 lines per inch.
2275 Epson FX-800/1000 Double Strike Off.
2276 Epson FX-800/1000 Double Strike On.
2277 Epson FX-800/1000 Italics Off.
2278 Epson FX-800/1000 Italics On.
2279 Epson FX-800/1000 Reset
2280 Epson FX-800/1000 Setup
2281 Epson FX-800/1000 Underline Off.
2282 Epson FX-800/1000 Underline On.
2283 Epson Laser EPL-6000 10 CPI
2284 Epson Laser EPL-6000 12 CPI
2285 Epson Laser EPL-6000 12 Lines/Inch
2286 Epson Laser EPL-6000 15-17 CPI
2287 Epson Laser EPL-6000 6 Lines/Inch
2288 Epson Laser EPL-6000 8 Lines/Inch
2289 Epson Laser EPL-6000 Alt. Var Ln Sp
2290 Epson Laser EPL-6000 Bold OFF
2291 Epson Laser EPL-6000 Bold ON
2292 Epson Laser EPL-6000 Condense Off
2293 Epson Laser EPL-6000 DbStrike OFF
2294 Epson Laser EPL-6000 DbStrike ON
2295 Epson Laser EPL-6000 DdlWIDE ON
2296 Epson Laser EPL-6000 Emphasize OFF
2297 Epson Laser EPL-6000 Emphasize ON
2298 Epson Laser EPL-6000 Initialize
2299 Epson Laser EPL-6000 Int Chr Spac'g
2300 Epson Laser EPL-6000 Italic OFF
2301 Epson Laser EPL-6000 Italic ON
2302 Epson Laser EPL-6000 Mastr Font/Typ
2303 Epson Laser EPL-6000 Move ABS Horiz
2304 Epson Laser EPL-6000 Move ABS Vert.
2305 Epson Laser EPL-6000 Move REL Horiz
2306 Epson Laser EPL-6000 Move REL Vert.
2307 Epson Laser EPL-6000 Pop Cursor
2308 Epson Laser EPL-6000 Propor'nl Off
2309 Epson Laser EPL-6000 Propor'nl On

2310 Epson Laser EPL-6000 Push Cursor
2311 Epson Laser EPL-6000 Sel. Prt Style
2312 Epson Laser EPL-6000 Select Char St
2313 Epson Laser EPL-6000 Set LFT Margin
2314 Epson Laser EPL-6000 Set RHT Margin
2315 Epson Laser EPL-6000 Set TOP Margin
2316 Epson Laser EPL-6000 Skip Perf OFF
2317 Epson Laser EPL-6000 Skip Perf ON
2318 Epson Laser EPL-6000 SUBScript OFF
2319 Epson Laser EPL-6000 SUBScript ON
2320 Epson Laser EPL-6000 SUP-Scr OFF
2321 Epson Laser EPL-6000 SUPERscript ON
2322 Epson Laser EPL-6000 Underline OFF
2323 Epson Laser EPL-6000 Underline ON
2324 Epson Laser EPL-6000 Var. Ln Space
2325 Epson Laser EPL-7000 10 CPI
2326 Epson Laser EPL-7000 12 CPI
2327 Epson Laser EPL-7000 12 Lines/Inch
2328 Epson Laser EPL-7000 15-17 CPI
2329 Epson Laser EPL-7000 6 Lines/Inch
2330 Epson Laser EPL-7000 8 Lines/Inch
2331 Epson Laser EPL-7000 Alt. Var Ln Sp
2332 Epson Laser EPL-7000 Bold OFF
2333 Epson Laser EPL-7000 Bold ON
2334 Epson Laser EPL-7000 Condense Off
2335 Epson Laser EPL-7000 DblStrike OFF
2336 Epson Laser EPL-7000 DblStrike ON
2337 Epson Laser EPL-7000 DdlWIDE ON
2338 Epson Laser EPL-7000 Emphasize OFF
2339 Epson Laser EPL-7000 Emphasize ON
2340 Epson Laser EPL-7000 Initialize
2341 Epson Laser EPL-7000 Int Chr Spac'g
2342 Epson Laser EPL-7000 Italic OFF
2343 Epson Laser EPL-7000 Italic ON
2344 Epson Laser EPL-7000 Mastr Font/Typ
2345 Epson Laser EPL-7000 Move ABS Horiz
2346 Epson Laser EPL-7000 Move ABS Vert.
2347 Epson Laser EPL-7000 Move REL Horiz
2348 Epson Laser EPL-7000 Move REL Vert.
2349 Epson Laser EPL-7000 Pop Cursor
2350 Epson Laser EPL-7000 Propor'nl Off
2351 Epson Laser EPL-7000 Propor'nl On
2352 Epson Laser EPL-7000 Push Cursor
2353 Epson Laser EPL-7000 Sel. Prt Style
2354 Epson Laser EPL-7000 Select Char St
2355 Epson Laser EPL-7000 Set LFT Margin
2356 Epson Laser EPL-7000 Set RHT Margin
2357 Epson Laser EPL-7000 Set TOP Margin
2358 Epson Laser EPL-7000 Skip Perf OFF

2359 Epson Laser EPL-7000 Skip Perf ON
2360 Epson Laser EPL-7000 SUBScript OFF
2361 Epson Laser EPL-7000 SUBScript ON
2362 Epson Laser EPL-7000 SUP-Scr OFF
2363 Epson Laser EPL-7000 SUPERscript ON
2364 Epson Laser EPL-7000 Underline OFF
2365 Epson Laser EPL-7000 Underline ON
2366 Epson Laser EPL-7000 Var. Ln Space
2367 Epson LX 10 CPI.
2368 Epson LX 12 CPI.
2369 Epson LX 6 lines per inch.
2370 Epson LX 8 lines per inch.
2371 Epson LX Double Stike Off.
2372 Epson LX Double Stike On.
2373 Epson LX Italics Off.
2374 Epson LX Italics On.
2375 Epson LX Reset
2376 Epson LX Setup
2377 Epson LX Underline Off.
2378 Epson LX Underline On.
2379 Epson LX-90 10 CPI.
2380 Epson LX-90 6 lines per inch.
2381 Epson LX-90 8 lines per inch.
2382 Epson LX-90 Double Stike Off.
2383 Epson LX-90 Double Stike On.
2384 Epson LX-90 Underline Off.
2385 Epson LX-90 Underline On.
2386 Epson MX-80 Compressed Off
2387 Epson MX-80 Compressed On
2388 Epson MX-80 Double Strike Off
2389 Epson MX-80 Double Strike On
2390 Epson MX-80 Eject Page
2391 Epson MX-80 Emphasized Print Off
2392 Epson MX-80 Emphasized Print On
2393 Epson MX-80 Expanded Print Off
2394 Epson MX-80 Expanded Print On
2395 Epson MX-80 Italics Off
2396 Epson MX-80 Italics On
2397 Epson MX-80 Reset Printer to Defaults
2398 Epson MX-80 Underline Off
2399 Epson MX-80 Underline On
2400 Facit 4513/4514 10 CPI
2401 Facit 4513/4514 12 CPI
2402 Facit 4513/4514 12 Lines/Inch
2403 Facit 4513/4514 15-17 CPI
2404 Facit 4513/4514 6 Lines/Inch
2405 Facit 4513/4514 8 Lines/Inch
2406 Facit 4513/4514 Alt. Var Ln Sp
2407 Facit 4513/4514 Bldirect'l ON

2408 Facit 4513/4514 Bold OFF
2409 Facit 4513/4514 Bold ON
2410 Facit 4513/4514 Condense Off
2411 Facit 4513/4514 DbIStrike OFF
2412 Facit 4513/4514 DbIStrike ON
2413 Facit 4513/4514 DbIWIDE OFF
2414 Facit 4513/4514 DdIWIDE ON
2415 Facit 4513/4514 Draft Mode
2416 Facit 4513/4514 Emphasize OFF
2417 Facit 4513/4514 Emphasize ON
2418 Facit 4513/4514 Initialize
2419 Facit 4513/4514 Italic OFF
2420 Facit 4513/4514 Italic ON
2421 Facit 4513/4514 Mastr Font/Typ
2422 Facit 4513/4514 NLQ Mode
2423 Facit 4513/4514 Propor'nl Off
2424 Facit 4513/4514 Propor'nl On
2425 Facit 4513/4514 Select Char St
2426 Facit 4513/4514 Set LFT Margin
2427 Facit 4513/4514 Set RHT Margin
2428 Facit 4513/4514 Set Tab Stops
2429 Facit 4513/4514 Skip Perf OFF
2430 Facit 4513/4514 Skip Perf ON
2431 Facit 4513/4514 SUBScript OFF
2432 Facit 4513/4514 SUBScript ON
2433 Facit 4513/4514 SUP-Scr OFF
2434 Facit 4513/4514 SUPERscript ON
2435 Facit 4513/4514 Underline OFF
2436 Facit 4513/4514 Underline ON
2437 Facit 4513/4514 UNIdirect'l ON
2438 Facit 4513/4514 Var. Ln Space
2439 Fortis DM2010/2015 10 CPI
2440 Fortis DM2010/2015 12 CPI
2441 Fortis DM2010/2015 12 Lines/Inch
2442 Fortis DM2010/2015 15-17 CPI
2443 Fortis DM2010/2015 6 Lines/Inch
2444 Fortis DM2010/2015 8 Lines/Inch
2445 Fortis DM2010/2015 Alt. Var Ln Sp
2446 Fortis DM2010/2015 Bldirect'l ON
2447 Fortis DM2010/2015 Bold OFF
2448 Fortis DM2010/2015 Bold ON
2449 Fortis DM2010/2015 Condense Off
2450 Fortis DM2010/2015 DbIStrike OFF
2451 Fortis DM2010/2015 DbIStrike ON
2452 Fortis DM2010/2015 DbIWIDE OFF
2453 Fortis DM2010/2015 DdIWIDE ON
2454 Fortis DM2010/2015 Draft Mode
2455 Fortis DM2010/2015 Emphasize OFF
2456 Fortis DM2010/2015 Emphasize ON

2457 Fortis DM2010/2015 Initialize
2458 Fortis DM2010/2015 Italic OFF
2459 Fortis DM2010/2015 Italic ON
2460 Fortis DM2010/2015 Mastr Font/Typ
2461 Fortis DM2010/2015 NLQ Mode
2462 Fortis DM2010/2015 Propor'nl Off
2463 Fortis DM2010/2015 Propor'nl On
2464 Fortis DM2010/2015 Sel. Prt Style
2465 Fortis DM2010/2015 Select Char St
2466 Fortis DM2010/2015 Set LFT Margin
2467 Fortis DM2010/2015 Set RHT Margin
2468 Fortis DM2010/2015 Set Tab Stops
2469 Fortis DM2010/2015 Skip Perf OFF
2470 Fortis DM2010/2015 Skip Perf ON
2471 Fortis DM2010/2015 SUBScript OFF
2472 Fortis DM2010/2015 SUBScript ON
2473 Fortis DM2010/2015 SUP-Scr OFF
2474 Fortis DM2010/2015 SUPERscript ON
2475 Fortis DM2010/2015 Underline OFF
2476 Fortis DM2010/2015 Underline ON
2477 Fortis DM2010/2015 UNldirect'l ON
2478 Fortis DM2010/2015 Var. Ln Space
2479 Fujitsu 24C/24I/DL/DPL 10 CPI
2480 Fujitsu 24C/24I/DL/DPL 12 CPI
2481 Fujitsu 24C/24I/DL/DPL 12 Lines/Inch
2482 Fujitsu 24C/24I/DL/DPL 15-17 CPI
2483 Fujitsu 24C/24I/DL/DPL 6 Lines/Inch
2484 Fujitsu 24C/24I/DL/DPL 8 Lines/Inch
2485 Fujitsu 24C/24I/DL/DPL Alt. Var Ln Sp
2486 Fujitsu 24C/24I/DL/DPL Bldirect'l ON
2487 Fujitsu 24C/24I/DL/DPL Bold OFF
2488 Fujitsu 24C/24I/DL/DPL Bold ON
2489 Fujitsu 24C/24I/DL/DPL Condense Off
2490 Fujitsu 24C/24I/DL/DPL DbIStrike OFF
2491 Fujitsu 24C/24I/DL/DPL DbIStrike ON
2492 Fujitsu 24C/24I/DL/DPL DbIWIDE OFF
2493 Fujitsu 24C/24I/DL/DPL DdIWIDE ON
2494 Fujitsu 24C/24I/DL/DPL Draft Mode
2495 Fujitsu 24C/24I/DL/DPL Emphasize OFF
2496 Fujitsu 24C/24I/DL/DPL Emphasize ON
2497 Fujitsu 24C/24I/DL/DPL Initialize
2498 Fujitsu 24C/24I/DL/DPL Italic OFF
2499 Fujitsu 24C/24I/DL/DPL Italic ON
2500 Fujitsu 24C/24I/DL/DPL Mastr Font/Typ
2501 Fujitsu 24C/24I/DL/DPL NLQ Mode
2502 Fujitsu 24C/24I/DL/DPL Propor'nl Off
2503 Fujitsu 24C/24I/DL/DPL Propor'nl On
2504 Fujitsu 24C/24I/DL/DPL Select Char St
2505 Fujitsu 24C/24I/DL/DPL Set LFT Margin

Sheet1

2506 Fujitsu 24C/24I/DL/DPL Set RHT Margin
2507 Fujitsu 24C/24I/DL/DPL Set Tab Stops
2508 Fujitsu 24C/24I/DL/DPL Skip Perf OFF
2509 Fujitsu 24C/24I/DL/DPL Skip Perf ON
2510 Fujitsu 24C/24I/DL/DPL SUBScript OFF
2511 Fujitsu 24C/24I/DL/DPL SUBScript ON
2512 Fujitsu 24C/24I/DL/DPL SUP-Scr OFF
2513 Fujitsu 24C/24I/DL/DPL SUPERscript ON
2514 Fujitsu 24C/24I/DL/DPL Underline OFF
2515 Fujitsu 24C/24I/DL/DPL Underline ON
2516 Fujitsu 24C/24I/DL/DPL UNIdirect'I ON
2517 Fujitsu 24C/24I/DL/DPL Var. Ln Space
2518 Fujitsu DL 10 CPI
2519 Fujitsu DL 12 CPI
2520 Fujitsu DL 12 Lines/Inch
2521 Fujitsu DL 15-17 CPI
2522 Fujitsu DL 6 Lines/Inch
2523 Fujitsu DL 8 Lines/Inch
2524 Fujitsu DL Alt. Var Ln Sp
2525 Fujitsu DL Bldirect'I ON
2526 Fujitsu DL Bold OFF
2527 Fujitsu DL Bold ON
2528 Fujitsu DL Condense Off
2529 Fujitsu DL DblStrike OFF
2530 Fujitsu DL DblStrike ON
2531 Fujitsu DL DblWIDE OFF
2532 Fujitsu DL DdlWIDE ON
2533 Fujitsu DL Draft Mode
2534 Fujitsu DL Emphasize OFF
2535 Fujitsu DL Emphasize ON
2536 Fujitsu DL Initialize
2537 Fujitsu DL Italic OFF
2538 Fujitsu DL Italic ON
2539 Fujitsu DL Mastr Font/Typ
2540 Fujitsu DL NLQ Mode
2541 Fujitsu DL Propor'nI Off
2542 Fujitsu DL Propor'nI On
2543 Fujitsu DL Select Char St
2544 Fujitsu DL Set LFT Margin
2545 Fujitsu DL Set RHT Margin
2546 Fujitsu DL Set Tab Stops
2547 Fujitsu DL Skip Perf OFF
2548 Fujitsu DL Skip Perf ON
2549 Fujitsu DL SUBScript OFF
2550 Fujitsu DL SUBScript ON
2551 Fujitsu DL SUP-Scr OFF
2552 Fujitsu DL SUPERscript ON
2553 Fujitsu DL Underline OFF
2554 Fujitsu DL Underline ON

2555 Fujitsu DL UNldirect'l ON
2556 Fujitsu DL Var. Ln Space
2557 Fujitsu DotMax 9f/9i 10 CPI
2558 Fujitsu DotMax 9f/9i 12 CPI
2559 Fujitsu DotMax 9f/9i 12 Lines/Inch
2560 Fujitsu DotMax 9f/9i 15-17 CPI
2561 Fujitsu DotMax 9f/9i 6 Lines/Inch
2562 Fujitsu DotMax 9f/9i 8 Lines/Inch
2563 Fujitsu DotMax 9f/9i Alt. Var Ln Sp
2564 Fujitsu DotMax 9f/9i Bldirect'l ON
2565 Fujitsu DotMax 9f/9i Bold OFF
2566 Fujitsu DotMax 9f/9i Bold ON
2567 Fujitsu DotMax 9f/9i Condense Off
2568 Fujitsu DotMax 9f/9i DblStrike OFF
2569 Fujitsu DotMax 9f/9i DblStrike ON
2570 Fujitsu DotMax 9f/9i DblWIDE OFF
2571 Fujitsu DotMax 9f/9i DdlWIDE ON
2572 Fujitsu DotMax 9f/9i Draft Mode
2573 Fujitsu DotMax 9f/9i Emphasize OFF
2574 Fujitsu DotMax 9f/9i Emphasize ON
2575 Fujitsu DotMax 9f/9i Initialize
2576 Fujitsu DotMax 9f/9i Italic OFF
2577 Fujitsu DotMax 9f/9i Italic ON
2578 Fujitsu DotMax 9f/9i Mastr Font/Typ
2579 Fujitsu DotMax 9f/9i NLQ Mode
2580 Fujitsu DotMax 9f/9i Propor'nl Off
2581 Fujitsu DotMax 9f/9i Propor'nl On
2582 Fujitsu DotMax 9f/9i Select Char St
2583 Fujitsu DotMax 9f/9i Set LFT Margin
2584 Fujitsu DotMax 9f/9i Set RHT Margin
2585 Fujitsu DotMax 9f/9i Set Tab Stops
2586 Fujitsu DotMax 9f/9i Skip Perf OFF
2587 Fujitsu DotMax 9f/9i Skip Perf ON
2588 Fujitsu DotMax 9f/9i SUBScript OFF
2589 Fujitsu DotMax 9f/9i SUBScript ON
2590 Fujitsu DotMax 9f/9i SUP-Scr OFF
2591 Fujitsu DotMax 9f/9i SUPERscript ON
2592 Fujitsu DotMax 9f/9i Underline OFF
2593 Fujitsu DotMax 9f/9i Underline ON
2594 Fujitsu DotMax 9f/9i UNldirect'l ON
2595 Fujitsu DotMax 9f/9i Var. Ln Space
2596 Fujitsu DX 10 CPI
2597 Fujitsu DX 12 CPI
2598 Fujitsu DX 12 Lines/Inch
2599 Fujitsu DX 15-17 CPI
2600 Fujitsu DX 6 Lines/Inch
2601 Fujitsu DX 8 Lines/Inch
2602 Fujitsu DX Alt. Var Ln Sp
2603 Fujitsu DX Bldirect'l ON

2604 Fujitsu DX Bold OFF
2605 Fujitsu DX Bold ON
2606 Fujitsu DX Condense Off
2607 Fujitsu DX DblStrike OFF
2608 Fujitsu DX DblStrike ON
2609 Fujitsu DX DblWIDE OFF
2610 Fujitsu DX DdlWIDE ON
2611 Fujitsu DX Draft Mode
2612 Fujitsu DX Emphasize OFF
2613 Fujitsu DX Emphasize ON
2614 Fujitsu DX Initialize
2615 Fujitsu DX Italic OFF
2616 Fujitsu DX Italic ON
2617 Fujitsu DX Mastr Font/Typ
2618 Fujitsu DX NLQ Mode
2619 Fujitsu DX Propor'nl Off
2620 Fujitsu DX Propor'nl On
2621 Fujitsu DX Select Char St
2622 Fujitsu DX Set LFT Margin
2623 Fujitsu DX Set RHT Margin
2624 Fujitsu DX Set Tab Stops
2625 Fujitsu DX Skip Perf OFF
2626 Fujitsu DX Skip Perf ON
2627 Fujitsu DX SUBScript OFF
2628 Fujitsu DX SUBScript ON
2629 Fujitsu DX SUP-Scr OFF
2630 Fujitsu DX SUPERscript ON
2631 Fujitsu DX Underline OFF
2632 Fujitsu DX Underline ON
2633 Fujitsu DX UNIdirect'l ON
2634 Fujitsu DX Var. Ln Space
2635 Fujitsu Laser RX 10 CPI
2636 Fujitsu Laser RX 12 CPI
2637 Fujitsu Laser RX 12 Lines/Inch
2638 Fujitsu Laser RX 15-17 CPI
2639 Fujitsu Laser RX 6 Lines/Inch
2640 Fujitsu Laser RX 8 Lines/Inch
2641 Fujitsu Laser RX Bold OFF
2642 Fujitsu Laser RX Bold ON
2643 Fujitsu Laser RX DblStrike OFF
2644 Fujitsu Laser RX DblStrike ON
2645 Fujitsu Laser RX DdlWIDE OFF
2646 Fujitsu Laser RX DdlWIDE ON
2647 Fujitsu Laser RX Emphasize ON
2648 Fujitsu Laser RX Initialize
2649 Fujitsu Laser RX Move ABS Horiz
2650 Fujitsu Laser RX Move ABS Vert.
2651 Fujitsu Laser RX NLQ Mode
2652 Fujitsu Laser RX Propor'nl Off

2653 Fujitsu Laser RX Propor'nl On
2654 Fujitsu Laser RX Set BOT Margin
2655 Fujitsu Laser RX Set LFT Margin
2656 Fujitsu Laser RX Set RHT Margin
2657 Fujitsu Laser RX Set Tab Stops
2658 Fujitsu Laser RX Set TOP Margin
2659 Fujitsu Laser RX SUBScript OFF
2660 Fujitsu Laser RX SUP-Scr OFF
2661 Fujitsu Laser RX SUPERscript ON
2662 Fujitsu Laser RX Underline OFF
2663 Fujitsu Laser RX Underline ON
2664 Fujitsu SP-320/SP-320e 10 CPI
2665 Fujitsu SP-320/SP-320e 12 CPI
2666 Fujitsu SP-320/SP-320e 12 Lines/Inch
2667 Fujitsu SP-320/SP-320e 15-17 CPI
2668 Fujitsu SP-320/SP-320e 6 Lines/Inch
2669 Fujitsu SP-320/SP-320e 8 Lines/Inch
2670 Fujitsu SP-320/SP-320e Bold OFF
2671 Fujitsu SP-320/SP-320e Bold ON
2672 Fujitsu SP-320/SP-320e DblStrike OFF
2673 Fujitsu SP-320/SP-320e DblStrike ON
2674 Fujitsu SP-320/SP-320e DdlWIDE OFF
2675 Fujitsu SP-320/SP-320e DdlWIDE ON
2676 Fujitsu SP-320/SP-320e Emphasize OFF
2677 Fujitsu SP-320/SP-320e Emphasize ON
2678 Fujitsu SP-320/SP-320e Initialize
2679 Fujitsu SP-320/SP-320e Move ABS Horiz
2680 Fujitsu SP-320/SP-320e Move ABS Vert.
2681 Fujitsu SP-320/SP-320e NLQ Mode
2682 Fujitsu SP-320/SP-320e Propor'nl Off
2683 Fujitsu SP-320/SP-320e Propor'nl On
2684 Fujitsu SP-320/SP-320e Set BOT Margin
2685 Fujitsu SP-320/SP-320e Set LFT Margin
2686 Fujitsu SP-320/SP-320e Set RHT Margin
2687 Fujitsu SP-320/SP-320e Set Tab Stops
2688 Fujitsu SP-320/SP-320e Set TOP Margin
2689 Fujitsu SP-320/SP-320e SUBScript OFF
2690 Fujitsu SP-320/SP-320e SUBScript ON
2691 Fujitsu SP-320/SP-320e SUP-Scr OFF
2692 Fujitsu SP-320/SP-320e SUPERscript ON
2693 Fujitsu SP-320/SP-320e Underline OFF
2694 Fujitsu SP-320/SP-320e Underline ON
2695 Genicom 3310/3320 10 CPI
2696 Genicom 3310/3320 12 CPI
2697 Genicom 3310/3320 12 Lines/Inch
2698 Genicom 3310/3320 15-17 CPI
2699 Genicom 3310/3320 6 Lines/Inch
2700 Genicom 3310/3320 8 Lines/Inch
2701 Genicom 3310/3320 Bold OFF

2702 Genicom 3310/3320 Bold ON
2703 Genicom 3310/3320 Condense Off
2704 Genicom 3310/3320 DbIStrike OFF
2705 Genicom 3310/3320 DbIStrike ON
2706 Genicom 3310/3320 DbIWIDE OFF
2707 Genicom 3310/3320 DdlWIDE ON
2708 Genicom 3310/3320 Draft Mode
2709 Genicom 3310/3320 Emphasize OFF
2710 Genicom 3310/3320 Emphasize ON
2711 Genicom 3310/3320 Initialize
2712 Genicom 3310/3320 Move ABS Horiz
2713 Genicom 3310/3320 Move ABS Vert.
2714 Genicom 3310/3320 NLQ Mode
2715 Genicom 3310/3320 Propor'nl Off
2716 Genicom 3310/3320 Propor'nl On
2717 Genicom 3310/3320 Set BOT Margin
2718 Genicom 3310/3320 Set LFT Margin
2719 Genicom 3310/3320 Set RHT Margin
2720 Genicom 3310/3320 Set Tab Stops
2721 Genicom 3310/3320 Set TOP Margin
2722 Genicom 3310/3320 SUBScript OFF
2723 Genicom 3310/3320 SUBScript ON
2724 Genicom 3310/3320 SUP-Scr OFF
2725 Genicom 3310/3320 SUPERscript ON
2726 Genicom 3310/3320 Underline OFF
2727 Genicom 3310/3320 Underline ON
2728 HP 2225C+ (Epson Mode) 10 CPI.
2729 HP 2225C+ (Epson Mode) 12 CPI.
2730 HP 2225C+ (Epson Mode) 6 lines per inch.
2731 HP 2225C+ (Epson Mode) 8 lines per inch.
2732 HP 2225C+ (Epson Mode) Double Stike Off.
2733 HP 2225C+ (Epson Mode) Double Stike On.
2734 HP 2225C+ (Epson Mode) Reset
2735 HP 2225C+ (Epson Mode) Setup
2736 HP 2225C+ (Epson Mode) Underline Off.
2737 HP 2225C+ (Epson Mode) Underline On.
2738 HP 2225C+ (HP Mode) 10 CPI.
2739 HP 2225C+ (HP Mode) 6 lines per inch.
2740 HP 2225C+ (HP Mode) 8 lines per inch.
2741 HP 2225C+ (HP Mode) Double Stike Off.
2742 HP 2225C+ (HP Mode) Double Stike On.
2743 HP 2225C+ (HP Mode) Reset
2744 HP 2225C+ (HP Mode) Setup
2745 HP 2225C+ (HP Mode) Underline Off.
2746 HP 2225C+ (HP Mode) Underline On.
2747 HP Label: 10x1" high 10 CPI.
2748 HP Label: 10x1" high 12 CPI.
2749 HP Label: 10x1" high 6 lines per inch.
2750 HP Label: 10x1" high 8 lines per inch.

2751 HP Label: 10x1" high Double Stike Off.
2752 HP Label: 10x1" high Double Stike On.
2753 HP Label: 10x1" high Italics Off.
2754 HP Label: 10x1" high Italics On.
2755 HP Label: 10x1" high Reset
2756 HP Label: 10x1" high Setup
2757 HP Label: 10x1" high Underline Off.
2758 HP Label: 10x1" high Underline On.
2759 HP Label: 11x1" high 10 CPI.
2760 HP Label: 11x1" high 12 CPI.
2761 HP Label: 11x1" high 6 lines per inch.
2762 HP Label: 11x1" high 8 lines per inch.
2763 HP Label: 11x1" high Double Stike Off.
2764 HP Label: 11x1" high Double Stike On.
2765 HP Label: 11x1" high Italics Off.
2766 HP Label: 11x1" high Italics On.
2767 HP Label: 11x1" high Reset
2768 HP Label: 11x1" high Setup
2769 HP Label: 11x1" high Underline Off.
2770 HP Label: 11x1" high Underline On.
2771 HP Label: 7x1.5" high 10 CPI.
2772 HP Label: 7x1.5" high 12 CPI.
2773 HP Label: 7x1.5" high 6 lines per inch.
2774 HP Label: 7x1.5" high 8 lines per inch.
2775 HP Label: 7x1.5" high Double Stike Off.
2776 HP Label: 7x1.5" high Double Stike On.
2777 HP Label: 7x1.5" high Italics Off.
2778 HP Label: 7x1.5" high Italics On.
2779 HP Label: 7x1.5" high Reset
2780 HP Label: 7x1.5" high Setup
2781 HP Label: 7x1.5" high Underline Off.
2782 HP Label: 7x1.5" high Underline On.
2783 HP PaintJet (HP3630) 10 CPI.
2784 HP PaintJet (HP3630) 12 CPI.
2785 HP PaintJet (HP3630) 6 lines per inch.
2786 HP PaintJet (HP3630) 8 lines per inch.
2787 HP PaintJet (HP3630) Double Stike Off.
2788 HP PaintJet (HP3630) Double Stike On.
2789 HP PaintJet (HP3630) Reset
2790 HP PaintJet (HP3630) Setup
2791 HP PaintJet (HP3630) Underline Off.
2792 HP PaintJet (HP3630) Underline On.
2793 HP-LaserJet I, 10 CPI.
2794 HP-LaserJet I, 12 CPI.
2795 HP-LaserJet I, 6 lines per inch.
2796 HP-LaserJet I, 8 lines per inch.
2797 HP-LaserJet I, Double Stike Off.
2798 HP-LaserJet I, Double Stike On.
2799 HP-LaserJet I, Italics Off.

Sheet1

2800 HP-LaserJet I, Italics On.
2801 HP-LaserJet I, Reset
2802 HP-LaserJet I, Setup
2803 HP-LaserJet I, Underline Off.
2804 HP-LaserJet I, Underline On.
2805 HPL3: Self test
2806 IBM 80 CPS Graphics 10 CPI.
2807 IBM 80 CPS Graphics 12 CPI.
2808 IBM 80 CPS Graphics 6 lines per inch.
2809 IBM 80 CPS Graphics 8 lines per inch.
2810 IBM 80 CPS Graphics Double Strike Off.
2811 IBM 80 CPS Graphics Double Strike On.
2812 IBM 80 CPS Graphics Reset
2813 IBM 80 CPS Graphics Setup
2814 IBM 80 CPS Graphics Underline Off.
2815 IBM 80 CPS Graphics Underline On.
2816 IBM 80 CPS Matrix 10 CPI.
2817 IBM 80 CPS Matrix 12 CPI.
2818 IBM 80 CPS Matrix 6 lines per inch.
2819 IBM 80 CPS Matrix 8 lines per inch.
2820 IBM 80 CPS Matrix Double Strike Off.
2821 IBM 80 CPS Matrix Double Strike On.
2822 IBM Color Printer 10 CPI.
2823 IBM Color Printer 12 CPI.
2824 IBM Color Printer 6 lines per inch.
2825 IBM Color Printer 8 lines per inch.
2826 IBM Color Printer Double Strike Off.
2827 IBM Color Printer Double Strike On.
2828 IBM Color Printer Reset
2829 IBM Color Printer Setup
2830 IBM Color Printer Underline Off.
2831 IBM Color Printer Underline On.
2832 IBM Graphics 12 Characters per inch
2833 IBM Graphics Disable proportional spacing
2834 IBM Graphics Enable proportional spacing
2835 IBM Graphics Reset Compressed print (16.7 CPI)
2836 IBM Graphics Reset double strike (NLQ simulated)
2837 IBM Graphics Reset double strike printing
2838 IBM Graphics Reset emphasized printing
2839 IBM Graphics Reset expanded printing (Double Width)
2840 IBM Graphics Reset Skip Perforation
2841 IBM Graphics Reset superscript mode
2842 IBM Graphics Select 8LPI mode
2843 IBM Graphics Select 10CPI for 12 point size print
2844 IBM Graphics Select 10CPI for normal point size
2845 IBM Graphics Select 12CPI for 10 point size print
2846 IBM Graphics Select 16.7CPI and expanded print mode
2847 IBM Graphics Select 16.7CPI for 7 point size print
2848 IBM Graphics Select Bidirectional printing (Normal)

Sheet1

2849 IBM Graphics Select Compressed print (16.7 CPI)
2850 IBM Graphics Select Courier type face
2851 IBM Graphics Select double strike (NLQ simulated)
2852 IBM Graphics Select double strike printing
2853 IBM Graphics Select emphasized printing
2854 IBM Graphics Select expanded printing (Double Width)
2855 IBM Graphics Select IBM character set #1 (Normal)
2856 IBM Graphics Select IBM character set #2
2857 IBM Graphics Select Lineprinter type face
2858 IBM Graphics Select normal type face (Lineprinter)
2859 IBM Graphics Select normal type face (Lineprinter)
2860 IBM Graphics Select Prestige Elite type face
2861 IBM Graphics Select previously downloaded font
2862 IBM Graphics Select superscript mode
2863 IBM Graphics Select Unidirectional printing
2864 IBM Graphics Set Skip Perforation to 4 lines
2865 IBM Graphics Sets Variable Line feed to 12/72's (6LPI)
2866 IBM Laser 4019 10 CPI
2867 IBM Laser 4019 12 CPI
2868 IBM Laser 4019 12 Lines/Inch
2869 IBM Laser 4019 15-17 CPI
2870 IBM Laser 4019 6 Lines/Inch
2871 IBM Laser 4019 8 Lines/Inch
2872 IBM Laser 4019 Alt. Var Ln Sp
2873 IBM Laser 4019 Bold OFF
2874 IBM Laser 4019 Bold ON
2875 IBM Laser 4019 Condense Off
2876 IBM Laser 4019 DblStrike OFF
2877 IBM Laser 4019 DblStrike ON
2878 IBM Laser 4019 DdlWIDE ON
2879 IBM Laser 4019 Emphasize OFF
2880 IBM Laser 4019 Emphasize ON
2881 IBM Laser 4019 Initialize
2882 IBM Laser 4019 Int Chr Spac'g
2883 IBM Laser 4019 Italic OFF
2884 IBM Laser 4019 Italic ON
2885 IBM Laser 4019 Mastr Font/Typ
2886 IBM Laser 4019 Move ABS Horiz
2887 IBM Laser 4019 Move ABS Vert.
2888 IBM Laser 4019 Move REL Horiz
2889 IBM Laser 4019 Move REL Vert.
2890 IBM Laser 4019 Pop Cursor
2891 IBM Laser 4019 Propor'nl Off
2892 IBM Laser 4019 Propor'nl On
2893 IBM Laser 4019 Push Cursor
2894 IBM Laser 4019 Sel. Prt Style
2895 IBM Laser 4019 Select Char St
2896 IBM Laser 4019 Set LFT Margin
2897 IBM Laser 4019 Set RHT Margin

2898 IBM Laser 4019 Set TOP Margin
2899 IBM Laser 4019 Skip Perf OFF
2900 IBM Laser 4019 Skip Perf ON
2901 IBM Laser 4019 SUBScript OFF
2902 IBM Laser 4019 SUBScript ON
2903 IBM Laser 4019 SUP-Scr OFF
2904 IBM Laser 4019 SUPERscript ON
2905 IBM Laser 4019 Underline OFF
2906 IBM Laser 4019 Underline ON
2907 IBM Laser 4019 Var. Ln Space
2908 IBM Laser 4216 10 CPI
2909 IBM Laser 4216 12 CPI
2910 IBM Laser 4216 12 Lines/Inch
2911 IBM Laser 4216 15-17 CPI
2912 IBM Laser 4216 6 Lines/Inch
2913 IBM Laser 4216 8 Lines/Inch
2914 IBM Laser 4216 Alt. Var Ln Sp
2915 IBM Laser 4216 Bold OFF
2916 IBM Laser 4216 Bold ON
2917 IBM Laser 4216 Condense Off
2918 IBM Laser 4216 DbIStrike OFF
2919 IBM Laser 4216 DbIStrike ON
2920 IBM Laser 4216 DdIWIDE ON
2921 IBM Laser 4216 Emphasize OFF
2922 IBM Laser 4216 Emphasize ON
2923 IBM Laser 4216 Initialize
2924 IBM Laser 4216 Int Chr Spac'g
2925 IBM Laser 4216 Italic OFF
2926 IBM Laser 4216 Italic ON
2927 IBM Laser 4216 Mastr Font/Typ
2928 IBM Laser 4216 Move ABS Horiz
2929 IBM Laser 4216 Move ABS Vert.
2930 IBM Laser 4216 Move REL Horiz
2931 IBM Laser 4216 Move REL Vert.
2932 IBM Laser 4216 Pop Cursor
2933 IBM Laser 4216 Propor'nl Off
2934 IBM Laser 4216 Propor'nl On
2935 IBM Laser 4216 Push Cursor
2936 IBM Laser 4216 Sel. Prt Style
2937 IBM Laser 4216 Select Char St
2938 IBM Laser 4216 Set LFT Margin
2939 IBM Laser 4216 Set RHT Margin
2940 IBM Laser 4216 Set TOP Margin
2941 IBM Laser 4216 Skip Perf OFF
2942 IBM Laser 4216 Skip Perf ON
2943 IBM Laser 4216 SUBScript OFF
2944 IBM Laser 4216 SUBScript ON
2945 IBM Laser 4216 SUP-Scr OFF
2946 IBM Laser 4216 SUPERscript ON

2947 IBM Laser 4216 Underline OFF
2948 IBM Laser 4216 Underline ON
2949 IBM Laser 4216 Var. Ln Space
2950 IBM LetterQuality 5218 10 CPI.
2951 IBM LetterQuality 5218 12 CPI.
2952 IBM LetterQuality 5218 6 lines per inch.
2953 IBM LetterQuality 5218 8 lines per inch.
2954 IBM LetterQuality 5218 Reset
2955 IBM LetterQuality 5218 Setup
2956 IBM LetterQuality 5218 Underline Off.
2957 IBM LetterQuality 5218 Underline On.
2958 IBM Pageprinter 3812 10 CPI.
2959 IBM Pageprinter 3812 6 lines per inch.
2960 IBM Pageprinter 3812 8 lines per inch.
2961 IBM Pageprinter 3812 Double Stike Off.
2962 IBM Pageprinter 3812 Double Stike On.
2963 IBM Pageprinter 3812 Reset
2964 IBM Pageprinter 3812 Setup
2965 IBM Pageprinter 3812 Underline Off.
2966 IBM Pageprinter 3812 Underline On.
2967 IBM Proprinter 10 CPI.
2968 IBM Proprinter 12 CPI.
2969 IBM Proprinter 6 lines per inch.
2970 IBM Proprinter 8 lines per inch.
2971 IBM Proprinter Double Stike Off.
2972 IBM Proprinter Double Stike On.
2973 IBM Proprinter Underline Off.
2974 IBM Proprinter Underline On.
2975 IBM Quietwriter 5201 10 CPI.
2976 IBM Quietwriter 5201 12 CPI.
2977 IBM Quietwriter 5201 6 lines per inch.
2978 IBM Quietwriter 5201 8 lines per inch.
2979 IBM Quietwriter 5201 Underline Off.
2980 IBM Quietwriter 5201 Underline On.
2981 IBM Quietwriter III 10 CPI.
2982 IBM Quietwriter III 12 CPI.
2983 IBM Quietwriter III 6 lines per inch.
2984 IBM Quietwriter III 8 lines per inch.
2985 IBM Quietwriter III Double Stike Off.
2986 IBM Quietwriter III Double Stike On.
2987 IBM Quietwriter III Underline Off.
2988 IBM Quietwriter III Underline On.
2989 IBM Wheelprinter 5216 10 CPI.
2990 IBM Wheelprinter 5216 12 CPI.
2991 IBM Wheelprinter 5216 6 lines per inch.
2992 IBM Wheelprinter 5216 8 lines per inch.
2993 IBM Wheelprinter 5216 Reset
2994 IBM Wheelprinter 5216 Setup
2995 IBM Wheelprinter 5216 Underline Off.

2996 IBM Wheelprinter 5216 Underline On.
2997 IDS 460 10 CPI.
2998 IDS 460 12 CPI.
2999 IDS 460 6 lines per inch.
3000 IDS 460 8 lines per inch.
3001 IDS 460 Reset
3002 IDS 460 Setup
3003 IDS Prism 80/132 10 CPI.
3004 IDS Prism 80/132 12 CPI.
3005 IDS Prism 80/132 6 lines per inch.
3006 IDS Prism 80/132 8 lines per inch.
3007 IDS Prism 80/132 Reset
3008 IDS Prism 80/132 Setup
3009 IQ Laser Super 1 10 CPI
3010 IQ Laser Super 1 12 CPI
3011 IQ Laser Super 1 12 Lines/Inch
3012 IQ Laser Super 1 15-17 CPI
3013 IQ Laser Super 1 6 Lines/Inch
3014 IQ Laser Super 1 8 Lines/Inch
3015 IQ Laser Super 1 Alt. Var Ln Sp
3016 IQ Laser Super 1 Bold OFF
3017 IQ Laser Super 1 Bold ON
3018 IQ Laser Super 1 Condense Off
3019 IQ Laser Super 1 DblStrike OFF
3020 IQ Laser Super 1 DblStrike ON
3021 IQ Laser Super 1 DdlWIDE ON
3022 IQ Laser Super 1 Emphasize OFF
3023 IQ Laser Super 1 Emphasize ON
3024 IQ Laser Super 1 Initialize
3025 IQ Laser Super 1 Int Chr Spac'g
3026 IQ Laser Super 1 Italic OFF
3027 IQ Laser Super 1 Italic ON
3028 IQ Laser Super 1 Landscape
3029 IQ Laser Super 1 Mastr Font/Typ
3030 IQ Laser Super 1 Move ABS Horiz
3031 IQ Laser Super 1 Move ABS Vert.
3032 IQ Laser Super 1 Move REL Horiz
3033 IQ Laser Super 1 Move REL Vert.
3034 IQ Laser Super 1 Pop Cursor
3035 IQ Laser Super 1 Portrait
3036 IQ Laser Super 1 Propor'nl Off
3037 IQ Laser Super 1 Propor'nl On
3038 IQ Laser Super 1 Push Cursor
3039 IQ Laser Super 1 Sel. Prt Style
3040 IQ Laser Super 1 Select Char St
3041 IQ Laser Super 1 Set LFT Margin
3042 IQ Laser Super 1 Set RHT Margin
3043 IQ Laser Super 1 Set TOP Margin
3044 IQ Laser Super 1 Skip Perf OFF

3045 IQ Laser Super 1 Skip Perf ON
3046 IQ Laser Super 1 SUBScript OFF
3047 IQ Laser Super 1 SUBScript ON
3048 IQ Laser Super 1 SUP-Scr OFF
3049 IQ Laser Super 1 SUPERscript ON
3050 IQ Laser Super 1 Underline OFF
3051 IQ Laser Super 1 Underline ON
3052 IQ Laser Super 1 Var. Ln Space
3053 ITT 9312 10 CPI
3054 ITT 9312 12 CPI
3055 ITT 9312 12 Lines/Inch
3056 ITT 9312 15-17 CPI
3057 ITT 9312 6 Lines/Inch
3058 ITT 9312 8 Lines/Inch
3059 ITT 9312 Alt. Var Ln Sp
3060 ITT 9312 Bldirect'l ON
3061 ITT 9312 Bold OFF
3062 ITT 9312 Bold ON
3063 ITT 9312 Condense Off
3064 ITT 9312 DblStrike OFF
3065 ITT 9312 DblStrike ON
3066 ITT 9312 DblWIDE OFF
3067 ITT 9312 DdlWIDE ON
3068 ITT 9312 Draft Mode
3069 ITT 9312 Emphasize OFF
3070 ITT 9312 Emphasize ON
3071 ITT 9312 Initialize
3072 ITT 9312 Italic OFF
3073 ITT 9312 Italic ON
3074 ITT 9312 Mastr Font/Typ
3075 ITT 9312 NLQ Mode
3076 ITT 9312 Propor'n'l Off
3077 ITT 9312 Propor'n'l On
3078 ITT 9312 Select Char St
3079 ITT 9312 Set LFT Margin
3080 ITT 9312 Set RHT Margin
3081 ITT 9312 Set Tab Stops
3082 ITT 9312 Skip Perf OFF
3083 ITT 9312 Skip Perf ON
3084 ITT 9312 SUBScript OFF
3085 ITT 9312 SUBScript ON
3086 ITT 9312 SUP-Scr OFF
3087 ITT 9312 SUPERscript ON
3088 ITT 9312 Underline OFF
3089 ITT 9312 Underline ON
3090 ITT 9312 UNldirect'l ON
3091 ITT 9312 Var. Ln Space
3092 JDL/Juki 850 EW 10 CPI
3093 JDL/Juki 850 EW 12 CPI

3094 JDL/Juki 850 EW 12 Lines/Inch
3095 JDL/Juki 850 EW 15-17 CPI
3096 JDL/Juki 850 EW 6 Lines/Inch
3097 JDL/Juki 850 EW 8 Lines/Inch
3098 JDL/Juki 850 EW Alt. Var Ln Sp
3099 JDL/Juki 850 EW Bldirect'l ON
3100 JDL/Juki 850 EW Bold OFF
3101 JDL/Juki 850 EW Bold ON
3102 JDL/Juki 850 EW Condense Off
3103 JDL/Juki 850 EW DbStrike OFF
3104 JDL/Juki 850 EW DbStrike ON
3105 JDL/Juki 850 EW DbWIDE OFF
3106 JDL/Juki 850 EW DdlWIDE ON
3107 JDL/Juki 850 EW Draft Mode
3108 JDL/Juki 850 EW Emphasize OFF
3109 JDL/Juki 850 EW Emphasize ON
3110 JDL/Juki 850 EW Initialize
3111 JDL/Juki 850 EW Italic OFF
3112 JDL/Juki 850 EW Italic ON
3113 JDL/Juki 850 EW Mastr Font/Typ
3114 JDL/Juki 850 EW NLQ Mode
3115 JDL/Juki 850 EW Propor'nl Off
3116 JDL/Juki 850 EW Propor'nl On
3117 JDL/Juki 850 EW Sel. Prt Style
3118 JDL/Juki 850 EW Select Char St
3119 JDL/Juki 850 EW Set LFT Margin
3120 JDL/Juki 850 EW Set RHT Margin
3121 JDL/Juki 850 EW Set Tab Stops
3122 JDL/Juki 850 EW Skip Perf OFF
3123 JDL/Juki 850 EW Skip Perf ON
3124 JDL/Juki 850 EW SUBScript OFF
3125 JDL/Juki 850 EW SUBScript ON
3126 JDL/Juki 850 EW SUP-Scr OFF
3127 JDL/Juki 850 EW SUPERscript ON
3128 JDL/Juki 850 EW Underline OFF
3129 JDL/Juki 850 EW Underline ON
3130 JDL/Juki 850 EW UNIdirect'l ON
3131 JDL/Juki 850 EW Var. Ln Space
3132 Juki 6100 10 CPI.
3133 Juki 6100 6 lines per inch.
3134 Juki 6100 8 lines per inch.
3135 Juki 6100 Double Stike Off.
3136 Juki 6100 Double Stike On.
3137 Juki 6100 Reset
3138 Juki 6100 Setup
3139 Juki 6100 Underline Off.
3140 Juki 6100 Underline On.
3141 Kyocera F-1010 (Land) 10 CPI.
3142 Kyocera F-1010 (Land) 12 CPI.

Sheet1

3143 Kyocera F-1010 (Land) 6 lines per inch.
3144 Kyocera F-1010 (Land) 8 lines per inch.
3145 Kyocera F-1010 (Land) Double Strike Off.
3146 Kyocera F-1010 (Land) Double Strike On.
3147 Kyocera F-1010 (Land) Italics Off.
3148 Kyocera F-1010 (Land) Italics On.
3149 Kyocera F-1010 (Land) Underline Off.
3150 Kyocera F-1010 (Land) Underline On.
3151 Kyocera F-1010 (Port) 10 CPI.
3152 Kyocera F-1010 (Port) 12 CPI.
3153 Kyocera F-1010 (Port) 6 lines per inch.
3154 Kyocera F-1010 (Port) 8 lines per inch.
3155 Kyocera F-1010 (Port) Double Strike Off.
3156 Kyocera F-1010 (Port) Double Strike On.
3157 Kyocera F-1010 (Port) Italics Off.
3158 Kyocera F-1010 (Port) Italics On.
3159 Kyocera F-1010 (Port) Underline Off.
3160 Kyocera F-1010 (Port) Underline On.
3161 Leading Edge A10/20/30 10 CPI
3162 Leading Edge A10/20/30 12 CPI
3163 Leading Edge A10/20/30 12 Lines/Inch
3164 Leading Edge A10/20/30 15-17 CPI
3165 Leading Edge A10/20/30 6 Lines/Inch
3166 Leading Edge A10/20/30 8 Lines/Inch
3167 Leading Edge A10/20/30 Bold OFF
3168 Leading Edge A10/20/30 Bold ON
3169 Leading Edge A10/20/30 Condense Off
3170 Leading Edge A10/20/30 DbStrike OFF
3171 Leading Edge A10/20/30 DbStrike ON
3172 Leading Edge A10/20/30 DbWIDE OFF
3173 Leading Edge A10/20/30 DdWIDE ON
3174 Leading Edge A10/20/30 Draft Mode
3175 Leading Edge A10/20/30 Emphasize OFF
3176 Leading Edge A10/20/30 Emphasize ON
3177 Leading Edge A10/20/30 Initialize
3178 Leading Edge A10/20/30 Move ABS Horiz
3179 Leading Edge A10/20/30 Move ABS Vert.
3180 Leading Edge A10/20/30 NLQ Mode
3181 Leading Edge A10/20/30 Propor'nl Off
3182 Leading Edge A10/20/30 Propor'nl On
3183 Leading Edge A10/20/30 Set BOT Margin
3184 Leading Edge A10/20/30 Set LFT Margin
3185 Leading Edge A10/20/30 Set RHT Margin
3186 Leading Edge A10/20/30 Set Tab Stops
3187 Leading Edge A10/20/30 Set TOP Margin
3188 Leading Edge A10/20/30 SUBScript OFF
3189 Leading Edge A10/20/30 SUBScript ON
3190 Leading Edge A10/20/30 SUP-Scr OFF
3191 Leading Edge A10/20/30 SUPERscript ON

Sheet1

3192 Leading Edge A10/20/30 Underline OFF
3193 Leading Edge A10/20/30 Underline ON
3194 Legend 808/1080/1200 10 CPI
3195 Legend 808/1080/1200 12 CPI
3196 Legend 808/1080/1200 12 Lines/Inch
3197 Legend 808/1080/1200 15-17 CPI
3198 Legend 808/1080/1200 6 Lines/Inch
3199 Legend 808/1080/1200 8 Lines/Inch
3200 Legend 808/1080/1200 Alt. Var Ln Sp
3201 Legend 808/1080/1200 Bldirect'l ON
3202 Legend 808/1080/1200 Bold OFF
3203 Legend 808/1080/1200 Bold ON
3204 Legend 808/1080/1200 Condense Off
3205 Legend 808/1080/1200 DbStrike OFF
3206 Legend 808/1080/1200 DbStrike ON
3207 Legend 808/1080/1200 DbIWIDE OFF
3208 Legend 808/1080/1200 DdIWIDE ON
3209 Legend 808/1080/1200 Draft Mode
3210 Legend 808/1080/1200 Emphasize OFF
3211 Legend 808/1080/1200 Emphasize ON
3212 Legend 808/1080/1200 Initialize
3213 Legend 808/1080/1200 Int Chr Spac'g
3214 Legend 808/1080/1200 Italic OFF
3215 Legend 808/1080/1200 Italic ON
3216 Legend 808/1080/1200 Mastr Font/Typ
3217 Legend 808/1080/1200 NLQ Mode
3218 Legend 808/1080/1200 Propor'nl Off
3219 Legend 808/1080/1200 Propor'nl On
3220 Legend 808/1080/1200 Sel. Prt Style
3221 Legend 808/1080/1200 Select Char St
3222 Legend 808/1080/1200 Set LFT Margin
3223 Legend 808/1080/1200 Set RHT Margin
3224 Legend 808/1080/1200 Set Tab Stops
3225 Legend 808/1080/1200 Skip Perf OFF
3226 Legend 808/1080/1200 Skip Perf ON
3227 Legend 808/1080/1200 SUBScript OFF
3228 Legend 808/1080/1200 SUBScript ON
3229 Legend 808/1080/1200 SUP-Scr OFF
3230 Legend 808/1080/1200 SUPERscript ON
3231 Legend 808/1080/1200 Underline OFF
3232 Legend 808/1080/1200 Underline ON
3233 Legend 808/1080/1200 UNldirect'l ON
3234 Legend 808/1080/1200 Var. Ln Space
3235 Litton Westrex 10 CPI
3236 Litton Westrex 12 CPI
3237 Litton Westrex 12 Lines/Inch
3238 Litton Westrex 15-17 CPI
3239 Litton Westrex 6 Lines/Inch
3240 Litton Westrex 8 Lines/Inch

3241 Litton Westrex Alt. Var Ln Sp
3242 Litton Westrex Bldirect'l ON
3243 Litton Westrex Bold OFF
3244 Litton Westrex Bold ON
3245 Litton Westrex Condense Off
3246 Litton Westrex DblStrike OFF
3247 Litton Westrex DblStrike ON
3248 Litton Westrex DblWIDE OFF
3249 Litton Westrex DdlWIDE ON
3250 Litton Westrex Draft Mode
3251 Litton Westrex Emphasize OFF
3252 Litton Westrex Emphasize ON
3253 Litton Westrex Initialize
3254 Litton Westrex Int Chr Spac'g
3255 Litton Westrex Italic OFF
3256 Litton Westrex Italic ON
3257 Litton Westrex Mastr Font/Typ
3258 Litton Westrex NLQ Mode
3259 Litton Westrex Propor'n'l Off
3260 Litton Westrex Propor'n'l On
3261 Litton Westrex Sel. Prt Style
3262 Litton Westrex Select Char St
3263 Litton Westrex Set LFT Margin
3264 Litton Westrex Set RHT Margin
3265 Litton Westrex Set Tab Stops
3266 Litton Westrex Skip Perf OFF
3267 Litton Westrex Skip Perf ON
3268 Litton Westrex SUBScript OFF
3269 Litton Westrex SUBScript ON
3270 Litton Westrex SUP-Scr OFF
3271 Litton Westrex SUPERscript ON
3272 Litton Westrex Underline OFF
3273 Litton Westrex Underline ON
3274 Litton Westrex UNldirect'l ON
3275 Litton Westrex Var. Ln Space
3276 Logitech FT-F002 10 CPI
3277 Logitech FT-F002 12 CPI
3278 Logitech FT-F002 12 Lines/Inch
3279 Logitech FT-F002 15-17 CPI
3280 Logitech FT-F002 6 Lines/Inch
3281 Logitech FT-F002 8 Lines/Inch
3282 Logitech FT-F002 Alt. Var Ln Sp
3283 Logitech FT-F002 Bldirect'l ON
3284 Logitech FT-F002 Bold OFF
3285 Logitech FT-F002 Bold ON
3286 Logitech FT-F002 Condense Off
3287 Logitech FT-F002 DblStrike OFF
3288 Logitech FT-F002 DblStrike ON
3289 Logitech FT-F002 DblWIDE OFF

3290 Logitech FT-F002 DdlWIDE ON
3291 Logitech FT-F002 Draft Mode
3292 Logitech FT-F002 Emphasize OFF
3293 Logitech FT-F002 Emphasize ON
3294 Logitech FT-F002 Initialize
3295 Logitech FT-F002 Int Chr Spac'g
3296 Logitech FT-F002 Italic OFF
3297 Logitech FT-F002 Italic ON
3298 Logitech FT-F002 Mastr Font/Typ
3299 Logitech FT-F002 NLQ Mode
3300 Logitech FT-F002 Propor'nl Off
3301 Logitech FT-F002 Propor'nl On
3302 Logitech FT-F002 Sel. Prt Style
3303 Logitech FT-F002 Select Char St
3304 Logitech FT-F002 Set LFT Margin
3305 Logitech FT-F002 Set RHT Margin
3306 Logitech FT-F002 Set Tab Stops
3307 Logitech FT-F002 Skip Perf OFF
3308 Logitech FT-F002 Skip Perf ON
3309 Logitech FT-F002 SUBScript OFF
3310 Logitech FT-F002 SUBScript ON
3311 Logitech FT-F002 SUP-Scr OFF
3312 Logitech FT-F002 SUPERscript ON
3313 Logitech FT-F002 Underline OFF
3314 Logitech FT-F002 Underline ON
3315 Logitech FT-F002 UNIdirect'I ON
3316 Logitech FT-F002 Var. Ln Space
3317 Manesmann 91 10 CPI
3318 Manesmann 91 12 CPI
3319 Manesmann 91 12 Lines/Inch
3320 Manesmann 91 15-17 CPI
3321 Manesmann 91 6 Lines/Inch
3322 Manesmann 91 8 Lines/Inch
3323 Manesmann 91 Alt. Var Ln Sp
3324 Manesmann 91 Bold OFF
3325 Manesmann 91 Bold ON
3326 Manesmann 91 Condense Off
3327 Manesmann 91 DbIStrike OFF
3328 Manesmann 91 DbIStrike ON
3329 Manesmann 91 DdlWIDE ON
3330 Manesmann 91 Emphasize OFF
3331 Manesmann 91 Emphasize ON
3332 Manesmann 91 Initialize
3333 Manesmann 91 Int Chr Spac'g
3334 Manesmann 91 Italic OFF
3335 Manesmann 91 Italic ON
3336 Manesmann 91 Mastr Font/Typ
3337 Manesmann 91 Move ABS Horiz
3338 Manesmann 91 Move ABS Vert.

3339 Manesmann 91 Move REL Horiz
3340 Manesmann 91 Move REL Vert.
3341 Manesmann 91 Pop Cursor
3342 Manesmann 91 Propor'n'l Off
3343 Manesmann 91 Propor'n'l On
3344 Manesmann 91 Push Cursor
3345 Manesmann 91 Sel. Prt Style
3346 Manesmann 91 Select Char St
3347 Manesmann 91 Set LFT Margin
3348 Manesmann 91 Set RHT Margin
3349 Manesmann 91 Set TOP Margin
3350 Manesmann 91 Skip Perf OFF
3351 Manesmann 91 Skip Perf ON
3352 Manesmann 91 SUBScript OFF
3353 Manesmann 91 SUBScript ON
3354 Manesmann 91 SUP-Scr OFF
3355 Manesmann 91 SUPERscript ON
3356 Manesmann 91 Underline OFF
3357 Manesmann 91 Underline ON
3358 Manesmann 91 Var. Ln Space
3359 Mannesmann MT160/180 10 CPI.
3360 Mannesmann MT160/180 12 CPI.
3361 Mannesmann MT160/180 6 lines per inch.
3362 Mannesmann MT160/180 8 lines per inch.
3363 Mannesmann MT160/180 Double Stike Off.
3364 Mannesmann MT160/180 Double Stike On.
3365 Mannesmann MT160/180 Reset
3366 Mannesmann MT160/180 Setup
3367 Mannesmann MT160/180 Underline Off.
3368 Mannesmann MT160/180 Underline On.
3369 Mannesmann Spirit-80 10 CPI.
3370 Mannesmann Spirit-80 6 lines per inch.
3371 Mannesmann Spirit-80 8 lines per inch.
3372 Mannesmann Spirit-80 Double Stike Off.
3373 Mannesmann Spirit-80 Double Stike On.
3374 Mannesmann Spirit-80 Italics Off.
3375 Mannesmann Spirit-80 Italics On.
3376 Mannesmann Spirit-80 Reset
3377 Mannesmann Spirit-80 Setup
3378 Mannesmann Spirit-80 Underline Off.
3379 Mannesmann Spirit-80 Underline On.
3380 Morrow MP-100/MP-200 Emphasize OFF
3381 Morrow MP-100/MP-200 SUBScript ON
3382 Morrow MP-100/MP-200 10 CPI
3383 Morrow MP-100/MP-200 12 CPI
3384 Morrow MP-100/MP-200 12 Lines/Inch
3385 Morrow MP-100/MP-200 15-17 CPI
3386 Morrow MP-100/MP-200 6 Lines/Inch
3387 Morrow MP-100/MP-200 8 Lines/Inch

3388 Morrow MP-100/MP-200 Bold OFF
3389 Morrow MP-100/MP-200 Bold ON
3390 Morrow MP-100/MP-200 Condense Off
3391 Morrow MP-100/MP-200 DblStrike OFF
3392 Morrow MP-100/MP-200 DblStrike ON
3393 Morrow MP-100/MP-200 DdlWIDE OFF
3394 Morrow MP-100/MP-200 DdlWIDE ON
3395 Morrow MP-100/MP-200 Draft Mode
3396 Morrow MP-100/MP-200 Emphasize ON
3397 Morrow MP-100/MP-200 Initialize
3398 Morrow MP-100/MP-200 Move ABS Horiz
3399 Morrow MP-100/MP-200 Move ABS Vert.
3400 Morrow MP-100/MP-200 NLQ Mode
3401 Morrow MP-100/MP-200 Propor'nl Off
3402 Morrow MP-100/MP-200 Propor'nl On
3403 Morrow MP-100/MP-200 Set BOT Margin
3404 Morrow MP-100/MP-200 Set LFT Margin
3405 Morrow MP-100/MP-200 Set RHT Margin
3406 Morrow MP-100/MP-200 Set Tab Stops
3407 Morrow MP-100/MP-200 Set TOP Margin
3408 Morrow MP-100/MP-200 SUBScript OFF
3409 Morrow MP-100/MP-200 SUP-Scr OFF
3410 Morrow MP-100/MP-200 SUPERscript ON
3411 Morrow MP-100/MP-200 Underline OFF
3412 Morrow MP-100/MP-200 Underline ON
3413 NEC 3515-25, 8815 10 CPI
3414 NEC 3515-25, 8815 12 CPI
3415 NEC 3515-25, 8815 12 Lines/Inch
3416 NEC 3515-25, 8815 15-17 CPI
3417 NEC 3515-25, 8815 6 Lines/Inch
3418 NEC 3515-25, 8815 8 Lines/Inch
3419 NEC 3515-25, 8815 Bold OFF
3420 NEC 3515-25, 8815 Bold ON
3421 NEC 3515-25, 8815 Condense Off
3422 NEC 3515-25, 8815 DblStrike OFF
3423 NEC 3515-25, 8815 DblStrike ON
3424 NEC 3515-25, 8815 DblWIDE OFF
3425 NEC 3515-25, 8815 DdlWIDE ON
3426 NEC 3515-25, 8815 Draft Mode
3427 NEC 3515-25, 8815 Emphasize OFF
3428 NEC 3515-25, 8815 Emphasize ON
3429 NEC 3515-25, 8815 Initialize
3430 NEC 3515-25, 8815 Move ABS Horiz
3431 NEC 3515-25, 8815 Move ABS Vert.
3432 NEC 3515-25, 8815 NLQ Mode
3433 NEC 3515-25, 8815 Propor'nl Off
3434 NEC 3515-25, 8815 Propor'nl On
3435 NEC 3515-25, 8815 Set BOT Margin
3436 NEC 3515-25, 8815 Set LFT Margin

3437 NEC 3515-25, 8815 Set RHT Margin
3438 NEC 3515-25, 8815 Set Tab Stops
3439 NEC 3515-25, 8815 Set TOP Margin
3440 NEC 3515-25, 8815 SUBScript OFF
3441 NEC 3515-25, 8815 SUBScript ON
3442 NEC 3515-25, 8815 SUP-Scr OFF
3443 NEC 3515-25, 8815 SUPERscript ON
3444 NEC 3515-25, 8815 Underline OFF
3445 NEC 3515-25, 8815 Underline ON
3446 NEC 8835 10 CPI
3447 NEC 8835 10 CPI
3448 NEC 8835 10 CPI
3449 NEC 8835 12 CPI
3450 NEC 8835 12 CPI
3451 NEC 8835 12 CPI
3452 NEC 8835 12 Lines/Inch
3453 NEC 8835 12 Lines/Inch
3454 NEC 8835 12 Lines/Inch
3455 NEC 8835 15-17 CPI
3456 NEC 8835 15-17 CPI
3457 NEC 8835 15-17 CPI
3458 NEC 8835 6 Lines/Inch
3459 NEC 8835 6 Lines/Inch
3460 NEC 8835 6 Lines/Inch
3461 NEC 8835 8 Lines/Inch
3462 NEC 8835 8 Lines/Inch
3463 NEC 8835 8 Lines/Inch
3464 NEC 8835 Bold OFF
3465 NEC 8835 Bold OFF
3466 NEC 8835 Bold OFF
3467 NEC 8835 Bold ON
3468 NEC 8835 Bold ON
3469 NEC 8835 Bold ON
3470 NEC 8835 Condense Off
3471 NEC 8835 Condense Off
3472 NEC 8835 Condense Off
3473 NEC 8835 DblStrike OFF
3474 NEC 8835 DblStrike OFF
3475 NEC 8835 DblStrike OFF
3476 NEC 8835 DblStrike ON
3477 NEC 8835 DblStrike ON
3478 NEC 8835 DblStrike ON
3479 NEC 8835 DblWIDE OFF
3480 NEC 8835 DblWIDE OFF
3481 NEC 8835 DdlWIDE OFF
3482 NEC 8835 DdlWIDE ON
3483 NEC 8835 DdlWIDE ON
3484 NEC 8835 DdlWIDE ON
3485 NEC 8835 Draft Mode

3486 NEC 8835 Draft Mode
3487 NEC 8835 Draft Mode
3488 NEC 8835 Emphasize OFF
3489 NEC 8835 Emphasize OFF
3490 NEC 8835 Emphasize OFF
3491 NEC 8835 Emphasize ON
3492 NEC 8835 Emphasize ON
3493 NEC 8835 Emphasize ON
3494 NEC 8835 Initialize
3495 NEC 8835 Initialize
3496 NEC 8835 Initialize
3497 NEC 8835 Move ABS Horiz
3498 NEC 8835 Move ABS Horiz
3499 NEC 8835 Move ABS Horiz
3500 NEC 8835 Move ABS Vert.
3501 NEC 8835 Move ABS Vert.
3502 NEC 8835 Move ABS Vert.
3503 NEC 8835 NLQ Mode
3504 NEC 8835 NLQ Mode
3505 NEC 8835 NLQ Mode
3506 NEC 8835 Propor'nl Off
3507 NEC 8835 Propor'nl Off
3508 NEC 8835 Propor'nl Off
3509 NEC 8835 Propor'nl On
3510 NEC 8835 Propor'nl On
3511 NEC 8835 Propor'nl On
3512 NEC 8835 Set BOT Margin
3513 NEC 8835 Set BOT Margin
3514 NEC 8835 Set BOT Margin
3515 NEC 8835 Set LFT Margin
3516 NEC 8835 Set LFT Margin
3517 NEC 8835 Set LFT Margin
3518 NEC 8835 Set RHT Margin
3519 NEC 8835 Set RHT Margin
3520 NEC 8835 Set RHT Margin
3521 NEC 8835 Set Tab Stops
3522 NEC 8835 Set Tab Stops
3523 NEC 8835 Set Tab Stops
3524 NEC 8835 Set TOP Margin
3525 NEC 8835 Set TOP Margin
3526 NEC 8835 Set TOP Margin
3527 NEC 8835 SUBScript OFF
3528 NEC 8835 SUBScript OFF
3529 NEC 8835 SUBScript OFF
3530 NEC 8835 SUBScript ON
3531 NEC 8835 SUBScript ON
3532 NEC 8835 SUBScript ON
3533 NEC 8835 SUP-Scr OFF
3534 NEC 8835 SUP-Scr OFF

3535 NEC 8835 SUP-Scr OFF
3536 NEC 8835 SUPERscript ON
3537 NEC 8835 SUPERscript ON
3538 NEC 8835 SUPERscript ON
3539 NEC 8835 Underline OFF
3540 NEC 8835 Underline OFF
3541 NEC 8835 Underline OFF
3542 NEC 8835 Underline ON
3543 NEC 8835 Underline ON
3544 NEC 8835 Underline ON
3545 NEC Laser LC-85-/LC-86 10 CPI
3546 NEC Laser LC-85-/LC-86 12 CPI
3547 NEC Laser LC-85-/LC-86 12 Lines/Inch
3548 NEC Laser LC-85-/LC-86 15-17 CPI
3549 NEC Laser LC-85-/LC-86 6 Lines/Inch
3550 NEC Laser LC-85-/LC-86 8 Lines/Inch
3551 NEC Laser LC-85-/LC-86 Alt. Var Ln Sp
3552 NEC Laser LC-85-/LC-86 Bold OFF
3553 NEC Laser LC-85-/LC-86 Bold ON
3554 NEC Laser LC-85-/LC-86 Condense Off
3555 NEC Laser LC-85-/LC-86 DblStrike OFF
3556 NEC Laser LC-85-/LC-86 DblStrike ON
3557 NEC Laser LC-85-/LC-86 DdlWIDE ON
3558 NEC Laser LC-85-/LC-86 Emphasize OFF
3559 NEC Laser LC-85-/LC-86 Emphasize ON
3560 NEC Laser LC-85-/LC-86 Initialize
3561 NEC Laser LC-85-/LC-86 Int Chr Spac'g
3562 NEC Laser LC-85-/LC-86 Italic OFF
3563 NEC Laser LC-85-/LC-86 Italic ON
3564 NEC Laser LC-85-/LC-86 Mastr Font/Typ
3565 NEC Laser LC-85-/LC-86 Move ABS Horiz
3566 NEC Laser LC-85-/LC-86 Move ABS Vert.
3567 NEC Laser LC-85-/LC-86 Move REL Horiz
3568 NEC Laser LC-85-/LC-86 Move REL Vert.
3569 NEC Laser LC-85-/LC-86 Pop Cursor
3570 NEC Laser LC-85-/LC-86 Propor'nl Off
3571 NEC Laser LC-85-/LC-86 Propor'nl On
3572 NEC Laser LC-85-/LC-86 Push Cursor
3573 NEC Laser LC-85-/LC-86 Sel. Prt Style
3574 NEC Laser LC-85-/LC-86 Select Char St
3575 NEC Laser LC-85-/LC-86 Set LFT Margin
3576 NEC Laser LC-85-/LC-86 Set RHT Margin
3577 NEC Laser LC-85-/LC-86 Set TOP Margin
3578 NEC Laser LC-85-/LC-86 Skip Perf OFF
3579 NEC Laser LC-85-/LC-86 Skip Perf ON
3580 NEC Laser LC-85-/LC-86 SUBScript OFF
3581 NEC Laser LC-85-/LC-86 SUBScript ON
3582 NEC Laser LC-85-/LC-86 SUP-Scr OFF
3583 NEC Laser LC-85-/LC-86 SUPERscript ON

Sheet1

3584 NEC Laser LC-85-/LC-86 Underline OFF
3585 NEC Laser LC-85-/LC-86 Underline ON
3586 NEC Laser LC-85-/LC-86 Var. Ln Space
3587 NEC Laser LC-89 10 CPI
3588 NEC Laser LC-89 12 CPI
3589 NEC Laser LC-89 12 Lines/Inch
3590 NEC Laser LC-89 15-17 CPI
3591 NEC Laser LC-89 6 Lines/Inch
3592 NEC Laser LC-89 8 Lines/Inch
3593 NEC Laser LC-89 Alt. Var Ln Sp
3594 NEC Laser LC-89 Bold OFF
3595 NEC Laser LC-89 Bold ON
3596 NEC Laser LC-89 Condense Off
3597 NEC Laser LC-89 DbIStrike OFF
3598 NEC Laser LC-89 DbIStrike ON
3599 NEC Laser LC-89 DdIWIDE ON
3600 NEC Laser LC-89 Emphasize OFF
3601 NEC Laser LC-89 Emphasize ON
3602 NEC Laser LC-89 Initialize
3603 NEC Laser LC-89 Int Chr Spac'g
3604 NEC Laser LC-89 Italic OFF
3605 NEC Laser LC-89 Italic ON
3606 NEC Laser LC-89 Mastr Font/Typ
3607 NEC Laser LC-89 Move ABS Horiz
3608 NEC Laser LC-89 Move ABS Vert.
3609 NEC Laser LC-89 Move REL Horiz
3610 NEC Laser LC-89 Move REL Vert.
3611 NEC Laser LC-89 Pop Cursor
3612 NEC Laser LC-89 Propor'nI Off
3613 NEC Laser LC-89 Propor'nI On
3614 NEC Laser LC-89 Push Cursor
3615 NEC Laser LC-89 Sel. Prt Style
3616 NEC Laser LC-89 Select Char St
3617 NEC Laser LC-89 Set LFT Margin
3618 NEC Laser LC-89 Set RHT Margin
3619 NEC Laser LC-89 Set TOP Margin
3620 NEC Laser LC-89 Skip Perf OFF
3621 NEC Laser LC-89 Skip Perf ON
3622 NEC Laser LC-89 SUBScript OFF
3623 NEC Laser LC-89 SUBScript ON
3624 NEC Laser LC-89 SUP-Scr OFF
3625 NEC Laser LC-89 SUPERscript ON
3626 NEC Laser LC-89 Underline OFF
3627 NEC Laser LC-89 Underline ON
3628 NEC Laser LC-89 Var. Ln Space
3629 NEC Pinwriter P2/P3 10 CPI.
3630 NEC Pinwriter P2/P3 12 CPI.
3631 NEC Pinwriter P2/P3 6 lines per inch.
3632 NEC Pinwriter P2/P3 8 lines per inch.

3633 NEC Pinwriter P2/P3 Double Stike Off.
3634 NEC Pinwriter P2/P3 Double Stike On.
3635 NEC Pinwriter P2/P3 Underline Off.
3636 NEC Pinwriter P2/P3 Underline On.
3637 NEC Pinwriter P2200 10 CPI.
3638 NEC Pinwriter P2200 12 CPI.
3639 NEC Pinwriter P2200 6 lines per inch.
3640 NEC Pinwriter P2200 8 lines per inch.
3641 NEC Pinwriter P2200 Double Stike Off.
3642 NEC Pinwriter P2200 Double Stike On.
3643 NEC Pinwriter P2200 Italics Off.
3644 NEC Pinwriter P2200 Italics On.
3645 NEC Pinwriter P2200 Reset
3646 NEC Pinwriter P2200 Setup
3647 NEC Pinwriter P2200 Underline Off.
3648 NEC Pinwriter P2200 Underline On.
3649 NEC Pinwriter P5/P6/P7 10 CPI.
3650 NEC Pinwriter P5/P6/P7 12 CPI.
3651 NEC Pinwriter P5/P6/P7 6 lines per inch.
3652 NEC Pinwriter P5/P6/P7 8 lines per inch.
3653 NEC Pinwriter P5/P6/P7 Double Stike Off.
3654 NEC Pinwriter P5/P6/P7 Double Stike On.
3655 NEC Pinwriter P5/P6/P7 Italics Off.
3656 NEC Pinwriter P5/P6/P7 Italics On.
3657 NEC Pinwriter P5/P6/P7 Reset
3658 NEC Pinwriter P5/P6/P7 Setup
3659 NEC Pinwriter P5/P6/P7 Underline Off.
3660 NEC Pinwriter P5/P6/P7 Underline On.
3661 NEC Silentwriter LC850 10 CPI.
3662 NEC Silentwriter LC850 12 CPI.
3663 NEC Silentwriter LC850 6 lines per inch.
3664 NEC Silentwriter LC850 8 lines per inch.
3665 NEC Silentwriter LC850 Double Stike Off.
3666 NEC Silentwriter LC850 Double Stike On.
3667 NEC Silentwriter LC850 Reset
3668 NEC Silentwriter LC850 Setup
3669 NEC Silentwriter LC850 Underline Off.
3670 NEC Silentwriter LC850 Underline On.
3671 NEC Silentwriter LC860 10 CPI.
3672 NEC Silentwriter LC860 12 CPI.
3673 NEC Silentwriter LC860 6 lines per inch.
3674 NEC Silentwriter LC860 8 lines per inch.
3675 NEC Silentwriter LC860 Double Stike Off.
3676 NEC Silentwriter LC860 Double Stike On.
3677 NEC Silentwriter LC860 Italics Off.
3678 NEC Silentwriter LC860 Italics On.
3679 NEC Silentwriter LC860 Reset
3680 NEC Silentwriter LC860 Setup
3681 NEC Silentwriter LC860 Underline Off.

3682 NEC Silentwriter LC860 Underline On.
3683 NEC Spinwriter 3550 10 CPI.
3684 NEC Spinwriter 3550 12 CPI.
3685 NEC Spinwriter 3550 6 lines per inch.
3686 NEC Spinwriter 3550 8 lines per inch.
3687 NEC Spinwriter 3550 Double Stike Off.
3688 NEC Spinwriter 3550 Double Stike On.
3689 NEC Spinwriter 3550 Reset
3690 NEC Spinwriter 3550 Setup
3691 NEC Spinwriter 3550 Underline Off.
3692 NEC Spinwriter 3550 Underline On.
3693 NEC Spinwriter 5515/25 10 CPI.
3694 NEC Spinwriter 5515/25 12 CPI.
3695 NEC Spinwriter 5515/25 6 lines per inch.
3696 NEC Spinwriter 5515/25 8 lines per inch.
3697 NEC Spinwriter 7710/20 10 CPI.
3698 NEC Spinwriter 7710/20 12 CPI.
3699 NEC Spinwriter 7710/20 6 lines per inch.
3700 NEC Spinwriter 7710/20 8 lines per inch.
3701 NEC Spinwriter 7710/20 Double Stike Off.
3702 NEC Spinwriter 7710/20 Double Stike On.
3703 NEC Spinwriter 7710/20 Reset
3704 NEC Spinwriter 7710/20 Setup
3705 NEC Spinwriter 7710/20 Underline Off.
3706 NEC Spinwriter 7710/20 Underline On.
3707 NEC Spinwriter 7715/25 10 CPI.
3708 NEC Spinwriter 7715/25 12 CPI.
3709 NEC Spinwriter 7715/25 6 lines per inch.
3710 NEC Spinwriter 7715/25 8 lines per inch.
3711 NEC Spinwriter 7715/25 Double Stike Off.
3712 NEC Spinwriter 7715/25 Double Stike On.
3713 NEC Spinwriter 7715/25 Reset
3714 NEC Spinwriter 7715/25 Setup
3715 NEC Spinwriter 7715/25 Underline Off.
3716 NEC Spinwriter 7715/25 Underline On.
3717 NEC Spinwriter 7730 10 CPI.
3718 NEC Spinwriter 7730 12 CPI.
3719 NEC Spinwriter 7730 6 lines per inch.
3720 NEC Spinwriter 7730 8 lines per inch.
3721 Oki 393/393C 10 CPI
3722 Oki 393/393C 12 CPI
3723 Oki 393/393C 12 Lines/Inch
3724 Oki 393/393C 15-17 CPI
3725 Oki 393/393C 6 Lines/Inch
3726 Oki 393/393C 8 Lines/Inch
3727 Oki 393/393C Alt. Var Ln Sp
3728 Oki 393/393C Bldirect'l ON
3729 Oki 393/393C Bold OFF
3730 Oki 393/393C Bold ON

3731 Oki 393/393C Condense Off
3732 Oki 393/393C DblHeight OFF
3733 Oki 393/393C DblHeight ON
3734 Oki 393/393C DblStrike OFF
3735 Oki 393/393C DblStrike ON
3736 Oki 393/393C DblWIDE OFF
3737 Oki 393/393C DdlWIDE ON
3738 Oki 393/393C Draft Mode
3739 Oki 393/393C Emphasize OFF
3740 Oki 393/393C Emphasize ON
3741 Oki 393/393C Initialize
3742 Oki 393/393C Int Chr Spac'g
3743 Oki 393/393C Italic OFF
3744 Oki 393/393C Italic ON
3745 Oki 393/393C Mastr Font/Typ
3746 Oki 393/393C Move ABS Horiz
3747 Oki 393/393C Move REL Horiz
3748 Oki 393/393C NLQ Mode
3749 Oki 393/393C Propor'nl Off
3750 Oki 393/393C Propor'nl On
3751 Oki 393/393C Sel. Prt Style
3752 Oki 393/393C Select Char St
3753 Oki 393/393C Set LFT Margin
3754 Oki 393/393C Set RHT Margin
3755 Oki 393/393C Set Tab Stops
3756 Oki 393/393C Skip Perf OFF
3757 Oki 393/393C Skip Perf ON
3758 Oki 393/393C SUBScript OFF
3759 Oki 393/393C SUBScript ON
3760 Oki 393/393C SUP-Scr OFF
3761 Oki 393/393C SUPERscript ON
3762 Oki 393/393C Underline OFF
3763 Oki 393/393C Underline ON
3764 Oki 393/393C UNIdirect'l ON
3765 Oki 393/393C Var. Ln Space
3766 Oki Laserline 6 10 CPI.
3767 Oki Laserline 6 12 CPI.
3768 Oki Laserline 6 6 lines per inch.
3769 Oki Laserline 6 8 lines per inch.
3770 Oki Laserline 6 Double Stike Off.
3771 Oki Laserline 6 Double Stike On.
3772 Oki Laserline 6 Italics Off.
3773 Oki Laserline 6 Italics On.
3774 Oki Laserline 6 Reset
3775 Oki Laserline 6 Setup
3776 Oki Laserline 6 Underline Off.
3777 Oki Laserline 6 Underline On.
3778 Oki Microline 182/183 10 CPI.
3779 Oki Microline 182/183 12 CPI.

3780 Oki Microline 182/183 6 lines per inch.
3781 Oki Microline 182/183 8 lines per inch.
3782 Oki Microline 182/183 Double Stike Off.
3783 Oki Microline 182/183 Double Stike On.
3784 Oki Microline 182/183 Underline Off.
3785 Oki Microline 182/183 Underline On.
3786 Oki Microline 192/193 10 CPI.
3787 Oki Microline 192/193 12 CPI.
3788 Oki Microline 192/193 6 lines per inch.
3789 Oki Microline 192/193 8 lines per inch.
3790 Oki Microline 192/193 Double Stike Off.
3791 Oki Microline 192/193 Double Stike On.
3792 Oki Microline 192/193 Italics Off.
3793 Oki Microline 192/193 Italics On.
3794 Oki Microline 192/193 Reset
3795 Oki Microline 192/193 Setup
3796 Oki Microline 192/193 Underline Off.
3797 Oki Microline 192/193 Underline On.
3798 Oki Microline 292/3/4 10 CPI.
3799 Oki Microline 292/3/4 12 CPI.
3800 Oki Microline 292/3/4 6 lines per inch.
3801 Oki Microline 292/3/4 8 lines per inch.
3802 Oki Microline 292/3/4 Double Stike Off.
3803 Oki Microline 292/3/4 Double Stike On.
3804 Oki Microline 292/3/4 Italics Off.
3805 Oki Microline 292/3/4 Italics On.
3806 Oki Microline 292/3/4 Reset
3807 Oki Microline 292/3/4 Setup
3808 Oki Microline 292/3/4 Underline Off.
3809 Oki Microline 292/3/4 Underline On.
3810 Oki Microline 82A/83A 10 CPI.
3811 Oki Microline 82A/83A 6 lines per inch.
3812 Oki Microline 82A/83A 8 lines per inch.
3813 Oki Microline 84/92/93 10 CPI.
3814 Oki Microline 84/92/93 12 CPI.
3815 Oki Microline 84/92/93 6 lines per inch.
3816 Oki Microline 84/92/93 8 lines per inch.
3817 Oki Microline 84/92/93 Double Stike Off.
3818 Oki Microline 84/92/93 Double Stike On.
3819 Oki Microline 84/92/93 Reset
3820 Oki Microline 84/92/93 Setup
3821 Oki Microline 84/92/93 Underline Off.
3822 Oki Microline 84/92/93 Underline On.
3823 Oki Okimate 20 10 CPI.
3824 Oki Okimate 20 12 CPI.
3825 Oki Okimate 20 6 lines per inch.
3826 Oki Okimate 20 8 lines per inch.
3827 Oki Okimate 20 Italics Off.
3828 Oki Okimate 20 Italics On.

3829 Oki Okimate 20 Underline Off.
3830 Oki Okimate 20 Underline On.
3831 Oki Pacemark 2350 10 CPI.
3832 Oki Pacemark 2350 12 CPI.
3833 Oki Pacemark 2350 6 lines per inch.
3834 Oki Pacemark 2350 8 lines per inch.
3835 Oki Pacemark 2350 Underline Off.
3836 Oki Pacemark 2350 Underline On.
3837 Oki Pacemark 2410 10 CPI.
3838 Oki Pacemark 2410 12 CPI.
3839 Oki Pacemark 2410 Reset
3840 Oki Pacemark 2410 Setup
3841 Oki Pacemerk 2410-IBM 10 CPI.
3842 Oki Pacemerk 2410-IBM 12 CPI.
3843 Oki Pacemerk 2410-IBM 6 lines per inch.
3844 Oki Pacemerk 2410-IBM 8 lines per inch.
3845 Oki Pacemerk 2410-IBM Double Stike Off.
3846 Oki Pacemerk 2410-IBM Double Stike On.
3847 Oki Pacemerk 2410-IBM Underline Off.
3848 Oki Pacemerk 2410-IBM Underline On.
3849 Oki Plug&Play 192/193 10 CPI.
3850 Oki Plug&Play 192/193 12 CPI.
3851 Oki Plug&Play 192/193 6 lines per inch.
3852 Oki Plug&Play 192/193 8 lines per inch.
3853 Oki Plug&Play 192/193 Double Stike Off.
3854 Oki Plug&Play 192/193 Double Stike On.
3855 Oki Plug&Play 192/193 Italics Off.
3856 Oki Plug&Play 192/193 Italics On.
3857 Oki Plug&Play 192/193 Reset
3858 Oki Plug&Play 192/193 Setup
3859 Oki Plug&Play 192/193 Underline Off.
3860 Oki Plug&Play 192/193 Underline On.
3861 Oki Plug&Play 82A/83A 10 CPI.
3862 Oki Plug&Play 82A/83A 12 CPI.
3863 Oki Plug&Play 82A/83A 6 lines per inch.
3864 Oki Plug&Play 82A/83A 8 lines per inch.
3865 Oki Plug&Play 84/92/93 10 CPI.
3866 Oki Plug&Play 84/92/93 12 CPI.
3867 Oki Plug&Play 84/92/93 6 lines per inch.
3868 Oki Plug&Play 84/92/93 8 lines per inch.
3869 Oki Plug&Play 84/92/93 Double Stike Off.
3870 Oki Plug&Play 84/92/93 Double Stike On.
3871 Oki Plug&Play 84/92/93 Reset
3872 Oki Plug&Play 84/92/93 Setup
3873 Oki Plug&Play 84/92/93 Underline Off.
3874 Oki Plug&Play 84/92/93 Underline On.
3875 Okidata 192 10.0 cpi
3876 Okidata 192 12.0 cpi
3877 Okidata 192 17.1 cpi

Sheet1

3878 Okidata 192 Bold Off
3879 Okidata 192 Bold On
3880 Okidata 192 Eject Page
3881 Okidata 192 Enhanced Print Off
3882 Okidata 192 Enhanced Print On
3883 Okidata 192 Italics Off
3884 Okidata 192 Italics On
3885 Okidata 92 12 CPI Elite
3886 Okidata 92 12CPIOFF
3887 Okidata 92 17.1 CPI/Condensed (Compressed Print)
3888 Okidata 92 6 lpi
3889 Okidata 92 8 lpi
3890 Okidata 92 Clear Buffer; Reset most features
3891 Okidata 92 COMPOFF
3892 Okidata 92 Correspondence Quality (NLQ)
3893 Okidata 92 Double Width (Expanded) Print
3894 Okidata 92 DOUBLEOFF
3895 Okidata 92 Emphasized Print
3896 Okidata 92 EMPHOFF
3897 Okidata 92 Enhanced (Double Strike) Print
3898 Okidata 92 EXPANDOFF
3899 Okidata 92 Form Feed Character
3900 Okidata 92 NLQOFF
3901 Okilaser 400/800 10 CPI
3902 Okilaser 400/800 12 CPI
3903 Okilaser 400/800 12 Lines/Inch
3904 Okilaser 400/800 15-17 CPI
3905 Okilaser 400/800 6 Lines/Inch
3906 Okilaser 400/800 8 Lines/Inch
3907 Okilaser 400/800 Alt. Var Ln Sp
3908 Okilaser 400/800 Bold OFF
3909 Okilaser 400/800 Bold ON
3910 Okilaser 400/800 Condense Off
3911 Okilaser 400/800 DblStrike OFF
3912 Okilaser 400/800 DblStrike ON
3913 Okilaser 400/800 DdlWIDE ON
3914 Okilaser 400/800 Emphasize OFF
3915 Okilaser 400/800 Emphasize ON
3916 Okilaser 400/800 Initialize
3917 Okilaser 400/800 Int Chr Spac'g
3918 Okilaser 400/800 Italic OFF
3919 Okilaser 400/800 Italic ON
3920 Okilaser 400/800 Landscape
3921 Okilaser 400/800 Mastr Font/Typ
3922 Okilaser 400/800 Move ABS Horiz
3923 Okilaser 400/800 Move ABS Vert.
3924 Okilaser 400/800 Move REL Horiz
3925 Okilaser 400/800 Move REL Vert.
3926 Okilaser 400/800 Pop Cursor

3927 Okilaser 400/800 Portrait
3928 Okilaser 400/800 Propor'nl Off
3929 Okilaser 400/800 Propor'nl On
3930 Okilaser 400/800 Push Cursor
3931 Okilaser 400/800 Sel. Prt Style
3932 Okilaser 400/800 Select Char St
3933 Okilaser 400/800 Set LFT Margin
3934 Okilaser 400/800 Set RHT Margin
3935 Okilaser 400/800 Set TOP Margin
3936 Okilaser 400/800 Skip Perf OFF
3937 Okilaser 400/800 Skip Perf ON
3938 Okilaser 400/800 SUBScript OFF
3939 Okilaser 400/800 SUBScript ON
3940 Okilaser 400/800 SUP-Scr OFF
3941 Okilaser 400/800 SUPERscript ON
3942 Okilaser 400/800 Underline OFF
3943 Okilaser 400/800 Underline ON
3944 Okilaser 400/800 Var. Ln Space
3945 Olivetti DM-600 10 CPI
3946 Olivetti DM-600 12 CPI
3947 Olivetti DM-600 12 Lines/Inch
3948 Olivetti DM-600 15-17 CPI
3949 Olivetti DM-600 6 Lines/Inch
3950 Olivetti DM-600 8 Lines/Inch
3951 Olivetti DM-600 Alt. Var Ln Sp
3952 Olivetti DM-600 Bldirect'I ON
3953 Olivetti DM-600 Bold OFF
3954 Olivetti DM-600 Bold ON
3955 Olivetti DM-600 Condense Off
3956 Olivetti DM-600 DblHeight OFF
3957 Olivetti DM-600 DblHeight ON
3958 Olivetti DM-600 DblStrike OFF
3959 Olivetti DM-600 DblStrike ON
3960 Olivetti DM-600 DblWIDE OFF
3961 Olivetti DM-600 DdlWIDE ON
3962 Olivetti DM-600 Draft Mode
3963 Olivetti DM-600 Emphasize OFF
3964 Olivetti DM-600 Emphasize ON
3965 Olivetti DM-600 Initialize
3966 Olivetti DM-600 Int Chr Spac'g
3967 Olivetti DM-600 Italic OFF
3968 Olivetti DM-600 Italic ON
3969 Olivetti DM-600 Mastr Font/Typ
3970 Olivetti DM-600 Move ABS Horiz
3971 Olivetti DM-600 Move REL Horiz
3972 Olivetti DM-600 NLQ Mode
3973 Olivetti DM-600 Propor'nl Off
3974 Olivetti DM-600 Propor'nl On
3975 Olivetti DM-600 Sel. Prt Style

3976 Olivetti DM-600 Select Char St
3977 Olivetti DM-600 Set LFT Margin
3978 Olivetti DM-600 Set RHT Margin
3979 Olivetti DM-600 Set Tab Stops
3980 Olivetti DM-600 Skip Perf OFF
3981 Olivetti DM-600 Skip Perf ON
3982 Olivetti DM-600 SUBScript OFF
3983 Olivetti DM-600 SUBScript ON
3984 Olivetti DM-600 SUP-Scr OFF
3985 Olivetti DM-600 SUPERscript ON
3986 Olivetti DM-600 Underline OFF
3987 Olivetti DM-600 Underline ON
3988 Olivetti DM-600 UNIdirect'l ON
3989 Olivetti DM-600 Var. Ln Space
3990 Olympia ES-95I 10 CPI
3991 Olympia ES-95I 12 CPI
3992 Olympia ES-95I 12 Lines/Inch
3993 Olympia ES-95I 15-17 CPI
3994 Olympia ES-95I 6 Lines/Inch
3995 Olympia ES-95I 8 Lines/Inch
3996 Olympia ES-95I Bold OFF
3997 Olympia ES-95I Bold ON
3998 Olympia ES-95I Condense Off
3999 Olympia ES-95I DblStrike OFF
4000 Olympia ES-95I DblStrike ON
4001 Olympia ES-95I DdIWIDE OFF
4002 Olympia ES-95I DdIWIDE ON
4003 Olympia ES-95I Draft Mode
4004 Olympia ES-95I Emphasize OFF
4005 Olympia ES-95I Emphasize ON
4006 Olympia ES-95I Initialize
4007 Olympia ES-95I Move ABS Horiz
4008 Olympia ES-95I Move ABS Vert.
4009 Olympia ES-95I NLQ Mode
4010 Olympia ES-95I Propor'nl Off
4011 Olympia ES-95I Propor'nl On
4012 Olympia ES-95I Set BOT Margin
4013 Olympia ES-95I Set LFT Margin
4014 Olympia ES-95I Set RHT Margin
4015 Olympia ES-95I Set Tab Stops
4016 Olympia ES-95I Set TOP Margin
4017 Olympia ES-95I SUBScript OFF
4018 Olympia ES-95I SUBScript ON
4019 Olympia ES-95I SUP-Scr OFF
4020 Olympia ES-95I SUPERscript ON
4021 Olympia ES-95I Underline OFF
4022 Olympia ES-95I Underline ON
4023 Olympia LaserStar 10 CPI
4024 Olympia LaserStar 12 CPI

4025 Olympia LaserStar 12 Lines/Inch
4026 Olympia LaserStar 15-17 CPI
4027 Olympia LaserStar 6 Lines/Inch
4028 Olympia LaserStar 8 Lines/Inch
4029 Olympia LaserStar Bold OFF
4030 Olympia LaserStar Bold OFF
4031 Olympia LaserStar Bold ON
4032 Olympia LaserStar Bold ON
4033 Olympia LaserStar Condense Off
4034 Olympia LaserStar DblStrike OFF
4035 Olympia LaserStar DblStrike ON
4036 Olympia LaserStar DdIWIDE OFF
4037 Olympia LaserStar DdIWIDE ON
4038 Olympia LaserStar Draft Mode
4039 Olympia LaserStar Emphasize OFF
4040 Olympia LaserStar Emphasize OFF
4041 Olympia LaserStar Emphasize ON
4042 Olympia LaserStar Emphasize ON
4043 Olympia LaserStar Initialize
4044 Olympia LaserStar Move ABS Horiz
4045 Olympia LaserStar Move ABS Vert.
4046 Olympia LaserStar NLQ Mode
4047 Olympia LaserStar Propor'nl Off
4048 Olympia LaserStar Propor'nl On
4049 Olympia LaserStar Set BOT Margin
4050 Olympia LaserStar Set LFT Margin
4051 Olympia LaserStar Set RHT Margin
4052 Olympia LaserStar Set Tab Stops
4053 Olympia LaserStar Set TOP Margin
4054 Olympia LaserStar SUBScript OFF
4055 Olympia LaserStar SUBScript OFF
4056 Olympia LaserStar SUBScript ON
4057 Olympia LaserStar SUBScript ON
4058 Olympia LaserStar SUP-Scr OFF
4059 Olympia LaserStar SUP-Scr OFF
4060 Olympia LaserStar SUPERscript ON
4061 Olympia LaserStar SUPERscript ON
4062 Olympia LaserStar Underline OFF
4063 Olympia LaserStar Underline OFF
4064 Olympia LaserStar Underline ON
4065 Olympia LaserStar Underline ON
4066 Olympia Masertype 10 CPI
4067 Olympia Masertype 12 CPI
4068 Olympia Masertype 12 Lines/Inch
4069 Olympia Masertype 15-17 CPI
4070 Olympia Masertype 6 Lines/Inch
4071 Olympia Masertype 8 Lines/Inch
4072 Olympia Masertype Bold OFF
4073 Olympia Masertype Bold ON

4074 Olympia Masertype Condense Off
4075 Olympia Masertype DbIStrike OFF
4076 Olympia Masertype DbIStrike ON
4077 Olympia Masertype DdIWIDE OFF
4078 Olympia Masertype DdIWIDE ON
4079 Olympia Masertype Draft Mode
4080 Olympia Masertype Emphasize OFF
4081 Olympia Masertype Emphasize ON
4082 Olympia Masertype Initialize
4083 Olympia Masertype Move ABS Horiz
4084 Olympia Masertype Move ABS Vert.
4085 Olympia Masertype NLQ Mode
4086 Olympia Masertype Propor'nl Off
4087 Olympia Masertype Propor'nl On
4088 Olympia Masertype Set BOT Margin
4089 Olympia Masertype Set LFT Margin
4090 Olympia Masertype Set RHT Margin
4091 Olympia Masertype Set Tab Stops
4092 Olympia Masertype Set TOP Margin
4093 Olympia Masertype SUBScript OFF
4094 Olympia Masertype SUBScript ON
4095 Olympia Masertype SUP-Scr OFF
4096 Olympia Masertype SUPERscript ON
4097 Olympia Masertype Underline OFF
4098 Olympia Masertype Underline ON
4099 OSM Daisy Wheel 10 CPI
4100 OSM Daisy Wheel 12 CPI
4101 OSM Daisy Wheel 12 Lines/Inch
4102 OSM Daisy Wheel 15-17 CPI
4103 OSM Daisy Wheel 6 Lines/Inch
4104 OSM Daisy Wheel 8 Lines/Inch
4105 OSM Daisy Wheel Bold OFF
4106 OSM Daisy Wheel Bold ON
4107 OSM Daisy Wheel Condense Off
4108 OSM Daisy Wheel DbIStrike OFF
4109 OSM Daisy Wheel DbIStrike ON
4110 OSM Daisy Wheel DdIWIDE OFF
4111 OSM Daisy Wheel DdIWIDE ON
4112 OSM Daisy Wheel Draft Mode
4113 OSM Daisy Wheel Emphasize OFF
4114 OSM Daisy Wheel Emphasize ON
4115 OSM Daisy Wheel Initialize
4116 OSM Daisy Wheel Move ABS Horiz
4117 OSM Daisy Wheel Move ABS Vert.
4118 OSM Daisy Wheel NLQ Mode
4119 OSM Daisy Wheel Propor'nl Off
4120 OSM Daisy Wheel Propor'nl On
4121 OSM Daisy Wheel Set BOT Margin
4122 OSM Daisy Wheel Set LFT Margin

4123 OSM Daisy Wheel Set RHT Margin
4124 OSM Daisy Wheel Set Tab Stops
4125 OSM Daisy Wheel Set TOP Margin
4126 OSM Daisy Wheel SUBScript OFF
4127 OSM Daisy Wheel SUBScript ON
4128 OSM Daisy Wheel SUP-Scr OFF
4129 OSM Daisy Wheel SUPERscript ON
4130 OSM Daisy Wheel Underline OFF
4131 OSM Daisy Wheel Underline ON
4132 Pacific Laser 25 in 1 10 CPI
4133 Pacific Laser 25 in 1 12 CPI
4134 Pacific Laser 25 in 1 12 Lines/Inch
4135 Pacific Laser 25 in 1 15-17 CPI
4136 Pacific Laser 25 in 1 6 Lines/Inch
4137 Pacific Laser 25 in 1 8 Lines/Inch
4138 Pacific Laser 25 in 1 Alt. Var Ln Sp
4139 Pacific Laser 25 in 1 Bold OFF
4140 Pacific Laser 25 in 1 Bold ON
4141 Pacific Laser 25 in 1 Condense Off
4142 Pacific Laser 25 in 1 DbIStrike OFF
4143 Pacific Laser 25 in 1 DbIStrike ON
4144 Pacific Laser 25 in 1 DdIWIDE ON
4145 Pacific Laser 25 in 1 Emphasize OFF
4146 Pacific Laser 25 in 1 Emphasize ON
4147 Pacific Laser 25 in 1 Initialize
4148 Pacific Laser 25 in 1 Int Chr Spac'g
4149 Pacific Laser 25 in 1 Italic OFF
4150 Pacific Laser 25 in 1 Italic ON
4151 Pacific Laser 25 in 1 Mastr Font/Typ
4152 Pacific Laser 25 in 1 Move ABS Horiz
4153 Pacific Laser 25 in 1 Move ABS Vert.
4154 Pacific Laser 25 in 1 Move REL Horiz
4155 Pacific Laser 25 in 1 Move REL Vert.
4156 Pacific Laser 25 in 1 Pop Cursor
4157 Pacific Laser 25 in 1 Propor'nl Off
4158 Pacific Laser 25 in 1 Propor'nl On
4159 Pacific Laser 25 in 1 Push Cursor
4160 Pacific Laser 25 in 1 Sel. Prt Style
4161 Pacific Laser 25 in 1 Select Char St
4162 Pacific Laser 25 in 1 Set LFT Margin
4163 Pacific Laser 25 in 1 Set RHT Margin
4164 Pacific Laser 25 in 1 Set TOP Margin
4165 Pacific Laser 25 in 1 Skip Perf OFF
4166 Pacific Laser 25 in 1 Skip Perf ON
4167 Pacific Laser 25 in 1 SUBScript OFF
4168 Pacific Laser 25 in 1 SUBScript ON
4169 Pacific Laser 25 in 1 SUP-Scr OFF
4170 Pacific Laser 25 in 1 SUPERscript ON
4171 Pacific Laser 25 in 1 Underline OFF

4172 Pacific Laser 25 in 1 Underline ON
4173 Pacific Laser 25 in 1 Var. Ln Space
4174 Panasonic KX-1124/1624 10 CPI.
4175 Panasonic KX-1124/1624 12 CPI.
4176 Panasonic KX-1124/1624 6 lines per inch.
4177 Panasonic KX-1124/1624 8 lines per inch.
4178 Panasonic KX-1124/1624 Double Stike Off.
4179 Panasonic KX-1124/1624 Double Stike On.
4180 Panasonic KX-1124/1624 Italics Off.
4181 Panasonic KX-1124/1624 Italics On.
4182 Panasonic KX-1124/1624 Reset
4183 Panasonic KX-1124/1624 Setup
4184 Panasonic KX-1124/1624 Underline Off.
4185 Panasonic KX-1124/1624 Underline On.
4186 Panasonic KX-P1090 10 CPI.
4187 Panasonic KX-P1090 12 CPI.
4188 Panasonic KX-P1090 6 lines per inch.
4189 Panasonic KX-P1090 8 lines per inch.
4190 Panasonic KX-P1090 Double Stike Off.
4191 Panasonic KX-P1090 Double Stike On.
4192 Panasonic KX-P1090 Italics Off.
4193 Panasonic KX-P1090 Italics On.
4194 Panasonic KX-P1090 Reset
4195 Panasonic KX-P1090 Setup
4196 Panasonic KX-P1090 Underline Off.
4197 Panasonic KX-P1090 Underline On.
4198 Panasonic KX-P1091 10 CPI.
4199 Panasonic KX-P1091 12 CPI.
4200 Panasonic KX-P1091 6 lines per inch.
4201 Panasonic KX-P1091 8 lines per inch.
4202 Panasonic KX-P1091 Double Stike Off.
4203 Panasonic KX-P1091 Double Stike On.
4204 Panasonic KX-P1091 Italics Off.
4205 Panasonic KX-P1091 Italics On.
4206 Panasonic KX-P1091 Reset
4207 Panasonic KX-P1091 Setup
4208 Panasonic KX-P1091 Underline Off.
4209 Panasonic KX-P1091 Underline On.
4210 Panasonic KX-P3151 10 CPI.
4211 Panasonic KX-P3151 12 CPI.
4212 Panasonic KX-P3151 6 lines per inch.
4213 Panasonic KX-P3151 8 lines per inch.
4214 Panasonic KX-P3151 Double Stike Off.
4215 Panasonic KX-P3151 Double Stike On.
4216 Panasonic KX-P3151 Reset
4217 Panasonic KX-P3151 Setup
4218 Panasonic KX-P3151 Underline Off.
4219 Panasonic KX-P3151 Underline On.
4220 Panasonic Laser 4420 10 CPI

4221 Panasonic Laser 4420 12 CPI
4222 Panasonic Laser 4420 12 Lines/Inch
4223 Panasonic Laser 4420 15-17 CPI
4224 Panasonic Laser 4420 6 Lines/Inch
4225 Panasonic Laser 4420 8 Lines/Inch
4226 Panasonic Laser 4420 Alt. Var Ln Sp
4227 Panasonic Laser 4420 Bold OFF
4228 Panasonic Laser 4420 Bold ON
4229 Panasonic Laser 4420 Condense Off
4230 Panasonic Laser 4420 DblStrike OFF
4231 Panasonic Laser 4420 DblStrike ON
4232 Panasonic Laser 4420 DdIWIDE ON
4233 Panasonic Laser 4420 Emphasize OFF
4234 Panasonic Laser 4420 Emphasize ON
4235 Panasonic Laser 4420 Initialize
4236 Panasonic Laser 4420 Int Chr Spac'g
4237 Panasonic Laser 4420 Italic OFF
4238 Panasonic Laser 4420 Italic ON
4239 Panasonic Laser 4420 Mastr Font/Typ
4240 Panasonic Laser 4420 Move ABS Horiz
4241 Panasonic Laser 4420 Move ABS Vert.
4242 Panasonic Laser 4420 Move REL Horiz
4243 Panasonic Laser 4420 Move REL Vert.
4244 Panasonic Laser 4420 Pop Cursor
4245 Panasonic Laser 4420 Propor'n'l Off
4246 Panasonic Laser 4420 Propor'n'l On
4247 Panasonic Laser 4420 Push Cursor
4248 Panasonic Laser 4420 Sel. Prt Style
4249 Panasonic Laser 4420 Select Char St
4250 Panasonic Laser 4420 Set LFT Margin
4251 Panasonic Laser 4420 Set RHT Margin
4252 Panasonic Laser 4420 Set TOP Margin
4253 Panasonic Laser 4420 Skip Perf OFF
4254 Panasonic Laser 4420 Skip Perf ON
4255 Panasonic Laser 4420 SUBScript OFF
4256 Panasonic Laser 4420 SUBScript ON
4257 Panasonic Laser 4420 SUP-Scr OFF
4258 Panasonic Laser 4420 SUPERscript ON
4259 Panasonic Laser 4420 Underline OFF
4260 Panasonic Laser 4420 Underline ON
4261 Panasonic Laser 4420 Var. Ln Space
4262 Panasonic Laser 4450 10 CPI
4263 Panasonic Laser 4450 12 CPI
4264 Panasonic Laser 4450 12 Lines/Inch
4265 Panasonic Laser 4450 15-17 CPI
4266 Panasonic Laser 4450 6 Lines/Inch
4267 Panasonic Laser 4450 8 Lines/Inch
4268 Panasonic Laser 4450 Alt. Var Ln Sp
4269 Panasonic Laser 4450 Bold OFF

4270 Panasonic Laser 4450 Bold ON
4271 Panasonic Laser 4450 Condense Off
4272 Panasonic Laser 4450 DbIStrike OFF
4273 Panasonic Laser 4450 DbIStrike ON
4274 Panasonic Laser 4450 DdIWIDE ON
4275 Panasonic Laser 4450 Emphasize OFF
4276 Panasonic Laser 4450 Emphasize ON
4277 Panasonic Laser 4450 Initialize
4278 Panasonic Laser 4450 Int Chr Spac'g
4279 Panasonic Laser 4450 Italic OFF
4280 Panasonic Laser 4450 Italic ON
4281 Panasonic Laser 4450 Mastr Font/Typ
4282 Panasonic Laser 4450 Move ABS Horiz
4283 Panasonic Laser 4450 Move ABS Vert.
4284 Panasonic Laser 4450 Move REL Horiz
4285 Panasonic Laser 4450 Move REL Vert.
4286 Panasonic Laser 4450 Pop Cursor
4287 Panasonic Laser 4450 Propor'nI Off
4288 Panasonic Laser 4450 Propor'nI On
4289 Panasonic Laser 4450 Push Cursor
4290 Panasonic Laser 4450 Sel. Prt Style
4291 Panasonic Laser 4450 Select Char St
4292 Panasonic Laser 4450 Set LFT Margin
4293 Panasonic Laser 4450 Set RHT Margin
4294 Panasonic Laser 4450 Set TOP Margin
4295 Panasonic Laser 4450 Skip Perf OFF
4296 Panasonic Laser 4450 Skip Perf ON
4297 Panasonic Laser 4450 SUBScript OFF
4298 Panasonic Laser 4450 SUBScript ON
4299 Panasonic Laser 4450 SUP-Scr OFF
4300 Panasonic Laser 4450 SUPERscript ON
4301 Panasonic Laser 4450 Underline OFF
4302 Panasonic Laser 4450 Underline ON
4303 Panasonic Laser 4450 Var. Ln Space
4304 Panasonic Laser 4450i 10 CPI
4305 Panasonic Laser 4450i 12 CPI
4306 Panasonic Laser 4450i 12 Lines/Inch
4307 Panasonic Laser 4450i 15-17 CPI
4308 Panasonic Laser 4450i 6 Lines/Inch
4309 Panasonic Laser 4450i 8 Lines/Inch
4310 Panasonic Laser 4450i Alt. Var Ln Sp
4311 Panasonic Laser 4450i Bold OFF
4312 Panasonic Laser 4450i Bold ON
4313 Panasonic Laser 4450i Condense Off
4314 Panasonic Laser 4450i DbIStrike OFF
4315 Panasonic Laser 4450i DbIStrike ON
4316 Panasonic Laser 4450i DdIWIDE ON
4317 Panasonic Laser 4450i Emphasize OFF
4318 Panasonic Laser 4450i Emphasize ON

4319 Panasonic Laser 4450i Initialize
4320 Panasonic Laser 4450i Int Chr Spac'g
4321 Panasonic Laser 4450i Italic OFF
4322 Panasonic Laser 4450i Italic ON
4323 Panasonic Laser 4450i Mastr Font/Typ
4324 Panasonic Laser 4450i Move ABS Horiz
4325 Panasonic Laser 4450i Move ABS Vert.
4326 Panasonic Laser 4450i Move REL Horiz
4327 Panasonic Laser 4450i Move REL Vert.
4328 Panasonic Laser 4450i Pop Cursor
4329 Panasonic Laser 4450i Propor'nl Off
4330 Panasonic Laser 4450i Propor'nl On
4331 Panasonic Laser 4450i Push Cursor
4332 Panasonic Laser 4450i Sel. Prt Style
4333 Panasonic Laser 4450i Select Char St
4334 Panasonic Laser 4450i Set LFT Margin
4335 Panasonic Laser 4450i Set RHT Margin
4336 Panasonic Laser 4450i Set TOP Margin
4337 Panasonic Laser 4450i Skip Perf OFF
4338 Panasonic Laser 4450i Skip Perf ON
4339 Panasonic Laser 4450i SUBScript OFF
4340 Panasonic Laser 4450i SUBScript ON
4341 Panasonic Laser 4450i SUP-Scr OFF
4342 Panasonic Laser 4450i SUPERscript ON
4343 Panasonic Laser 4450i Underline OFF
4344 Panasonic Laser 4450i Underline ON
4345 Panasonic Laser 4450i Var. Ln Space
4346 Proprinter Automatic Linefeed OFF
4347 Proprinter Automatic Linefeed ON
4348 Proprinter Bell
4349 Proprinter Clear Printer Buffer
4350 Proprinter Compressed ON
4351 Proprinter Double Height OFF
4352 Proprinter Double Height ON
4353 Proprinter Double Line Spacing
4354 Proprinter Double Width OFF
4355 Proprinter Double Width ON
4356 Proprinter Emphasized OFF
4357 Proprinter Emphasized ON
4358 Proprinter Enhanced OFF
4359 Proprinter Enhanced ON
4360 Proprinter Form Feed
4361 Proprinter Italics OFF
4362 Proprinter Italics ON
4363 Proprinter Line Feed
4364 Proprinter Overscore OFF
4365 Proprinter Overscore ON
4366 Proprinter Paper-Out Sensor OFF
4367 Proprinter Paper-Out Sensor ON

4368 Proprinter Print Bidirectional
4369 Proprinter Print Unidirectional
4370 Proprinter Proportional Spacing OFF
4371 Proprinter Proportional Spacing ON
4372 Proprinter Reverse Line Feed
4373 Proprinter Select 10 CPI
4374 Proprinter Select 12 CPI
4375 Proprinter Select Font
4376 Proprinter Select Font: 10 CPI DLL Utility
4377 Proprinter Select Font: 10 CPI Utility
4378 Proprinter Select Font: 12 CPI DLL Utility
4379 Proprinter Select Font: 12 CPI High Speed Draft
4380 Proprinter Select Font: NLQ Courier
4381 Proprinter Select Font: NLQ Courier DLL
4382 Proprinter Select Font: NLQ Sans Serif
4383 Proprinter Select Font: NLQ Sans Serif DLL
4384 Proprinter Set Form Length In Inches: 11
4385 Proprinter Set Form Length In Inches: 14
4386 Proprinter Set Form Length In Lines: 56
4387 Proprinter Set Form Length In Lines: 65
4388 Proprinter Set Line Spacing 1/8
4389 Proprinter Set Line Spacing 7/72
4390 Proprinter Set Top Of Form
4391 Proprinter Single Line Spacing
4392 Proprinter Subscript OFF
4393 Proprinter Subscript ON
4394 Proprinter Superscript OFF
4395 Proprinter Superscript ON
4396 Proprinter Underline OFF
4397 Proprinter Underline ON
4398 QMS Kiss Laser 10 CPI
4399 QMS Kiss Laser 12 CPI
4400 QMS Kiss Laser 12 Lines/Inch
4401 QMS Kiss Laser 15-17 CPI
4402 QMS Kiss Laser 6 Lines/Inch
4403 QMS Kiss Laser 8 Lines/Inch
4404 QMS Kiss Laser Bold OFF
4405 QMS Kiss Laser Bold ON
4406 QMS Kiss Laser DbIStrike OFF
4407 QMS Kiss Laser DbIStrike ON
4408 QMS Kiss Laser DdIWIDE OFF
4409 QMS Kiss Laser DdIWIDE ON
4410 QMS Kiss Laser Emphasize OFF
4411 QMS Kiss Laser Emphasize ON
4412 QMS Kiss Laser Initialize
4413 QMS Kiss Laser Move ABS Horiz
4414 QMS Kiss Laser Move ABS Vert.
4415 QMS Kiss Laser NLQ Mode
4416 QMS Kiss Laser Propor'nl Off

4417 QMS Kiss Laser Propor'nl On
4418 QMS Kiss Laser Set BOT Margin
4419 QMS Kiss Laser Set LFT Margin
4420 QMS Kiss Laser Set RHT Margin
4421 QMS Kiss Laser Set Tab Stops
4422 QMS Kiss Laser Set TOP Margin
4423 QMS Kiss Laser SUBScript OFF
4424 QMS Kiss Laser SUBScript ON
4425 QMS Kiss Laser SUP-Scr OFF
4426 QMS Kiss Laser SUPERscript ON
4427 QMS Kiss Laser Underline OFF
4428 QMS Kiss Laser Underline ON
4429 QuadLaser 10 CPI.
4430 QuadLaser 12 CPI.
4431 QuadLaser 6 lines per inch.
4432 QuadLaser 8 lines per inch.
4433 QuadLaser Double Stike Off.
4434 QuadLaser Double Stike On.
4435 QuadLaser Italics Off.
4436 QuadLaser Italics On.
4437 QuadLaser Reset
4438 QuadLaser Setup
4439 QuadLaser Underline Off.
4440 QuadLaser Underline On.
4441 Quadram QuadJet 10 CPI.
4442 Quadram QuadJet 6 lines per inch.
4443 Quadram QuadJet 8 lines per inch.
4444 Quadram QuadJet Reset
4445 Quadram QuadJet Setup
4446 Qume Sprint 5 6 lines per inch.
4447 Qume Sprint 5 8 lines per inch.
4448 Qume Sprint 5 Reset
4449 Qume Sprint 5 Setup
4450 Qume Sprint 5 Underline Off.
4451 Qume Sprint 5 Underline On.
4452 Qume Sprint 9/45, 9/55 10 CPI.
4453 Qume Sprint 9/45, 9/55 12 CPI.
4454 Qume Sprint 9/45, 9/55 6 lines per inch.
4455 Qume Sprint 9/45, 9/55 8 lines per inch.
4456 Qume Sprint 9/45, 9/55 Double Stike Off.
4457 Qume Sprint 9/45, 9/55 Double Stike On.
4458 Qume Sprint 9/45, 9/55 Reset
4459 Qume Sprint 9/45, 9/55 Setup
4460 Qume Sprint 9/45, 9/55 Underline Off.
4461 Qume Sprint 9/45, 9/55 Underline On.
4462 Radio Laser LP-100 10 CPI
4463 Radio Laser LP-100 12 CPI
4464 Radio Laser LP-100 12 Lines/Inch
4465 Radio Laser LP-100 15-17 CPI

4466 Radio Laser LP-100 6 Lines/Inch
4467 Radio Laser LP-100 8 Lines/Inch
4468 Radio Laser LP-100 Alt. Var Ln Sp
4469 Radio Laser LP-100 Bold OFF
4470 Radio Laser LP-100 Bold ON
4471 Radio Laser LP-100 Condense Off
4472 Radio Laser LP-100 DblStrike OFF
4473 Radio Laser LP-100 DblStrike ON
4474 Radio Laser LP-100 DdlWIDE ON
4475 Radio Laser LP-100 Emphasize OFF
4476 Radio Laser LP-100 Emphasize ON
4477 Radio Laser LP-100 Initialize
4478 Radio Laser LP-100 Int Chr Spac'g
4479 Radio Laser LP-100 Italic OFF
4480 Radio Laser LP-100 Italic ON
4481 Radio Laser LP-100 Mastr Font/Typ
4482 Radio Laser LP-100 Move ABS Horiz
4483 Radio Laser LP-100 Move ABS Vert.
4484 Radio Laser LP-100 Move REL Horiz
4485 Radio Laser LP-100 Move REL Vert.
4486 Radio Laser LP-100 Pop Cursor
4487 Radio Laser LP-100 Propor'nl Off
4488 Radio Laser LP-100 Propor'nl On
4489 Radio Laser LP-100 Push Cursor
4490 Radio Laser LP-100 Sel. Prt Style
4491 Radio Laser LP-100 Select Char St
4492 Radio Laser LP-100 Set LFT Margin
4493 Radio Laser LP-100 Set RHT Margin
4494 Radio Laser LP-100 Set TOP Margin
4495 Radio Laser LP-100 Skip Perf OFF
4496 Radio Laser LP-100 Skip Perf ON
4497 Radio Laser LP-100 SUBScript OFF
4498 Radio Laser LP-100 SUBScript ON
4499 Radio Laser LP-100 SUP-Scr OFF
4500 Radio Laser LP-100 SUPERscript ON
4501 Radio Laser LP-100 Underline OFF
4502 Radio Laser LP-100 Underline ON
4503 Radio Laser LP-100 Var. Ln Space
4504 Roland LP-1100 10 CPI
4505 Roland LP-1100 12 CPI
4506 Roland LP-1100 12 Lines/Inch
4507 Roland LP-1100 15-17 CPI
4508 Roland LP-1100 6 Lines/Inch
4509 Roland LP-1100 8 Lines/Inch
4510 Roland LP-1100 Alt. Var Ln Sp
4511 Roland LP-1100 Bold OFF
4512 Roland LP-1100 Bold ON
4513 Roland LP-1100 Condense Off
4514 Roland LP-1100 DblStrike OFF

4515 Roland LP-1100 DbIStrike ON
4516 Roland LP-1100 DdIWIDE ON
4517 Roland LP-1100 Emphasize OFF
4518 Roland LP-1100 Emphasize ON
4519 Roland LP-1100 Initialize
4520 Roland LP-1100 Int Chr Spac'g
4521 Roland LP-1100 Italic OFF
4522 Roland LP-1100 Italic ON
4523 Roland LP-1100 Landscape
4524 Roland LP-1100 Mastr Font/Typ
4525 Roland LP-1100 Move ABS Horiz
4526 Roland LP-1100 Move ABS Vert.
4527 Roland LP-1100 Move REL Horiz
4528 Roland LP-1100 Move REL Vert.
4529 Roland LP-1100 Pop Cursor
4530 Roland LP-1100 Portrait
4531 Roland LP-1100 Propor'nl Off
4532 Roland LP-1100 Propor'nl On
4533 Roland LP-1100 Push Cursor
4534 Roland LP-1100 Sel. Prt Style
4535 Roland LP-1100 Select Char St
4536 Roland LP-1100 Set LFT Margin
4537 Roland LP-1100 Set RHT Margin
4538 Roland LP-1100 Set TOP Margin
4539 Roland LP-1100 Skip Perf OFF
4540 Roland LP-1100 Skip Perf ON
4541 Roland LP-1100 SUBScript OFF
4542 Roland LP-1100 SUBScript ON
4543 Roland LP-1100 SUP-Scr OFF
4544 Roland LP-1100 SUPERscript ON
4545 Roland LP-1100 Underline OFF
4546 Roland LP-1100 Underline ON
4547 Roland LP-1100 Var. Ln Space
4548 Roland PR-2417 10 CPI
4549 Roland PR-2417 12 CPI
4550 Roland PR-2417 12 Lines/Inch
4551 Roland PR-2417 15-17 CPI
4552 Roland PR-2417 6 Lines/Inch
4553 Roland PR-2417 8 Lines/Inch
4554 Roland PR-2417 Alt. Var Ln Sp
4555 Roland PR-2417 Bldirect'I ON
4556 Roland PR-2417 Bold OFF
4557 Roland PR-2417 Bold ON
4558 Roland PR-2417 Condense Off
4559 Roland PR-2417 DbIHeight OFF
4560 Roland PR-2417 DbIHeight ON
4561 Roland PR-2417 DbIStrike OFF
4562 Roland PR-2417 DbIStrike ON
4563 Roland PR-2417 DbIWIDE OFF

Sheet1

4564 Roland PR-2417 DdlWIDE ON
4565 Roland PR-2417 Draft Mode
4566 Roland PR-2417 Emphasize OFF
4567 Roland PR-2417 Emphasize ON
4568 Roland PR-2417 Initialize
4569 Roland PR-2417 Int Chr Spac'g
4570 Roland PR-2417 Italic OFF
4571 Roland PR-2417 Italic ON
4572 Roland PR-2417 Mastr Font/Typ
4573 Roland PR-2417 Move ABS Horiz
4574 Roland PR-2417 Move REL Horiz
4575 Roland PR-2417 NLQ Mode
4576 Roland PR-2417 Propor'nl Off
4577 Roland PR-2417 Propor'nl On
4578 Roland PR-2417 Sel. Prt Style
4579 Roland PR-2417 Select Char St
4580 Roland PR-2417 Set LFT Margin
4581 Roland PR-2417 Set RHT Margin
4582 Roland PR-2417 Set Tab Stops
4583 Roland PR-2417 Skip Perf OFF
4584 Roland PR-2417 Skip Perf ON
4585 Roland PR-2417 SUBScript OFF
4586 Roland PR-2417 SUBScript ON
4587 Roland PR-2417 SUP-Scr OFF
4588 Roland PR-2417 SUPERscript ON
4589 Roland PR-2417 Underline OFF
4590 Roland PR-2417 Underline ON
4591 Roland PR-2417 UNIdirect'l ON
4592 Roland PR-2417 Var. Ln Space
4593 Sanyo PR-5500 10 CPI.
4594 Sanyo PR-5500 12 CPI.
4595 Sanyo PR-5500 6 lines per inch.
4596 Sanyo PR-5500 8 lines per inch.
4597 Sanyo PR-5500 Reset
4598 Sanyo PR-5500 Setup
4599 Seikosha SP-1000 10 CPI
4600 Seikosha SP-1000 12 CPI
4601 Seikosha SP-1000 12 Lines/Inch
4602 Seikosha SP-1000 15-17 CPI
4603 Seikosha SP-1000 6 Lines/Inch
4604 Seikosha SP-1000 8 Lines/Inch
4605 Seikosha SP-1000 Alt. Var Ln Sp
4606 Seikosha SP-1000 Bldirect'l ON
4607 Seikosha SP-1000 Bold OFF
4608 Seikosha SP-1000 Bold ON
4609 Seikosha SP-1000 Condense Off
4610 Seikosha SP-1000 DblStrike OFF
4611 Seikosha SP-1000 DblStrike ON
4612 Seikosha SP-1000 DbIWIDE OFF

4613 Seikosha SP-1000 DdlWIDE ON
4614 Seikosha SP-1000 Draft Mode
4615 Seikosha SP-1000 Emphasize OFF
4616 Seikosha SP-1000 Emphasize ON
4617 Seikosha SP-1000 Initialize
4618 Seikosha SP-1000 Int Chr Spac'g
4619 Seikosha SP-1000 Italic OFF
4620 Seikosha SP-1000 Italic ON
4621 Seikosha SP-1000 Mastr Font/Typ
4622 Seikosha SP-1000 NLQ Mode
4623 Seikosha SP-1000 Propor'nl Off
4624 Seikosha SP-1000 Propor'nl On
4625 Seikosha SP-1000 Sel. Prt Style
4626 Seikosha SP-1000 Select Char St
4627 Seikosha SP-1000 Set LFT Margin
4628 Seikosha SP-1000 Set RHT Margin
4629 Seikosha SP-1000 Set Tab Stops
4630 Seikosha SP-1000 Skip Perf OFF
4631 Seikosha SP-1000 Skip Perf ON
4632 Seikosha SP-1000 SUBScript OFF
4633 Seikosha SP-1000 SUBScript ON
4634 Seikosha SP-1000 SUP-Scr OFF
4635 Seikosha SP-1000 SUPERscript ON
4636 Seikosha SP-1000 Underline OFF
4637 Seikosha SP-1000 Underline ON
4638 Seikosha SP-1000 UNIdirect'l ON
4639 Seikosha SP-1000 Var. Ln Space
4640 Seikosha SP-1200AI 10 CPI
4641 Seikosha SP-1200AI 12 CPI
4642 Seikosha SP-1200AI 12 Lines/Inch
4643 Seikosha SP-1200AI 15-17 CPI
4644 Seikosha SP-1200AI 6 Lines/Inch
4645 Seikosha SP-1200AI 8 Lines/Inch
4646 Seikosha SP-1200AI Alt. Var Ln Sp
4647 Seikosha SP-1200AI Bldirect'l ON
4648 Seikosha SP-1200AI Bold OFF
4649 Seikosha SP-1200AI Bold ON
4650 Seikosha SP-1200AI Condense Off
4651 Seikosha SP-1200AI DbIStrike OFF
4652 Seikosha SP-1200AI DbIStrike ON
4653 Seikosha SP-1200AI DbIWIDE OFF
4654 Seikosha SP-1200AI DdlWIDE ON
4655 Seikosha SP-1200AI Draft Mode
4656 Seikosha SP-1200AI Emphasize OFF
4657 Seikosha SP-1200AI Emphasize ON
4658 Seikosha SP-1200AI Initialize
4659 Seikosha SP-1200AI Int Chr Spac'g
4660 Seikosha SP-1200AI Italic OFF
4661 Seikosha SP-1200AI Italic ON

4662 Seikosha SP-1200AI Mastr Font/Typ
4663 Seikosha SP-1200AI NLQ Mode
4664 Seikosha SP-1200AI Propor'nI Off
4665 Seikosha SP-1200AI Propor'nI On
4666 Seikosha SP-1200AI Sel. Prt Style
4667 Seikosha SP-1200AI Select Char St
4668 Seikosha SP-1200AI Set LFT Margin
4669 Seikosha SP-1200AI Set RHT Margin
4670 Seikosha SP-1200AI Set Tab Stops
4671 Seikosha SP-1200AI Skip Perf OFF
4672 Seikosha SP-1200AI Skip Perf ON
4673 Seikosha SP-1200AI SUBScript OFF
4674 Seikosha SP-1200AI SUBScript ON
4675 Seikosha SP-1200AI SUP-Scr OFF
4676 Seikosha SP-1200AI SUPERscript ON
4677 Seikosha SP-1200AI Underline OFF
4678 Seikosha SP-1200AI Underline ON
4679 Seikosha SP-1200AI UNIdirect'I ON
4680 Seikosha SP-1200AI Var. Ln Space
4681 Siemens PT88/PT89 10 CPI
4682 Siemens PT88/PT89 12 CPI
4683 Siemens PT88/PT89 12 Lines/Inch
4684 Siemens PT88/PT89 15-17 CPI
4685 Siemens PT88/PT89 6 Lines/Inch
4686 Siemens PT88/PT89 8 Lines/Inch
4687 Siemens PT88/PT89 Alt. Var Ln Sp
4688 Siemens PT88/PT89 Bldirect'I ON
4689 Siemens PT88/PT89 Bold OFF
4690 Siemens PT88/PT89 Bold ON
4691 Siemens PT88/PT89 Condense Off
4692 Siemens PT88/PT89 DbIStrike OFF
4693 Siemens PT88/PT89 DbIStrike ON
4694 Siemens PT88/PT89 DbIWIDE OFF
4695 Siemens PT88/PT89 DdlWIDE ON
4696 Siemens PT88/PT89 Draft Mode
4697 Siemens PT88/PT89 Emphasize OFF
4698 Siemens PT88/PT89 Emphasize ON
4699 Siemens PT88/PT89 Initialize
4700 Siemens PT88/PT89 Italic OFF
4701 Siemens PT88/PT89 Italic ON
4702 Siemens PT88/PT89 Mastr Font/Typ
4703 Siemens PT88/PT89 NLQ Mode
4704 Siemens PT88/PT89 Propor'nI Off
4705 Siemens PT88/PT89 Propor'nI On
4706 Siemens PT88/PT89 Select Char St
4707 Siemens PT88/PT89 Set LFT Margin
4708 Siemens PT88/PT89 Set RHT Margin
4709 Siemens PT88/PT89 Set Tab Stops
4710 Siemens PT88/PT89 Skip Perf OFF

4711 Siemens PT88/PT89 Skip Perf ON
4712 Siemens PT88/PT89 SUBScript OFF
4713 Siemens PT88/PT89 SUBScript ON
4714 Siemens PT88/PT89 SUP-Scr OFF
4715 Siemens PT88/PT89 SUPERscript ON
4716 Siemens PT88/PT89 Underline OFF
4717 Siemens PT88/PT89 Underline ON
4718 Siemens PT88/PT89 UNldirect'l ON
4719 Siemens PT88/PT89 Var. Ln Space
4720 Silver Reed 550 (Line) Double Stike Off.
4721 Silver Reed 550 (Line) Double Stike On.
4722 Silver Reed 550 (Line) Underline Off.
4723 Silver Reed 550 (Line) Underline On.
4724 Silver Reed 550 (Ser) 10 CPI.
4725 Silver Reed 550 (Ser) 12 CPI.
4726 Silver Reed 550 (Ser) 6 lines per inch.
4727 Silver Reed 550 (Ser) 8 lines per inch.
4728 Silver Reed 550 (Ser) Reset
4729 Silver Reed 550 (Ser) Setup
4730 Silver Reed 770 10 CPI.
4731 Silver Reed 770 12 CPI.
4732 Silver Reed 770 6 lines per inch.
4733 Silver Reed 770 8 lines per inch.
4734 Silver Reed 770 Double Stike Off.
4735 Silver Reed 770 Double Stike On.
4736 Silver Reed 770 Reset
4737 Silver Reed 770 Setup
4738 Silver Reed 770 Underline Off.
4739 Silver Reed 770 Underline On.
4740 Smith Corona D-100 10 CPI
4741 Smith Corona D-100 12 CPI
4742 Smith Corona D-100 12 Lines/Inch
4743 Smith Corona D-100 15-17 CPI
4744 Smith Corona D-100 6 Lines/Inch
4745 Smith Corona D-100 8 Lines/Inch
4746 Smith Corona D-100 Alt. Var Ln Sp
4747 Smith Corona D-100 Bldirect'l ON
4748 Smith Corona D-100 Bold OFF
4749 Smith Corona D-100 Bold ON
4750 Smith Corona D-100 Condense Off
4751 Smith Corona D-100 DbIStrike OFF
4752 Smith Corona D-100 DbIStrike ON
4753 Smith Corona D-100 DbIWIDE OFF
4754 Smith Corona D-100 DdlWIDE ON
4755 Smith Corona D-100 Draft Mode
4756 Smith Corona D-100 Emphasize OFF
4757 Smith Corona D-100 Emphasize ON
4758 Smith Corona D-100 Initialize
4759 Smith Corona D-100 Italic OFF

4760 Smith Corona D-100 Italic ON
4761 Smith Corona D-100 Mastr Font/Typ
4762 Smith Corona D-100 NLQ Mode
4763 Smith Corona D-100 Propor'nl Off
4764 Smith Corona D-100 Propor'nl On
4765 Smith Corona D-100 Select Char St
4766 Smith Corona D-100 Set LFT Margin
4767 Smith Corona D-100 Set RHT Margin
4768 Smith Corona D-100 Set Tab Stops
4769 Smith Corona D-100 Skip Perf OFF
4770 Smith Corona D-100 Skip Perf ON
4771 Smith Corona D-100 SUBScript OFF
4772 Smith Corona D-100 SUBScript ON
4773 Smith Corona D-100 SUP-Scr OFF
4774 Smith Corona D-100 SUPERscript ON
4775 Smith Corona D-100 Underline OFF
4776 Smith Corona D-100 Underline ON
4777 Smith Corona D-100 UNIdirect'I ON
4778 Smith Corona D-100 Var. Ln Space
4779 Smith D-200/D-300 10 CPI
4780 Smith D-200/D-300 12 CPI
4781 Smith D-200/D-300 12 Lines/Inch
4782 Smith D-200/D-300 15-17 CPI
4783 Smith D-200/D-300 6 Lines/Inch
4784 Smith D-200/D-300 8 Lines/Inch
4785 Smith D-200/D-300 Alt. Var Ln Sp
4786 Smith D-200/D-300 Bldirect'I ON
4787 Smith D-200/D-300 Bold OFF
4788 Smith D-200/D-300 Bold ON
4789 Smith D-200/D-300 Condense Off
4790 Smith D-200/D-300 DbIStrike OFF
4791 Smith D-200/D-300 DbIStrike ON
4792 Smith D-200/D-300 DbIWIDE OFF
4793 Smith D-200/D-300 DdlWIDE ON
4794 Smith D-200/D-300 Draft Mode
4795 Smith D-200/D-300 Emphasize OFF
4796 Smith D-200/D-300 Emphasize ON
4797 Smith D-200/D-300 Initialize
4798 Smith D-200/D-300 Int Chr Spac'g
4799 Smith D-200/D-300 Italic OFF
4800 Smith D-200/D-300 Italic ON
4801 Smith D-200/D-300 Mastr Font/Typ
4802 Smith D-200/D-300 NLQ Mode
4803 Smith D-200/D-300 Propor'nl Off
4804 Smith D-200/D-300 Propor'nl On
4805 Smith D-200/D-300 Sel. Prt Style
4806 Smith D-200/D-300 Select Char St
4807 Smith D-200/D-300 Set LFT Margin
4808 Smith D-200/D-300 Set RHT Margin

4809 Smith D-200/D-300 Set Tab Stops
4810 Smith D-200/D-300 Skip Perf OFF
4811 Smith D-200/D-300 Skip Perf ON
4812 Smith D-200/D-300 SUBScript OFF
4813 Smith D-200/D-300 SUBScript ON
4814 Smith D-200/D-300 SUP-Scr OFF
4815 Smith D-200/D-300 SUPERscript ON
4816 Smith D-200/D-300 Underline OFF
4817 Smith D-200/D-300 Underline ON
4818 Smith D-200/D-300 UNIdirect'l ON
4819 Smith D-200/D-300 Var. Ln Space
4820 Star Gemini 10-X/15-X 10 CPI.
4821 Star Gemini 10-X/15-X 12 CPI.
4822 Star Gemini 10-X/15-X 6 lines per inch.
4823 Star Gemini 10-X/15-X 8 lines per inch.
4824 Star Gemini 10-X/15-X Double Stike Off.
4825 Star Gemini 10-X/15-X Double Stike On.
4826 Star Gemini 10-X/15-X Italics Off.
4827 Star Gemini 10-X/15-X Italics On.
4828 Star Gemini 10-X/15-X Reset
4829 Star Gemini 10-X/15-X Setup
4830 Star Gemini 10-X/15-X Underline Off.
4831 Star Gemini 10-X/15-X Underline On.
4832 Star ND-1 10 CPI
4833 Star ND-1 12 CPI
4834 Star ND-1 12 Lines/Inch
4835 Star ND-1 15-17 CPI
4836 Star ND-1 6 Lines/Inch
4837 Star ND-1 8 Lines/Inch
4838 Star ND-1 Alt. Var Ln Sp
4839 Star ND-1 Bldirect'l ON
4840 Star ND-1 Bold OFF
4841 Star ND-1 Bold ON
4842 Star ND-1 Condense Off
4843 Star ND-1 DbIStrike OFF
4844 Star ND-1 DbIStrike ON
4845 Star ND-1 DbIWIDE OFF
4846 Star ND-1 DdIWIDE ON
4847 Star ND-1 Draft Mode
4848 Star ND-1 Emphasize OFF
4849 Star ND-1 Emphasize ON
4850 Star ND-1 Initialize
4851 Star ND-1 Int Chr Spac'g
4852 Star ND-1 Italic OFF
4853 Star ND-1 Italic ON
4854 Star ND-1 Mastr Font/Typ
4855 Star ND-1 NLQ Mode
4856 Star ND-1 Propor'nI Off
4857 Star ND-1 Propor'nI On

4858 Star ND-1 Sel. Prt Style
4859 Star ND-1 Select Char St
4860 Star ND-1 Set LFT Margin
4861 Star ND-1 Set RHT Margin
4862 Star ND-1 Set Tab Stops
4863 Star ND-1 Skip Perf OFF
4864 Star ND-1 Skip Perf ON
4865 Star ND-1 SUBScript OFF
4866 Star ND-1 SUBScript ON
4867 Star ND-1 SUP-Scr OFF
4868 Star ND-1 SUPERscript ON
4869 Star ND-1 Underline OFF
4870 Star ND-1 Underline ON
4871 Star ND-1 UNldirect'l ON
4872 Star ND-1 Var. Ln Space
4873 Star NX-100/1000/240/241 10 CPI
4874 Star NX-100/1000/240/241 12 CPI
4875 Star NX-100/1000/240/241 12 Lines/Inch
4876 Star NX-100/1000/240/241 15-17 CPI
4877 Star NX-100/1000/240/241 6 Lines/Inch
4878 Star NX-100/1000/240/241 8 Lines/Inch
4879 Star NX-100/1000/240/241 Alt. Var Ln Sp
4880 Star NX-100/1000/240/241 Bldirect'l ON
4881 Star NX-100/1000/240/241 Bold OFF
4882 Star NX-100/1000/240/241 Bold ON
4883 Star NX-100/1000/240/241 Condense Off
4884 Star NX-100/1000/240/241 DblHeight OFF
4885 Star NX-100/1000/240/241 DblHeight ON
4886 Star NX-100/1000/240/241 DblStrike OFF
4887 Star NX-100/1000/240/241 DblStrike ON
4888 Star NX-100/1000/240/241 DblWIDE OFF
4889 Star NX-100/1000/240/241 DdlWIDE ON
4890 Star NX-100/1000/240/241 Draft Mode
4891 Star NX-100/1000/240/241 Emphasize OFF
4892 Star NX-100/1000/240/241 Emphasize ON
4893 Star NX-100/1000/240/241 Initialize
4894 Star NX-100/1000/240/241 Int Chr Spac'g
4895 Star NX-100/1000/240/241 Italic OFF
4896 Star NX-100/1000/240/241 Italic ON
4897 Star NX-100/1000/240/241 Mastr Font/Typ
4898 Star NX-100/1000/240/241 Move ABS Horiz
4899 Star NX-100/1000/240/241 Move REL Horiz
4900 Star NX-100/1000/240/241 NLQ Mode
4901 Star NX-100/1000/240/241 Propor'nl Off
4902 Star NX-100/1000/240/241 Propor'nl On
4903 Star NX-100/1000/240/241 Sel. Prt Style
4904 Star NX-100/1000/240/241 Select Char St
4905 Star NX-100/1000/240/241 Set LFT Margin
4906 Star NX-100/1000/240/241 Set RHT Margin

4907 Star NX-100/1000/240/241 Set Tab Stops
4908 Star NX-100/1000/240/241 Skip Perf OFF
4909 Star NX-100/1000/240/241 Skip Perf ON
4910 Star NX-100/1000/240/241 SUBScript OFF
4911 Star NX-100/1000/240/241 SUBScript ON
4912 Star NX-100/1000/240/241 SUP-Scr OFF
4913 Star NX-100/1000/240/241 SUPERscript ON
4914 Star NX-100/1000/240/241 Underline OFF
4915 Star NX-100/1000/240/241 Underline ON
4916 Star NX-100/1000/240/241 UNIdirect'l ON
4917 Star NX-100/1000/240/241 Var. Ln Space
4918 Star NX10 6 Lines Per Inch
4919 Star NX10 8 Lines Per Inch
4920 Star NX10 Compressed Printing Off
4921 Star NX10 Compressed Printing On
4922 Star NX10 Emphasized Mode OFF
4923 Star NX10 Emphasized Mode ON
4924 Star NX10 Expanded Mode OFF
4925 Star NX10 Expanded Mode ON
4926 Star NX10 Form Feed Character
4927 Star NX10 Initialization Code
4928 Star NX10 Italics Mode OFF
4929 Star NX10 Italics Mode ON
4930 Star NX10 Master reset code
4931 Star NX10 Near Letter Quality OFF
4932 Star NX10 Near Letter Quality ON
4933 Star NX10 Proportional Print Mode OFF
4934 Star NX10 Proportional Print Mode On
4935 Star NX10 Set FORM LENGTH
4936 Star NX10 Use DOWNLOADABLE Font
4937 Star NX10 Use NORMAL Font
4938 Star NX10 Use NORMAL Print FONT
4939 Star NX10 Use ROMAN 8 Font
4940 Star Radix 10/15 10 CPI.
4941 Star Radix 10/15 12 CPI.
4942 Star Radix 10/15 6 lines per inch.
4943 Star Radix 10/15 8 lines per inch.
4944 Star Radix 10/15 Double Stike Off.
4945 Star Radix 10/15 Double Stike On.
4946 Star Radix 10/15 Italics Off.
4947 Star Radix 10/15 Italics On.
4948 Star Radix 10/15 Reset
4949 Star Radix 10/15 Setup
4950 Star Radix 10/15 Underline Off.
4951 Star Radix 10/15 Underline On.
4952 Swintec 8000 10 CPI
4953 Swintec 8000 12 CPI
4954 Swintec 8000 12 Lines/Inch
4955 Swintec 8000 15-17 CPI

4956 Swintec 8000 6 Lines/Inch
4957 Swintec 8000 8 Lines/Inch
4958 Swintec 8000 Bold OFF
4959 Swintec 8000 Bold ON
4960 Swintec 8000 Condense Off
4961 Swintec 8000 DbIStrike OFF
4962 Swintec 8000 DbIStrike ON
4963 Swintec 8000 DbIWIDE OFF
4964 Swintec 8000 DdIWIDE ON
4965 Swintec 8000 Draft Mode
4966 Swintec 8000 Emphasize OFF
4967 Swintec 8000 Emphasize ON
4968 Swintec 8000 Initialize
4969 Swintec 8000 Move ABS Horiz
4970 Swintec 8000 Move ABS Vert.
4971 Swintec 8000 NLQ Mode
4972 Swintec 8000 Propor'nl Off
4973 Swintec 8000 Propor'nl On
4974 Swintec 8000 Set BOT Margin
4975 Swintec 8000 Set LFT Margin
4976 Swintec 8000 Set RHT Margin
4977 Swintec 8000 Set Tab Stops
4978 Swintec 8000 Set TOP Margin
4979 Swintec 8000 SUBScript OFF
4980 Swintec 8000 SUBScript ON
4981 Swintec 8000 SUP-Scr OFF
4982 Swintec 8000 SUPERscript ON
4983 Swintec 8000 Underline OFF
4984 Swintec 8000 Underline ON
4985 Swintec 8016 10 CPI
4986 Swintec 8016 12 CPI
4987 Swintec 8016 12 Lines/Inch
4988 Swintec 8016 15-17 CPI
4989 Swintec 8016 6 Lines/Inch
4990 Swintec 8016 8 Lines/Inch
4991 Swintec 8016 Bold OFF
4992 Swintec 8016 Bold ON
4993 Swintec 8016 Condense Off
4994 Swintec 8016 DbIStrike OFF
4995 Swintec 8016 DbIStrike ON
4996 Swintec 8016 DbIWIDE OFF
4997 Swintec 8016 DdIWIDE ON
4998 Swintec 8016 Draft Mode
4999 Swintec 8016 Emphasize OFF
5000 Swintec 8016 Emphasize ON
5001 Swintec 8016 Initialize
5002 Swintec 8016 Move ABS Horiz
5003 Swintec 8016 Move ABS Vert.
5004 Swintec 8016 NLQ Mode

Sheet1

5005 Swintec 8016 Propor'nl Off
5006 Swintec 8016 Propor'nl On
5007 Swintec 8016 Set BOT Margin
5008 Swintec 8016 Set LFT Margin
5009 Swintec 8016 Set RHT Margin
5010 Swintec 8016 Set Tab Stops
5011 Swintec 8016 Set TOP Margin
5012 Swintec 8016 SUBScript OFF
5013 Swintec 8016 SUBScript ON
5014 Swintec 8016 SUP-Scr OFF
5015 Swintec 8016 SUPERscript ON
5016 Swintec 8016 Underline OFF
5017 Swintec 8016 Underline ON
5018 Tandy DMP 130A Bold OFF
5019 Tandy DMP 130A Bold ON
5020 Tandy DMP 130A Compressed OFF
5021 Tandy DMP 130A Compressed ON (12 CPI)
5022 Tandy DMP 130A Condensed OFF
5023 Tandy DMP 130A Condensed ON
5024 Tandy DMP 130A Expanded OFF
5025 Tandy DMP 130A Expanded ON
5026 Tandy DMP 130A Italics OFF
5027 Tandy DMP 130A Italics ON
5028 Tandy DMP 130A Normal (10 CPI)
5029 Tandy DMP 130A Page eject
5030 Texas Inst 850/855 10 CPI.
5031 Texas Inst 850/855 12 CPI.
5032 Texas Inst 850/855 6 lines per inch.
5033 Texas Inst 850/855 8 lines per inch.
5034 Texas Inst 850/855 Cancels shadow print.
5035 Texas Inst 850/855 Double Stike Off.
5036 Texas Inst 850/855 Double Stike On.
5037 Texas Inst 850/855 Draft Print On.
5038 Texas Inst 850/855 Quality Print On.
5039 Texas Inst 850/855 Reset
5040 Texas Inst 850/855 Select Font One.
5041 Texas Inst 850/855 Select Font Three.
5042 Texas Inst 850/855 Select Font two.
5043 Texas Inst 850/855 Selects shadow print.
5044 Texas Inst 850/855 Setup
5045 Texas Inst 850/855 Underline Off.
5046 Texas Inst 850/855 Underline On.
5047 Texas Inst 860/865 10 CPI.
5048 Texas Inst 860/865 12 CPI.
5049 Texas Inst 860/865 6 lines per inch.
5050 Texas Inst 860/865 8 lines per inch.
5051 Texas Inst 860/865 Cancels shadow print.
5052 Texas Inst 860/865 Double Stike Off.
5053 Texas Inst 860/865 Double Stike On.

5054 Texas Inst 860/865 Draft Print On.
5055 Texas Inst 860/865 Quality Print On.
5056 Texas Inst 860/865 Reset
5057 Texas Inst 860/865 Select Font One.
5058 Texas Inst 860/865 Select Font Three.
5059 Texas Inst 860/865 Select Font two.
5060 Texas Inst 860/865 Selects shadow print.
5061 Texas Inst 860/865 Setup
5062 Texas Inst 860/865 Underline Off.
5063 Texas Inst 860/865 Underline On.
5064 Toshiba P 341/351 12 CPI.
5065 Toshiba P 341/351 6 lines per inch.
5066 Toshiba P 341/351 8 lines per inch.
5067 Toshiba P 341/351 Double Stike Off.
5068 Toshiba P 341/351 Double Stike On.
5069 Toshiba P 341/351 Italics Off.
5070 Toshiba P 341/351 Italics On.
5071 Toshiba P 341/351 Reset
5072 Toshiba P 341/351 Setup
5073 Toshiba P 341/351 Underline Off.
5074 Toshiba P 341/351 Underline On.
5075 Toshiba P1340 6 lines per inch.
5076 Toshiba P1340 8 lines per inch.
5077 Toshiba P1340 Reset
5078 Toshiba P1340 Setup
5079 Toshiba P1340 Underline Off.
5080 Toshiba P1340 Underline On.
5081 Toshiba P1350 12 CPI.
5082 Toshiba P1350 6 lines per inch.
5083 Toshiba P1350 8 lines per inch.
5084 Toshiba P1350 Reset
5085 Toshiba P1350 Setup
5086 Toshiba P1350 Underline Off.
5087 Toshiba P1350 Underline On.
5088 Toshiba P1351 12 CPI.
5089 Toshiba P1351 6 lines per inch.
5090 Toshiba P1351 8 lines per inch.
5091 Toshiba P1351 Reset
5092 Toshiba P1351 Setup
5093 Toshiba P1351 Underline Off.
5094 Toshiba P1351 Underline On.
5095 Toshiba P321SL 1/120" Graphics OFF
5096 Toshiba P321SL 1/120" Graphics ON
5097 Toshiba P321SL 1/60" Graphics OFF
5098 Toshiba P321SL 1/60" Graphics ON
5099 Toshiba P321SL Automatic CR/LF OFF
5100 Toshiba P321SL Automatic CR/LF ON
5101 Toshiba P321SL Automatic LF OFF
5102 Toshiba P321SL Automatic LF ON

Sheet1

5103 Toshiba P321SL Bell
5104 Toshiba P321SL Bold Overprint OFF
5105 Toshiba P321SL Bold Overprint ON: once
5106 Toshiba P321SL Bold Overprint ON: twice
5107 Toshiba P321SL Coded Graphics OFF
5108 Toshiba P321SL Coded Graphics ON
5109 Toshiba P321SL Condensed OFF
5110 Toshiba P321SL Condensed ON
5111 Toshiba P321SL Double Height OFF
5112 Toshiba P321SL Double Height ON
5113 Toshiba P321SL Expanded Character OFF
5114 Toshiba P321SL Expanded Character ON
5115 Toshiba P321SL Form Feed
5116 Toshiba P321SL Half Line Feed
5117 Toshiba P321SL IBM Emulation Mode:
5118 Toshiba P321SL Italics OFF
5119 Toshiba P321SL Italics ON
5120 Toshiba P321SL Line Feed
5121 Toshiba P321SL Native Toshiba Emulation Mode:
5122 Toshiba P321SL Negative Half Line Feed
5123 Toshiba P321SL Negative Line Feed
5124 Toshiba P321SL Optional emulation card:
5125 Toshiba P321SL Print Bidirectional
5126 Toshiba P321SL Print Unidirectional
5127 Toshiba P321SL Proportional Spacing OFF
5128 Toshiba P321SL Proportional Spacing ON
5129 Toshiba P321SL Reset
5130 Toshiba P321SL Right Margin Control OFF
5131 Toshiba P321SL Right Margin Control ON
5132 Toshiba P321SL Select Bin 1
5133 Toshiba P321SL Select Bin 2
5134 Toshiba P321SL Select high speed resident font.
5135 Toshiba P321SL Select letter quality downloaded font.
5136 Toshiba P321SL Select letter quality font (Courier).
5137 Toshiba P321SL Select letter quality proportional font.
5138 Toshiba P321SL Select letter quality resident font(Prestige)
5139 Toshiba P321SL Set Bottom Margin at the current line.
5140 Toshiba P321SL Set Left Margin at the current printing posit
5141 Toshiba P321SL Set Right Margin at the current printing posi
5142 Toshiba P321SL Set Top Margin at the current line.
5143 Toshiba P321SL Shadow Print OFF
5144 Toshiba P321SL Shadow Print ON
5145 Toshiba P321SL Start Backward Print
5146 Toshiba P321SL Start Forward Print
5147 Toshiba P321SL Subscript OFF
5148 Toshiba P321SL Subscript ON
5149 Toshiba P321SL Superscript OFF
5150 Toshiba P321SL Superscript ON
5151 Toshiba P321SL Underline OFF

Sheet1

5152 Toshiba P321SL Underline ON
5153 Toshiba P351C 1/120 Graphics OFF
5154 Toshiba P351C 1/120 Graphics ON
5155 Toshiba P351C 1/60 Graphics OFF
5156 Toshiba P351C 1/60 Graphics ON
5157 Toshiba P351C Automatic CR/LF OFF
5158 Toshiba P351C Automatic CR/LF ON
5159 Toshiba P351C Automatic LF OFF
5160 Toshiba P351C Automatic LF ON
5161 Toshiba P351C Bell
5162 Toshiba P351C Bold Overprint OFF
5163 Toshiba P351C Bold Overprint ON: once
5164 Toshiba P351C Bold Overprint ON: twice
5165 Toshiba P351C Coded Graphics OFF
5166 Toshiba P351C Coded Graphics ON
5167 Toshiba P351C Condensed OFF
5168 Toshiba P351C Condensed ON
5169 Toshiba P351C Expanded Character OFF
5170 Toshiba P351C Expanded Character ON
5171 Toshiba P351C Form Feed
5172 Toshiba P351C Half Line Feed
5173 Toshiba P351C Italics OFF
5174 Toshiba P351C Italics ON
5175 Toshiba P351C Letter quality proportional spacing (Courier)
5176 Toshiba P351C Line Feed
5177 Toshiba P351C Negative Half Line Feed
5178 Toshiba P351C Negative Line Feed
5179 Toshiba P351C Print Bidirectional
5180 Toshiba P351C Print Unidirectional
5181 Toshiba P351C Proportional Spacing OFF
5182 Toshiba P351C Proportional Spacing ON
5183 Toshiba P351C Reset
5184 Toshiba P351C Right Margin Control OFF
5185 Toshiba P351C Right Margin Control ON
5186 Toshiba P351C Select Automatic Ribbon Band Shift
5187 Toshiba P351C Select Bin 1
5188 Toshiba P351C Select Bin 2
5189 Toshiba P351C Select IBM Emulation
5190 Toshiba P351C Select letter quality downloaded.
5191 Toshiba P351C Select letter quality resident font (Prestige)
5192 Toshiba P351C Select Ribbon Band 1 (Yellow)
5193 Toshiba P351C Select Ribbon Band 2 (Magenta)
5194 Toshiba P351C Select Ribbon Band 3 (Cyan)
5195 Toshiba P351C Select Ribbon Band 4 (Black)
5196 Toshiba P351C Select Toshiba Emulation
5197 Toshiba P351C Set Bottom Margin at the current line.
5198 Toshiba P351C Set Left Margin: current printing position.
5199 Toshiba P351C Set Right Margin: current printing position
5200 Toshiba P351C Set Top Margin at the current line.

5201 Toshiba P351C Shadow Print OFF
5202 Toshiba P351C Shadow Print ON
5203 Toshiba P351C Start Backward Print
5204 Toshiba P351C Start Forward Print
5205 Toshiba P351C Underline OFF
5206 Toshiba P351C Underline ON
5207 UDP Laser 65 in 1 10 CPI
5208 UDP Laser 65 in 1 12 CPI
5209 UDP Laser 65 in 1 12 Lines/Inch
5210 UDP Laser 65 in 1 15-17 CPI
5211 UDP Laser 65 in 1 6 Lines/Inch
5212 UDP Laser 65 in 1 8 Lines/Inch
5213 UDP Laser 65 in 1 Alt. Var Ln Sp
5214 UDP Laser 65 in 1 Bold OFF
5215 UDP Laser 65 in 1 Bold ON
5216 UDP Laser 65 in 1 Condense Off
5217 UDP Laser 65 in 1 DblStrike OFF
5218 UDP Laser 65 in 1 DblStrike ON
5219 UDP Laser 65 in 1 DdIWIDE ON
5220 UDP Laser 65 in 1 Emphasize OFF
5221 UDP Laser 65 in 1 Emphasize ON
5222 UDP Laser 65 in 1 Initialize
5223 UDP Laser 65 in 1 Int Chr Spac'g
5224 UDP Laser 65 in 1 Italic OFF
5225 UDP Laser 65 in 1 Italic ON
5226 UDP Laser 65 in 1 Mastr Font/Typ
5227 UDP Laser 65 in 1 Move ABS Horiz
5228 UDP Laser 65 in 1 Move ABS Vert.
5229 UDP Laser 65 in 1 Move REL Horiz
5230 UDP Laser 65 in 1 Move REL Vert.
5231 UDP Laser 65 in 1 Pop Cursor
5232 UDP Laser 65 in 1 Propor'n'l Off
5233 UDP Laser 65 in 1 Propor'n'l On
5234 UDP Laser 65 in 1 Push Cursor
5235 UDP Laser 65 in 1 Sel. Prt Style
5236 UDP Laser 65 in 1 Select Char St
5237 UDP Laser 65 in 1 Set LFT Margin
5238 UDP Laser 65 in 1 Set RHT Margin
5239 UDP Laser 65 in 1 Set TOP Margin
5240 UDP Laser 65 in 1 Skip Perf OFF
5241 UDP Laser 65 in 1 Skip Perf ON
5242 UDP Laser 65 in 1 SUBScript OFF
5243 UDP Laser 65 in 1 SUBScript ON
5244 UDP Laser 65 in 1 SUP-Scr OFF
5245 UDP Laser 65 in 1 SUPERscript ON
5246 UDP Laser 65 in 1 Underline OFF
5247 UDP Laser 65 in 1 Underline ON
5248 UDP Laser 65 in 1 Var. Ln Space
5249 Xerox 2700 II Double Stike Off.

Sheet1

5250 Xerox 2700 II Double Strike On.
5251 Xerox 2700 II Reset
5252 Xerox 2700 II Setup
5253 Xerox 2700 II Underline Off.
5254 Xerox 2700 II Underline On.
5255 Xerox 4045 - 630 Mode 10 CPI.
5256 Xerox 4045 - 630 Mode 12 CPI.
5257 Xerox 4045 - 630 Mode 6 lines per inch.
5258 Xerox 4045 - 630 Mode 8 lines per inch.
5259 Xerox 4045 - 630 Mode Double Strike Off.
5260 Xerox 4045 - 630 Mode Double Strike On.
5261 Xerox 4045 - 630 Mode Underline Off.
5262 Xerox 4045 - 630 Mode Underline On.
300 PCL3: Characters/inch: 10.0
301 PCL3: Characters/inch: 12.0
302 PCL3: Characters/inch: 16.7
303 PCL3: Font Stroke Weight : Bold
304 PCL3: Font Stroke Weight : Normal
305 PCL3: Form Feed
306 PCL3: lines/inch: 1
307 PCL3: lines/inch: 2
308 PCL3: lines/inch: 3
309 PCL3: lines/inch: 4
310 PCL3: lines/inch: 6
311 PCL3: lines/inch: 8
312 PCL3: lines/inch:12
313 PCL3: lines/inch:16
314 PCL3: lines/inch:24
315 PCL3: lines/inch:48
316 PCL3: Orientation: Landscape
317 PCL3: Orientation: Portrait
318 PCL3: Paper Size: A4
319 PCL3: Paper Size: Default
320 PCL3: Paper Size: DL envelope (landscape)
321 PCL3: Paper Size: Executive
322 PCL3: Paper Size: Legal
323 PCL3: Paper Size: Letter
324 PCL3: Paper Size: No. 10 envelope (landscape)
325 PCL3: Paper Source: Eject Page
326 PCL3: Paper Source: Envelope Feed
327 PCL3: Paper Source: Feed from tray
328 PCL3: Points: 8
329 PCL3: Points: 10
330 PCL3: Points: 12
331 PCL3: Points: 14
332 PCL3: Print Mode (Text) Bidirectional
333 PCL3: Print Mode (Text) Unidirectional left to right
334 PCL3: Print Mode (Text) Unidirectional right to left
335 PCL3: Print Quality - Draft

336 PCL3: Print Quality - Letter
337 PCL3: Raster Graphics: 100 DPI resolution
338 PCL3: Raster Graphics: 150 DPI resolution
339 PCL3: Raster Graphics: 300 DPI resolution
340 PCL3: Raster Graphics: 75 DPI resolution
341 PCL3: Raster Graphics: End Graphics
342 PCL3: Raster Graphics: Start at current position
343 PCL3: Raster Graphics: Start at left most position
344 PCL3: Reset Printer
345 PCL3: Self test
346 PCL3: Set Left Margin: 1 line
347 PCL3: Set left margin: 2 Lines
348 PCL3: Set Left Margin: 4 lines
349 PCL3: Set Left Margin:10 lines
350 PCL3: Set Page Length: 56
351 PCL3: Set Page length: 60
352 PCL3: Set Page Length: 65
353 PCL3: Set Top Margin: 1 line
354 PCL3: Set Top Margin: 2 Lines
355 PCL3: Set Top Margin: 4 lines
356 PCL3: Set Top Margin:10 lines
357 PCL3: Spacing: Fixed
358 PCL3: Spacing: Proportional
359 PCL3: Style: Italic
360 PCL3: Style: Upright (Solid)
361 PCL3: Typeface: CG Times
362 PCL3: Typeface: Courier
363 PCL3: Typeface: Letter Gothic
364 PCL3: Typeface: Univers
365 PCL3: Underline: Disable
366 PCL3: Underline: Enable Fixed
367 PCL3: Underline: Enable Floating
200 HP LaserJet 4/III Characters/inch: 10.0
201 HP LaserJet 4/III Characters/inch: 12.0
202 HP LaserJet 4/III Characters/inch: 16.7
203 HP LaserJet 4/III Duplex, Long Edge binding
204 HP LaserJet 4/III Duplex, Short Edge binding
205 HP LaserJet 4/III Font Stroke Weight : Black
206 HP LaserJet 4/III Font Stroke Weight : Bold
207 HP LaserJet 4/III Font Stroke Weight : Demi Bold
208 HP LaserJet 4/III Font Stroke Weight : Demi Light
209 HP LaserJet 4/III Font Stroke Weight : Extra Black
210 HP LaserJet 4/III Font Stroke Weight : Extra Bold
211 HP LaserJet 4/III Font Stroke Weight : Extra Light
212 HP LaserJet 4/III Font Stroke Weight : Extra Thin
213 HP LaserJet 4/III Font Stroke Weight : Light
214 HP LaserJet 4/III Font Stroke Weight : Medium (book or text)
215 HP LaserJet 4/III Font Stroke Weight : Semi Bold
216 HP LaserJet 4/III Font Stroke Weight : Semi Light

Sheet1

217 HP LaserJet 4/III Font Stroke Weight : Thin
218 HP LaserJet 4/III Font Stroke Weight : Ultra Black
219 HP LaserJet 4/III Font Stroke Weight : Ultra Thin
220 HP LaserJet 4/III Form Feed
221 HP LaserJet 4/III lines/inch: 1
222 HP LaserJet 4/III lines/inch: 2
223 HP LaserJet 4/III lines/inch: 3
224 HP LaserJet 4/III lines/inch: 4
225 HP LaserJet 4/III lines/inch: 6
226 HP LaserJet 4/III lines/inch: 8
227 HP LaserJet 4/III lines/inch:12
228 HP LaserJet 4/III lines/inch:16
229 HP LaserJet 4/III lines/inch:24
230 HP LaserJet 4/III lines/inch:48
231 HP LaserJet 4/III Orientation: Landscape
232 HP LaserJet 4/III Orientation: Portrait
233 HP LaserJet 4/III Orientation: Reverse Landscape
234 HP LaserJet 4/III Orientation: Reverse Portrait
235 HP LaserJet 4/III Paper Size: A4
236 HP LaserJet 4/III Paper Size: C5
237 HP LaserJet 4/III Paper Size: COM 10 [Envelope]
238 HP LaserJet 4/III Paper Size: DL
239 HP LaserJet 4/III Paper Size: Executive
240 HP LaserJet 4/III Paper Size: Legal
241 HP LaserJet 4/III Paper Size: Letter
242 HP LaserJet 4/III Paper Size: Monarch
243 HP LaserJet 4/III Paper Source: Eject Page
244 HP LaserJet 4/III Paper Source: Manual Envelope Feed
245 HP LaserJet 4/III Paper Source: Manual Feed
246 HP LaserJet 4/III Paper Source: Paper Cassette
247 HP LaserJet 4/III Points: 8
248 HP LaserJet 4/III Points: 10
249 HP LaserJet 4/III Points: 12
250 HP LaserJet 4/III Points: 14
251 HP LaserJet 4/III Reset Printer
252 HP LaserJet 4/III Set Left Margin: 1 line
253 HP LaserJet 4/III Set left margin: 2 Lines
254 HP LaserJet 4/III Set Left Margin: 4 lines
255 HP LaserJet 4/III Set Left Margin:10 lines
256 HP LaserJet 4/III Set Page Length: 56
257 HP LaserJet 4/III Set Page length: 60
258 HP LaserJet 4/III Set Page Length: 65
259 HP LaserJet 4/III Set Top Margin: 1 line
260 HP LaserJet 4/III Set Top Margin: 2 Lines
261 HP LaserJet 4/III Set Top Margin: 4 lines
262 HP LaserJet 4/III Set Top Margin:10 lines
263 HP LaserJet 4/III Simplex
264 HP LaserJet 4/III Spacing: Fixed
265 HP LaserJet 4/III Spacing: Proportional

Sheet1

266 HP LaserJet 4/III Style: Compressed (Extra Condensed)
267 HP LaserJet 4/III Style: Condensed
268 HP LaserJet 4/III Style: Condensed Italic
269 HP LaserJet 4/III Style: Expanded
270 HP LaserJet 4/III Style: Inline
271 HP LaserJet 4/III Style: Italic
272 HP LaserJet 4/III Style: Outline
273 HP LaserJet 4/III Style: Outline Shadowed
274 HP LaserJet 4/III Style: Shadowed
275 HP LaserJet 4/III Style: Upright (Solid)
276 HP LaserJet 4/III Typeface: Albertus
277 HP LaserJet 4/III Typeface: Antique Olive
278 HP LaserJet 4/III Typeface: CG Times
279 HP LaserJet 4/III Typeface: Coronet
280 HP LaserJet 4/III Typeface: Courier
281 HP LaserJet 4/III Typeface: Letter Gothic
282 HP LaserJet 4/III Typeface: Univers
283 HP LaserJet 4/III Typeface: Wingdings
284 HP LaserJet 4/III Underline: Disable
285 HP LaserJet 4/III Underline: Enable Fixed
286 HP LaserJet 4/III Underline: Enable Floating
100 HP LaserJet II 10 Characters Per Inch
101 HP LaserJet II 12 Characters Per Inch
102 HP LaserJet II Carriage Return
103 HP LaserJet II Courier Font: 10 CPI
104 HP LaserJet II Courier Font: 12 CPI
105 HP LaserJet II Double Strike On
106 HP LaserJet II Double Strike Off
107 HP LaserJet II Font Stroke Weight : Bold
108 HP LaserJet II Font Stroke Weight : Normal
109 HP LaserJet II Form Feed
110 HP LaserJet II Italics Off
111 HP LaserJet II Italics On
112 HP LaserJet II Landscape
113 HP LaserJet II Line Feed
114 HP LaserJet II Line Printer Font: 16.6 CPI
115 HP LaserJet II lines/inch: 1
116 HP LaserJet II lines/inch: 2
117 HP LaserJet II lines/inch: 3
118 HP LaserJet II lines/inch: 4
119 HP LaserJet II lines/inch: 6
120 HP LaserJet II lines/inch: 8
121 HP LaserJet II lines/inch:12
122 HP LaserJet II lines/inch:16
123 HP LaserJet II lines/inch:24
124 HP LaserJet II lines/inch:48
125 HP LaserJet II Master Reset
126 HP LaserJet II Paper Size: A4
127 HP LaserJet II Paper Size: C5

Sheet1

- 128 HP LaserJet II Paper Size: COM 10 [Envelope]
- 129 HP LaserJet II Paper Size: DL
- 130 HP LaserJet II Paper Size: Executive
- 131 HP LaserJet II Paper Size: Legal
- 132 HP LaserJet II Paper Size: Letter
- 133 HP LaserJet II Paper Size: Monarch
- 134 HP LaserJet II Paper Source: Manual Envelope Feed
- 135 HP LaserJet II Paper Source: Manual Feed
- 136 HP LaserJet II Paper Source: Paper Cassette
- 137 HP LaserJet II Points: 8
- 138 HP LaserJet II Points: 10
- 139 HP LaserJet II Points: 12
- 140 HP LaserJet II Points: 14
- 141 HP LaserJet II Portait
- 142 HP LaserJet II Raster Graphics: 100 DPI resolution
- 143 HP LaserJet II Raster Graphics: 150 DPI resolution
- 144 HP LaserJet II Raster Graphics: 300 DPI resolution
- 145 HP LaserJet II Raster Graphics: 75 DPI resolution
- 146 HP LaserJet II Raster Graphics: End Graphics
- 147 HP LaserJet II Raster Graphics: Start at current position
- 148 HP LaserJet II Raster Graphics: Start at left most position
- 149 HP LaserJet II Self test
- 150 HP LaserJet II Set Left Margin: 1 line
- 151 HP LaserJet II Set left margin: 2 Lines
- 152 HP LaserJet II Set Left Margin: 4 lines
- 153 HP LaserJet II Set Left Margin:10 lines
- 154 HP LaserJet II Set Page Length: 56
- 155 HP LaserJet II Set Page length: 60
- 156 HP LaserJet II Set Page Length: 65
- 157 HP LaserJet II Set Top Margin: 1 line
- 158 HP LaserJet II Set Top Margin: 2 Lines
- 159 HP LaserJet II Set Top Margin: 4 lines
- 160 HP LaserJet II Set Top Margin:10 lines
- 161 HP LaserJet II Spacing: Fixed
- 162 HP LaserJet II Spacing: Proportional
- 163 HP LaserJet II Underline Off
- 164 HP LaserJet II Underline On

88888888 Autostart codes:

CODES,C,88
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31,13
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,38

27,79
27,31
27,31,25
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1

Sheet1

27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,45
27,45,1
27,85,1
27,84
27,83
27,65,251
27,120,1
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,32,27,120,27,80
27,70
27,69
27,64,32,32,32,32,32,32,32,32,32,32,32,32,93
27,53
27,52
27,33,251
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251

27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45

27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,32,27,120,32,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251

27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53,27,116,1
27,116,32,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,38
27,79
27,31
27,31,25

27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1

27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251

Sheet1

27,68,251,251,251,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,85
27,84
27,72
27,73
31
30
27,81
27,84
27,72
27,73
27,113
27,112
27,117
27,116
27,57
27,56
18,27,72
26
27,72
27,73
31
30
18,27,72
27,72
27,73
31
30
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18

Sheet1

27,119
27,119,1
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1

18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48

Sheet1

27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
18,27,72
27,37,10
27,50
27,48
27,72
27,71
27,40
27,40
27,45,48
27,45,1
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251

27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83

27,45
27,45,1
27,85,1
27,65,251
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,30,9
27,30,7
17
17
27,82
27,69

27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,38
27,79
27,31
27,31,25
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251

Sheet1

27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,80
27,69
27,54
17
17
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85

27,68
27,82
27,69
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38

Sheet1

27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,78
27,69
27,65
27,66
27,34
27,33
17
17
27,89
27,88
27,120,1,27,80
18,27,87,27,120,27,77
27,65,6
27,80,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71

27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,69,49,50
27,69,49,48
27,76,48,56
27,76,48,54
27,38
27,79
27,82
27,95
27,40,115,49,48,72
27,40,115,49,50,72
27,38,108,55,46,50,55,67
27,38,108,53,46,52,53,67
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
40,79,93,32,83,69,77,32,54,59,32,69,88,73,84,59,27,69
40,79,93,32,83,69,77,32,54,59,32,69,88,73,84,59,27,69
27,38,100,64
27,38,100,68
27,31

27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70

Sheet1

27,69
27,64
27,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48

Sheet1

27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79

27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,38
27,85
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76

27,57
27,48
27,49
27,84
27,68
27,85
27,68
27,82
27,69
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,79
27,58,27,13,80
27,58,27,13,80
27,82
27,69
155,48,32,75
155,49,32,75
155,48,32,66
155,52,32,66
155,50,50,109
155,49,109
155,50,50,109
155,51,109
27,99
27,99
155,50,52,109
155,52,109
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69

Sheet1

27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251

Sheet1

27,68,251,251,251,251,251,251,251,251,251,251

27,79

27,78,251

27,84

27,83,1

27,84

27,83

27,45

27,45,1

27,85,1

27,65,251

27,91,49,119

27,91,50,119

27,91,49,122

27,91,50,122

27,91,48,109

27,91,52,109

27,80

18,27,87,27,77

27,65,6

15

27,50

27,48

27,74,251

27,85

27,70

27,69

18

27,72

27,71

27,87

27,87,1

18,27,87,27,120,27,80

27,70

27,69

27,64

27,53

27,52

27,33,251

27,120,1

27,112

27,112,1

27,82,251

27,108,251

27,81,251

27,68,251,251,251,251,251,251,251,251,251,251

27,79

27,78,251

27,84

27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
18,27,87,32,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
18,27,72
27,77
27,50

27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,120,1,27,80
18,27,87,27,120,27,77
27,65,6
27,80,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1

27,65,251
18
15
12
27,70
27,69
27,87,0
27,87,1
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45

Sheet1

27,45,1
27,85,1
27,65,251
27,5
27,4
27,120,1
27,120,1
27,80
27,77
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,80
27,77
27,64
27,45,48
27,45,49
27,80
27,69
27,54
17
17
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,70
17,27,13,80
17,27,13,80
27,82
27,69
27,80
27,69
27,56,48,56
27,56,48,54
27,38
27,79
17,27,26,83
17,27,26,83
27,74
27,73

Sheet1

29
30
27,66,44,56,44,36
27,66,44,54,44,36
27,101
27,100
17,24
17,24
27,102,44,48,44,36
27,102,44,49,44,36
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,91,49,119
27,91,50,119
27,91,49,122
27,91,50,122
27,36,50
27,36,49

27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,40,115,48,66
27,40,115,51,66
27,57
27,38,108,48,72
27,38,115,49,67
27,38,115,48,67
27,38,108,51,72
12
27,61
27,40,115,48,83

27,40,115,49,83
10
27,38,108,49,68
27,38,108,50,68
27,38,108,51,68
27,38,108,52,68
27,38,108,54,68
27,38,108,56,68
27,38,108,49,50,68
27,38,108,49,54,68
27,38,108,50,52,68
27,38,108,52,56,68
27,38,108,48,76
27,38,108,49,76
27,38,107,49,87
27,38,107,48,87
27,38,107,50,87
27,40,115,48,80
27,40,115,49,80
27,69
27,40,115,49,48,72
27,40,115,49,50,86
27,40,115,49,54,72
27,40,115,50,48,72
27,40,115,53,72
27,40,115,54,86
27,40,115,49,81
27,40,115,50,81
27,122
27,38,108,49,79
27,38,97,49,76
27,38,97,50,76
27,38,97,52,78
27,38,97,49,48,76
27,38,108,53,54,80
27,38,108,54,48,80
27,38,108,54,53,80
27,38,108,26,65
27,38,108,81,65
27,38,108,3,65
27,38,108,2,65
27,38,108,48,79
27,38,108,49,69
27,38,108,50,69
27,38,108,52,69
27,38,108,49,48,69
27,40,115,45,49,85
27,40,115,43,49,85
27,40,115,48,85

27,38,107,53,87
27,38,107,54,87
27,38,108,49,72
27,38,100,64
27,38,100,2,68
27,38,100,4,68
27,38,100,1,68
27,38,100,3,68
27,38,107,48,69
27,38,107,49,69
27,31,11
27,31
27,31,11,27,80
27,79
27,81
27,31,25
27,38
27,79
27
27,31
27,49
27,30
27,38
27,87
27,31,9
27,31,11
27,30,5
27,30,9
27,31
27,11,251
27,9,251
27,57
27,48
27,68
27,85
27,85
27,68
27,82
27,69
27,88,27,81
27,31
27,38
27,63
27,60
8
27,8
27,10
27,38
27,79

13
27,50
27,88
27,56
27,67
27,62
27,33
27,25,82
12
27,85
9
27,66
27,65
10
27,61
29
27,90
27,89
27,68
27,77
15
27,15
27,23,1
27,23,2
27,23,3
14
27,76
27,49
27,57
27,12,66
27,48
27,84
27,45
32
27,32,54
27,87
27,52
22,55
27,9,1
27,9,8
27,82
27,69
11
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,87

Sheet1

27,13,80
27,13,80
27,82
27,69
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48

27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,70
17,27,13,80
17,27,13,80
27,82
27,69
27,80,18,27,72
27,77,18,27,72
27,50
27,48

Sheet1

27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
24
18
15
27,119,0,0
27,119,1
27,87,0,0
27,87,1
27,70
27,69
27,72
27,71
12
27,40,1
27,40,0,0
27,53
27,52
10
27,56
27,57
27,85,0,0
27,107,0,0
27,115,0,0
27,115,1
27,107,1
17
19
27,85,1
27,112,0,0
27,112,1
27,64
27,80
27,77
27,120,1
27,120,0,0
27,67,0,0,11
27,67,0,0,14
27,67,56
27,67,65
27,97,1
27,97,3
27,97,0

27,97,2
27,50
27,48
27,49
27,84
27,83,1
27,84
27,83,0,0
27,45,0,0
27,45,1
27,80,18,27,72
27,77,18,27,72
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80

27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76

Sheet1

27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,80,18,27,72
27,77,18,27,72
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
18,27,72
27,50
27,48
27,72
27,71
27,45,48
27,45,1
18
15
27,72
27,71
12
27,70
27,69
27,87,0
27,87,1
27,53
27,52
27,64
27,45,0
27,45,1
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85

Sheet1

27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69

Sheet1

27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251

27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1

Sheet1

27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85

27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31,13
27,31,11
27,30,5
27,31,9,27,38
27,30,9,27,85
27,30
27,38
27,79
27,38
27,79
27,31
27,31,25
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81

Sheet1

27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,68
27,82
27,69
27,88,27,81
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,38
27,79
27,31
27,31,25
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38

27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,80,18,27,72
27,77,18,27,72
27,50
27,48
27,70
27,69
27,64
27,64
27,45,48
27,45,49
27,38,107,48,83
27,38,108,54,68
27,38,108,56,68
27,40,115,48,66
27,40,115,49,66
27,69
27,69
27,38,100,64
27,38,100,68
27,40,115,49,48,72
27,40,115,49,50,72
27,38,108,54,68
27,38,108,56,68

27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,69
27,69
27,38,100,64
27,38,100,68
27,40,115,49,48,72
27,40,115,49,50,72
27,38,108,54,68
27,38,108,56,68
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,69,27,38,108,54,101,53,52,70
27,69,27,38,108,54,101,53,52,70
27,38,100,64
27,38,100,68
27,40,115,49,48,72
27,40,115,49,50,72
27,38,108,54,68
27,38,108,56,68
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,69,27,38,108,51,101,54,51,70
27,69,27,38,108,51,101,54,51,70
27,38,100,64
27,38,100,68
27,38,107,48,83
27,38,107,52,83
27,38,108,54,68
27,38,108,56,68
27,40,115,48,66
27,40,115,49,66
27,69
27,69
27,38,100,64
27,38,100,68
27,38,107,49,50,72
27,38,107,49,48,72
27,38,108,55,46,50,55,67
27,38,108,53,46,52,53,67
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83

Sheet1

27,40,115,49,83
27,69
27,69
27,38,100,64
27,38,100,68
27,122
18,27,72
27,58
27,50
27,48
27,72
27,71
27,54
27,54
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
27,72
27,71
18,27,72
27,58
27,50
27,48
27,72
27,71
27,63
27,63
27,45,48
27,45,1
27,58
27,80,0
27,80,1
18
27,72
27,72
27,70
27,87,0
27,79
27,84
27,48
18
18
27,58
15,27,87,1
15
27,85,0

15
27,73,3
27,71
27,71
27,69
27,87,1
27,55
27,54
27,73,1
27,73,1
27,73,1
27,73,2
27,73,4
27,83,0
27,85,1
27,78,4
27,65,12,27,50
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77

27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82

Sheet1

27,38,100,64
27,38,100,68
27,38,108,251,68
18,27,72
27,58
27,50
27,48
27,112,27,53
27,112,27,53
27,45,48
27,45,1
18,27,72
27,50
27,48
27,70
27,69
1
1
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
27,72
27,71
27,45,48
27,45,1
15,27,88,1,132
27,88,1,158
27,50
27,48
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
27,70
27,69
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
17
17
27,45,48

27,45,1
29
30
27,66,44,56,44,36
27,66,44,54,44,36
17
17
29
30
27,66,44,56,44,36
27,66,44,54,44,36
17
17
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,38,108,49,79
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,38,108,48,79
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76

Sheet1

27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,80
18,27,87,27,77
27,65,6
15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77

Sheet1

27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31,13
27,30,9
27,30,7
27,38
27,79
27,26,73,27,81
27,26,73,27,81
27,82
27,69
27,40,115,49,48,72
27,40,115,49,50,72

Sheet1

33,82,33,32,83,84,77,32,49,48,50,59,32,83,76,80,80
33,82,33,32,83,84,77,32,56,53,59,32,83,76,80,80,32
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,38,100,64
27,38,100,68
27,40,115,49,48,72
27,40,115,49,50,72
33,82,33,32,83,84,77,32,49,51,50,59,32,83,76,80,80
33,82,33,32,83,84,77,32,49,49,48,59,32,83,76,80,80
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,38,100,64
27,38,100,68
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68

27,82
27,69
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,120,1,27,80
18,27,87,27,120,27,77
27,65,6
27,80,15
27,50
27,48

27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,120,1,27,80
18,27,87,27,120,27,77
27,65,6
27,80,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87

27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86

Sheet1

27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,91,52,119
27,91,53,119
27,91,51,122
27,91,52,122
27,91,62,122
27,91,61,122
27,91,54,126
27,91,54,126
27,91,48,109
27,91,52,109
18,27,72
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,38
27,85
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30

Sheet1

27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57

Sheet1

27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31
27,31
27,31,11
27,31,11
27,31,11
27,30,5
27,30,5
27,30,5
27,31,9
27,31,9
27,31,9
27,30,9
27,30,9
27,30,9
27,30
27,30
27,30
27,38
27,38
27,38
27,79
27,79
27,79
27,31
27,31
27,31
27,38
27,38
27,38
27,79
27,79
27,79
27,31
27,31
27,31
27,31,25
27,31,25
27,31,25
27,31

27,31
27,31
27,38
27,38
27,38
27,87
27,87
27,87
27,88,27,81
27,88,27,81
27,88,27,81
27,9,251
27,9,251
27,9,251
27,11,251
27,11,251
27,11,251
27,11,251
27,31,11
27,31,11
27,31,11
27,81
27,81
27,81
27,31,11,27,80
27,31,11,27,80
27,31,11,27,80
27,76
27,76
27,76
27,57
27,57
27,57
27,48
27,48
27,48
27,49
27,49
27,49
27,84
27,84
27,84
27,68
27,68
27,68
27,85
27,85
27,85
27,85
27,85

27,85
27,68
27,68
27,68
27,82
27,82
27,82
27,69
27,69
27,69
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82

Sheet1

27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,63,49
27,63,51
27,50
27,48

27,72
27,71
27,45,48
27,45,49
27,80
27,77
27,50
27,48
27,70
27,69
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,80
27,77
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,49
27,83
27,73
27,50
27,48
27,70
27,69
27,35,65
27,35,65
27,39
27,45
27,40,115,49,48,72
27,40,115,49,50,72
27,38,108,55,46,50,55,67
27,38,108,53,46,52,53,67
27,40,115,48,66
27,40,115,51,66
27,40,115,48,83
27,40,115,49,83
27,69
27,69
27,38,100,64

27,38,100,68
27,83
27,73
27,50
27,48
27,70
27,69
27,61
27,61
27,39
27,45
27,93,76
27,93,74
27,93,87
27,93,85
27,93,76
27,93,74
27,93,87
27,93,85
27,44
27,42
27,35,66
27,35,66
27,39
27,45
27,93,76
27,93,74
27,93,87
27,93,85
27,38
27,79
27,26,82
27,26,82
27,82
27,69
27,93,76
27,93,74
27,93,87
27,93,85
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251
27,85
27,70
27,69

18
27,119
27,119,1
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,38,108,48,79,27,40,48,85,27,40,115,49,112,49,48
27,40,115,49,50,72,27,38,108,48,79,27,40,48,85,27,
27,38,108,54,68
27,38,108,56,68
27,40,115,48,66
27,40,115,49,66
27,40,115,48,83
27,40,115,49,83
27,69
27,69
27,38,100,64
27,38,100,68
18,27,72
27,58

Sheet1

27,51,36
27,48
27,72
27,71
27,45,48
27,45,49
30
28
27,54
27,56
27,73
27,84
27,33,42
27,33,47
24
24
27,68
27,67
30
28
27,54
27,56
27,73
27,84
27,33,47
27,33,42
24
24
27,68
27,67
30
27,54
27,56
30
28
27,54
27,56
27,73
27,72
24
24
27,68
27,67
18,27,72
27,58
27,50
27,65,12
27,37,72
27,37,71

Sheet1

27,45,48
27,45,1
27,54
27,65
27,52
27,53
27,86
27,85
27,54
27,65
24
24
18,27,72
27,58
27,50
27,48
27,72
27,71
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
27,72
27,71
27,37,72
27,37,71
24
24
27,45,48
27,45,1
18,27,72
27,58
27,50
27,48
18,27,72
27,58
27,50
27,48
27,72
27,71
24
24
27,45,48
27,45,1
18
27,58
15

27,70
27,69
12
27,72
27,71
27,37,72
27,37,71
28
30
29
27,54
27,56
24
30
27,49
31
27,73
27,84
27,73
27,72
30
12
27,48
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,38,108,49,79
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83

Sheet1

27,38,108,48,79
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251

Sheet1

27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11

Sheet1

27,30,5
27,31,9
27,30,9
27,30
27,38
27,38
27,79
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,38
27,87
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,68
27,85
27,85
27,85
27,85
27,68
27,68
27,82
27,82
27,69
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79

Sheet1

27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57

27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64

Sheet1

27,38,100,68
27,38,108,251,68
27,80
27,77
27,50
27,48
27,72
27,71
27,53
27,52
27,54
27,54
27,45,48
27,45,1
27,80,1
27,80
27,50
27,48
27,72
27,71
27,53
27,52
17,27,64
17,27,64
27,45,48
27,45,1
27,80
27,77
27,50
27,48
27,72
27,71
27,53
27,52
17,27,64
17,27,64
27,45,48
27,45,1
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,79
27,26,73
27,26,73
27,82
27,69
27,40,115,112,49,48,72

Sheet1

27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66

27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66

27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,53,0,0
27,53,1
7
24
15
27,91,64,4,0,0,0,0,0,0,1,0,0
27,91,64,4,0,0,0,0,0,0,2,0,0
27,91,64,4,0,0,0,0,0,0,32,0,0
27,91,64,4,0,0,0,0,0,0,0,0,1
27,91,64,4,0,0,0,0,0,0,0,0,2
27,70
27,69
27,72
27,71
12
27,37,72
27,37,71
10
27,95,0,0
27,95,1
27,56
27,57

Sheet1

27,85,0,0
27,85,1
27,80,0,0
27,80,1
27,93
18
27,58
27,73,0
27,73,4
27,73,0
27,73,5
27,73,1
27,73,3
27,73,7
27,73,2
27,73,6
27,67,0,0,11
27,67,0,0,14
27,67,56
27,67,65
27,48
27,49
27,52
27,91,64,4,0,0,0,0,0,0,16,0,0
27,84
27,83,1
27,84
27,83,0,0
27,45,0,0
27,45,1
27,31,13
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,38
27,79
27,31
27,31,25
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81

27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,79
27,38
27,87
27,124,49,101,27,26,73,27,124,49,115,27,124,50,105
27,124,49,101,27,26,73,27,124,49,115,27,124,50,105
27,74
27,73
27,78
27,70,6
27,70,8
17
17
27,30,8
27,30,6
27,26,73
27,26,73
27,74
27,73
27,31,12
27,31,10
27,30,56
27,30,54
27,77
27,75,2
27,26,73
27,26,73
27,74
27,73
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72

27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66

Sheet1

27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,38,108,49,79
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,38,108,48,79
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,80
27,77
27,51,15
27,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87

Sheet1

27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,31,12
27,31,10
27,30,8
27,30,6
27,13,80
27,13,80
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87

27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53
27,52

Sheet1

27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251,251
27,79

Sheet1

27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,38
27,79
27,82
27,69
27,31,12
27,31,10
27,30,9
27,30,7
27,13,80
27,13,80
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,79
27,13,80
27,13,80
27,82
27,69
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,53

Sheet1

27,52
27,33,251
27,120,1
27,112
27,112,1
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,80
27,77
27,65,6
27,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,32,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251

Sheet1

27,68,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,66,1
27,66,2
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,120,1,27,80
18,27,87,27,120,27,77
27,65,6
27,80,15
27,50
27,48
27,74,251
27,85
27,70
27,69
18
27,72
27,71
27,87
27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53
27,52
27,33,251
27,120,1
27,112
27,112,1

Sheet1

27,107,251
27,82,251
27,108,251
27,81,251
27,68,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,120,1,27,80
18,27,87,27,120,27,77
27,51,18
27,80,15
27,50
27,48
27,51,251
27,85
27,70
27,69
18
27,119
27,119,1
27,72
27,71
27,87
27,80,27,87,1
18,27,87,27,120,27,80
27,70
27,69
27,64
27,251
27,53,27,116,1
27,116,27,52
27,33,251
27,36,251,251
27,92,251,251
27,120,1
27,112
27,112,1
27,107,251
27,82,251
27,108,251
27,81,251

Sheet1

27,68,251,251,251,251,251,251,251,251,251,251,251,251,251
27,79
27,78,251
27,84
27,83,1
27,84
27,83
27,45
27,45,1
27,85,1
27,65,251
27,50
27,48
18
27,15
27,70
27,69
27,87,0
27,87,1
12
17
27,53
27,52
27,64
27,12,00
27,12,01
27,112,48
27,112,49
27,67
27,37,10
27,37,00
27,120,48
27,53
27,66,1
27,66,2
27,50
27,48
27,72
27,71
27,53
27,52
27,64
27,64
27,45,48
27,45,1
27,31
27,31,11
27,30,5
27,31,9

Sheet1

27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11
27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,31
27,31,11
27,30,5
27,31,9
27,30,9
27,30
27,38
27,79
27,31
27,38
27,79
27,31
27,31,25
27,31
27,38
27,87
27,88,27,81
27,9,251
27,11,251
27,31,11

Sheet1

27,81
27,31,11,27,80
27,76
27,57
27,48
27,49
27,84
27,68
27,85
27,85
27,68
27,82
27,69
27,32
27,31
27,19
27,23
27,19
27,20
27,15
27,14
27,66,0
27,66,1
27,19
27,12
27,121
27,122
27,30,9
27,30,7
27,82
27,77
27,75,4
27,100
27,113
17
27,102,1
27,102,3
27,102,2
27,81
17
27,74
27,73
27,121
27,122
27,50
27,48
27,82
27,72
27,71

Sheet1

27,100
27,113
27,64
27,102,1
27,102,3
27,102,2
27,81
27,64
27,74
27,73
27,31,11
27,30,9
27,30,7
27,82
27,81
27,20
27,18,27,72
27,26,73
27,26,73
27,74
27,73
27,30,9
27,30,7
27,26,73
27,26,73
27,74
27,73
27,31,11
27,30,9
27,30,7
27,26,73
27,26,73
27,74
27,73
27,31,11
27,30,9
27,30,7
27,26,73
27,26,73
27,74
27,73
27,52
27,71
27,52
27,51
27,90
27,87
27,89
27,46

7
27,77
27,75,1
27,75,2
27,63
27,61
27,93
27,91
27,118,48
27,118,49
27,34
27,33
12
27,85
27,95,1
27,20
27,18
10
27,95,0
27,68
27,10
27,95,2
27,60
27,62
27,37
27,36
27,26,73
27,89
27,79
27,47,0
27,47,1
27,42,0
27,42,4
27,42,2
27,42,3
27,42,1
27,45
27,57
27,48
27,43
27,82
27,81
27,54
27,53
27,126,83,48,49,48
27,126,83,48,49,50
27,126,83,48,49,48
27,126,83,48,49,49
27,74

Sheet1

27,73
27,52
27,71
27,52
27,51
27,90
27,87
27,46
27,44
7
27,77
27,75,1
27,75,2
27,63
27,61
27,93
27,91
27,34
27,33
12
27,85
27,20
27,18
27,42,3
10
27,68
27,10
27,60
27,62
27,37
27,36
27,26,73
27,89
27,79
27,102
27,47,0
27,47,1
27,95,1
27,42,4
27,42,1
27,121
27,109
27,99
27,98
27,95,0,0
27,45
27,57
27,48
27,43

27,82
27,81
27,54
27,53
27,74
27,73
27,40,115,112,49,48,72
27,40,115,112,49,50,72
27,38,108,49,50,68
27,40,115,112,49,54,46,54,54,72
27,38,108,54,68
27,38,108,56,68
27,38,108,251,67
27,40,115,48,66
27,40,115,51,66
27,40,115,112,49,48,72
27,40,115,48,66
27,40,115,51,66
27,40,115,49,112,49,52,46,52,86
27,40,115,48,66
27,40,115,51,66
27,69
27,38,107,251,72
27,40,115,48,83
27,40,115,49,83
27,40,115,251,84
27,38,97,251,72
27,38,97,251,86
27,38,97,251,251,72
27,38,97,251,251,86
27,38,102,49,83
27,40,115,48,80
27,40,115,49,80
27,38,102,48,83
27,40,115,251,84
27,40,251,251
27,38,97,251,76
27,38,97,251,77
27,38,108,251,69
27,38,108,48,76
27,38,108,49,76
27,38,97,45,46,53,82
27,61
27,61
27,38,97,45,46,53,82
27,38,100,64
27,38,100,68
27,38,108,251,68
27,112

27,98
27,43,88,10
27,43,88,10
27,87
27,85
27,31,13
27,31,11
27,30,9
27,30,7
27,38
27,87
27,82
27,69
27,38,107,48,83
27,38,107,52,83
27,38,107,50,83
27,40,115,51,66
27,40,115,48,66
12
27,38,108,49,68
27,38,108,50,68
27,38,108,51,68
27,38,108,52,68
27,38,108,54,68
27,38,108,56,68
27,38,108,49,50,68
27,38,108,49,54,68
27,38,108,50,52,68
27,38,108,52,56,68
27,38,108,49,79
27,38,108,48,79
27,38,108,50,54,65
27,38,108,57,48,65
27,38,108,45,57,48,65
27,38,108,49,65
27,38,108,51,65
27,38,108,50,65
27,38,108,45,56,49,65
27,38,108,48,72
27,38,108,51,72
27,38,108,49,72
27,40,115,56,86
27,40,115,49,48,86
27,40,115,49,50,86
27,40,115,49,52,86
27,38,107,49,87
27,38,107,48,87
27,38,107,50,87
27,40,115,49,81

Sheet1

27,40,115,50,81
27,42,116,49,48,48,82
27,42,116,49,53,48,82
27,42,116,51,48,48,82
27,42,116,55,53,82
27,42,114,98,65
27,42,114,49,65
27,42,114,48,65
27,69
27,122
27,38,97,49,76
27,38,97,50,76
27,38,97,52,78
27,38,97,49,48,76
27,38,108,53,54,80
27,38,108,54,48,80
27,38,108,54,53,80
27,38,108,49,69
27,38,108,50,69
27,38,108,52,69
27,38,108,49,48,69
27,40,115,48,80
27,40,115,49,80
27,40,115,49,83
27,40,115,48,83
27,40,115,52,49,48,49,84
27,40,115,51,84
27,40,115,54,84
27,40,115,53,50,84
27,38,100,64
27,38,100,49,68
27,38,100,51,68
27,38,107,48,83
27,38,107,52,83
27,38,107,50,83
27,38,108,49,83
27,38,108,50,83
27,40,115,53,66
27,40,115,51,66
27,40,115,50,66
27,40,115,45,50,66
27,40,115,54,66
27,40,115,52,66
27,40,115,45,52,66
27,40,115,45,54,66
27,40,115,45,51,66
27,40,115,48,66
27,40,115,49,66
27,40,115,45,49,66

27,40,115,45,53,66
27,40,115,55,66
27,40,115,45,55,66
12
27,38,108,49,68
27,38,108,50,68
27,38,108,51,68
27,38,108,52,68
27,38,108,54,68
27,38,108,56,68
27,38,108,49,50,68
27,38,108,49,54,68
27,38,108,50,52,68
27,38,108,52,56,68
27,38,108,49,79
27,38,108,48,79
27,38,108,51,79
27,38,108,50,79
27,38,108,50,54,65
27,38,108,57,49,65
27,38,108,56,49,65
27,38,108,57,48,65
27,38,108,49,65
27,38,108,51,65
27,38,108,50,65
27,38,108,56,48,65
27,38,108,48,72
27,38,108,51,72
27,38,108,50,72
27,38,108,49,72
27,40,115,56,86
27,40,115,49,48,86
27,40,115,49,50,86
27,40,115,49,52,86
27,69
27,38,97,49,76
27,38,97,50,76
27,38,97,52,78
27,38,97,49,48,76
27,38,108,53,54,80
27,38,108,54,48,80
27,38,108,54,53,80
27,38,108,49,69
27,38,108,50,69
27,38,108,52,69
27,38,108,49,48,69
27,38,108,48,83
27,40,115,48,80
27,40,115,49,80

Sheet1

27,40,115,56,83
27,40,115,52,83
27,40,115,53,83
27,40,115,50,52,83
27,40,115,54,52,83
27,40,115,49,83
27,40,115,51,50,83
27,40,115,49,54,48,83
27,40,115,49,50,56,83
27,40,115,48,83
27,40,115,52,51,54,50,84
27,40,115,52,49,54,56,84
27,40,115,52,49,48,49,84
27,40,115,52,49,49,54,84
27,40,115,52,48,57,57,84
27,40,115,52,49,48,50,84
27,40,115,52,49,52,56,84
27,40,115,54,56,50,54,84
27,38,100,64
27,38,100,48,68
27,38,100,51,68
27,40,115,49,48,72
27,40,115,49,50,72
13
27,69
27,40,115,49,50,72
27,40,115,51,66
27,40,115,48,66
27,40,115,51,66
27,40,115,48,66
12
27,40,115,48,83
27,40,115,49,83
27,38,108,49,111
10
27,40,115,49,54,46,54,72
27,38,108,49,68
27,38,108,50,68
27,38,108,51,68
27,38,108,52,68
27,38,108,54,68
27,38,108,56,68
27,38,108,49,50,68
27,38,108,49,54,68
27,38,108,50,52,68
27,38,108,52,56,68
27,69
27,38,108,50,54,65
27,38,108,57,49,65

Sheet1

27,38,108,56,49,65
27,38,108,57,48,65
27,38,108,49,65
27,38,108,51,65
27,38,108,50,65
27,38,108,56,48,65
27,38,108,51,72
27,38,108,50,72
27,38,108,49,72
27,40,115,56,86
27,40,115,49,48,86
27,40,115,49,50,86
27,40,115,49,52,86
27,38,108,48,111
27,42,116,49,48,48,82
27,42,116,49,53,48,82
27,42,116,51,48,48,82
27,42,116,55,53,82
27,42,114,98,65
27,42,114,49,65
27,42,114,48,65
27,122
27,38,97,49,76
27,38,97,50,76
27,38,97,52,78
27,38,97,49,48,76
27,38,108,53,54,80
27,38,108,54,48,80
27,38,108,54,53,80
27,38,108,49,69
27,38,108,50,69
27,38,108,52,69
27,38,108,49,48,69
27,40,115,48,80
27,40,115,49,80
27,38,100,64
27,38,100,68