




Codes for Pioneer.

Code length 32 bits.  
Carrier: 40kHz



T=500us approx

Example to play a pioneer CD:

```

\<< PION                               @ get info string #45BAh #10000h * E817h +   @ get the
data TRANSMIT                           @ transmit \>>

```

\*\*\*\*\*

Pioneer

```

-----
Amp: 659A
Power           38C7
Vol +           50AF
Vol -           D02F
Dat/Video 31CE
Phono           30CF
CD direct 59A6
Surround 7A85

```

```

-----
Tape: 659A      Deck a   Deck b
Play           5AA5     E817
RewPlay        9A65     A857
Stop           DA25     6897
Rew            6A95     8877
FF             EA15     08F7
Pause         18E7
Rec           28D7

```

```

-----
CD: 45BA
Play           E817
Stop           6897
Rew            8877
FF             08F7
Pause         18E7
Disc          B847

```

-----  
Tuner: 25DA  
Station + 08F7  
Station - 8877

-----  
Eq: 05FA  
On/Off           BC43  
Select            0CF3

-----  
Timer: 659A  
Sleep            9867  
Wake up         738C  
Snooze           B34C