

<b>Make/Model</b>	<b>Battery (Std)</b>	<b>Battery (Extended)</b>	<b>Battery (Slim)</b>	<b>Plug-in Charger</b>	<b>Leather Case</b>
<b>Alcatel</b>					
HC300/HC500	FLBT3ST £12.99	FLBT3EX £19.99	FLBT3SB £29.99	FLBT3PC £ 8.99	FLBT3LC £ 6.99
<b>Amstrad</b>					
600	FLDC1ST £12.99	FLDC1EX £19.99	FLDC1SB £29.99	FLDC1PC £ 8.99	FLDC1LC £ 6.99
<b>Dancal</b>					
DC1	FLDC1ST £12.99	FLDC1EX £19.99	FLDC1SB £29.99	FLDC1PC £ 8.99	FLDC1LC £ 6.99
<b>Ericsson</b>					
EH237/MD200	FLE2ST			FLE2PC	FLE2LC
EH338	£12.99			£ 8.99	£ 6.99
<b>Maxon Amber</b>					
BT CMH400		FLBTM4EX £ 19.99	FLBTM4SB £29.99		FLBTM4L £ 6.99
<b>Mercury One2One</b>					
M300/M301	FLM30070			FLM090PC	FLBTM3L
M400	£12.99			£ 8.99	£6.99
<b>Mitsubishi</b>					
MT7/MT8/MT9	FLMIST £12.99			FLMIPC £ 8.99	FLMILC £ 6.99
<b>Mitsubishi</b>					
MT20	FLMT20ST £12.99	FLMT20EX £19.99	FLMT20SB £29.99	FLMT20PC £ 8.99	FLMT20LC £ 6.99
<b>Motorola/Microtac/Bosch</b>					
9800, Classic	FLM09STB	FLM09EXB		FLM09PC	FLM09LCF
5200/7200	£12.99	£19.99		£ 8.99	£ 6.99
<b>Motorola</b>					
Flip phone	FLM09STG	FLM09EXG		FLM09PC	FLM09LCF
Roadstar	£12.99	£19.99		£ 8.99	£ 6.99
<b>Motorola</b>					
Flare	FLM09STB	FLM09EXB		FLM0EPC	FLM0FLC
Elite, 8200	£12.99	£19.99		£ 8.99	£ 6.99
<b>NEC</b>					
G8	FLNG8ST £12.99	FLNG8EX £19.99	FLNG8SB £29.99	FLNG8PC £ 8.99	FLNG8LC £ 6.99
<b>NEC</b>					
P3	FLNP3ST £12.99				FLNP3LC £ 6.99
<b>NEC</b>					
P4	FLNP4STG £12.99			FLNP4PC £ 8.99	FLNP4LC £ 6.99
<b>NEC</b>					
P7	FLNP7ST £12.99			FLNP7PC £ 8.99	FLNP7LC £ 6.99
<b>NEC</b>					
P8 (Blue)	FLNP8ST £12.99	FLNP8EX £19.99	FLNP8SB £29.99	FLNP7PC £ 8.99	FLNP8LC £ 6.99
<b>NEC</b>					
P100	FLNP1070			FLNP10PC	FLNP10LC
BT Jet/Jade	£12.99			£ 8.99	£ 6.99
<b>Nokia</b>					
101/121/TP4	FLNO101S £12.99			FLNO101P £ 8.99	FLNO101L £ 6.99

<b>Nokia</b> 232/500	FLNO232S £12.99			FLORPC £ 8.99	FLNO232L £ 6.99
<b>Nokia</b> 909	FLNO09ST £12.99	FLNO09EX £19.99	FLNO09SB £29.99	FLNO09PC £ 8.99	FLNO09L £ 6.99
<b>Make/Model</b>	<b>Battery (Std)</b>	<b>Battery (Extended)</b>	<b>Battery Slim)</b>	<b>Plug-in Charger</b>	<b>Leather Case</b>
<b>Nokia</b> 1610	FLNO16ST £12.99	FLNO16EX £19.99	FLNO16SB £29.99	FLNO16PC £ 8.99	FLNO16LC £ 6.99
<b>Nokia</b> Orange 2110 OKI 1130/1150	FLOK50ST £12.99	FLOREX £19.99		FLOK50PC £ 8.99	FLOK30LC £ 6.99
<b>OKI</b> 1325	FLOK25ST £12.99	FLOK25EX £19.99	FLOK25SB £29.99	FLOK25PC £ 8.99	FLOK25LC £ 6.99
<b>Orbitel</b> 902	FLORB700 £12.99			FLORNPC £ 8.99	FLORBLC £ 6.99
<b>Orbitel</b> 905	FLORB5ST £12.99	FLORB5EX £19.99	FLORB5S £29.99	FLORB5PC £ 8.99	FLORB5LC £ 6.99
<b>Panasonic</b> "F"	FLPFST £12.99			FLPFPC £ 8.99	FLPFLC £ 6.99
<b>Panasonic</b> G400	FLPG4ST £12.99	FLPG4EX £19.99	FLPG4SB £29.99	FLPG4PC £ 8.99	FLPG4LC £ 6.99
<b>Panasonic</b> "I"	FLPIST £12.99				FLPILC £ 6.99
<b>Panasonic</b> "J"	FLPJST £12.99				FLPJLC £ 6.99
<b>Samsung</b> SH710/810	FLSH710S £12.99			FLSH710P £ 8.99	FLSH710L £ 6.99
<b>Samsung</b> SGH100	FLSGH1ST £12.99	FLSGH1EX £19.99	FLSGH1S £29.99	FLSGH1PC £ 8.99	FLSGH1LC £ 6.99
<b>Sony</b> CMH333	FLSY3ST £12.99			FLSY3PC £8.99	FLSY3LC £ 6.99
<b>Sony</b> CMR111	FLSY1ST £12.99			FLSY1PC £8.99	FLSY1LC £ 6.99
<b>Sony</b> CMDX1000	FLSYD1ST £12.99	FLSYD1EX £19.99	FLSYD1S £29.99	FLSYD1PC £ 8.99	FLSYD1L £ 6.99

**Antennas are available for some models as below:**

Ericsson EH237	FLE2WA
Mitsubishi MT7/8/9	FLMIWA
Mitsubishi MT7 (Retractable)	FLMIRA
Motorloa 9800/Flip phone	FLM9RAT1
NEC P3	FLNP3WA
NEC P7 (Rubber)	FLNP7WA
NEC P100	FLNP10WA
Nokia 101/121/TP4	FLNOWA
Nokia 101 (Retractable)	FLNORA
Nokia Orange	FLORWA
OKI 1130/1150	FLSY3WA
OKI 1130 (Retractable)	FLOK30RA
Panasonic "F","J"	FLPFWA
Panasonic "I"	FLPIWA
Sony CMH333	FLSY3WA
Sony CMR111	FLSY1WA

**Fast Charger/Dischargers are available for some models.**