

# Contents

<b>Part I</b>	<b>Getting Started</b>	<b>1</b>
	<b>Chapter 1 Introduction</b>	<b>2</b>
	Drivers and Utilities	2
	Virtual Tablet Editor	2
	Using This Manual	2
	Getting Help	3
	<b>Chapter 2 Installation and Startup</b>	<b>5</b>
	Installing the Interface	5
	Starting the Editor	5
	Screen Layout	6
	Accessing Files	7
	Exiting the Editor	7
	<b>Chapter 3 Navigation Aids</b>	<b>8</b>
	Changing Views	8
	Using Scroll Bars	8
	Keyboard Shortcuts	8
	Mouse Cursors	9
	Cursor Selections	10
	Tablet Guides	10
	Tool Bar	10
	Status Bar	10
	<b>Chapter 4 One-Minute Templates</b>	<b>11</b>
	Building	11
	Saving Files	13
	Printing	13
	Compiling	14
	Executing	14
<b>Part II</b>	<b>Creating Templates</b>	<b>17</b>
	<b>Chapter 5 Tablet Properties</b>	<b>18</b>
	Tablet Types	18
	Metric System	19
	<b>Chapter 6 Creating Regions</b>	<b>20</b>
	Drawing Regions	20
	Region Properties	20
	Selecting Regions	23
	Stretching and Moving Regions	23
	Aligning Regions	24
	Duplicating Regions	25
	Removing Regions	26
	<b>Chapter 7 Styles &amp; Combinations</b>	<b>27</b>

	Styles	27
	Default Styles	27
	Applying Styles	27
	Combinations	28
	Creating Combinations	29
	Breaking Combinations	29
<b>Chapter 8</b>	<b>Importing &amp; Exporting</b>	<b>30</b>
	Importing Graphics Files	30
	Exporting Graphics Files	31
	Editor Export Files	33
<b>Chapter 9</b>	<b>Printing</b>	<b>35</b>
	Selecting Printers	35
	Configuring Printers	35
	Printing Templates	35
	Printing Tips	37
<b>Part III</b>	<b>Tools &amp; Options</b>	<b>38</b>
<b>Chapter 10</b>	<b>Using Tools</b>	<b>39</b>
	Compiling	39
	Tracing Regions	40
	Executing Templates	40
<b>Chapter 11</b>	<b>Changing Options</b>	<b>44</b>
	Display	44
	Guides	44
	Backups	45
	Comments	46
<b>Chapter 12</b>	<b>The Clipboard</b>	<b>47</b>
	Undo	47
	Cutting	47
	Copying	47
	Pasting	48
	Viewing	48
<b>Part IV</b>	<b>Appendices</b>	<b>49</b>
Appendix A	Virtual Key Codes	50
Appendix B	Windows Driver	52
Appendix C	DOS Driver	54
Appendix D	Digitizers Supported	55