

Commands

Selecting Plotter mode from either the list box or the command menu will change the LaserJet III to the HPGL mode.

Selecting LaserJet mode from either the list box or the command menu will change the LaserJet III to the PCL5 mode.

Selecting Minimize on use will cause Qwik Change III to change to an icon whenever something is selected.

To select from the list box double click (or hit [Enter]) on the mode you want.

The last mode chosen will be displayed above the list box and checked off in the Command menu.

Command Menu

Glossary

Context Sensitive Topics