 [目次へ戻る](#)

# Elitegroup ComputerSystems BIOS

URL: <http://www.ecs.com.tw/>

'**1** FŠeff [f^, i' ~ i CE , í A "A • Ê, i' f, è, a, È, ç, ©, -, è, » , ê, ¼, ê, i ŠJ" -  
f [fj] [ , É < A ' ® , µ, Û , · B


'**2** FŽû ~ ^ Še ŽĐ, ", æ, ÑDOS/V POWER  
REPORT • Ò W • " , Å, í AfAfbfvff [fg, É, æ, é  
, ç, ©, È, é 'ŠQ, ÉŠÖ, µ, Ä, à ^ ê Ø Ó " C, ð • % , ç, Û, ¹, ñ, Ì, Å, , ç, ©, ¶, ß, ² — ¹ ³, -  
, ¾, ³, ç B

**NEW!** V < K, É Ž û ~ ^ , ¾ BIOS

**UP!** X V, ¾ BIOS

 **ft [fefBfŠfefB ^ fhfLf... f] "fg**

**BIOS flash utility Žg — p ā, i' ^ Ó i % o p ¶ j @**

 DISC2:\BIOS\ELITE\FLASH {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\FLASH\README.TXT', 1)} [à-¾, ð • Ž!](#)

**AMIFlash BIOS flash utility @**

 DISC2:\BIOS\ELITE\AMIFLASH {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\AMIFLASH\README.TXT', 1)} [à-¾, ð • Ž!](#)

**ECSFlash BIOS flash utility @**

 DISC2:\BIOS\ELITE\ECSFLASH {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\ECSFLASH\README.TXT', 1)} [à-¾, ð • Ž!](#)

**Flash3.6 BIOS flash utility @**

 DISC2:\BIOS\ELITE\FLASH36 {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\FLASH36\README.TXT', 1)} [à-¾, ð • Ž!](#)


 **Pentium II f} fU [f { [fh**

 **P6BX-A+**

**P6BX-A+ PCB V1.0, V1.1 (w/z 83781D) BIOS Ver1.3c @**

 DISC2:\BIOS\ELITE\BXAP13C {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\BXAP13C\README.TXT', 1)} [à-¾, ð • Ž!](#)

**P6BX-A+ PCB V1.1 (w/o 83781D) BIOS Ver2.3 @**


 DISC2:\BIOS\ELITE\BXAP23 {button ,EF( `..\MENUDATA\IMPVIEW', `ELITE\BXAP23\README.TXT', 1)} [à-¾, ð • Ž!](#)

 **P6KFX-A**

**P6KFX-A PCB1.1,1.2 BIOS Ver1.5**

DISC2:\BIOS\ELITE\P6KFXA15 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\P6KFXA15\README.TXT',1)}     

**P6KFX-A PCB2.0 BIOS Ver2.2**

DISC2:\BIOS\ELITE\P6KFXA22 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\P6KFXA22\README.TXT',1)}     






**P6LX2-A**

**P6LX2-A PCB1.0(W/Z SCSI, 2Mb) BIOS Ver1.4** 






DISC2:\BIOS\ELITE\LX2A14 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LX2A14\README.TXT',1)}     

**P6LX-A**






**P6LX-A PCB1.1a(W/Z SCSI,W/Z LM78 2Mb) BIOS Ver1.4**

DISC2:\BIOS\ELITE\LX-A14 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LX-A14\README.TXT',1)}     

**P6LX-A PCB1.1a(W/O SCSI, W/Z LM78, 1Mb) BIOS Ver2.4**

DISC2:\BIOS\ELITE\LX-A24 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LX-A24\README.TXT',1)}     

**P6LX-A PCB1.1a(W/O SCSI, W/O LM78, 1Mb) BIOS Ver3.2**

DISC2:\BIOS\ELITE\LX-A32 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LX-A32\README.TXT',1)}     

**P6LX-A PCB1.1a(W/O SCSI,W/O LM78) BIOS Ver4.0**

DISC2:\BIOS\ELITE\P6LXA40 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\P6LXA40\README.TXT',1)}     

**P6LX-A+**

**P6LX-A+ PCB1.1(W/O LM78) BIOS Ver2.1**

DISC2:\BIOS\ELITE\LXAP22 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LXAP22\README.TXT',1)}     

**P6LX-A+ PCB1.1(W/Z LM78) BIOS Ver1.2**

DISC2:\BIOS\ELITE\LXAP12 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\LXAP12\README.TXT',1)}     

**Pentium Pro f}fU[f{[f**

**P6FX1-A**

**P6FX1-A PCB1.0,1.1,1.2 BIOS Ver1.5**@

DISC2:\BIOS\ELITE\FX1A15 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\FX1A15\README.TXT',1)} à-¾,ø·Ž!

**P6FX1-B**

**P6FX1-B PCB1.0,1.0A BIOS Ver1.1**@

DISC2:\BIOS\ELITE\FX1B11 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\FX1B11\README.TXT',1)} à-¾,ø·Ž!

**P6FX2-A**

**P6FX2-A PCB1.0,1.1 BIOS Ver1.2**@

DISC2:\BIOS\ELITE\FX2A12 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\FX2A12\README.TXT',1)} à-¾,ø·Ž!

**Pentium f}fU[f{[fh**

**P5HX-A**

**P5HX-A PCB2.1,2.3 BIOS Ver1.2q**@ **UP!**

DISC2:\BIOS\ELITE\HXA12Q {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\HXA12Q\README.TXT',1)} à-¾,ø·Ž!

**P5HX-A PCB1.0A BIOS Ver1.0**@

DISC2:\BIOS\ELITE\HXA10 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\HXA10\README.TXT',1)} à-¾,ø·Ž!

**P5HX-B**

**P5HX-B PCB1.0,1.1 BIOS Ver1.6h**@ **UP!**

DISC2:\BIOS\ELITE\HXB16H {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\HXB16H\README.TXT',1)} à-¾,ø·Ž!

**P5HX-LA**

**P5HX-LA PCB VT/1.0A BIOS Ver1.0D**@


DISC2:\BIOS\ELITE\HXLA10D {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\HXLA10D\README.TXT',1)} à-¾,ø·Ž!


**P5SD-A**

**P5SD-A PCB2.0,2.0a,3.0 BIOS Ver1.3**@ **UP!**

DISC2:\BIOS\ELITE\SD-A13 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\SD-A13\README.TXT',1)} à-¾,ø·Ž!


**i P5SD-B**  
P5SD-B PCB1.1A BIOS Ver2.3a @ **UP!**

 DISC2:\BIOS\ELITE\SD-B23A {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\SD-B23A\README.TXT',1)} [⌂](#)  
**P5SD-B PCB1.0,1.0A,1.11 BIOS Ver1.3**


 DISC2:\BIOS\ELITE\SD-B13 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\SD-B13\README.TXT',1)} [⌂](#)

**i P5Sj-A/P5Sj-AU**  
P5Sj-A/P5Sj-AU PCB1.0 BIOS Ver1.1 @

 DISC2:\BIOS\ELITE\P5SJA11 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\P5SJA11\README.TXT',1)} [⌂](#)


**i P5Sj-B**  
P5Sj-B PCB1.1 BIOS Ver1.4 @  


 DISC2:\BIOS\ELITE\P5SJB14 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\P5SJB14\README.TXT',1)} [⌂](#)

**i P5SV-B**  
P5SV-B PCB1.0 BIOS Ver1.2 @  



 DISC2:\BIOS\ELITE\P5SVB12 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\P5SVB12\README.TXT',1)} [⌂](#)


**i P5TX-A**  
P5TX-A PCB1.0,1.2,2.0,2.1,2.2 BIOS Ver1.3 @  



 DISC2:\BIOS\ELITE\TXA13 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\TXA13\README.TXT',1)} [⌂](#)  
**P5TX-A PCB3.0,3.1 BIOS Ver2.2**




 DISC2:\BIOS\ELITE\P5TXA22 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\P5TXA22\README.TXT',1)} [⌂](#)

**i P5TX-Apro**  
P5TX-Apro PCB2.X(W/O LM78/LM75) BIOS Ver2.1 @  



 DISC2:\BIOS\ELITE\P5TXAP21 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\



P5TXAP21\README.TXT',1)} [␣à-¾,ð·\Ž!](#)  
**P5TX-Apro PCB2.X(W/Z LM78/75) BIOS Ver1.1**␣@  



 DISC2:\BIOS\ELITE\P5TXAP11 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
P5TXAP11\README.TXT',1)} [␣à-¾,ð·\Ž!](#)


**P5TX-AR**  
**P5TX-AR PCB1.X BIOS Ver1.1**␣@  




 DISC2:\BIOS\ELITE\P5TXAR11 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
P5TXAR11\README.TXT',1)} [␣à-¾,ð·\Ž!](#)

**P5TX-B**  
**P5TX-B PCB1.0 BIOS Ver1.1**␣@  


 DISC2:\BIOS\ELITE\TXB11 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
README.TXT',1)} [␣à-¾,ð·\Ž!](#)  
**P5TX-B PCB2.0 BIOS Ver2.1**␣@  




 DISC2:\BIOS\ELITE\TXB21 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
README.TXT',1)} [␣à-¾,ð·\Ž!](#)

**P5TX-Bpro**  
**P5TX-Bpro PCB V3.X (W/O LM75/78) BIOS Ver4.1**␣@  


 DISC2:\BIOS\ELITE\TBPO41 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
TBPO41\README.TXT',1)} [␣à-¾,ð·\Ž!](#)  
**P5TX-Bpro PCB V3.X BIOS Ver3.0**␣@  


 DISC2:\BIOS\ELITE\TBPO0923 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
TBPO0923\README.TXT',1)} [␣à-¾,ð·\Ž!](#)

**P5TX-Bpro PCB2.X(W/O LM78/75) BIOS Ver2.1**␣@  


 DISC2:\BIOS\ELITE\TBPO21 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
TBPO21\README.TXT',1)} [␣à-¾,ð·\Ž!](#)  
**P5TX-Bpro PCB2.X(W/Z LM78/75) BIOS Ver1.1**␣@  


 DISC2:\BIOS\ELITE\TBPO11 {button ,EF(`..\MENUDATA\IMPVVIEW',`ELITE\  
TBPO11\README.TXT',1)} [␣à-¾,ð·\Ž!](#)

**P5TX-LA**

**P5TX-LA PCB1.X BIOS Ver1.1**@



DISC2:\BIOS\ELITE\TXLA11 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\TXLA11\README.TXT',1)} à-¾,ð·Ž!

**P5VX-A**

**P5VX-A PCB1.1 BIOS Ver1.1**@



DISC2:\BIOS\ELITE\VXA11 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\VXA11\README.TXT',1)} à-¾,ð·Ž!

**P5VX-B**

**P5VX-B PCB1.0,1.2 BIOS Ver1.5**@



DISC2:\BIOS\ELITE\VXB15 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\VXB15\README.TXT',1)} à-¾,ð·Ž!

**P5VX-Be**

**P5VX-Be PCB2.0,3.0 BIOS Ver1.4**@



DISC2:\BIOS\ELITE\VXBE14 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\VXBE14\README.TXT',1)} à-¾,ð·Ž!

**P6EX-Me**

**P6EX-Me PCB1.0 BIOS Ver1.2**@



DISC2:\BIOS\ELITE\EXME12 {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\EXME12\README.TXT',1)} à-¾,ð·Ž!

**P6LX-B**

**P6LX-B BIOS**@



DISC2:\BIOS\ELITE\P6LX09B {button ,EF(`..\MENUDATA\IMPVIEW',`ELITE\P6LX09B\README.TXT',1)} à-¾,ð·Ž!



