

## **TimeOut**

Set the length of time for the EPSON Printer Port to retry transmission after a LPT port timeout.

## **Version**

Displays information about EPSON Printer Port.

## **EPSON Printer Port**

When you install the EPSON printer driver in Windows NT4.0, EPSON Printer Port will be automatically installed at the same time. It helps you increase printing speed by accelerating data transfer.

## **Resource Settings**

For LPT1, displays the I/O Port Address, IRQ, and DMA which you made settings in your computers BIOS settings. For LPT2 or LPT3, displays the I/O Port Address setting you made with your expansion board, and you need to put the same IRQ and DMA settings here as your expansion boards settings. Double-click the appropriate setting, or click the setting and then click Change Settings button.

## **Change Settings**

Select the value for your IRQ or DMA settings. It must have the same value as the settings you made to your expansion board.

## **Use DMA Transfer**

Select to accelerate data transfer to your printer.

## **Conflicting Information**

Displays a message if there are any conflicts in the IRQ or DMA settings.





