

Step Menu,

This menu is used in conjunction with the tuning buttons. It sets the frequency step which will be used by the stack whilst tuning up or down.