Contents

List of Figures vii

List of Tables ix

IRIX Admin Manual Set xi

About This Guide xiii
What This Guide Contains xiv
Conventions Used in This Guide xv
Additional Resources xvi

1. Terminals and Modems 1
About the TTY Subsystem 2
Terms 3
Installing an ASCII Terminal 4
Connecting the Terminal Hardware 4
Configuring the Terminal Software 4
Setting Terminal Options 8
Installing a Modem 9
Before You Begin 10
Connecting the Modem Hardware 11
Setting Up the Modem Software 12
Modem Software Setup, All Modes 12
Dial-out Mode 14
Dial-in Mode 15
Dialing Out to Another Modem 17
Managing the TTY Subsystem 18
Checking Line Settings Using IRIX Shell Commands 18
Creating and Testing Line Settings 19
Modifying Line Characteristics 19

Serial Port Pin Signal Tables 20
Defining the Serial Interface 21
Cabling the Serial Ports 22
DB-9 Serial Connector Cabling 22
Mini-DIN8 Serial Connector Cabling 25

2. Printers 29
Understanding the lp Spooler 30
Terms 31
Command Interface to lp 32
User Command Summary 32
lp: Send a Print Job to a Printer 33
cancel: Remove a Print Request 34
disable: Stop Printer From Processing Requests 35
enable: Allow Printer to Process Requests 36
lpstat: Report lp Status 36
Administrator Command Summary 37
lpsched: Start the lp Scheduler 37
lpshut: Stop the lp Scheduler 38
reject: Prevent Print Requests 38
accept: Allow Print Requests 38
lpmove: Move a Request to Another Printer 39
lpadmin: Configure Printers 40
Managing the lp System 41
Adding a Printer 41
Adding Parallel and Serial Printers 42
Adding a SCSI Printer 43
Adding a Network Print Server 44
Removing a Printer 46
Changing the Default Printer Destination 46
Managing Printing on Print Server Systems 47
Checking Print Server Status 47
Canceling Print Server Requests 47

Configuring the BSD lpr Spooler System 48
Verifying Installation of the BSD lpr Subsystem 49
Configuring the Printcap File 50
Printcap Examples 51
Using the lpr Command to Print 52
Printer Cable Pin Signal Tables 53
Parallel Port Pin Signal Table 53
Serial Port Pin Signal Tables 55
DB-9 Connector Cabling 55
Mini-DIN8 Connector Cabling 58

3. CD-ROM, Floptical, and Floppy Disk Drives 61
Floppy Disk and CD-ROM Filesystems 61
CD-ROM Filesystems 62
Floppy Disk Filesystems 62
Configuring Floppy Disk Drive Device Files 63
Using Floppy Disk Drives 65
Using DOS and Macintosh Floppy Disks 65
Using a Floppy Disk Drive for IRIX File Transfer 65
Floppy Disk File Transfer With tar 66
Floppy Disk File Transfer With cpio 66
Floppy Disk File Transfer With dd 66

4. Tape Drives 69
Adding a Tape Drive 70
MAKEDEV Commands for Tape Drives 71
Tape Capacities 71
Making Tape Drive Links 73
1/2-Inch Tape Drives 74
Switch Settings for the Kennedy 1/2-Inch SCSI Tape Drive 74
8mm and 4mm Tape Drives 75
Exabyte 8mm Cartridge Tape Media Specifications 75
QIC Tape Drives 76

Using dump With DAT Tapes 78
Tape Drive Cleaning Process 78
1/2-Inch Reel-to-Reel Cipher Tape Drive Cleaning Process 79
1/2-Inch Reel-to-Reel Kennedy Tape Drive Cleaning Process 81
8mm and 4mm Tape Drive Cleaning Process 82

5. Troubleshooting 83
Troubleshooting Your Modem Setup 83
Troubleshooting Your Printing System 84
Hardware Troubleshooting Checklist 84
Software Troubleshooting Checklist 85
Troubleshooting Network Printers 86
Emergency Measures 86
Troubleshooting the BSD lpr Spooling System 87
Troubleshooting Inaccessible Tape Drives 91
Checking the Hardware 91
Checking the Software 92
Troubleshooting Tape Read Errors 94

A. Error Messages 95
lp Error Messages 95
Tape Drive Error Indications 107

B. Peripheral Device Files 109

Index 111