Contents

Chapter 1 Introduction **1**

History 1

Chapter 2 User Interface **3**

Invoking BSVC 3

Simulator Menu 4

Creating a New Setup 4

Loading a Setup 4

Editing a Setup 4

Saving a Setup 5

Quitting BSVC 5

Device Management 5

Attaching a Device 5

Detaching a Device 5

Detaching all Devices 6

System Menu 6

Loading a Program 6

Viewing the Simulator's Memory 6

Source Level Debugging 6

System Reset 6

Memory Viewer 7

Dumping Memory to a File 7

Altering Memory Locations 7

Viewing Different Memory Locations 7

Scrolling through Memory 7

Notes 8

Program Listing 8

Notes 8

Help Menu 9

Register Manipulation 9

Modifying a Register's Value 9

Clearing all the Registers 9

Getting a Register Description 9
Simulator Statistics 10
Clearing Statistics 10
Program Execution and Control 10
Single Stepping 10
Running 11
Breakpoints 11
Trace Window 11
Saving Contents 12
Clearing Contents 12
Inserting Registers 12
Inserting Statistics 12
Setting Trace Preferences 12
Bugs 13
Chapter 3 Framework Overview 15
Overview 15
Class Descriptions 16
AddressSpace 16
BasicCPU 17
BasicDevice 17
BasicDeviceRegistry 17
BasicLoader 17
BreakpointList 17
Event 17
EventHandler 17
Interface 18
Communication with the User Interface 18
Chapter 4 Building a Simulator 19
Creating a Development Directory 19
Sim*Processor* Directory 19
cpu Subdirectory 20
device Subdirectory 20
loader Subdirectory 20
Microprocessor Classes 20

Devices 21
Appendix A Framework Class Declarations 23
BasicCPU Class Declaration 23
BasicDevice Class Declaration 26
BasicDeviceRegistry Class Declaration 28
AddressSpace Class Declaration 29
BasicLoader Class Declaration 31
EventHandler Class Declaration 32
RegisterInformationList Class Declaration 34
StatisticalInformationList Class Declaration 36
Interface Class Declaration 38
Appendix B HECTOR 1600 Data Path Simulator 41
Introduction 41
Hector Class 42
Hector Class Declaration 42
DataPath Class 43
DataPath Class Declaration 44
RegisterSet Class 46
RegisterSet Class Declaration 46
ALU Class 47
ALU Class Declaration 47
ControlUnit Class 48
ControlUnit Class Declaration 49
Modifying the Simulator 50
Contacts 50
Appendix C Motorola 68000 Simulator and Assembler 51
Simulator 51
Notes 51
Simulator Devices 52
M68681 Dual UART Device 52
RAM Device 56
Assembler 57

Acknowledgments 58
Contacts 58