



## INSTALLING MONITORMOUSE FOR WINDOWS 95

1. Start your computer.
2. Insert the MonitorMouse for Windows 95 disk into drive A.
3. Click the Start button then click Run.
4. Type "a:\setup" in the space provided and press Enter.
5. Follow the directions on the screen.
6. MonitorMouse for Windows 95 provides two installation options. Most users should select Typical (the default) and click Next to continue. Custom allows you to install the sample touchscreen programming files.
7. The Touchscreen Setup dialog box will appear. Specify the type of touchscreen controller you are using and how it is connected. Click OK to confirm that the Setup is correct.
8. Complete the Setup program.
9. Restart Windows 95.
10. Click the Start button, then click Settings, then click Control Panel.
11. Double-click Elo Touchscreen to run the Touchscreen Control Panel.
12. Click the Calibrate button and touch each of the three targets as they appear on the screen. Click Yes when the cursor lines up correctly with your finger. Click OK to close the Touchscreen control panel.

### ***Contacting Elo TouchSystems Technical Support***

**VOICE:** (800) 489-9935 or (510) 651-7589

**FAX:** (510) 651-3511

**EMAIL:** [elotech@elotouch.com](mailto:elotech@elotouch.com)

**Web:** <http://www.elotouch.com>

**BBS:** (423) 482-9840

**CompuServe:** GO ELOTOUCH *Select Elo from the Messages and Library menus.*