

```
; *****
; PRINTER CONFIGURATION FILE FOR EPSON LQ AND COMPATIBLES          DEC 1987
; *****
```

!NAME

EPSON LQ; NEC Pinwriter; (Select option I for more Information)

!INFORMATION

; Additional printer information is given here

EPSON LQ AND COMPATIBLES - Additional Information	
1.	You must have run the program called 24PIN before running INTEXT. If you do not, you will not see non-English characters.
2.	Certain Epson printers will print newly defined characters instead of Italics.
3.	Your printer must be set up to accept downloadable characters. A DIP switch may select this option.
4.	Your printer must be configured for EPSON rather than IBM codes.
5.	Other DIP switches in your printer (see your manual) can select: <ul style="list-style-type: none"> A) Default print size B) Slashed 0 or plain 0 C) End of single sheet paper D) Default print style E) Extra line-feeds F) 1 inch skip over perforations

!STYLES

; Table of styles available for these printers

52 styles available

EPSON LQ STYLE SHEET		STYLE COMBINATIONS										
Abbr.	BASIC STYLE	Single style	Und	Bld	Cnd	Dbl	Elt	Ita	Bld Und	Ita Und	Bld Ita	Und Ita
Und =	Underlined	A	:	:	:	:	:	:	:	:	:	:
Bld =	Bold	B	I	:	:	:	:	:	:	:	:	:
Cnd =	Condensed	C	J	P	:	:	:	:	g	m	r	w
Dbl =	Double width	D	K	Q	:	:	:	:	h	n	s	x
Elt =	Elite	E	L	R	:	:	:	:	i	o	t	y
Ita =	Italics	F	M	S	V	Y	b	:	j	:	:	:
	Subscript	G	N	T	W	Z	c	e	k	p	u	:
	Superscript	H	O	U	X	a	d	f	l	q	v	:
	Backspace	Z	:	:	:	:	:	:	:	:	:	:

For example, style 'g' would produce: Bold+Underline+Condensed

Backspace is not a style, but allows the combination of two or more

characters by over-printing them. For example, when in the print formatter, by giving a character the style 'z' will make it overprint the previous character.

!CODES

;	ON	OFF
A	27,45,1	27,45,0
B	27,69	27,70
C	15	18
D	27,87,1	27,87,0
E	27,77	27,80
F	27,52	27,53
G	27,83,1	27,84
H	27,83,0	27,84
I	A,B	
J	A,C	
K	A,D	
L	A,E	
M	A,F	
N	A,G	
O	A,H	
P	B,C	
Q	B,D	
R	B,E	
S	B,F	
T	B,G	
U	B,H	
V	C,F	
W	C,G	
X	C,H	
Y	D,F	
Z	D,G	
a	D,H	
b	E,F	
c	E,G	
d	E,H	
e	F,G	
f	F,H	
g	I,C	
h	I,D	
i	I,E	
j	I,F	
k	I,G	
l	I,H	
m	M,C	
n	M,D	
o	M,E	
p	M,G	
q	M,H	
r	S,C	
s	S,D	
t	S,E	
u	S,G	
v	S,H	
w	j,C	
x	j,D	
y	j,E	
z	8	

```
; Since backspace is not 'disabled', this feature is represented by a null  
; that is ignored by the printer.
```

```
; Character labels ^ [ \ ] _ ' are used for special escape sequences outline  
; below.
```

```
^ 27,64          27,58,0,0,0,27,37,1,0,27,54 ;ON = General Printer initialiasation  
                ;OFF = Downloadable character sets init.
```

```
→
```