

```

Carrier: approx 35.5kHz The code is 16 bits long. +-----+ Header: | | ..+
+-----+ 4T 8T The header is only transmitted once. +--+ +--+ 1 is
coded: | | | | ..+ +-----+ +.. T 3T T +--+ +--+ 0 is coded: | | | |
..+ +--+ +.. T T T T = 520 us approx pulse 500us space 600us To use the codes recall
infosting and put the number on level 1 of stack. Example to play a JVC video: \<< JVC
@ get info string #0C43h @ get the data TRANSMIT
@ transmit \>> ***** video operate 0B43 1
2143 2 2243 3 2343 4 2443 5
2543 6 2643 7 2743 8 2843 9 2943 0
3343 ch 3443 program 3743 cancel
3643 ch- 1843 ch+ 1943 go-to 3B43 display
3843 counter reset 3943 sp/lp 3143 audio monitor 1743 slow- 1543
slow+ 1443 rew 0743 ff 0643 rec CC43 play
0C43 pause 0D43 stop 0343
----- cd 1 61B3 2 62B3 3 63B3 4
64B3 5 65B3 6 66B3 7 67B3 8 68B3 9
69B3 10 6AB3 +10 6FB3 0 60B3 play
3DA3 stop 43B3 pause 4DB3 open/close 44B3
skip rew 58B3 skip ff 59B3 rew 70B3 ff 76B3
----- amp vol- 1FA3 vol+ 1EA3 muting
1CA3 tuner 0BA3 phono 3CA3 video/aux 3EA3
tape 0C83 tape stop 0383 ----- tuner pre+ 19A3
pre- 18A3 1 21A3 2 22A3 3 23A3 4
24A3 5 25A3 6 26A3 7 27A3 8 28A3 9
29A3 0 20A3 10 2AA3 +10 2FA3 >From:
kwmccoy@mentor.cc.purdue.edu (Ken) JVC CD (these were found to work
on model XL-V450) CODE Function CODE Function ---- ----- 43B3 stop
5EB3 ? 44B3 open/close 5FB3 ? 46B3 search f 61B3
one 47B3 search r 62B3 two 48B3 intro 63B3 three 49B3
editing 64B3 four 4CB3 play 65B3 five 4DB3 pause
66B3 six ? Code recognized, but 54B3 display 67B3
seven no function performed 55B3 ? 68B3 eight
56B3 index 69B3 nine 57B3 ? 6AB3
program 58B3 skip <- 6EB3 ten 59B3 skip -> 6FB3 +10
5BB3 repeat all 70B3 search r 5CB3 A<->B 72B3 random 5DB3 ?
76B3 search f JVC TV CODE Function CODE Function ---- -----
---- ----- 0403 display 2003 zero 0503 return 2103 one 0603
function 2203 two 0A03 set choice 2303 three 0B03 ANT/Cable 2403
four 0D03 AV status 2503 five 1003 channel 2603 six 1103 channel
2703 seven 1203 channel 2803 eight 1303 channel
2903 nine 1403 channel 3C03 recall choice 1703 on/off 5A03
fun + 1803 ch - 5B03 fun - 1903 ch + 7703 ?? 1A03 off
7A03 menu 1C03 mute 7B03 fun for 1E03 vol + 7C03
fun back 1F03 vol -

```