

**ZJTools**

COLLABORATORS

	TITLE : ZJTools		
ACTION	NAME	DATE	SIGNATURE
WRITTEN BY		August 3, 2024	

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME

# Contents

<b>1</b>	<b>ZJTools</b>	<b>1</b>
1.1	ZJTools.guide	1
1.2	ZJTools.guide/Introduction	1
1.3	ZJTools.guide/Features	2
1.4	ZJTools.guide/Disclaimer	2
1.5	ZJTools.guide/Copyright & Distribution	2
1.6	ZJTools.guide/Requirements	3
1.7	ZJTools.guide/Installation	3
1.8	ZJTools.guide/Usage	3
1.9	ZJTools.guide/ZJWatch	4
1.10	ZJTools.guide/ZJWatch Tool Types	4
1.11	ZJTools.guide/ZJWatch Arguments	5
1.12	ZJTools.guide/ZJWatch AppIcon	6
1.13	ZJTools.guide/ZJTool	7
1.14	ZJTools.guide/ZJTool Arguments	7
1.15	ZJTools.guide/ZJTool Examples	8
1.16	ZJTools.guide/ZJToolMUI	8
1.17	ZJTools.guide/Starting ZJToolMUI	9
1.18	ZJTools.guide/Using ZJToolMUI	9
1.19	ZJTools.guide/ZJToolMUI and ZJWatch	10
1.20	ZJTools.guide/About MUI	11
1.21	ZJTools.guide/ZJTools.prefs	11
1.22	ZJTools.guide/Hints	12
1.23	ZJTools.guide/Translations	13
1.24	ZJTools.guide/Author	14
1.25	ZJTools.guide/Acknowledgements	14
1.26	ZJTools.guide/History	15
1.27	ZJTools.guide/To do	15
1.28	ZJTools.guide/Index	16

---

# Chapter 1

## ZJTools

### 1.1 ZJTools.guide

ZJTools 1.1

A software package for Iomega Zip and Jaz drives

Introduction	A brief overview.
Features	That's why you should use it.
Disclaimer	Use it at your own risk.
Copyright & Distribution	Important to know.
Requirements	What's needed to make it work?
Installation	How to install it.
Usage	The most important section.
Hints	Special hints.
Translations	Translators wanted!
Author	Who did it?
Acknowledgements	Your name? - Look!
History	Changes from version to version.
To do	What about future versions?

### 1.2 ZJTools.guide/Introduction

Introduction  
\*\*\*\*\*

Iomega Zip and Jaz drives are getting more and more popular. Their easy installation, flawless operation and their nice price, make them the ideal replacement for both hard- and floppy disks.

On the Amiga, the installation of Zip and Jaz drives is especially simple: Plug and play! No special software or drivers are required to make Zip and Jaz drives work.

Nevertheless there are some features that Zip and Jaz drives offer, that do need special software to access it. For PC and Macintosh users,

---

this is no problem, since Iomega ships a lot of drivers and other related software with their drive, but as always Amiga users have to find another solution.

One of these solutions is 'ZJTools'. It provides you with the same functionality as the software that is shipped with the drive.

## 1.3 ZJTools.guide/Features

### Features

\*\*\*\*\*

- Surveys your drives for insertions of protected disks
- Change read/write protection of your disks
- Eject disks by dropping them onto an AppIcon
- Adjust inactivity spindown timeout
- Low-level format
- Fully localized
- Easy installation using 'Installer'

## 1.4 ZJTools.guide/Disclaimer

### Disclaimer

\*\*\*\*\*

This software is provided 'as is'. No warranties are made, either expressed or implied, with respect to the reliability, quality, performance, or operation of this software. The use of this program is at your own risk. The author assumes no responsibility or liability for any damage or losses resulting from the use of this software.

## 1.5 ZJTools.guide/Copyright & Distribution

### Copyright & Distribution

\*\*\*\*\*

'ZJTools' is Copyright (C) 1996 by Oliver Hitz. All rights reserved.

'ZJTools' is FREeware. This means that it is freely distributable as long as all files of the original distribution are included without any modifications.

---

No profit may be made by distributing 'ZJTools'. You may charge fees for copying and disks, but not for the software. It is for example not permitted to sell a disk containing this software if the price exceeds 4 US\$ or the equivalent in another currency.

## 1.6 ZJTools.guide/Requirements

### Requirements

\*\*\*\*\*

To use 'ZJTools', you will need

- AmigaOS version 2.0 or higher
- Iomega Zip or Jaz drive(s) (SCSI version)
- 'reqtools.library' version 38 or higher for 'ZJWatch'
- MUI for 'ZJToolMUI' ('muimaster.library' version 12 or higher)

## 1.7 ZJTools.guide/Installation

### Installation

\*\*\*\*\*

Installation of 'ZJTools' is very easy. Just double-click the 'Install' icon and follow the instructions given. Please note that there is a mounted disk in your Zip or Jaz drive before the installation is started. The Installer-Script will then automatically generate a preferences file that fits your setup.

'Installer' is needed for the installation. You may find it on the 'Install' disk of your Workbench package.

## 1.8 ZJTools.guide/Usage

### Usage

\*\*\*\*\*

ZJTools consists of the three following programs:

ZJWatch	A Commodity for everyday-use.
ZJTool	A CLI-only utility.
ZJToolMUI	ZJTool with a powerful MUI interface.

Preferences file for ZJToolMUI and ZJWatch

ZJTools.prefs	Format of the preferences file
---------------	--------------------------------

## 1.9 ZJTools.guide/ZJWatch

ZJWatch  
=====

'ZJWatch' is a very handy commodity. It may be copied into the 'WBStartup' drawer of your Workbench and will then automatically be started everytime your computer is reset.

'ZJWatch' surveys your Zip and Jaz drives for insertions of read protected disks. As soon as such a disk is detected, it will pop up a requester and ask you a password to temporarily unprotect it.

'ZJWatch' will also provide you with an AppIcon on your Workbench. Whenever the icon of one of your Zip or Jaz disks is dropped on that AppIcon, the disk is automatically ejected. This will also work with other removable devices such as CD-ROM drives.

ZJWatch Tool Types	Starting ZJWatch from the Workbench.
ZJWatch Arguments	Starting ZJWatch from the Shell.
ZJWatch AppIcon	What exactly is its purpose?

## 1.10 ZJTools.guide/ZJWatch Tool Types

ZJWatch Tool Types  
-----

The behaviour of 'ZJWatch' may be controlled via the following tool types:

'WATCH=<device>,<unit>[, [<flags>] [, [<spindown>]]]'

This tells 'ZJWatch' to override the settings in the prefs file. You may use this tooltype to tell 'ZJWatch' directly which drives it has to survey for diskchanges. You may specify multiple 'WATCH' tool types.

'CX\_PRIORITY=<pri> (Default: 0)'

Specifies the priority of the commodities broker.

'CX\_POPKEY=<key> (Default: 'ctrl alt z')'

Set the keyboard sequence that will load and display the GUI. This is the same as if you double click the AppIcon.

'CX\_POPUP=[YES|DISK|NO] (Default: YES)'

Controls whether the AppIcon is visible or not. The special value

'DISK' will make the AppIcon visible only if a disk is in your drive. This is useful for people who don't need the AppIcon for other removable media.

'PWVISIBLE=[YES|NO] (Default: NO)'

Controls whether the text entered as password in the requester that pops up whenever a read protected disk is inserted is visible or not.

'ICON=<filename> (Default: 'ZJWatch')'

Specify the icon imagery file of the AppIcon. The filename is to be entered without the '.info' suffix.

'ICONTITLE=<title> (Default: 'Eject')'

Set the text that is displayed below the AppIcon.

'TOOL=<filename> (Default: 'ZJToolMUI')'

Specify the full path and filename of the program that is launched when the AppIcon is double clicked or when the keyboard sequence set with 'CX\_POPKEY' is encountered. This should point to the location where 'ZJToolMUI' is stored.

'EJECTDELAY=<delay> (Default: 100)'

The drive needs to be locked for a certain amount of time after a disk has been ejected to make sure the disk is no longer in the drive. If your disks aren't ejected properly, increase this value. (The time is done in 1/50 seconds)

## 1.11 ZJTools.guide/ZJWatch Arguments

ZJWatch Arguments

-----

Format

```
{WATCH <device>,<unit>[,<flags>,<spindown>]} [CX_PRIORITY <n>]
[CX_POPUP] [CX_POPKEY <key>] [PWVISIBLE] [ICON <filename>]
[ICONTITLE <title>] [TOOL <filename>] [EJECTDELAY <delay>]
```

Template

```
WATCH/K/M, CX_PRIORITY/K/N, CX_POPUP/K, CX_POPKEY/K, PWVISIBLE/S,
ICON/K, ICONTITLE/K, TOOL/K
```

WATCH=<device>,<unit>[,<flags>][,<spindown>]]

This tells 'ZJWatch' to override the settings in the prefs file. You may use this tooltype to tell 'ZJWatch' directly which drives it has to survey for diskchanges. You may specify multiple 'WATCH' arguments.

CX\_PRIORITY=<pri> (Default: 0)

Specifies the priority of the commodities broker.

CX\_POPKEY=<key> (Default: 'ctrl alt z')

Set the keyboard sequence that will load and display the GUI. This is the same as if you double click the AppIcon.

CX\_POPUP=[YES|DISK|NO] (Default: YES)

Controls whether the AppIcon is visible or not. The special value 'DISK' will make the AppIcon visible only if a disk is in your drive. This is useful for people who don't need the AppIcon for other removable media.

PWVISIBLE

By default, the password entered in the requester is invisible. Use this switch to make it visible.

ICON=<filename> (Default: 'ZJWatch.info')

Specify the icon imagery file of the AppIcon. The filename is to be entered without the '.info' suffix.

ICONTITLE=<title> (Default: Eject)

Set the text that is displayed below the AppIcon.

TOOL=<filename> (Default: 'ZJToolMUI')

Specify the full path and filename of the program that is launched when the AppIcon is double clicked or when the keyboard sequence set with 'CX\_POPKEY' is encountered. This should point to the location where 'ZJToolMUI' is stored.

EJECTDELAY=<delay> (Default: 100)

The drive needs to be locked for a certain amount of time after a disk has been ejected to make sure the disk is no longer in the drive. If your disks aren't ejected properly, increase this value. (The time is done in 1/50 seconds)

## 1.12 ZJTools.guide/ZJWatch AppIcon

ZJWatch AppIcon

-----

The 'ZJWatch' AppIcon serves for the following two purposes:

Eject Disks

Disks may be ejected by simply dropping them onto the AppIcon. This behaviour is similar to the 'Trash' icon of the Apple Macintosh. This works also with other removable media such as CD-ROMs.

Start ZJToolMUI

By double-clicking onto the AppIcon, the 'ZJToolMUI' program is loaded. If this doesn't work, make sure the correct path and filename is set using the 'TOOL' tooltype.

When 'ZJWatch' is started with 'CX\_POPUP=DISK', the AppIcon is only visible if there is a disk in your drive. As soon as the disk is ejected, the AppIcon disappears from the Workbench.

## 1.13 ZJTools.guide/ZJTool

ZJTool  
=====

'ZJTool' is a command line driven utility that lets you control every special feature your Zip or Jaz drive offers.

'ZJTool' is pure and can be made resident.

ZJTool Arguments	How to launch 'ZJTool'.
ZJTool Examples	Some examples.

## 1.14 ZJTools.guide/ZJTool Arguments

ZJTool Arguments  
-----

### Format

```
[[DRIVE] <drive>| [DEVICE=<device>] [UNIT=<unit>] [FLAGS=<flags>]]  
[WLOCK|RWLOCK|UNLOCK|TUNLOCK|EJECT|SPINDOWN=<n>]  
[PASSWORD=<password>]
```

### Template

DRIVE, DEVICE/K, UNIT/K/N, FLAGS/K/N, WLOCK/S, RWLOCK/S, UNLOCK/S,  
TUNLOCK/S, EJECT/S, SPINDOWN/K/N, PASSWORD/K

DRIVE=<drive>

This is one way of telling 'ZJTool' on which drive to operate.

DEVICE=<device>

UNIT=<unit>

FLAGS=<flags>

This lets you directly specify the name, unit and flags of the SCSI driver your Zip or Jaz drive is connected to. By default, FLAGS is 0, so you usually won't have to specify it.

### WLOCK

Write protect disk. If 'PASSWORD' is supplied, the disk in question will be password protected.

### RWLOCK

Read/write protect disk. This command requires a password.

### UNLOCK

Unlock any read and/or write protected disk. Also supply 'PASSWORD' if the disk in question is password protected.

### TUNLOCK

Temporary unlock read and/or write protected disks. Also supply 'PASSWORD' if the disk in question is password protected.

---

## EJECT

Eject disk from your Zip or Jaz drive.

## SPINDOWN=<timeout>

Set the inactivity spindown timeout in minutes. Legal values are from 0 to 255.

## PASSWORD=<password>

Specify the password for the 'WLOCK', 'RWLOCK', 'UNLOCK' and 'TUNLOCK' operations. If the password contains spaces, surround it with quotation marks.

If only the 'DRIVE' or 'DEVICE', 'UNIT' and 'FLAGS' are given, the protection state of the disk is displayed.

## 1.15 ZJTools.guide/ZJTool Examples

### ZJTool Examples

-----

- We want to see the state of the disk mounted as 'ZIP:':

```
1> ZJTool ZIP:
Unprotected.
```

- We would like to read/write protect the disk at 'scsi.device' unit 5:

```
1> ZJTool DEVICE scsi.device UNIT 5 RWLOCK PASSWORD "My password"
```

- Now let's adjust the inactivity spindown timeout of the drive 'JAZ:' to 10 minutes:

```
1> ZJTool JAZ: SPINDOWN 10
```

## 1.16 ZJTools.guide/ZJToolMUI

### ZJToolMUI

=====

'ZJToolMUI' is probably the program most people will use when they need to change the protection of a disk on the fly. It is practically the same as 'ZJTool', but its powerful MUI interface makes it a lot easier to use.

Although it should be more or less self-explaining, here is everything you have to know about it.

Starting ZJToolMUI

How to start 'ZJToolMUI'.

Using ZJToolMUI	Explanation of the buttons.
Further information...	
ZJToolMUI and ZJWatch	Teamwork.
Legal stuff...	
About MUI	Great work!

## 1.17 ZJTools.guide/Starting ZJToolMUI

Starting ZJToolMUI

'ZJToolMUI' may be started from the Workbench as well as from a Shell window. There is no need to specify any Workbench tool types or Shell arguments.

Although it is possible to start 'ZJToolMUI' from the 'WBStartup' drawer, it is not recommended. 'ZJToolMUI' isn't designed as a to be launched at boot time. Use 'ZJWatch' instead and 'ZJToolMUI' will always be available by double clicking the AppIcon.

## 1.18 ZJTools.guide/Using ZJToolMUI

Using ZJToolMUI

After starting 'ZJToolMUI', a window with a few gadgets is opened.

The listview gadget displays all the devices that were found in your 'ZJTools.prefs' file. The status line below the listview gadget displays the state of the currently selected entry.

Depending on that state, the action buttons will be disabled or enabled. Their meaning is as follows:

Write lock

Make the disk in the currently selected drive write protected. A string requester will pop up, asking you for an \*optional\* password. Remember, this password is \*optional\*. There's no need to enter anything here.

Read/write lock

Make the disk in the currently selected drive read and write protected. There will also be a string requester popping up asking you for a password. This password is not optional, since it makes no sense to read protect a disk without a password. Please take extreme care when using this feature. If you forget your password,

you will never be able to recover the data on that disk.

#### Unlock

Click this button to unlock a disk that is either write or read/write protected. A password requester will pop up when the disk is password protected. The disk is unprotected permanently.

#### Unlock temporarily

This button is used to unlock a disk temporarily. You will be able to read/write to the disk as long as it is in the drive and as long as the computer is not reset (1). This is the mode 'ZJWatch' uses to unlock read/write protected disks that are inserted.

#### Eject

Clicking on this button will eject the currently selected disk.

'ZJToolMUI' also features some menus. Only one of them is really of importance.

#### Project, About...

This menu shows version and Copyright information.

#### Project, Quit

You may use this menu to quit 'ZJToolMUI'.

#### Misc, Low-level Format

Use this menu for a 'real' low-level format. Caution: This function will kill \*everything\* on your disk!

This function should only be needed when you forget the password of password protected disks. In that case, at least the disk may be re-used, your data however will be destroyed.

A low-level format will take several minutes and cannot be aborted. Please be patient when using this.

----- Footnotes -----

(1) On my A3000T it will be unprotected even after a reset, but this might not be the case with other controllers.

## 1.19 ZJTools.guide/ZJToolMUI and ZJWatch

### ZJToolMUI and ZJWatch

-----

'ZJToolMUI' and 'ZJWatch' work together. Here are some important things to know:

- Both 'ZJToolMUI' and 'ZJWatch' use the same preferences file. However, 'ZJWatch' allows to override the preferences files using the 'WATCH' argument or tool type.
- 'ZJToolMUI' may be started by double clicking the AppIcon of

'ZJWatch'. You may need to adjust the path manually using the appropriate tool types. This can be done with the 'TOOL' argument or tool type.

- As soon as 'ZJToolMUI' is started, 'ZJWatch' is deactivated. It is re-activated when 'ZJToolMUI' is quit. This disables the requesters of 'ZJWatch'.

## 1.20 ZJTools.guide/About MUI

This application uses

MUI - MagicUserInterface

(c) Copyright 1993-96 by Stefan Stuntz

MUI is a system to generate and maintain graphical user interfaces. With the aid of a preferences program, the user of an application has the ability to customize the outfit according to his personal taste.

MUI is distributed as shareware. To obtain a complete package containing lots of examples and more information about registration please look for a file called "muiXXusr.lha" (XX means the latest version number) on your local bulletin boards or on public domain disks.

If you want to register directly, feel free to send

DM 30.- or US\$ 20.-

to

Stefan Stuntz

Eduard-Spranger-Straße 7

80935 München

GERMANY

Support and online registration is available at

<http://www.sasg.com/>

## 1.21 ZJTools.guide/ZJTools.prefs

ZJWatch and ZJToolMUI Preferences

-----

The preferences file for 'ZJWatch' and 'ZJToolMUI' is called 'ZJTools.prefs' and is located either in the current directory or in the

'ENV:' directory.

It consists of one or more lines of the following format:

```
<devicename>,<unit>[, [<flags>][, [<spindown>]]]
```

The first three parameters tell 'ZJWatch' and 'ZJToolMUI' where they can find Zip and Jaz drives and how they can be accessed. If you don't know anything about the <flags> value, leave it 0 or omit it. This will be the correct choice in 99.9% of all cases, but it might be useful for certain people to be able to specify it.

The fourth parameter, <spindown>, is only of importance for 'ZJWatch'. Use it to adjust the drive's inactivity spindown timeout. If you don't enter anything here, this value defaults to 15 minutes. Valid values are from 0 to 255. If the value is 0, the inactivity spindown timeout is disabled.

Here follows an example of a 'ZJTools.prefs' file:

```
scsi.device,3,,60
2ndscsi.device,5,0,5
```

In this example, two drives are specified. One at 'scsi.device' unit 3, the other at '2ndscsi.device' unit 5. The first one will spin down after one hour of inactivity, the second after five minutes.

## 1.22 ZJTools.guide/Hints

### Hints

\*\*\*\*\*

#### Low-level format

'ZJToolMUI' features a 'real' low-level format. Note that if your disk is read and/or write protected, it cannot be formatted with 'HDToolBox'. You will need to use this function instead.

#### Disk shipped with your drive (ZipTools or JazTools)

The disk that is shipped with your drive is write protected. It may be unlocked with the following password: 'APlaceForYourStuff'. This password work with both Zip and Jaz drives.

#### Speedup loading of ZJWatch

You may find that 'ZJWatch' is loaded only very slowly. In this case you should take a look at your preferences file 'ZJTools.prefs'. When 'ZJWatch' is started, it checks every entry in the preferences file for Zip and Jaz drives. If you enter units that do not exist, it may take up to 2 seconds for the scsi driver to detect that there is no drive on that unit. Drives that do exist, however, are checked very quickly.

#### Diskchanges

After an action is done to a drive, all three programs provided in this package tell the system that a disk change has occurred,

similar to how the Shell command 'DiskChange' does it. This way filesystems should re-read the disk information and know the new protection state. Unfortunately, there might still be problems with some controllers as removable media aren't fully supported by every driver software. If you are experiencing problems with your controller, contact the manufacturer and ask for a driver update.

#### Passwords

Please take *\*extremely\** care when protecting your disks with passwords. There is *\*no\** possibility to unlock a disk if you forget your password. Use it only when you absolutely need it.

#### Inactivity spindown

The inactivity spindown is a very useful feature of the Zip and Jaz drives. It not only saves power but it also prolongs the lifetime of your drives and disks. By default, Zip drives spin down after 15 minutes of inactivity, Jaz drives after 30 minutes. 'ZJWatch', however, will set the timeout to 15 minutes for both types of drives if no value is specified in the preferences file.

By the way, the inactivity spindown is a setting of the drive. It isn't saved on disk.

#### Iomega ZipTools and ShapeShifter

The disk that is shipped with the Zip drive contains software for Macintosh and PC systems. If you are running the Macintosh emulator ShapeShifter, you might want to take a look at that software. Mount the ZipTools disk using CrossDOS and you will see a 50 MByte file called 'PARTISHN.MAC'. Open the preferences editor of ShapeShifter and mount this file as filedisk.

This might also work with the Jaz drive, but as I don't own one, I cannot test it.

#### Saving the position of the AppIcon

It is very easy to save the position of the AppIcon. To do that, open the drawer 'ZJTools' and select the menu item 'Window/Show/All files'. Open the drawer 'Icons' now and drag the icon that's inside there onto the workbench and place it at your favourite position. Select the menu item 'Icons/Snapshot' now and put the icon back into its drawer. It's that easy!

## 1.23 ZJTools.guide/Translations

#### Translations

\*\*\*\*\*

Every component of 'ZJTools' is fully localized. To let as many people as possible use it in their native language, the 'CatComp' sources for the catalogs are included in the 'Catalogs/Sources' directory of the distribution.

Feel free to translate it to your native language and send your translation to me so I can include it in the next release.

---

It is suggested that you contact me before translating the catalogs as there might already be somebody else who is working on that.

\*Please note:\*

- Only translations with 'CatComp' source code will be included.
- Please do always send your translations to me. Do not upload your catalogs as 'zjtxxx.lha' files to the Aminet. If there won't be new releases of this software for some reasons, I'll tell you and you can still upload it yourself.

## 1.24 ZJTools.guide/Author

Author

\*\*\*\*\*

The author of 'ZJTools' may be reached at:

E-mail

oliver.hitz@unifr.ch

Snail-mail

Oliver Hitz  
Weiermattweg 13  
3186 Düringen  
Switzerland

BBS

FRI Byte BBS, located near Fribourg/Switzerland  
USR V.34: +41-37-43 03 03 (from November 2nd: +41-26-492 03 03)  
SoLIS X.75: +41-37-43 03 04 (from November 2nd: +41-26-492 03 04)

Contacts via e-mail and BBS are preferred. There's no guarantee that letters to the snail-mail address will be answered. (Sorry!)

## 1.25 ZJTools.guide/Acknowledgements

Acknowledgements

\*\*\*\*\*

Thanks must go to everyone who has helped me in the development of this software either by suggestions, bug reports and moral support.

Especially, I would like to thank the following people:

---

- Fred Fish and everybody who is working on the ADE project
- Matthias Fleischer and Gunther Nikl for Libnix
- Stefan Stuntz for his great MUI
- Nico François and Magnus Holmgren for reqtools.library
- Dietmar Eilert for GoldED
- Daniel J. Andrea II for his suggestions, bug reports and for testing the beta version of 'ZJTools'
- Chun Tham for testing the beta version with his Jaz drive
- Dave for the italian translation
- ...and of course everybody who has sent me a postcard for my program 'ZipTool'!

## 1.26 ZJTools.guide/History

### History

\*\*\*\*\*

#### Version 0.9 (9.9.96)

- first beta release

#### Version 1.0 (17.9.96)

- low-level format menu added in ZJToolMUI
- German documentation
- German and French catalogs
- icons added...
- some bugs in the Installer script fixed

#### Version 1.1 (27.10.96)

- fixed bug in ZJWatch's prefs line scanning
- ZJWatch didn't properly eject all disks - delay adjustable
- possible to have AppIcon displayed only when disks are inserted
- Italian catalogs
- sometimes the string requester in ZJWatch didn't disappear when Cancel was hit

## 1.27 ZJTools.guide/To do

### To do

\*\*\*\*\*

There are several things that are very likely to be improved in further releases:

- Make use of other GUI packages
- Make 'ZJWatch' use its own string requester instead of the one from 'reqtools.library'
- Draw some nice icons (Artists wanted!)
- Read current spindown setting

As you can see, this list isn't very long yet. If you have suggestions for further improvements, feel free to send them to me.

## 1.28 ZJTools.guide/Index

Index

\*\*\*\*\*

Acknowledgements  
 AppIcon  
 AppIcon Position  
 Arguments, ZJTool  
 Arguments, ZJWatch  
 Author  
 Commodity  
 Copyright  
 Disclaimer  
 Diskchanges  
 Distribution  
 Examples, ZJTool  
 Features  
 Format, ZJTool  
 Format, ZJWatch  
 Hints  
 History  
 Inactivity spindown  
 Installation  
 Introduction  
 Iomega ZipTools  
 JazTools  
 Low-level format <1>  
 Low-level format  
 Passwords  
 Preferences  
 Requirements  
 Speedup loading of ZJWatch  
 Spindown <1>  
 Spindown  
 Start, ZJToolMUI  
 Suggestions  
 Template, ZJTool  
 Template, ZJWatch  
 To do  
 Tool Types, ZJWatch

Acknowledgements  
 ZJWatch AppIcon  
 Hints  
 ZJTool Arguments  
 ZJWatch Arguments  
 Author  
 ZJWatch  
 Copyright & Distribution  
 Disclaimer  
 Hints  
 Copyright & Distribution  
 ZJTool Examples  
 Features  
 ZJTool Arguments  
 ZJWatch Arguments  
 Hints  
 History  
 Hints  
 Installation  
 Introduction  
 Hints  
 Hints  
 Using ZJToolMUI  
 Hints  
 Hints  
 ZJTools.prefs  
 Requirements  
 Hints  
 Hints  
 ZJTools.prefs  
 Starting ZJToolMUI  
 To do  
 ZJTool Arguments  
 ZJWatch Arguments  
 To do  
 ZJWatch Tool Types

Translations	Translations
Usage	Usage
Usage, ZJToolMUI	Using ZJToolMUI
ZipTools	Hints
ZJTool	ZJTool
ZJTool.prefs	ZJTools.prefs
ZJToolMUI	ZJToolMUI
ZJToolMUI, using	Using ZJToolMUI
ZJWatch	ZJWatch
ZJWatch AppIcon	ZJWatch AppIcon