

DSSETNT für BigWinNT Online Help

Rel: 0296.1

Click on the area of the configuration box which you need online help on!

Extended

Color Depth

Resolution

Refresh Rate

Fonts

Test Settings

OK (Restart Options for Windows)

Oben: Hauptteil - DSSETNT-Dialoguebox
Evtl. weitere Themen (nach Bedarf einblenden)

Hardware Video SupportHID_HARDWARE
MonitorHID_MONITOR

Start einzelne Teile des Hauptdialogues

Extended

The options in this dialogue enable you to make a number of changes for your system which can accommodate for problems you may encounter with the automatic (default) settings. In addition, you can activate/deactivate the BigWin start logo as required.

Linear Address

Possible Values: '32 MB', '64 MB', '128 MB'

Your graphics board is used via an address in the RAM (memory) of your PC. The 'position' of this address is automatically set by the software and is normally not a cause of problems. However, in some complex system configurations, it is possible that conflicts with other hardware may occur. This option allows you to relocate the address of the board in linear memory by the value shown.

If you experience problems such as system crashes, you can move the address (trial and error method!). The smallest value that is displayed depends on the amount of memory the PC has available. **Please note, that this value does not actually represent the size of the memory itself**, but is much more a value for the board address which is closely related to the amount of memory in the PC.

Chip-Sync

This option determines the operating mode of the FIFO buffer of the S3 graphics processor on the board. The default setting is OFF (accelerated display). If you experience problems (system crashes, icons distorted, scroll bar refuses to stop scrolling), switch this option ON. The graphics display will be slower but should then be corrected.

Company Logo during start

The company logo displayed when you start Windows has the following purposes:

- it confirms that the BigWin driver is loaded
- it informs you which version of BigWin is active (important when upgrading!)

The start logo slows down the Windows start-up procedure minimally. If however, you wish to remove the start logo, use this option to do so.

Color Depth

Allows you to select the maximum number of colors that can be simultaneously displayed on your screen (64K = 65,536 colors, True Color = 16,777,216 colors).

Changing this parameter may influence the resolution and refresh rate settings. If the current screen refresh rate is not available for the number of colors selected, then the program automatically uses the first entry from the corresponding selection box.

Resolution

Select the screen resolution with this setting. If more than one resolution is available, use the arrow down button to open a selection list.

Changing this parameter may influence the refresh rate and the fonts selection. If the current screen refresh rate is not available for the current resolution, then the program automatically uses the first entry from the corresponding selection box.

If the selected resolution is smaller than 1024 x 768 pixels, the small fonts will automatically be used, else the large fonts.

Refresh Rate

This setting determines the refresh rate of the display. If more than one refresh rate is available, use the arrow down button to open a selection list.

The TEST button is only active if a BigWin driver is already loaded and the selected refresh rate is possible for current video mode. Alternatively, read the manual of your monitor to check which refresh rates it can handle.

Testing the Refresh Rate: **Currently not available!**

Click on the TEST button in order to test whether your monitor is able to handle the selected refresh rate.

Restore Click here or press the RETURN key to restore the previous refresh rate.

Keep Click here to retain the current refresh rate. You can also press the ESC key.

Warning: If you permanently use a refresh rate that is too high for your monitor you may damage it!
Read the manual of your monitor to check which refresh rates it can handle.

Fonts

Selects small or large fonts for screen display.

By changing the resolution, the fonts will be automatically adjusted to an optimal size. If the selected resolution is smaller than 1024 x 768 pixels, small fonts will automatically be selected, else the large fonts.

OK - Restart Options for Windows NT

You must restart Windows NT to activate your changes.
To do this, select one of the following options in DSSETNT:

Windows NT

- Shutdown and restart: Ends your current Windows NT session and restarts using the new driver.
- Shutdown: Ends your current Windows NT session without restarting. The changes you have made will be activated when you start Windows NT again.
- No Shutdown: Leaves DSSETNT without ending the current Windows NT session. The changes you have made will be activated when you start Windows NT again.

Test Button **Currently not available!**

After you have changed one or more settings, you should check that your monitor can handle the new configuration before you leave DSSETNT. If you click on the TEST button, the start-up logo will be shown for about 5 seconds using the following settings: colors, resolution and refresh rate.

Warning: If you permanently use a refresh rate that is too high for your monitor you may damage it! Read the manual of your monitor to check which refresh rates it can handle.

Start Optionale Teile des Hauptdialogues - nach Bedarf einblenden

Derzeit deaktiviert!
Monitor

Use the arrow-down button to scroll through monitors available and to select one. If you can't find your monitor type in the list, select a horizontal frequency which doesn't exceed that of your monitor (e.g. 58 kHz).

Warning: Do not select a frequency which is higher than that of your monitor! Continuously using a refresh rate which is too high will damage your monitor! Check the manufacturer's manual for technical specifications.

Derzeit deaktiviert!
Hardware Video Support

Activates/deactivates the Feature Connector (important for video playback if a corresponding board is connected to this interface).

Ende Optionale Teile des Hauptdialogues - nach Bedarf einblenden

Ende einzelne Teile des Hauptdialogues

Error Messages (Overview)

Not sufficient memory on the destination drive

File '...' cannot be created

File '...' cannot be copied

File '...' not found

WARNING : Program group cannot be created

WARNING : Program group cannot be created/updated

ERROR : No driver is available for the chosen resolution

ERROR : 'lzexpand.dll' cannot be loaded

ERROR : File cannot be loaded

ERROR : No graphics board found

ERROR : The target file ... is newer than the source file

ERROR : File ... can not be deleted

ERROR : Your system has been detected as a network installation

Please enter a valid name for the target directory

The directory ... cannot be created

This board is not supported by the current installation

'xxx' cannot be loaded

Not all files for a VGA configuration are available

Not sufficient memory on the destination drive

There is not enough space on the drive where you have installed Windows. DSSETNT can't copy the file to the WINDOWS - or SYSTEM - directory. Delete one or more unnecessary files on this drive, and try again.

File '...' cannot be created

DSSETNT can't create the file in the WINDOWS - or SYSTEM - directory. It is possible that the specified file already exists with write-protection or that the drive is write-protected. Remove the write-protection of the drive or existing file.

File '...' cannot be updated

Appears during a first-time installation in a network and the file can not be updated or written due to the lack of Write rights on the target drive.

File '...' cannot be copied

DSSETNT can't copy the specified file. If you receive a system error message you must find the origin and eliminate this problem before trying again.

File '...' cannot be copied

Appears during a first-time installation in a network and the file can not be updated or written due to the lack of Write rights on the target drive or because the file is already in use by another user. A network installation can only be correctly made if the files to be updated are not in use.

File '...' not found

DSSETNT can't find the specified file. Be sure you have inserted the correct Windows disk (or installation CD) **for your board** and that the source path is correct. Try again after checking these entries.

File '...' not found

'Please take care that the network installation has been executed with the correct installation disks'

Appears if DSSETNT is called from a network installation and one of the drivers is not available (network installation incomplete or files inadvertently deleted).

WARNING : Program group cannot be created

DSSETNT can't create the Program Manager Group. You can create the group manually or place the DSSETNT icon in another program group.

WARNING : Program group cannot be created

If your system fails to react to the command to create the program group (or to update an existing one) within 20 seconds, then this message will appear. The installation itself will however be continued.

ERROR : No driver is available for the chosen resolution

There is no driver available for the video mode specified. Select other values for colors or resolution.

ERROR : 'lzexpand.dll' cannot be loaded

DSSETNT needs this library to copy files from the Windows installation disk to the WINDOWS- or SYSTEM -directory. During the Windows installation procedure lzexpand.dll is copied to the SYSTEM directory. If the file is present and this error message still appears, then Windows doesn't have enough free memory to load the file. Close one or more applications and try again.

If the file exists but this error message still appears, then Windows doesn't have enough free memory to load the file. Close one or more applications and repeat the process.

ERROR : 'File ... can not be loaded'

It is possible that the file on the installation disk is corrupted. If the file exists but the error message persists, it is possible that Windows doesn't have enough free memory to load the file. Close one or more applications and try again.

'ERROR : 'No graphics board found!'
'Please take care that you use the correct installation disk'

ERROR : 'No graphics board found!'
'Please start DSSETNT from the installation disk'

Possible causes:

(a) You are trying to install the software from the wrong disks or for the wrong hardware.

Example:

You are using the installation disks for the MIRAGE P-**32**, although a MIRAGE P-**64** is actually installed. The board which is actually installed is displayed when the PC is booted, e.g. 'MIRAGE P-64 BIOS 4.xx'. The program displays which board the software is intended for.

(b) You haven't installed the graphics board in your system (yet). Do not attempt to run the software installation without installing your hardware first.

(c) Make sure that the hardware hasn't been exchanged!

'ERROR : 'No graphics board found!'
'Please take care that the network installation has been executed with the correct installation disks'

Appears when DSSETNT is called from a network drive but doesn't match the board locally installed.

**ERROR : The target file ... is newer than the source file'
'Should the file be nevertheless overwritten?'**

This message is self-explanatory. Check the release number or file dates of the software already installed.

ERROR : 'File ... cannot be deleted'

'After a restart in Standard VGA mode, delete this file manually'

The access to a certain file is denied, possibly because it is currently in use by the active display driver. Reconfigure Windows to standard VGA (640 x 480, 16 colors) and restart the system. Delete the file concerned manually using the File Manager or Explorer and then start DSSETNT again.

**ERROR : 'Your system has been detected as a network installation'
'Please first execute the network installation and then start DSSETNT from the network directory'**

Appears when - during a network installation (= SYSTEM directory is not located directly under the WINDOWS directory) DSSETNT is called from the installation disk.

'Please enter a valid name for the target directory!'

First-time installation or network installation: the name being used does not conform to the DOS conventions.

'The directory .. cannot be created.'

'Please enter a valid name for the target directory!'

First-time installation or network installation error message shown when the target directory doesn't exist and can not be created, e.g. because the drive concerned is write-protected.

'This board is not supported by the current installation!'
'Please use a newer version.'

The board installed has not been implemented in the version of DSSETNT being used.

'Not all files for a VGA configuration are available'
'Use the Windows Setup to reconfigure to standard VGA!'

Deinstall : Windows 3.xx checks whether the VGA drivers, grabber files and font files are located in the SYSTEM directory. If a file is missing, the VGA driver can not be loaded.

Start spezielle Dialogue

First-time Installation **Currently not available!**

Important note for Network Administrators:

DSSETNT can be installed on a network server by the System Administrator in order to save disk space. To do this it is necessary to start DSSETNT with the following call from the disk or CD: DSSETNT /n. See also: [Installing in a network.](#)

Language:

Install the software in the language (English) that you wish to use afterwards too! DSSETNT remembers the language selected and error messages and dialogues etc. will be shown in that language only. Note that other Windows utilities may also be affected by this setting!

Target Directory:

If the GDC environment variable call already exists in your AUTOEXEC.BAT, then this path will be offered again. Otherwise, C:\WINDOWS will be recommended. Only change this path if necessary! The DSSETNT and utility software will be installed in the directory stated.

Create/Update Program Group

If this option is marked, then a program group will be created, or if one already exists, updated.

Network Installation **Currently not available!**
- for Network Administrators

DSSETNT can be installed on a network server by the System Administrator in order to save disk space. To do this it is necessary to start DSSETNT with the following call from the disk or CD: DSSETNT /n.

Language:

Install the software in the language (English) that you wish to use afterwards too! DSSETNT remembers the language selected and error messages and dialogues etc. will be shown in that language only. Note that other Windows utilities may also be affected by this setting!

Target Directory:

An installation in a network is different to that onto a local hard disk. In a network, all the files are copied into the SYSTEM directory. Network installations normally hold the SYSTEM directory on the server which means that the board files only need to exist once, rather than on every PC.

If you click on 'OK' all files will be copied into the target directory and will be write-protected.

Only check the access rights:

If this option is marked, files will not be copied. Instead, they will only be checked to see if you have the necessary access rights (for example, if a file is currently being used, the System Administrator can not overwrite the file).

If the files can all be overwritten, the following message will be shown: 'The necessary access rights are available'. DSSETNT will then return to the original dialogue box. If files are found that can not be overwritten, then one of the following messages will appear: 'File DSSETNT.EXE cannot be updated' or 'The necessary access rights are not available for all files !'. In both cases the System Administrator must change the access rights before proceeding.

After installing as System Administrator:

The installation is continued interactively (as with a local installation). The only differences are that the field 'Target directory' which shows the server path is greyed out (inactive) so that workstation users can't change it, and that the language is also inactive (fixed). DSSETNT checks whether the correct drivers are available for the locally installed board and produces a corresponding error report if necessary.

Target Directory

If the GDC environment variable call already exists in your AUTOEXEC.BAT, then this path will be offered again. Otherwise, C:\WINDOWS will be recommended. Only change this path if necessary! The DSSETNT and utility software will be installed in the directory stated.

Network Installations: Currently not available!
Check the access rights on the network server first!!

De-installation

If you click on 'OK' then Windows will be reconfigured to Standard VGA (640 x 480, 16 colors). If the box 'Delete files and entries' is not checked then the software will only reconfigure to VGA and will not actually delete any files. If the box is marked then the following will be executed:

- the program group will be deleted
- entries in the WIN.INI and SYSTEM.INI files will be removed
- files in the directories WINDOWS, SYSTEM and INSTALL will be deleted*.

*Note for network installations: if this box is marked, only the files in your local WINDOWS directory will be physically deleted.

Ende spezielle Dialogue

