Video Card Installation for Windows 95/98

Hardware Installation

- 1. Shut down Windows and power down system. Unplug power cable from the system.
- 2. Remove screws and open system enclosure.
- 3. Remove static electricity by touching the metal power supply case before touching any cards.

Note: Static electricity can damage electric components. Always handle cards by the edges and avoid touching contacts or internal components.

4. If there is a video card currently installed in the system, locate it and determine if it is a card in an expansion slot or a video card built into the motherboard. If it is built into the motherboard it may need to be disabled (check with the manufacturer or the documentation for details). If it is a card plugged into an expansion slot, remove the screw that retains the card in place and carefully pull the card out of the system. Determine which type of card you are installing, ISA, PCI or AGP. Verify that there is an available slot of the correct type in the system (see figure below) and remove the screw attached to the slot cover for that slot and remove the slot cover.



- 5. Press new card firmly into the slot until it is seated completely.
- 6. Tighten the screw that retains the bracket to the enclosure.
- 7. If there are any open expansion slot holes, install the slot covers and screws to close each of them.
- 8. Close system enclosure and replace screws.
- 9. Firmly plug in the monitor cable to the 15 pin VGA connector on the card.
- 10. Reattach power cable to the system.
- 11. Power up the system and boot into Windows.

The next step is the software installation on the following pages.

Software Installation

If you ARE prompted for a driver as windows loads: **Skip to Step skip to "Plug and Play installation"**

If you are NOT prompted for a driver as windows loads:

- 1. Click Start > Run.
- 2. Click on the "**Browse**" button and navigate the driver disk to look for a "**Setup**" application to install the video drivers and any applications that are supplied by the video card manufacturer. Follow the instructions carefully as the install program continues through the install procedure. Once the driver is installed the video settings can be modified to your preferences. If no setup program is on the disk then proceed to the next step, otherwise installation should be complete.
- 3. Right click in an empty place on the desktop.
- 4. Choose **Properties** from the gray box that appears.
- 5. Choose the **Settings** tab near the top of the Display Properties box.
- 6. Click the **Advanced** button near the bottom of the box.
- 7. Choose the **Adapter** tab from the box that appears.
- 8. Click the **<u>C</u>hange** button.



9. When the Update Driver Device Wizard appears click the "Next" button.



10. You are prompted with two options for finding the drivers. Select **Search for the best** driver for your device. Click **Next**.



11. You are offered several search options. Select the Specify a location check box. Insert the driver disk into your CD-ROM or floppy drive and set the path in the Specify a location window to X:\ (Where X is the letter that corresponds to the drive the disk is in). Then click the Browse button.



12. Navigate to the driver located on the disk. Then click the "OK" button.



- 13. Confirm that the driver location is correct in the "**Specify a location**" box and click the "Next" button.
- 14. Windows will confirm that it has located the drivers for the item you are installing. Click **Next**.

Note: If the drivers could not be located, click **Back** and verify that the correct path to the appropriate driver has been entered.

- 15. Windows 98 will now copy the driver files to your hard drive and inform you when the task has completed.
- 16. Click Finish and reboot your computer, if prompted.

Plug and Play installation

Installation steps will vary depending on which operating system you are using on your system. Because of this it is necessary to have separate instructions for Windows 98 and Windows 95 operating systems. Please find the appropriate instructions for your system below:

Windows 98 installation



 The first time the system boots up after physically installing the video card, the Add New Hardware Wizard appears. The Wizard displays the text: This wizard searches for new drivers for your product. Click Next.



2. You are prompted with two options for finding the drivers. Select **Search for the best** driver for your device. Click **Next**.

Add New Hardware Wizard		
	Windows will search for new drivers in it's driver database on your hard drive, and in any of the following selected locations. Click Next to start the search. Floppy disk drives CD-ROM drive	
	💼 Microsoft Windows Update	
	🔎 Specify a location:	
	A3	
	Browse	
	< Back Next > Cancel	

3. You are offered several search options. Select the **Specify a location** check box. Insert the driver disk into your CD-ROM or floppy drive and set the path in the **Specify a location window** to **X:**\ (Where X is the letter that corresponds to the drive the disk is in). Then click the **Browse** button.

E Deskte	P				-
	wiy Computer	y (A:)			
	🚃 (C:) Ceek's Driv	er disk (D:)			
	E Geek'	s Driver folder			
		iel			
1	Scheduled 7	rasks			
	Ay Documents Recycle Bin				1000
6 ir	Inline Services				
		100	ОК	Cancel	

4. Navigate to the driver located on the disk. Then click the "**OK**" button.



- 5. Confirm that the driver location is correct in the "**Specify a location**" box and click the "**Next**" button.
- 6. Windows will confirm that it has located the drivers for the item you are installing. Click **Next**.
- 7. Note: If the drivers could not be located, click **Back** and verify that the correct path to the appropriate driver has been entered.
- 8. Windows 98 will now copy the driver files to your hard drive and inform you when the task has completed.
- 9. Click Finish and reboot your computer, if prompted.

Additional drivers may now be installed. Please wait until Windows 98 finishes loading all driverswhich may take an extra minute or two.

Windows 95 installation

There are several versions of the Windows 95 operating system. Verify your version of Windows 95 by clicking Start > Settings > Control Panel. After the Control Panel directory opens, doubleclick System. The designations 4.00.950 B or 4.00.950 C indicate you are using one of the OEM Service Releases of Windows 95. Be sure to follow the instructions below for the appropriate operating system you are using.

Notes: You may need your original Windows 95 CD to complete this installation. Windows may request the original Windows CD to update or install some necessary files. Remove the Driver CD and insert the Windows CD into the CD-ROM drive. Once Windows has installed the necessary components, the installation requests the driver installation CD. Remove the Windows CD and reinsert the driver installation CD. If you are using one of the OEM Service Releases, skip to the second section, Windows 95 (versions OSR2.X).

Windows 95 (version 4.00.950)

After your system boots, it will inform you that it has found a new device and prompts you with selections:

- 1. Select the option **Driver from disk provided by hardware manufacturer** from the "New Hardware Found" dialog. Click **OK**.
- Insert the Driver disk into your CD-ROM or floppy drive. In the space Copy manufacturers files from, type x:\ (Where X is the letter that corresponds to the appropriate drive). Then click Browse and navigate to the driver.
- 3. Windows 95 now copies the driver files to your hard drive. Click **OK**.
- 4. You may be requested to reboot your computer. If so, please restart your computer now.

Windows 95 (versions OSR2.X)

This section provides driver installation procedures for the OSR2 releases (version 4.00.950 B or 4.00.950 C) of Windows 95.

1. After your system boots, it will inform you that it has found a new Device and display the Update Device Driver Wizard. Click **Next**.

Update Device Driver W	/izard
Update Device Driver W	fizard This wizard will complete the installation of: Geek's Multimedia device by searching your local drives, network, and Internet locations for the most current driver. If you have a disk or CD-ROM that came with this device, insert it now. It is recommended that you let Windows search for an updated driver. To do this, click Next to continue.
	< Back Next> Cancel

2. Windows now searches for the location of the driver files. Wait a few moments until you see the **Other Locations** button. Click **Other Locations**.

Update Device Driver V	√izard
	Windows was unable to locate a driver for this device. If you do not want to install a driver now, click Finish. To search for a driver maually, click Uther Locations. Or, to begin the automatic search again, click Back.
	Other Locations
	< <u>B</u> ack Finish Cancel

3. Insert the Driver Disk into your CD-ROM or floppy drive and click **Browse** and navigate to the driver.

Select Other Location	X
Type the name of the folder that contains the driver you want. To search Browse.	for a folder, click
Location	
	D <u>r</u> owse
OK	Cancel

4. Click **OK**, and then click **Finish**. The driver files will be copied to their destination directories.

Update Device Driver W	√izard
	Windows found the following updated driver for this device: Geek's Multimedia device If you want to use this driver, click Finish. If this is not the correct driver and you want to search for a different driver manually, click Other Locations. Location of Driver drv dther Locations
	< Back Finish Cancel

You may be asked to reboot your computer. If so, please restart your computer.