

EMME Interactive

User's Handbook

PC

This handbook is designed for beginners and experts alike who want to know more about the function of their CD-ROMs. Amateurs will find a complete guide to any questions about their multimedia programs. In addition to step-by-step installation instructions, you will find the user's main "computer" concerns, as well as numerous insights and recommendations that give you a hand in solving the most frequent problems. After you've read your handbook carefully, feel free to send us your comments and any additional questions.

Contents

- How to Install Your CD-ROM
- Installation Trouble Shooting
- Helpful Hints
- Key Words
- Customer Service

How to Install Your CD-ROM

Windows™ 95 Installation Guide

- 1.Insert the CD-ROM in your CD-ROM drive.
- 2.From *My Computer* in Windows™ 95, select the CD-ROM drive.
- 3.Double click on *Setup*⁽¹⁾ to start the installation, then follow the instructions that appear on your screen.

OR

- 1.Insert the CD-ROM in your CD-ROM drive.
- 2.Select *Start / Run*.
- 3.Type *D:\setup.exe*⁽¹⁾ on the command line ("D" corresponds to the logic unit of your CD-ROM drive), click on *OK* to start the installation, then follow the instructions that appear on your screen.

Once the installation is complete, an icon is created in the *Multimedia from E.M.M.E.* group⁽²⁾.

Windows™ 95 Run Guide

- 1.Select *Start / Programs*.

2. Move the cursor over the *Multimedia from E.M.M.E.* group, then click on the icon corresponding to the CD-ROM.

Note: To facilitate the CD-ROM installation, some CD-ROMs contain automatic installation and run programs, "Autoplay" (in Windows™ 95 only). With "Autoplay", you just need to insert the CD-ROM to install and run the program.

Minimum setup requirements recommended

- Pentium 75
- 16 Mb of RAM
- Windows 95
- Monitor configuration: 640x480, 32,000 colors
- 4-speed CD-ROM drive
- Sound Blaster card or compatible
- Speakers or headphones
- Mouse compatible with Microsoft Windows

⁽¹⁾ Or Install.exe in some cases.

⁽²⁾ The group may differ. Check the installation notice that comes with the CD-ROM.

Trouble Shooting

Note: The words followed by an asterisk (*) are defined in *Key Words* on page 7.

⇓ If you encounter problems printing paintings or photos...

In some CD-ROMs, you may print images directly using the print option. If the program prints a blank page, please change your printer's resolution configuration to 300 DPI:

- Select **Start** then **Control Panel** from the Windows 95 tool bar.
- Click on **Printers** and select the icon that corresponds to your printer.
- Select **File/Properties**.
- Choose **Graphics** at the top of the window, then select **300 DPI** from the **Resolution** line.
- Click on **OK** to confirm your selection.

⇓ If the program does not install...

- Check that the CD-ROM* is correctly inserted printed side up in the drive.
- Verify the CD-ROM version, Mac or PC.
- If you install the CD-ROM while one or more programs are open in Windows (word processor, screen saver, etc.), application errors may occur and error

messages, like *Not Enough Memory*, may appear on your screen. Close any other program(s) in order to free enough RAM*.

- Avoid installing a CD-ROM in a program group containing a large number of icons. The new application icon might not appear. If this is the case, delete or remove several icons before beginning the installation procedure.

↓ If the program does not run...

- Did you follow the installation procedures correctly?
- Is the CD-ROM inserted in the CD-ROM drive correctly, printed side up?
- Check that the disk is clean (no spots, scratches, fingerprints, etc.). Use a soft, dry cloth or a special CD cleaning product to wipe the disk clean. Do not use an alcohol-based product.
- During the program installation, a directory is proposed and should not be modified. Continue the installation process keeping the suggested path*.

↓ If the program asks for a specific display (installation or run message), the color definition is not clear, lines are not straight or flashes appear...

- Modify the resolution of your display* by increasing or lowering the number of pixels* (640x480, 800x600, etc.) and/or the color palette (256 colors, 65,000 colors, etc.) in Windows. Check the recommended display setup on the CD-ROM case.

To change the setup of your monitor, select in the following order:

Windows™ 95

- *My Computer*
- *Control Panel*
- *Display*
- *Setup*

In the same section, check that *Small Fonts* is selected, rather than *Large Fonts*.

Important: The computer must be restarted after each modification to the setup.

↓ If the computer has crashed or the screen is frozen...

- Does your system correspond to the technical requirements of the CD-ROM (version of Windows, display* resolution, RAM*, etc.)?
- The CD-ROM may conflict with other pre-installed software* (anti-virus, word processor, scanner, fax modem, etc.). Close all other programs using memory.
- Some graphics cards may also cause problems during program use. An update of the driver* is sometimes necessary--check with your dealer. Windows™ 95 always provides you with the choice of several drivers. On the desktop, click and select the following with the right mouse button: *Properties / Setup / Change Display Type*.
- In Windows™ 95, check that the video display size is set correctly as *Window / Original size*, not *Full Screen (Control Panel / Multimedia / Video)*.
- Some memory managers may disrupt the correct functioning of the CD-ROM. Microsoft Windows supplies its own manager: EMM386. If technical problems arise, especially while running the CD-ROM, it is suggested that you use only this manager and uninstall any other pre-installed managers.

General comment: To restart Windows without turning off the computer, press the following keys twice and at the same time:

Ctrl + Alt + Del

This function allows you to quit an application that does not respond to the system. All information that has not been saved will be lost!

↓ If video playback does not work properly...

- Is Video For Windows™ or QuickTime For Windows™ installed correctly? These are system extensions that allow the viewing of videos under Windows. Most interactive programs create a directory with one of these names: *VFW* or *QTW*. Select the corresponding directory and click on *Setup.exe* to run the software installation. During the installation of a CD-ROM, a message box proposes the automatic installation of the extensions on the hard disk.

↓ If the sound is fuzzy or choppy...

- Is the sound card in use compatible with Sound Blaster*? Is it configured correctly? Check the card's drivers* and use the most recent if possible.
- In Windows™ 95, check the sound playback level: *Control Panel / Multimedia / Audio*.
- In Windows™ 95, *Control Panel / Add/Remove Programs / Windows Setup*, make sure that all of the proposed components are selected.

Helpful Hints

The following suggestions have been compiled to help you better understand the use of your CD-ROMs.

Note: The words followed by an asterisk (*) are defined in *Key Words* on page 7.

- ◇The CD-ROM* surface is delicate. Handle it with care and caution. Replace the disk in its case after each use. Avoid scratches, dust and fingerprints on the reading surface.
- ◇All CD-ROMs have a *Help* section and/or a *Read Me* file which you can consult to receive important information on the navigation and content of the program.
- ◇To avoid any memory overload, click on the mouse only once. It is not advisable to click several times in a row on “active” zones. Wait several seconds while the program is loading (an hourglass will appear on the screen).
- ◇Before starting the installation, make sure the program group in which the new icon will be created is not overcrowded with previously installed program icons. The icon of the new CD-ROM might not appear in the program group if it is full. If the icon fails to appear, remove or delete several icons from the selected program group.
- ◇Press the *Ctrl + Esc* keys at the same time to pull up the *Task List* and to see which programs are in use.
- ◇To exit a multimedia program or to quit Windows, never cut your computer’s power supply directly. This may permanently damage your system.
- ◇All CD-ROM drives are provided with a LED display. After inserting the disk, a light comes on to indicate the loading of the CD-ROM. This stabilization period lasts between one and four seconds. If you click on the program icon or installation during this intermediary process, the system may not detect the CD-ROM. Wait until the light turns off before running an application.

Key Words

- A **CD-ROM** (**C**ompact **D**isk **R**ead **O**nly **M**emory) is a digital optical disk

readable by laser beams only. During the writing of the disk, a concentrated light ray perforates a layer of thermosensitive material within the disk. The light is then reflected during the reading of the disk. A CD-ROM contains up to 650 million bytes, equivalent to 452 3.5" HD disks.

- The **path** describes the route that allows access to a program or file. During the installation of a CD-ROM, the program proposes a pre-selected path, such as: Path: c:\emme. The command line indicates the creation of a new "emme" directory at the root of the hard disk. Once the installation is complete, the CD-ROM will automatically arrange its files in this directory.
- Virtual memory** is a "swap file" run by the system and located on the hard disk. Its purpose is to free RAM in order to speed up the running of programs.
- A **byte** is an information element made up of 8 bits. It permits the representation of a single alpha-numeric character on two hexadecimal characters. The byte is the basic unit used to measure computer information storage capacity (kilobytes, megabytes, etc...).
- The **driver** is a piece software that controls a peripheral, enabling all equipment to be connected to the CPU (sound card, printer, CD-ROM drive, etc...).
- RAM (Random Access Memory)** is a writeable storage medium as opposed to ROM (Read Only Memory) which can only be read.
- Display resolution** is represented by the number of lines and columns that define the number of image points on a screen. These points, called pixels (abbreviation for PICTURE ELEMENT), define the quality of the image. A VGA monitor with 640 columns by 480 lines, the standard PC display (14" screen), contains 307,200 pixels.
- Sound Blaster** is the standard sound card used as a reference in the multimedia field.

Customer Service

Most of your technical problems are likely to be addressed in this handbook. For more information, feel free to contact EMME Interactive technicians at the following numbers:

<http://www.emme.com>

EMME Interactive products and services:

games and CD-ROMs to win,
press releases on all of our products,
an updated list of our CD-ROM titles,
what the critics are saying about our products,
and other information...

TECHNICAL SUPPORT LINE

(33 1) 53 04 60 30

Monday-Friday 10AM-6PM

Technical assistance by telephone guarantees the maximum use of your CD-ROMs. To better serve you, please fill in and return the comment card found in the EMME Interactive product that you recently purchased. If you have difficulties contacting us by phone, please write to us by fax at **(33 1) 53 04 60 40**. Don't forget to include your system setup and any technical problems you've had. You can also reach us by mail at the below address, attention of:

Customer Service

EMME Interactive (main office)
48, boulevard des Batignolles
75017 Paris, FRANCE
Telephone: (33 1) 53 04 60 00
Fax: (33 1) 53 04 60 40

©EMME - 1998 - All rights reserved. - All products cited are trademarked by their respective companies.