



DJ\_BothSides 1.3 demo

© Copyright David R. Tilley, 1992

## Help Index

### Commands

[Document menu](#)

[Port menu](#)

[Help menu](#)

### Printing topics

[Print options](#)

[Reloading the paper](#)

[Hints](#)

[Error messages](#)

### Keyboard

[Escape key](#)

[PgUp key](#)



## Document menu

The Document menu includes commands that enable you to select a file and to print it.

For more information, select a Document menu command name:

<u>F</u> ile	Select a file for printing.
<u>P</u> rint	Print the selected file.
<u>P</u> rint <u>m</u> inimized	Iconize main window on 'Print'.
<u>R</u> eport	Obtain a running commentary.
<u>O</u> ptions	Select print options.
<u>S</u> ave <u>o</u> ptions	Save selected print options.
<u>E</u> xit	Exit DJ_BothSides.



## **Port menu**

The Port menu provides commands for identifying the printer port.

For more information, select an item:

<u>LPT</u>	Parallel ports.
<u>COM</u>	Serial ports.
<u>Addresses</u>	Parallel port addresses.



## **Help menu**

The Help menu provides useful information on using DJ\_BothSides.

For more information, select an item:

- [Index](#) Displays an index to on-line help on DJ\_BothSides.
- [About](#) Displays information on DJ\_BothSides.

**Document File Command**

Use the File command to choose the file you wish to print.

**Document Print command**

Use the Print command to print the chosen file using the default (or previously selected) options.

### **Document Print minimized command**

Click on this menu item to cause DJ\_BothSides' main window to shrink to an icon when you click on 'Print'. BothSides makes a beep when it's ready for paper reinsertion and when it's finished printing.

N.B: reports and the special cursors are disabled when you select this item.

**Document Report command**

Use the Report command to obtain a running commentary on the print run.

The margins, diskette and printing cursors are disabled when reports are requested.



### **Document Options command**

Use the Options command to bring up the Print options dialogue form.

**Document Save options command**

Use the Save options command to save your choice of print options for the next time you use DJ\_BothSides.

**Document Exit command**

Use the Exit command to leave DJ\_BothSides.

### **Parallel Port commands**

Use the LPT1, LPT2 or LPT3 command to identify the parallel port to which your printer is connected.

### **Serial Port commands**

Use the COM1, COM2, COM3 or COM4 command to identify the serial port to which your printer is connected.

### **Port addresses command**

Click on this command and select the 'Calculate' button to determine the parallel printer port address. This stops an 'Unrecoverable Application Error' when the printer is switched off.

**Help Index command**

Use the Index command to access DJ\_BothSides' on-line help information.

**Help About command**

Use the About command to display DJ\_BothSides' version number and copyright notice.





## **Print options**

When the Document menu Options command is used, the Print Options dialogue form appears, which is subdivided into the following groups:

Print Quality

Paper size

Column format

Margin

Font

Footer

Page range and tab expansion

OK and Cancel buttons

**Print quality**

**Draft|Letter**


Radio buttons which select draft or letter-quality output. (High-grade paper is recommended with the latter.)

## Paper size

### A4|US letter|US legal|Envelope

Radio buttons that select the following paper sizes:

European A4	210 x 297 mm
US letter	8.5 x 11 in
US legal	8.5 x 14 in
European DL envelope	110 x 221 mm or
US No.10 envelope	4.12 x 9.5 in



For the last two, the address will have 50 mm (2 in) left-hand and top margins (approximately) provided the envelope is loaded as indicated.

## Column format

### Single|Double|Folded

Radio buttons which select:



single-columned output



double-columned output



booklet output (which is folded in half).

N.B:

Proportionally-spaced fonts and centred output are unavailable when double-columned or folded output is requested.

Double-columned output is unavailable for files containing form-feeds.

Folded output has half-inch margins.

## **Margin**

### **1-inch LH|Centred**

Radio buttons which select a one-inch left-hand margin or centred output.

N.B: centering is unavailable when a proportionally-spaced font is selected.

## Font

### Monospaced|Proportional|Prestige Elite|Garamond Collection

Four radio buttons which select the font to be used. Those which come as standard with your Deskjet 500 are:

The Courier and Letter Gothic **monospaced** fonts. Which of Courier and Gothic is used depends upon the maximum line width of the document.

The CG Times **proportional** font.

Those available on cartridge from Hewlett-Packard and which are supported by DJ\_BothSides are:

The **Prestige Elite** monospaced font.

The **Garamond** proportional font collection. You are invited to choose a character size from 10-, 12- or 14-point if you select this font.

The other cartridge fonts, CG Century Schoolbook, Helvetica, Times Roman and CG Triumvirate, are not implemented and their buttons are greyed out.

## **Footers**

### **Page number footer**

#### **Page #|Page #/#|None**

Radio buttons which cause the page number to be printed at the foot of each page - or not at all with 'None'. When 'Page #/#' is selected, the total number of pages is also printed, separated from the page number by the solidus '/'.

N.B: 'Page #/#' is unavailable when the 'Start' or 'End' entry is changed.

### **Date footer**

#### **File date|System date|None**

The 'File date' radio button causes the date of creation or most recent amendment for the file being printed to appear at the foot of the page. 'System date' causes the current date, as known to your system, to be printed instead. No dates are printed when you select the 'None' radio button.

### **File name footer**

#### **Filename footer...**

Check this box to cause the name of the file being printed to appear at the foot of the page...

#### **...with path**

...and this one to print its path also.

***None of the page footer options is available for files containing form-feeds.***

## **Page range and tab expansion**

### **'Start' and 'End'**

These entries are used to print some of the pages of a document. By default, all pages are printed.

### **'Tabs'**

This entry specifies the expansion of tab characters (default: 4).



## **OK and Cancel buttons**

### **OK**

The OK button confirms your options selection.

### **Cancel**

The Cancel button throws away your options selection.



## Reloading the Paper

Load your Deskjet's input hopper as normal.

DJ\_BothSides will send the **back** pages of your document to the printer first and then display a dialogue form prompting you to reinsert the paper, but don't do this until the Deskjet's busy light **stays** off.


Remove the paper (possibly including a blank page on top) from the output hopper.

[N.B: once you are familiar with using DJ\_BothSides, this is the time to check for unexpected, completely blank pages in case the Deskjet had fed two pages at once. Remove any before you reload the paper.]

Reinsert the sheets **without changing their order** all together into the input hopper (on top of any unused sheets), **making sure that the printed side is on the top**, and:



If DJ\_BothSides selects portrait mode, make sure the top edge of the paper (nearest the first line) goes into the hopper first (**turn the paper through 180 degrees**), or



If landscape mode is selected, make sure the left-hand edge of the paper (nearest the first column) goes into the hopper first (**no rotation is necessary**).

Ensure that the paper is nicely stacked and then click on the [Ready] button.

The document arrives in the output hopper the right way up in the correct order.

Very occasionally, the Deskjet will feed two sheets at once, messing up the whole process. It's best to start again from scratch if this occurs.

If you've enabled reports, pressing the [Esc] key will stop subsequent pages being printed.



## Hints

Whilst DJ\_BothSides' operation is essentially automatic, the following text widths are recommended for single-column output and all paper sizes:

<b>Courier</b>	<b>Prestige or Letter Gothic</b>	<b>CG Times</b>	<b>Garamond</b>		
			<b>10-pt</b>	<b>12-pt</b>	<b>14-pt</b>
67	80	~86	~100	~86	~74

The widths for the proportional fonts are necessarily approximate.

Unless CG Times, Garamond or Prestige is selected, a smaller point-size and/or landscape orientation is triggered for files wider than 81 characters:

### Document width (characters)

<b>US letter</b>	<b>82-94</b>	<b>95-132</b>	<b>133-157</b>
<b>A4</b>	<b>82-102</b>	<b>103-132</b>	<b>133-171</b>
<b>US legal</b>	<b>82-126</b>	<b>a</b>	<b>127-211</b>
<b>Portrait</b>	Courier 6-pt, 20 cpi, 10 lpi, lpp: 104/97 (A4/US letter)		<i>a</i>
<b>Landscape</b>	Courier 12-pt, 10 cpi, 6 lpi, 48 lpp	<i>a</i>	Courier 6-pt, 16.67 cpi, 10 lpi, 75 lpp

### Key

The following page sizes (depth in single-spaced lines, width in characters) are recommended for paginated, pre-formatted text intended for folded output (which is always in 6- or 12-point Courier):

<b>Paper size</b>	<b>12-point, 6 lpi, 10 cpi</b>		<b>10-point, 7 lpi, 16.67 cpi</b>		<b>6-point, 10 lpi, 16.67 cpi</b>	
	<b>Depth</b>	<b>Width</b>	<b>Depth</b>	<b>Width</b>	<b>Depth</b>	<b>Width</b>
US letter	47	46 54	74	74	74	74
A4	47	50 54	81	74	81	81
US legal	47	60 54	100	74	100	100

Eighty-page documents begin to get unmanageable for folding and anything less than a heavy-duty, long-arm stapler.

Reduce the chance of double-feeding by using high-grade paper (greater than 80 gsm or 16.4 pounds).



## Error messages

"A line in the document is too long."

The length of at least one line in the document exceeds the maximum permitted (> 400).

**Solution:** reduce the tab size.

"A printed line will be too long."

The length of two adjacent lines 'across the fold' exceeds the maximum permitted (> 400). This is often due to the combination of underline and bold.

**Solution:** reduce the text enhancement.

"Document is too wide for folded output." or

"Document is too wide for two columns." or

"Your document is too wide for printing."

**Solutions:** reduce the tab size and/or select single-column output.

"Double-columning is unavailable for files containing form-feeds."

**Solutions:** select single-column or folded output.

"Final page is before start page." or

"Start is after last page." or

"You can't start at page 0." or

"Invalid integer entry."

**Solution:** refill the 'Start' and 'End' entries.

"Form-feed position exceeds the maximum page depth."

The page depth of a pre-formatted document is too large for the paper.

**Solution:** read the hints in the on-line help.

"The demo doesn't print more than 16 pages. Buy the full version."

Self-explanatory.

**Escape key**

If you've enabled reports, the [Esc] key may be used to abort a print run. This facility is unavailable otherwise.

It's useful if the Deskjet had fed two sheets at once or if you decide that the format selected by DJ\_BothSides is unsuitable.

N.B: you'll have to wait whilst pages, sent to the printer before you pressed [Esc], are printed.

## PgUP key

The [PgUp] key on the numeric keypad acts as a toggle that suppresses or activates printing (if reports are requested). But be careful: more than a single press during a print run could produce muddled output.

This key is useful for obtaining statistics on a document and a print sample.

[MAP]

```
#define HELPID_reload_info 699
#define HELPID_DOCUMENT_FILE 700
#define HELPID_DOCUMENT_RUN 706
#define HELPID_DOCUMENT_PRINT 701
#define HELPID_DOCUMENT_REPORT 702
#define HELPID_DOCUMENT_OPTIONS 703
#define HELPID_DOCUMENT_SAVE 704
#define HELPID_DOCUMENT_EXIT 705
#define HELPID_PORT_PARALLEL 710
#define HELPID_PORT_SERIAL 711
#define HELPID_PORT_ADDRESSES 712
#define HELPID_HELP_INDEX 720
#define HELPID_HELP_ABOUT 721
```

## **Portrait orientation**

With portrait paper orientation, all lines are printed parallel to the **shortest** edge of the paper.

N.B: all the Deskjet 500's internal fonts - and most Cartridge fonts - may be used with portrait orientation.



## **Landscape orientation**

With landscape paper orientation, all lines are printed parallel to the **longest** edge of the paper.

N.B:

Of the Deskjet 500's internal fonts, only the Courier font can be used with landscape orientation.

The Prestige Elite and Garamond Collection cartridge fonts **cannot** be used with landscape orientation.

**Key**

<i>a</i>	not available
<i>b</i>	optional
cpi	characters per inch
lpi	lines per inch
lpp	lines per page (including footer)
pt	point-size

