


User's Manual
English

The  symbol on our products signifies that they have been certified according to the EMC directive 89/336/EEC, the Telecommunications directive 91/263/EEC, and the Low Voltage directive 73/23/EEC when applicable. The products fulfil the requirements according to the following standards:

Cellular Phones and Accessories in Combination:

ETS 300 342-1 EMC for European digital cellular telecommunications.

Accessories Without Direct Connection to a Cellular Phone:

*EN 50081 Electromagnetic compatibility, Generic Emission Standard, and
EN 50082 Electromagnetic compatibility, Generic Immunity Standard.*

This manual describes Ericsson GA628, all versions

First edition (March 1997)

This manual is published by **Ericsson Mobile Communications AB**, without any warranty. Improvements and changes to this manual necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by **Ericsson Mobile Communications AB** at any time and without notice. Such changes will, however, be incorporated into new editions of this manual.

All rights reserved.

© **Ericsson Mobile Communications AB**, 1997.

Publication number: **LZT 126 1352/7 R1A**

Printed in Sweden

INNOVATRON PATENTS

Guidelines for Safe and Efficient Use

Important: Read this information before using your portable phone

General

Since its introduction in the mid 1980s the portable phone is one of the most exciting and innovative products ever developed. With it, you can stay in contact with your office, your home, emergency services, and others.

Your telephone is a radio transmitter and receiver. When it is ON it receives and also sends out radio frequency (RF) energy. Depending upon the type of mobile phone you have purchased, it operates in different frequency ranges and employs commonly used modulation techniques. When you use your phone, the system handling your call controls the power level at which your phone transmits.

For the safe and efficient operation of your phone, observe these guidelines.

Exposure to radio frequency energy

The International Commission on Non-Ionizing Radiation Protection (ICNIRP), sponsored by the World Health Organization (WHO), published a statement in 1996 which sets limits for exposure to RF fields from handheld mobile phone. According to this statement, which is based on the available body of research, there is no evidence that mobile terminals meeting the recommended limits can cause any adverse health effects. All Ericsson telephones conform to the ICNIRP recommendations, and international exposure standards, such as:

- CENELEC European Pre-standard ENV50166-2

- ANSI/IEEE C95.1-1992 (USA, Asia-Pacific)

If you want to limit RF exposure even further, you may choose to control the duration of your calls and operate your phone in the most power efficient manner.

Efficient phone operation

How to use your phone for optimum performance with minimum power consumption:

- Hold the phone as you would any other telephone. While speaking directly into the mouthpiece, angle the antenna in a direction up and over your shoulder. If the antenna is extendable, it should be extended during a call.
- **Do not** hold the antenna when the phone is **IN USE**. Holding the antenna affects call quality, may cause the phone to operate at a higher power level than needed and shorten talk and standby times.

Antenna care and replacement

Do not use the phone with a damaged antenna. Replace a damaged antenna immediately. Consult your manual to see if you may change the antenna yourself. If so, use only an Ericsson approved antenna. Otherwise, take your phone to a qualified service centre for repair.

Use only the designated Ericsson antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate the appropriate regulations.

Do not use an antenna designed for any other type of portable telephone than the telephone you have purchased.

Driving

Check the laws and regulations on the use of telephones in the areas where you drive. Always obey them. Also, when using your phone while driving, please:

- Give full attention to driving.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

RF energy may affect some electronic systems in motor vehicles. In addition, some vehicle manufacturers forbid the use of mobile phones in their vehicles. Check with your vehicle manufacturer's representative to be sure your phone will not affect the electronic systems of your vehicle.

Electronic devices

Most modern electronic equipment, for example, equipment in hospitals and cars, is shielded from RF energy. However, RF energy from telephones may affect some electronic equipment.

Turn your phone OFF in health care facilities when regulations posted in the areas instruct you to do so. Always request permission before using your phone near medical equipment.

Mobile telephones may affect the operation of some implanted cardiac pacemakers, equipment for people with hearing impairments and other medically implanted equipment. Pacemaker patients should be aware that the use of a mobile phone very close to a pacemaker may cause the device to malfunction. Avoid placing the phone over the pacemaker, i.e. in your breast pocket. When using the phone, place it at your ear opposite the pacemaker. If a distance of 15cm. is kept between the phone and the pacemaker, the risk of interference is limited. Contact your cardiologist for more information.

Aircraft

Turn your phone OFF before boarding any aircraft.

- Use it on the ground only with crew permission
- Turn off your phone before the aircraft leaves the ground. Do not use it in the air.

To prevent possible interference with aircraft systems, safety regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent interference with communication systems, you must not use your phone while the plane is in the air.

Power Supply

- Connect AC (Power supply) only to designated power sources as marked on the product.
- To reduce risk of damage to electric cord, remove from outlet by holding onto AC adapter rather than cord.
- Make sure the cord is located so that it will not be stepped on, tripped over or otherwise subjected to damage or stress.

- To reduce risk of electric shock, unplug unit from power source before attempting any cleaning, then use soft cloth dampened on with water.

Children

Do not allow children to play with your phone. It is not a toy. Children could hurt themselves or others (by poking themselves or others in the eye with the antenna for example). Children could also damage the phone or make calls that increase your telephone bills.

Blasting areas

To avoid interfering with blasting operations, turn your unit OFF when in a “blasting area” or in areas posted “turn off two-way radio”. Construction crews often use remote control RF devices to set off explosives.

Potentially explosive atmospheres

Turn your phone OFF when in any area with a potentially explosive atmosphere. It is rare, but your phone or its accessories could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fuelling areas, such as gas stations, below deck on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Do not transport or store flammable gas, liquid, or explosives in the compartment of your vehicle which contains your phone and accessories.

Product care

- **Do Not** expose product to water or moisture. Example: bathtub, laundry sink, wet/damp basement, swimming pools, etc.
- **Do Not** expose product to extreme temperatures such as found near a hot radiator or stove, or in a car parked in the sun.
- **Do not** expose product to extreme cold temperatures such as a car parked outdoors in winter.
- **Do Not** expose product to lit candles, cigarettes, cigars, open flames, etc.
- **Use only Ericsson Original accessories.** Failure to do so may result in loss of performance, fire, electric shock, or injury, and will void the warranty.
- **Do Not** attempt to disassemble the product. Doing so will void warranty. This product does not contain consumer serviceable components. Service should only be performed by Authorized Service Centres.

Table of Contents

Guidelines for Safe and Efficient Use	i	Useful Information while Talking	7	Personalizing Your Phone	13
Assembly Instructions	1	Changing Volume while Talking	7	Changing Ring Volume	13
Assemble and Charge – Four Steps	1	Muting Microphone	7	About Ring Type	13
1. Inserting SIM Card	1	Using Phone as Scratch Pad	7	About Display Language	13
2. Attaching Battery	2	Sending Tone Signals	7	Changing Key Sound	14
3. Connecting Charger to Phone	2	Checking Time of Calls	7	Diverting Calls	14
4. Connecting Charger to Mains	3	About Calling Line Identification (CLI)	7	About Diverting Calls	14
About the Charging Function	3	Handling Two Calls	8	Diverting Your Calls	14
About the Battery and the SIM Card	3	Navigating the Menu System	9	Viewing Status of Call Divert	15
Turning On the Phone and General Information	3	About the Menu System	9	Cancelling Call Divert	15
Turning On the Phone	3	Moving Through the Menu System	9	Protecting Your Keypad, Phone and SIM Card	15
About the Display	4	Selecting the Ring Vol Menu	9	About Locks	15
Learning about Your Phone	5	Creating Your Own Phone Book	11	Keypad Lock	15
Making and Receiving Calls	6	About the Phone Book	11	Card Lock (SIM)	15
Making a Call	6	Storing Numbers on SIM Card	11	Changing PIN	16
Ending a Call	6	Storing Numbers in Phone's Memory	11	Unlocking with PUK	16
Making an International Call	6	About Recalling Phone Numbers	12	Phone Lock	16
Making an Emergency Call	6	Position Recall	12	(Un)Locking Phone	16
Retry Function	6	Deleting Storage Position	12	Barring Calls – Restricting Calls	17
Receiving a Call	6	About Last Dialed Numbers	13	About Barring Calls	17
Answering a Call	6	About Unanswered Calls	13	Activating Call Bars for Any Call Type	17
Rejecting a Call	6			Cancelling All Call Bars	17
Putting a Call on Hold	7			Sending and Receiving Text Messages	18
				About Text Messages	18
				Checking Subscription	18

Setting Service Center Address	18
Sending SMS	18
Receiving a Message	18
Reading an Old Message	19
Receiving Area Information	19
About Area Information	19
Activating the Area Information	20
Adding a Code	20
Erasing a Code	20
Changing a Code	20
Knowing Duration of Calls	20
About Duration of Calls	20
Viewing Calling Information	20
Resetting a Call Meter	21
Other Networks	21
About Choosing Network	21
Selecting a Network	21
Your Phone and Accessories	22
Front Panel	22
Handsfree Equipment	22
PC-card	22
Index	23

Assembly Instructions

This chapter describes how you assemble the phone, what the SIM Card is, and how you handle the battery.

Assemble and Charge – Four Steps

- Insert the SIM Card.
- Attach the battery.
- Connect the charger to the phone.
- Connect the charger to the mains.

1. Inserting SIM Card

Insert the SIM Card into the SIM Card holder as described in Figure 1 and lock the holder.

Make sure the cut corner of the SIM Card is placed as in Figure 1.

Removing SIM Card

1. Make sure the battery is removed.
2. Lift up the SIM Card holder as described in Figure 1.
3. Pull out the SIM Card.




Figure 1. Inserting SIM Card

2. Attaching Battery

Place the battery on top of the phone and push until you hear a click (see Figure 2).

Removing Battery

1. Make sure the phone is turned off.
2. Press the locking catch on the bottom of the battery (see Figure 2).
3. Lift the battery up and away from the phone.




Figure 2. Attaching and removing battery.

3. Connecting Charger to Phone

Have the battery attached to the phone and connect the charger as described in Figure 3. The flash symbol on the charger plug has to be turned up.

Disconnecting Charger

Lift the plug up and pull it out (see Figure 3).




Figure 3. Connecting and disconnecting charger.

4. Connecting Charger to Mains

Plug the charger into a mains socket. The phone now starts to charge the battery and you can see the battery meter in the display move while charging.

About the Charging Function

When you connect external power to the phone, the battery is charged. When the battery is fully charged, the charging stops. You cannot overcharge your battery.

When you are charging the battery you can use your phone as normal; however the charging time will be longer.

About the Battery and the SIM Card

The Battery

Your phone is supplied with a Nickel Metal Hydride battery. The battery is not charged before shipment, even though there might be enough power to turn the phone on.

Remember to recycle the battery when you will not use it anymore.

The SIM Card

Before you can start using your phone, you need to order a SIM Card from a GSM service provider. The SIM Card is a computer circuit that keeps track of your phone number, the services that you have ordered from the service provider, and your phone book information.

The SIM Card sometimes contains information that lets the phone automatically change the display texts into the language of the SIM Card.

Your SIM Card is supplied with a security code or PIN (Personal Identity Number) that you need to enter into the phone to gain access to the phone and network.

Turning On the Phone and General Information

This chapter describes the display information you receive from your phone when you use it.

Turning On the Phone

1. Press and hold down the **NO** key until you hear a click. The display will prompt you to enter the PIN (the security code that follows your SIM Card).

PIN:

2. Enter the PIN and press **YES**.
The PIN is indicated as **** in the display.

LZT 126 1352/7 R1A

If you entered the PIN correctly, you will be welcomed by your phone. Then it searches for a network.

When a network is found, the indicator light on top of the phone flashes green once every second and the standby display is shown (see Figure 4).



Figure 4. Standby display.

Turning Off the Phone

- Press and hold the **NO** key until you hear a click and the display is dark.

About the Display

Your phone display will help you to:

- Verify that you are dialling correctly.
- Check your battery status.
- Check your signal strength and service availability.
- Indicate that you have received messages.

Looking at the Display

The picture below shows how the display looks when the entire icon row is lit. Table 1 explains what each icon means.

Note!

All icons may not be visible at all times.




Figure 5. Display with all icons lit.




Table 1. Description of display icons.

Icon:	Indicates:
Network	The name and country of the network.
Signal Strength	The received signal strength in five steps, depending on the strength of the signal.
Line	Whether line 1 or 2 is active. The respective icon is lit when the current line is activated. These icons only show if you have two lines on your SIM Card.
Divert	The divert arrow indicates that the phone has a divert active. The arrows corresponds to the line that is diverted.
Silent Ring Signal	Shows that no ring signal will sound when the phone is ringing.
Letter	That you have received a short text message or area information.
Phone	That you are engaged in a call.
Battery	The current battery strength – more bars means more power remaining.

Learning about Your Phone

The parts list corresponds to Figures 6 and 7:

- 1. Antenna
- 2. Status light
- 3. Beeper
- 4. Earpiece
- 5. Display
- 6. Keypad
- 7. Microphone
- 8. Charging connector
- 9. Battery
- 10. SIM Card holder
- 11. Phone clip holder
- 12. External antenna connector




Figure 6. Front view of your phone.




Figure 7. Semi-back view of your phone.

Making and Receiving Calls

This chapter describes how to you make and receive calls, make international- and emergency calls.

Making a Call

1. Enter the area code and phone number. The phone number is shown in the display. If the number is longer than 12 digits, the beginning of the number will be shown as an arrow (see Figure 8).



Figure 8. Number with more than 12 digits.

To erase a digit, press **CLR**. To erase the entire phone number, press and hold down **CLR** for a couple of seconds.

2. Press **YES** to make the call. The display shows **Calling**, followed by **Connecting** and the phone icon is lit.

Ending a Call

- Press **NO** to end the call.

Making an International Call

1. Press and hold the zero key until the international + prefix is displayed.
2. Enter the country code, area code (without any leading zero) and the phone number.
3. Press **YES** to make the call.

Making an Emergency Call

- Enter **112** (The international emergency number) and press **YES**.

The **112** emergency number can be used in any country with or without a SIM Card, provided a GSM network is within range.

Retry Function

If the call connection fails or if the number you are trying to reach is busy, the display shows **Retry?**. Press **YES** to redial the number, otherwise **NO**.

If you press **YES**, the number will automatically be redialled until the call is answered, or 10

times at the most. If you press any key, or you receive a call, the redialling is interrupted.

If the redialling is successful, the phone rings twice to inform you.

Receiving a Call

When you receive a call, the phone rings and the indicator light on the top of the phone blinks green rapidly. The display shows **Answer?**

Answering a Call

- Press **YES** to answer the call
- When the call is finished, press **NO**.

Rejecting a Call

- Press **NO** when the phone rings. The display now looks like this:

BusyTone

If the caller's network supports it, the caller will hear a busy tone.

If you have been unable to answer, or you have rejected a call, the number of the unanswered call will be shown in the **MissedCall** menu.

Putting a Call on Hold

- Press **YES** to put a call on hold.
To put the call **off hold**, press **YES** again.

Useful Information while Talking

This chapter describes how you can: change the volume of the ear piece; use the display as a scratch pad; send DTMF tones; check the duration of the current call; show or hide your phone number (CLI – Calling Line Identification); handle two calls simultaneously.

Changing Volume while Talking

During a call, you can use the arrow keys to increase or decrease the ear piece volume.

Muting Microphone

- Press and hold the CLR key.

Using Phone as Scratch Pad

1. Enter a phone number on the keypad while talking.
When you end the call, the number remains in the display.
2. Press **YES** to make the call in the display.

Sending Tone Signals

During a call you can press keys 0 – 9, * and # to send DTMF tones. For example, to perform banking by phone or to control an answering machine.

Checking Time of Calls

When you start a call (incoming or outgoing), the airtime is counted in minutes and seconds and shown on the display, like this:

1:34

About Calling Line Identification (CLI)

The Calling Line Identification service shows the caller's phone number when you receive a call (you have to order this service from your network provider). If the caller's name is stored in your phone book, you will see both the name and number.

Showing Your Phone Number

If you subscribe to normally **withhold** your number when calling, you can show the number on a particular call.

1. Enter the number you wish to call.
2. Press **↵**.
The display shows **Send Id?**
3. Press **YES** to make the call.

Hiding Your Phone Number

If you subscribe to normally **show** your number when calling, you can hide your number on a particular call.

1. Enter the number you wish to call.
2. Press **↔** twice.
The display shows **Hide Id?**
3. Press **YES** to make the call.

Handling Two Calls

Your phone can handle two calls simultaneously. This allows you to hold one call and make or receive another, then you can switch between the two calls.

To be able to receive a second call, you must activate the Call Wait function.

Activating the Call Wait Function

- Press * 43 # followed by **YES**.
The display will say **Please Wait** followed by **ON**.

Deactivating the Call Wait Function

- Press # 43 # followed by **YES**.

Receiving a Second Call While a Call Is in Progress

When you receive a second call, you will hear a tone in the earpiece and the display shows **Call Wait**.

- Press **YES** answer the second call. The current call is put on hold.
The display now looks like this.

1 On Hold

- To **reject** the second call, press zero followed by **YES**.

Switching Between Two Calls

- Press **YES** to switch between the two calls.

Ending the Current Call and Return to the Held Call

1. Press **NO** to end the current call.
The display shows **Retrieve?** and you hear two beeps.
2. Press **YES** within three seconds to return to the held call.

If you do not press **YES** within three seconds, the held call is automatically ended.

Making a Second Call while a Call Is in Progress

- Enter the second phone number and press **YES**. The first call is put on hold and the display looks like this:

1 On Hold

Receiving a Third Call

If you are engaged in one call and have a second one on hold, you may receive a third call. You will hear a tone in the ear piece and **Call-Wait** is shown in the display.

You can only have one call on hold at a time, so you need to end the first or second call before you answer the call.

You can do one of the following:

- Press zero followed by **YES** to reject the third call.
- End the first call, retrieve the held call, and answer the incoming call
- End both calls. The phone rings and the question **Answer?** appears in the display. Press **YES** to answer the call.

Navigating the Menu System

This chapter describes how you navigate through the menu system to get maximum use of your phone.

About the Menu System

You control the functions of your phone by a menu system.

Some menus have sub-menus that have individual settings. If the menu has sub-menus, three dots appear after the menu name. See the example below:

Settings...

Moving Through the Menu System

Use these keys to move through the menu system and to find the different menus.



When you reach the desired menu, press **YES** to choose the menu. Use the **↔** keys until you reach the function or setting you want. Then, in the same way you chose a menu, press **YES** to select the setting or function.

Press this:	To:
YES	confirm a setting or a selection.
NO	reject a setting or a function.
CLR	return to the standby display.
↔	scroll to the right in the menu system.
↔	scroll to the left in the menu system.

Glossary

These terms will be used throughout the manual.

Scroll: Pressing the left or right arrow key to move between the menus.

Select: Scrolling to a menu and then press **YES**.

Enter: Keying in letters or numbers from the keypad.

Selecting the Ring Vol Menu

1. Press **CLR** to clear the display.
Press the right arrow key until you reach the **Ring Vol** menu.
2. Press **YES**.
You are now in the **Ring Vol** menu.
3. Press the arrow keys to change the ring volume and then press **YES** to confirm.

Menu Overview



Creating Your Own Phone Book

This chapter describes how you can store phone numbers both on your SIM Card and in your phone's own memory.

About the Phone Book

You can store phone numbers both on your SIM Card and in your phone's own memory. The difference between the two is you can remove the SIM Card and use all those numbers in other phones, while the phone's memory always stays the same no matter which SIM Card is inserted. When you store phone numbers, you do not get a real phone book. Instead you need to keep track of where on the SIM Card or in the phone that you have stored your phone number.

You can store up to 50 phone numbers in the phone memory. The number of phone numbers you can store on your SIM Card is SIM Card dependent.

International Numbers

If you intend to use your phone book both at home and abroad, you should store all phone numbers as international phone numbers, i.e. with the international prefix "+" and the country code before the area code (without any leading zero) and the number.

LZT 126 1352/7 R1A


- To enter the plus prefix, press and hold the zero until you see the plus in the display.

Speed Dialling

The phone numbers that you store in positions 1–9 on the SIM Card can be called by entering the position number and then pressing YES. You should, therefore, save positions 1–9 for important numbers.

Storing Numbers on SIM Card

1. Enter the phone number you wish to store.
2. Press the left arrow key until **Store** is shown and press YES twice.
3. Enter the first letter of the name by pressing the appropriate numeric key as many times as required (see Table 2 for all characters). Enter the next letter when the cursor has moved to the next letter position. The number of letters the name can have is SIM Card dependent. Press YES when you are done with the name.



4. If you want to store the phone number in the storage position suggested in the display, go directly to step 5.

If you want to store the number in a **different position**, press CLR to erase the position number displayed and enter another number.

5. Press YES to confirm the position number. The display shows **Stored**.

If you have chosen a position number that is already occupied, **Overwrite?** is displayed. Press YES to overwrite or NO to return to the position number and change it.

Storing Numbers in Phone's Memory

Follow the the same procedure as storing a phone number on the SIM Card up to step 4. When you are prompted to set storage position number, press # once to enter the # character (which indicates storage in phone memory) and twice to have the phone suggesting the first free storage position. Press YES to confirm the storage.



11

About Recalling Phone Numbers

You can recall a phone number any time from either the SIM Card or the phone memory. You can recall the phone number by either the name or the storage position number.

Recalling by Name

1. Press **CLR** to erase any digits from the display.
2. Select the **RecallName** menu.
You are prompted to enter a name.
3. Enter either the full name or the first letter and press **YES**.
The first name that matches the letter string is displayed. If needed, scroll to the name you want.

Press the * key to see the storage position.

4. Press **YES** to call the number.

Position Recall

Recalling by Number – Speed Dialling

1. Press **CLR** to erase any digits from the display.
2. Enter a position number between 1 and 9.
3. Press **YES** to make the call.

From SIM Card

1. Enter the position number and press #.
2. Press **YES** to call the number,
or scroll until you find the number you want to call and press **YES**.

- Press **CLR** or **NO** to return to the standby display with the number showing.

From Phone Memory

1. Press and hold # until the ☒ symbol is shown.
2. Enter the position number.
3. Press # to recall number.

4. Press **YES** to call the number,
or scroll until you find the number you want to call and press **YES**.

Deleting Storage Position

1. Select the **RecallName** menu.
2. Choose the name you want to delete, press and hold **CLR**.
3. Press **YES** at the Erase prompt.

Table 2. List of keypad numbers, symbols and letters.
Press * to get lower-case letters. Press and hold a key to get the number directly

Key	Press the corresponding key this many times to get the symbol.											
	1	2	3	4	5	6	7	8	9	10	11	12
1	space	-	?	!	,	.	:	"	'	()	1
2	A	B	C	Å	Ä	Æ	à	Ç	2			
3	D	E	F	è	É	3						
4	G	H	I	ì	4							
5	J	K	L	5								
6	M	N	O	Ñ	Ö	Ø	Ò	6				
7	P	Q	R	S	ß	7						
8	T	U	V	Ü	Û	8						
9	W	X	Y	Z	9							
0	+	&	@	/	\$	%	£	Θ	Ξ	Ψ	Ω	0
#	*	#										

About Last Dialed Numbers

Your phone can store the 5 last dialed numbers.

Recalling From List of Last Dialed Numbers

1. Press **CLR** to erase any digits from the display.
2. Press **YES**. The number last called is shown.

3. Press **YES** to call the number or scroll to the number you want to call and then press **YES**.

About Unanswered Calls

Sometimes you are unable to answer a call. Then the phone keeps track of your latest missed calls in the **MissedCall** menu.

Checking Unanswered Calls

Select the **MissedCall** menu a number, a name or **Unknown** is shown.

Now do one of the following:

- Press **YES** to call the number.
- Press **CLR** to erase the call.
- Scroll between the entries.

Personalizing Your Phone

This chapter describes all the different ways you can personalize your phone to your own requirements.

Changing Ring Volume

1. Select the **Ring Vol** menu.
2. Scroll to the desired ring volume, press **YES**.

Turning Off Ring Volume

1. Select the **Ring Vol** menu.
2. Press the left arrow key until no squares are lit and press **YES**.

The standby display now looks like this:



LZT 126 1352/7 R1A

About Ring Type

You can choose between different types of ring signals.

Changing Ring Type

1. Select **Ring Type** in the **Settings** menu. The display now looks like this.

Melody 1?

2. Press the right or left arrow to listen to the different ring types.
3. Press **YES** to select your preferred ring type.

About Display Language

Your phone has many languages that you can choose for your display texts. If your SIM Card supports the automatic function, the phone has automatically chosen the SIM Card default language.

Note!

When you change language, you change all display texts **immediately**.

Changing Display Language

1. Select **Language** in the **Settings** menu.
2. Scroll to the language you want to have for the display texts.
3. Press **YES** to select the language.

Resetting Display Language to English

1. Clear the display.
2. Enter the digit string ***#0000#**.

Changing Key Sound

1. Select **Key Sound** in the **Settings** menu.
2. Select the key sound you want.

Diverting Calls

This chapter describes the divert function.

About Diverting Calls

When supported by your service provider, you can use the **DivertLine** menu to divert (forward) your calls to another number, for example your voice mail or home phone.


Note!

If your SIM Card and your service provider support two lines, you need to set each line separately. Here we assume you have one line.

The divert service lets you divert:

- **All calls:** regardless of if your telephone is turned on or off.
- **Unanswered calls:** if you do not answer within 30 seconds, if your phone is busy, turned off or out of reach of a network.

As a reminder, the display will inform you about any activated call divert each time you turn on the phone.



Diverting Your Calls

1. Select the **DivertLine** menu.
2. Select a divert option.
3. Chose **Activate** and press **YES**.

You may now do one of the following:

- Enter a number at the prompt where you want your calls to be diverted, including the area code, and press **YES**.
- Press the left arrow key to enter a name from your phone book and press **YES**.
- Use the phone number that is suggested and press **YES**.

You will only get a number suggested if you have activated the divert function before.

There may be a short delay before the network responds to your divert option, and

your display will prompt you when the divert is active (on or off).

Your standby display looks like this when the divert is active:



Viewing Status of Call Divert

1. Select the **DivertLine** menu.
2. Select the divert option you wish to view and choose **GetStatus**.

There may be a short delay before the network responds, and your display will prompt you which divert is active (on or off).

Cancelling Call Divert

1. Select the **DivertLine** menu.
2. Select the divert option you wish to cancel and choose **Cancel** and press **YES**.

There may be a short delay before the network responds, but you will be prompted that your divert is cancelled.

Protecting Your Keypad, Phone and SIM Card

This chapter describes the different locks that you can use to protect your phone. These are the only ways of protecting your phone in case of theft.

About Locks

Your phone has three types of locks:

- Keypad lock (does not protect in case of theft)
- Card lock
- Phone lock

The card and phone locks are found in the **Locks** menu and you find the keypad lock in the **Settings** menu.

Keypad Lock

You can lock the keypad so that unintentional key action has no effect if the phone is turned

on when you are carrying it in a handbag or pocket. When activated, the keypad lock is turned on 20 seconds after the last key action. And the standby display has a lock icon.

The keypad remains locked until you:

- answer or reject a call.
- unlock the keypad yourself.

Note!

You can always make the international emergency call 112 when the keypad is locked.

Setting the Keypad Lock

1. Select **Key Lock** in the **Settings** menu.

2. Select **Auto**.


To turn off the automatic keypad lock, select the **Off** option.

Unlocking Keypad

- Press **▲** and press **YES**.

Card Lock (SIM)

The card lock protects your SIM Card. When the card lock is active, you will always be prompted to enter your PIN at startup.



PINs and PUKs

When you buy your SIM Card, you obtain a 4- to 8-digit PIN (Personal Identity Number) and a longer PUK (Personal Unblocking Key). If your SIM card allows it, you can turn off the card lock.

The PIN is the code that you enter to get access to and activate your subscription. PIN 2 is used with special functions.

The PUK (and PUK 2) is a little longer code that helps you unlock your phone when you have forgotten the PIN (PIN 2).

Changing PIN

1. Select **CardLock** in the **Locks** menu.
2. Select **NewPIN**.
3. Enter the old PIN at the prompt and press **YES**.
4. Enter the new PIN and press **YES**.
5. Repeat the new PIN at the prompt and press **YES**.

Unblocking with PUK

If you have entered the PIN incorrectly three times in a row, the display will read:

PUK:

1. Enter your PUK and press **YES**.
2. Enter a new PIN at the prompt and press **YES**.
3. Repeat the new PIN at the prompt and press **YES**.

If you entered both the PUK and the PIN correctly, the display will read:

New PIN

Phone Lock

The phone lock protects the phone against unauthorized use of the phone if there is theft. The phone lock is not activated when you buy the phone.



These are the two types of phone locks:

Autolock: you need to enter the phone lock code every time you change SIM Card in the phone.

Full lock: you need to enter the phone lock code every time you turn on the phone.

Changing Phone Lock Code

1. Select **Phone Lock** in the **Locks** menu.
2. Select **New Code**.
3. Enter 0000 at the prompt (the factory default code) or your own code and press **YES**.
4. Key in a 4 to 8 digit personal code at the prompt and press **YES**.
5. Repeat the new code at the prompt and press **YES**.

(Un)Locking Phone

1. Select **Phone Lock** in the **Locks** menu.
2. Select the desired lock option, for example **Auto Lock**.
3. Enter 0000 (the factory default code) or your own phone lock code at the prompt and press **YES**.

To unlock the phone, choose **Unlock** in the **Locks** menu.

Barring Calls – Restricting Calls

This chapter describes how you can bar (restrict) calls to and from your phone. This feature is available in your phone, but might not be supported in your subscription.

About Barring Calls

The call barring service lets you control which kind of calls can be made to or from your phone. This feature is convenient if you lend your phone to somebody else. This feature is GSM service dependent.

Barring Options

Your phone supports the following barring options (but your subscription might not support all):

- all outgoing calls – you cannot make any calls.
- all outgoing international calls – you cannot make any international calls.
- all outgoing international calls except to your home country – you cannot make any international calls except to the SIM Card home country.

- all incoming calls – you will not receive any calls.
- all incoming calls when you are abroad – you will not receive any calls when abroad.

Note!

To activate any of the barring functions, you need a password that comes with your subscription.

Activating Call Bars for Any Call Type

1. Select **Barring** in the **Settings** menu.
2. Select either **Incoming** or **Outgoing**.
3. Select the barring option you want.
4. Select **Activate**.
5. Enter your password (provided with your subscription) and press **YES**.

There may be a short delay before the network responds and your display will prompt you which call bars have been activated.

Press **CLR** to stop the responses from the network.

Cancelling All Call Bars

1. Select **Barring** in the **Settings** menu.
2. Select the **Cancel All** option.
3. Enter your password at the prompt and press **YES**.

There may be a short delay before the network responds and your display will prompt you which call bars have been cancelled.

Press **CLR** to stop the responses from the network.

Sending and Receiving Text Messages

This chapter describes SMS, what you need to do before you can send messages, how you send messages, and how you read messages. This service is network dependent.

About Text Messages

The Short Message Service (SMS) function allows you to send and receive text messages that contain up to 160 characters. Text messages can be received when the phone is in standby mode, when you are engaged in a call, or when incoming calls are diverted to another phone number. Also, if you have had your phone turned off for a while the network will keep track of the message and send it to your phone as soon as it is turned on.

After a message is received, it is left in the phone's memory, which works similar to a computer's working memory. The message remains in the phone's memory until you read it. You can even turn off the phone and the message will remain intact. If you, on the other hand, change SIM Card, you will lose the unread message. This is because messages should be personal.

Note!

You need to set the service center number before you can **send** any messages. If you only

want to receive messages, you do not need to do anything.

Checking Subscription

- Call your service provider to see which services your subscription supports, or check the service provider's manual.

Setting Service Center Address


1. Check the service center address (number) for your service provider.
2. Select **Serv Cent** in the **Send** menu.
3. Enter the service center address with the international prefix and press **YES**.

Sending SMS

1. Select **New** in the **Send** menu.
2. Enter your message and press **YES**. You can also enter a phone number. See Table 2 for all letters and symbols available.

3. Enter the phone number you want to send your message to and press **YES**. Or press the left arrow key to enter a name you want to send to and press **YES**.

The display now looks like this:



Receiving a Message

When you receive a message the display looks like this:




At the same time you will hear a beep as loud as the ring signal and the green light on top of the phone will flash.

Reading an Incoming Message

1. Press **YES** when you have received a message. The display will show you the time of the incoming SMS, you can see the date by pressing *****.

2. Press **YES**.

The display will show you from which phone number the message is sent, or the name if stored in your phone book. The display could now look like this:



The arrow shows that you can start scrolling through the message with the right arrow key

3. Press the right arrow key to read the message.

When you have read a message, you can do one of the following:

- **Call** a phone number in the message by pressing **YES**.
- **Erase** the message by pressing **YES** at the erase prompt.
- **Store** the message by pressing **NO** at the erase prompt (you may get a reply prompt if the sender has required a reply). Press **YES** at the **Store** prompt and the message is stored on the SIM Card.

Reading an Old Message

1. Select the **Read** menu.
2. Scroll to the message you want to read and press **YES**.
3. Read through the message by pressing the right arrow key.

Erasing a Message

- Press **CLR** any time during the message and answer **YES** on the question prompt.

Receiving Area Information


This chapter describes how you can make your phone available for Area Information (AI). This service is network dependent.

About Area Information

While the SMS function is a personal service with messages directed to you, the Area Information is a broadcast type message that is sent to all subscribers in a certain cell, for example a section of a city, at the same time. You can set your phone to receive only those types of messages you want to listen to, e.g.: the local weather forecast or the local traffic report. Each message is identified by a 3-digit code. Check

with your service provider for which message types are available in your network.

When you receive an AI the display looks like this:



The default setting for the phone is that the AI service is turned off.

At present the following message types exists:

Code	Title
000	Index
010	Flashes
020	Hospitals
022	Doctors
024	Pharmacy
030	Long-distance road reports
032	Local road reports
034	Taxis
040	Weather

050	District
052	Network information
054	Operator services
056	Directory enquiries (national)
057	Directory enquiries (international)
058	Customer care (national)
059	Customer care (international)

Activating the Area Information

- Select **On** in the **AreaInfo** sub-menu.

Adding a Code

1. Select **EditList** in the **AreaInfo** sub-menu.
2. Press the right arrow key to find the first empty position and press **YES**.
3. Enter a new code and press **YES**.

The display could now look like this if you have added the pharmacy title to the second position:

2	024
---	-----

Erasing a Code

1. Select **Edit List** in the **AreaInfo** sub-menu.
2. Scroll to the position (to the left in the display) you wish to erase and press **YES**.
3. Press **YES** at the erase prompt.

Changing a Code

1. Select **Edit List** in the **AreaInfo** sub-menu.
2. Scroll to the position (to the left in the display) you wish to change and press **YES**.
3. Scroll to **New Code** and press **YES**.
4. Enter the new code and press **YES**.

Knowing Duration of Calls

This chapter describes how you can keep track of the duration of your calls.

About Duration of Calls

Your phone is capable of keeping track of the following:

Total Calls:

This feature shows the total time of all calls in hours and minutes since the meter was last set.

Outgoing Calls:

This feature tracks the time of all your outgoing

calls in hours and minutes since the meter was last set.

Last Call:

This feature tracks the duration of your last call in minutes and seconds.

The duration of the call appears in the display after a call is finished. The total time of all calls is recorded in the phone and is also default.

Viewing Calling Information

There are two ways to view the calling information:

- Look in the display for the duration of your last call when it is ended.
- Select the **Info** menu to view all options.

Resetting a Call Meter

1. Select the **Info** menu.

2. Scroll to the meter option you want to reset and press **YES**.
3. Press **YES** at the reset prompt.

Other Networks

This chapter describes how you select a different network when you are out of range of your home service provider's network.

About Choosing Network

When you turn on the phone, it selects its home network. If this is not within range, you might not be able to get any reception or, if you are abroad, you can choose a different network, provided your service provider has an agreement allowing you to use the network. This is called roaming.

When you select the Networks menu, the phone automatically searches for all networks present in the area you are in. Each network that is found, has a status indication telling you whether the network is available or forbidden.

See the list below for a description of the status indication:

Display:	Meaning:
Network and #	home network
Network and *	currently used network
Network and A	other available networks
Network and S	other available network (given priority by your home service provider)
Network and F	forbidden networks
Auto	automatic network search

Note!

The status of forbidden networks can change, so it is important that you make a network search to update the list, especially when you are visiting another country.

Auto is the basic setting for the network search and selection. This setting means that your

phone takes care of all the network search and selection.

Selecting a Network

1. Select the **Networks** menu.
The phone performs a network search and the display shows the current network followed by the network list.
2. Scroll through the network list to see which networks are available.
3. Press **YES** to select a network.

When you have made a network selection, **Networks?** is shown whenever the phone cannot contact the desired network. You can now either:

- Select a new network.
- Set the phone to the automatic search mode.

Setting Phone to Automatic Network Search

1. Select the **Networks** menu.

2. Scroll, after the search, to **Auto** and press **YES**.

Your Phone and Accessories

This chapter describes few of those accessories that you buy for your phone.

Front Panel

You can change the front panel of your phone!
This allows you to match the phone to any of your different moods.

Changing the Front Panel

1. Lift the front panel as described in Figure 9.
2. Place the new front panel on the phone as described in Figure 9.




Figure 9. Changing front panel

Handsfree Equipment

If you drive and use your phone, you can connect it to a handsfree equipment. In some countries it is the law to have the mobile phone connected to a handsfree equipment while driving.

Answering/Rejecting Calls with Handsfree

- Press any key, except **NO**, to answer a call.
NO rejects the call.

PC-card

Your phone is capable of receiving fax and data calls through a PC-card (PCMCA). For best result with fax and data transmission, connect the phone to a suitable Mobile Office Kit (ask your retailer for which kit suits your phone).

Index

!

112 call

A

Accessories

AI

See Area information

Alphabetic characters

Answering calls

Antenna

Area information

about

activating

adding codes

changing codes

erasing codes

Assembly instructions

Autolock

B

Barring calls

about

activating

cancelling

Battery
about
attaching
removing
status

Battery icon

Beeper

Busy tone

C

Call wait

activating

deactivate

Calling line identification

Calls

answering

barring

diverting, about

duration

emergency

ending

international

making

on hold

outgoing

receiving

rejecting

restricting

retry

total

Charger

connecting

connector

disconnecting

function

CLI

D

Dialling

Display

information

Divert icon

Diverting calls

about

cancelling

view status

Duration of calls

E

Earpiece

Emergency calls

Enter

names in memory

numbers in memory

Erasing text message

External antenna connector

F

Front panel

Full lock

6

22

12

6

5

19

19

20

20

20

20

20

1

16

17

17

17

5

3

2

2

4

4

5

6

8

8

7

6

17

14

20

6

6

6

6

7

20

6

6

17

6

20

2

5

2

3

7

4

5

4

4

14

14

15

15

20

5

6

9

11

11

19

5

22

16

EN

G

General information 3
Glossary 9

H

Handsfree equipment 22

I

International numbers 11
 storing
International prefix 6

K

Key sound 14
 changing
Keypad 5
 lock 15
 unlock 15
Keypad lock 15
 activating
 turning off

L

Language 3
 automatic 13
 display 14
 display, changing 14
Language reset

Last dialled numbers

 about 3
 recalling 9
Letter icon
Line indicator icon

Locks

 about 22
 keypad
 phone
 SIM

Lower-case letters

M

11
6
Mains 3
Making calls 6
Memory 12
 erasing names/numbers
 phone 11
 SIM 5
 speed dialling 15
Menu system 15
 about
 overview
Messages 15
 See Text messages

Microphone 5
 mute 7

Moving through menus 9

Muting 7

N

3
13
14
14
Navigating the menus 9

Network

 selecting 21
Nickel metal hydride 3

O

15 ON/OFF 3
15 Overview 10
16 menus

P

PC-card 22
Phone 16
 locking 16
 locking code 16
 locks 16
 memory 11
 turning off 3
 unlocking 16
Phone book 12
 about 11
9 Phone clip holder 5
10 Phone icon 4
Phone number 12
 deleting 8
 hiding 7
 showing 11
 storing
7 PIN 7
 about 16
 changing 16
PIN 2 16

Position recall			
from phone	12	about	3
from SIM	12	holder	5
Protecting phone	15	inserting	1
PUK	16	protecting	15
about	16	removing	1
<hr/>			
R			
Recalling			
by name	12		
by number	12		
phone numbers	12		
Receiving calls	6		
Rejecting calls	6		
Retry	6		
Ring signal			
icon	4		
See Ring volume			
Ring type			
about	13		
changing	13		
Ring volume			
changing	13		
muting	13		
Roaming	21		
<hr/>			
S			
Scroll	9		
Select	9		
Service center			
setting	18		
Setting keypad lock	15		
Signal strength icon	4		
		SIM Card	
		about	3
		holder	5
		inserting	1
		protecting	15
		removing	1
		SMS	
		See Text messages	
		Speed dialling	12
		Status light	5
		Stopping calls	
		See Barring calls	
		Storing numbers	
		Phone memory	11
		SIM Card	11
<hr/>			
		T	
		Text message	
		about	18
		erasing	19
		reading	18
		saving	19
		sending	18
		Turning off phone	3
		Turning on phone	3
		Two calls	8
<hr/>			
		U	
		Unanswered calls	13
		Unblocking	16