

Adaptec 154x SCSI Host Adaptor Driver

This directory contains the all of the source files needed to build a driver for the Adaptec 1542B/C series of SCSI Host Adapters.

Files

The following files comprise this driver.

PB.project	Used by Project Builder.
Makefile	Created by Project Builder; used by 'make'.
Makefile.preamble	Standard boilerplate driverkit Makefile extension.
Makefile.postamble	Standard boilerplate driverkit Makefile extension.
Default.table	Default table file, used by Configure app.
English.lproj/Localizable.strings	Used by Configure app.
README.rtf	This file.

These files compile to build the actual relocatable driver binary. They reside in the Adaptec1542B_reloc.tproj subdirectory.

AHAController.h	Public class declaration.
AHAController.m	Implementation of public and common methods.
AHAThread.h	I/O thread definitions.
AHAThread.m	I/O Thread implementation.
AHARoutines.m	Common low-level I/O routines.
AHATypes.h	H/W defintions for Adaptec 1542B Host Adaptor.
AHAControllerPrivate.h	Driver-private typedefs.
AHAInline.h	Static inlines and macros.
scsivar.h	Device-independent SCSI definitions.
AHA.ddm	DDM defintions (for debugging only).
Default.table	Default config table.
Load_Commands.sect	Standard boilerplate driverkit tool.
Makefile	Builds the driver.

Architecture

This driver uses one I/O thread to perform all hardware operations which occur subsequent to +probe time. This eliminates the need for using locking protocols to gain access to the hardware or related resources. The I/O thread is actually implemented in IODirectDevice; it is started up by our superclass, IOSCSIController, in the -initWithDeviceDescription method.

Requests are passed from public methods (-executeRequest:buffer:client and -resetSCSIBus) to the

I/O thread via the struct `AHACmdBuf`, defined in `AHAControllerPrivate.h`. These `AHACmdBuf`'s are enqueued on the instance variable `commandQ` in the common method `-executeCmdBuf`; after enqueueing, a message with `msg_id` of `IO_COMMAND_MSG` is sent to the I/O thread (via the `interruptPort`). This wakes up the I/O thread, resulting in a call to our `-commandRequestOccurred` method. Command requests are then dispatched from `-commandRequestOccurred` to the appropriate command-specific code in `AHAThread.m`. During the execution of a command, `-executeCmdBuf` is waiting on the `cmdLock` field (an `NXConditionLock`) in `AHACmdBuf`. When the I/O thread completes a command, it unlocks the associated `cmdLock` with `condition = CMD_COMPLETE`; this wakes up `-executeCmdBuf`, which returns to the originating caller.

This implementation, using `AHACmdBuf`'s, is a textbook case of the mechanism described in the Driverkit Technical Documentation, Chapter 2 ("Designing a Driver"), in the section entitled "Communicating using Condition Locks".

The methods in this class can be grouped into the following 4 categories:

Initialization

The `+probe` and `-initWithDeviceDescription` methods each run once per hardware instance. They run in the I/O task context, but not in our I/O thread context.

Public Exported Methods

These consist of `-executeRequest:buffer:client` and `-resetSCSIBus`. Each of these merely create an `AHACommandBuf` and call `-executeCmdBuf`, which passes the `AHACommandBuf` over to the I/O thread for processing.

Methods Called by IODevice's I/O Thread

These methods are implemented in `AHAController.m` for a consistent API (since they are called from outside of the class), but they run in the I/O thread context. The three methods of interest are:

`-interruptOccurred`: a hardware interrupt has been detected. This generally means an I/O is complete.

`-timeoutOccurred`: A pending I/O has timed out. This is detected by a callout to the function `ahaTimeout()`, in `AHAThread.m`. A callout is scheduled to this function when a command is sent to the host adaptor in the form of a CCB. If the timeout specified in `IO SCSIRequest.timeoutLength` elapses without an I/O complete for the associated CCB, `ahaTimeout()` is called. `AhaTimeout()` then sends a message with `msg_id = IO_TIMEOUT_MSG` to the I/O thread via the `interruptPort`. The I/O thread then calls `-timeoutOccurred`. We abort the offending command with `driverStatus = SR_IOST_IOTO`, reset the SCSI bus, and abort all other pending commands with `driverStatus =`

SR_IOST_RESET.

-commandRequestOccurred: This is called by the I/O thread when it receives a message on interruptPort with msg_id = IO_COMMAND_MSG. Our response is to dequeue all of the commands we find on commandQ and send them to the host adaptor. One possible problem: the Host Adaptor's input queue (i.e., its array of mailboxes) might be full. In that case, commandRequestOccurred leaves the new I/O request(s) on commandQ. Later on, when we detect an I/O complete - thus freeing up one of the Host Adaptor's mailboxes, we call - commandRequestOccurred ourselves to process any possible pending commands in commandQ.

Private I/O thread methods

These methods, implemented in AHAThread.m, perform the bulk of the hardware manipulation. All of these methods run solely in the context of the I/O thread.

Debugging

This driver has been extensively instrumented with DDM calls. The file AHA.ddm can be loaded into DDMViewer (currently in /NextDeveloper/Demos) to allow selective access to various events in the driver. See the Driverkit Technical Documentation for more information on DDMViewer and the DDM

module in general. Note that the DDM calls are only enabled in the DEBUG build configuration.