TELECOMMUNICATION
STANDARDIZATION SECTOR
OF ITU

Q.781

(03/93)

SPECIFICATIONS OF SIGNALLING SYSTEM No. 7

SIGNALLING SYSTEM No. 7 - MTP LEVEL 2 TEST SPECIFICATION

ITU-T Recommendation Q.781

(Previously "CCITT Recommendation")

FOREWORD

The ITU Telecommunication Standardization Sector (ITU-T) is a permanent organ of the International Telecommunication Union. The ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunications on a worldwide basis.

The World Telecommunication Standardization Conference (WTSC), which meets every four years, established the topics for study by the ITU-T Study Groups which, in their turn, produce Recommendations on these topics.

ITU-T Recommendation Q.781 was revised by the ITU-T Study Group XI (1988-1993) and was approved by the WTSC (Helsinki, March 1-12, 1993).

NOTES

As a consequence of a reform process within the International Telecommunication Union (ITU), the CCITT ceased to exist as of 28 February 1993. In its place, the ITU Telecommunication Standardization Sector (ITU-T) was created as of 1 March 1993. Similarly, in this reform process, the CCIR and the IFRB have been replaced by the Radiocommunication Sector.

In order not to delay publication of this Recommendation, no change has been made in the text to references containing the acronyms "CCITT, CCIR or IFRB" or their associated entities such as Plenary Assembly, Secretariat, etc. Future editions of this Recommendation will contain the proper terminology related to the new ITU structure.

2 In this Recommendation, the expression "Administration" is used for conciseness to indicate both a telecommunication administration and a recognized operating agency.

© ITU 1994

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the ITU.

CONTENTS

		Page
1	Introduction	1
2	General principles of level 2 tests	1
3	Test configuration	1
4	Test environment	2
5	Test list	2
6	Test descriptions	4

SIGNALLING SYSTEM No. 7 – MTP LEVEL 2 TEST SPECIFICATION

(Melbourne, 1988; modified at Helsinki, 1993)

1 Introduction

This Recommendation contains a set of detailed tests of signalling system No. 7 MTP level 2 protocol. These tests intend to validate the protocol specified in Recommendation Q.703.

This Recommendation conforms to Recommendation Q.780 which describes the basic rules of the Test Specification. In addition the conditions which are specific to level 2 tests are described in the following clauses.

2 General principles of level 2 tests

2.1 Presentation of test descriptions

The level 2 tests aim at testing the level 2 protocol conformance in a given implementation.

Each test description indicates in the "type of test" column; "Validation" (VAT) or "Validation" (VAT) and "compatibility" (CPT).

Although signal units are transmitted and received continuously on level 2, only the signal units which cause and/or indicate the changes of level 2 status are shown in the EXPECTED SIGNAL UNIT SEQUENCE column of each test description.


2.2 Presentation of the test list

These tests as a whole, aim at a complete validation of the level 2 protocol without redundancies. Each test is described as simply as possible to check precisely each elementary function of the protocol, which is referred in the columns "reference", "title" and "sub-title" of each test description.

This list is presented in the form of a succession of tests. The presentation order is essentially functional. However, the operator performing these tests may change this order, taking into account some other practical criteria such as: use pre-test conditions to order the list, the end of a given test may be the pre-test condition of another test.

3 Test configuration

A single link will be used for level 2 tests. Figure 1 shows a single link between SP A and SP B. Test specifications are written to test the level 2 of the SP A.



NOTE – First digit: linkset number. Second digit: link number.

FIGURE 1/Q.781

Test configuration of MTP level 2 test Configuration 1

4 Test environment

See 6.2/Q.780.

5 Test list

NOTE - Compatibility test items are indicated in this list by an asterisk (*).

The abbreviations PO, LPO, RPO, EM and EDA are used for processor outage, local processor outage, remote processor outage, emergency and expected delay of acknowledgement, respectively.

- 1 Link State Control Expected signal units/orders (see Figures 8/Q.703 and 9/Q.703)
- * 1.1 Initialisation (Power-up)
- 1.2 Timer T2
 - 1.3 Timer T3
 - 1.4 Timer T1 and T4 (Normal)
- k 1.5 Normal alignment correct procedure (FISU)
 - 1.6 Normal alignment correct procedure (MSU)
 - 1.7 SIO received during normal proving period
 - 1.8 Normal alignment with PO set (FISU)
 - 1.9 Normal alignment with PO set (MSU)
 - 1.10 Normal alignment with PO set and clear
 - 1.11 Set RPO when "Aligned not ready"
 - 1.12 SIOS received when "Aligned not ready"
 - 1.13 SIO received when "Aligned not ready"
 - 1.14 Set and clear LPO when "Initial alignment"
 - 1.15 Set and clear LPO when "Aligned ready"
 - 1.16 Timer T1 in ""Aligned not ready" state
 - 1.17 No SIO sent during normal proving period
 - 1.18 Set and cease emergency prior to "start alignment"
- 1.19 Set emergency while in "not aligned state"
 - 1.20 Set emergency when "aligned"
 - 1.21 Both ends set emergency
 - 1.22 Individual end sets emergency
 - 1.23 Set emergency during normal proving
 - 1.24 No SIO sent during emergency alignment
- 1.25 Deactivation during initial alignment
 - 1.26 Deactivation during aligned state
 - 1.27 Deactivation during aligned not ready
 - 1.28 SIO received during link in service
- 1.29 Deactivation during link in service
 - 1.30 Deactivation during LPO
 - 1.31 Deactivation during RPO
- 1.32 Deactivation during the proving period
 - 1.33 SIO received instead of FISUs
 - 1.34 SIOS received instead of FISUs
 - 1.35 SIPO received instead of FISUs

2 Recommendation Q.781 (03/93

- 2 Link State Control Unexpected signal units/orders (see Figure 8/Q.703)
 - 2.1 Unexpected signal units/orders in "Out of service" state
 - 2.2 Unexpected signal units/orders in "Not aligned" state
 - 2.3 Unexpected signal units/orders in "Aligned" state
 - 2.4 Unexpected signal units/orders in "Proving" state
 - 2.5 Unexpected signal units/orders in "Aligned ready" state
 - 2.6 Unexpected signal units/orders in "Aligned not ready" state
 - 2.7 Unexpected signal units/orders in "In service" state
 - 2.8 Unexpected signal units/orders in "Processor outage" state
- 3 Transmission failure (see Figure 8/Q.703)
 - 3.1 Link aligned ready (Break Tx path)
 - 3.2 Link aligned ready (Corrupt FIBs)
 - 3.3 Link aligned not ready (Break Tx path)
 - 3.4 Link aligned not ready (Corrupt FIBs)
 - 3.5 Link in service (Break Tx path)
 - 3.6 Link in service (Corrupt FIBs Basic)
 - 3.7 Link in processor outage (Break Tx path)
 - 3.8 Link in processor outage (Corrupt FIBs Basic)
- 4 Processor Outage Control (see Figure 10/Q.703)
 - 4.1 Set and clear LPO while link in service
 - 4.2 RPO during LPO
 - 4.3 Clear LPO when "Both processor outage"
- 5 SU Delimitation, Alignment, Error Detection and Correction (see Figures 11/Q.703 and 12/Q.703)
 - 5.1 More than seven "1"s between MSU opening and closing flags
 - 5.2 Greater than maximum signal unit length
 - 5.3 Below minimum signal unit length
 - 5.4 Reception of single and multiple flags between FISUs
 - 5.5 Reception of single and multiple flags between MSUs
- 6 SUERM Check (see Figure 18/Q.703)
 - 6.1 Error rate of 1 in 256 Link remains in service
 - 6.2 Error rate of 1 in 254 Link into out of service
 - 6.3 Consecutive corrupted SUs
 - 6.4 Time controlled break of the link
- 7 AERM check (see Figure 17/Q.703)
 - 7.1 Error rate below the normal threshold
 - 7.2 Error rate at the normal threshold
 - 7.3 Error rate above the normal threshold
 - 7.4 Error rate at the emergency threshold
- 8 Transmission and reception control (Basic) (see Figures 13/Q.703 and 14/Q.703)
 - 8.1 MSU transmission and reception
 - 8.2 Negative acknowledgement of MSU
 - 8.3 Check RTB full

- 8.4 Single MSU with erroneous FIB
- 8.5 Duplicated FSN
- 8.6 Erroneous retransmission Single MSU
- 8.7 Erroneous retransmission Multiple FISUs
- 8.8 Single FISU with corrupt FIB
- 8.9 Single FISU prior to RPO being set
- 8.10 Abnormal BSN Single MSU
- 8.11 Abnormal BSN Two consecutive FISUs
- 8.12 Excessive delay of acknowledgement
- 8.13 Level 3 Stop Command
- 9 Transmission and reception control (PCR) (see Figures 15/Q.703 and 16/Q.703)
 - 9.1 MSU transmission and reception
 - 9.2 Priority control
 - 9.3 Forced retransmission with the value N₁
 - 9.4 Forced retransmission with the value N₂
 - 9.5 Forced retransmission cancel
 - 9.6 Repetition of forced retransmission
 - 9.7 MSU transmission while RPO set
 - 9.8 Abnormal BSN Single MSU
 - 9.9 Abnormal BSN Two MSUs
 - 9.10 Unexpected FSN
 - 9.11 Excessive delay of acknowledgement
 - 9.12 FISU with FSN expected for MSU
 - 9.13 Level 3 Stop Command
- 10 Congestion Control (see Figure 19/Q.703)
 - 10.1 Congestion abatement
 - 10.2 Timer T7
 - 10.3 Timer T6

6 Test descriptions

MTP, LEVEL 2

TEST NUMBER: 1.1 PAGE: 1 OF 1

REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 12; Fig. 13				
TITLE	: Link State Control – Expected sig	gnal units/orders		
SUB T	TTLE: Initialization (Power-up)			
PURP	OSE: To check that the No. 7 termin	nal equipment enters the correct state on J	power-up	
PRE-T	EST CONDITIONS: Line equipme	ent – ON; No. 7 equipment – OFF		
CONF	IGURATION: 1		TYPE O	OF TEST: VAT, CPT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
1 – 0	SIOS	>		
				: Power ON
		<	1 – 0	SIOS
TEST	DESCRIPTION			
1.	Check link enters correct state.			
2.	At "Power – On" or Initialization th FIN = BIB = 1 : FSN = BSN = 127	he FIB, BIB, FSN, and BSN shall be as fo (HEX 7F)	llows:	
3. Repeat test in reverse direction.				

TEST NUMBER: 1.2	PAGE: 1 OF 1			
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9; Fig. 11; Fig. 13; Fig. 14				
TITLE: Link State Control – Expected signal units/orders				
SUB TITLE: Timer T2				
PURPOSE: To check "Not Aligned" Timer T2				
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1	TYPE OF TEST: VAT, CPT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B	SP A			
Link	Link			
1 – 0 SIOS				
ζ	1 – 0 SIOS			
	: start			
<	1 – 0 SIO			
	T2			
<	1 – 0 SIOS			
TEST DESCRIPTION				
1. Timer T2 shall be in the range 5 secs to 150 secs.				

TEST N	IUMBER: 1.3		PAGE: 1 C	OF 1
REFER	ENCE: Q.703 Clause 7	STD: Fig. 9; Fig. 14		
TITLE:	Link State Control – Expec	ted signal units/orders		
SUB TI	TLE: Timer T3			
PURPO	SE: To check "Aligned" Ti	mer T3		
PRE-TE	EST CONDITIONS: Link or	at of service		
CONFI	GURATION: 1		TYPE OF	TEST: VAT
EXPEC	TED SIGNAL UNIT SEQUE	ENCE:	·	
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		ζ	1 – 0	SIO
1 – 0	SIO	·····>		
		<	1 – 0	SIN
				Т3
		<	1 – 0	SIOS
TEST DESCRIPTION				
1.	Timer T3 shall be in the rang	ge 1 sec to 1.5 secs.		

TEST	NUMBER: 1.4		PAGE: 1	PAGE: 1 OF 1		
REFEI	RENCE: Q.703 Clause 7	STD: Fig. 8; Fig. 9				
TITLE	: Link State Control – Expe	cted signal units/orders				
SUB T	TTLE: Timer T1 & Timer T	4 (Normal)				
PURP	OSE: To check "Aligned rea	ady" Timer T1 and "Proving period" Timer	T4 (Normal)			
PRE-T	EST CONDITIONS: Link of	out of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQU	ENCE:	'			
	SP B			SP A		
Link			Link			
		ζ	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 - 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
				T4 (Pn)		
		<	1 – 0	FISU		
				T1		
		<	1 – 0	SIOS		
TEST	DESCRIPTION					
1.	At 64 kbit/s Timer T4 shall 40 secs to 50 secs.	be in the range 7.5 secs to 9.5 secs (nomin	nally 8.2 secs) and 5	Timer T1 shall be in the range		
2.	2. At 4.8 kbit/s Timer T4 shall be in the range 100 secs to 120 secs (nominally 110 secs) and Timer T1 shall be in the range 500 secs to 600 secs.					

TEST	NUMBER: 1.5		PAGE: 1 OF	7.1
REFE	RENCE: Q.703 Clause 7			
TITLE	E: Link State Control – Expected signa	al units/orders		
SUB 7	FITLE: Normal alignment – correct pro	ocedure (FISU)		
PURP	OSE: To check normal alignment production	cedure		
PRE-T	TEST CONDITIONS: Link out of serv	ice		
CONF	FIGURATION: 1		TYPE OF TE	EST: VAT, CPT
MESS	AGE SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 – 0	FISU
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Start normal alignment procedure.			
2.	Check link aligns and enters "In servi	ice" state.		
3.	Check that "In service" state is maint	ained.		
4.	In VAT only check it is possible to pe use LSSU in point B with a statu use LSSU in point B with a statu	erform a normal alignment procedure in t s field of 8 bits; s field of 16 bits.	he following ca	ises:

TEST	NUMBER: 1.6		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Clause 7	STD: Fig. 8; Fig. 9			
TITLE	E: Link State Control – Expected	l signal units/orders			
SUB T	CITLE: Normal alignment – corr	ect procedure (MSU)			
PURP	OSE: To check normal alignmen	nt procedure			
PRE-T	TEST CONDITIONS: Link out of	of service			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
		ζ	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
		ζ	1 – 0	FISU	
1 – 0	MSU	>			
TEST	DESCRIPTION				
1.	Start normal alignment procedu	ire.			
2.	Check link aligns and enters "Ir	n service" state.			
3.	Check that "In service" state is	maintained.			

TEST	NUMBER: 1.7		PAGE: 1 OF	1
REFEI	RENCE: Q.703 Clauses 7, 10.3	STD: Fig. 9; Fig. 17		
TITLE	E: Link State Control – Expected signa	al units/orders		
SUB T	TITLE: SIO received during normal pr	oving period		
PURP	OSE: To test the response to the recep	otion of an SIO during the normal provin	g period	
PRE-T	TEST CONDITIONS: Link out of serv	ice		
CONF	IGURATION: 1		TYPE OF TES	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		T4
				Stopped
1 – 0	SIO (one only)	>		1
1 – 0	SIN	>		CINI
		<	1 – 0	SIN T4(Pn)
		<	1 – 0	FISU
TEST DESCRIPTION				
1.	Send an SIO at B during normal prov	ing period.		
2.	Check that new normal period is ente	red.		

TEST	TEST NUMBER: 1.8 PAGE: 1 OF 1			OF 1
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8		
TITLE	E: Link State Control – Expecte	d signal units/orders		
SUB 7	TITLE: Normal alignment with	PO set (FISU)		
PURP	OSE: To check the response fol	llowing normal alignment when PO has been s	et	
PRE-T	TEST CONDITIONS: Link out	of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUEN	CE:	1	
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: set LPO : start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 – 0	SIPO
1 – 0	FISU	>		
		<	1 – 0	SIPO
			_	
TEST	DESCRIPTION			
1.	Check that normal alignment is	s carried out with LPO set at A.		
2.	Check that SIPO is returned w	hen aligned, and that A stays in "processor out	tage" state.	
3.	Repeat test with LPO set at B.			

TEST	NUMBER: 1.9		PAGE: 10	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8				
TITLE	E: Link State Control – Expecte	ed signal units/orders				
SUB T	CITLE: Normal alignment with	PO set (MSU)				
PURP	OSE: To check the response fo	ollowing normal alignment when PO has be	een set			
PRE-T	TEST CONDITIONS: Link out	of service				
CONF	IGURATION: 1		TYPE OF	ΓEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: set LPO : start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
		<	1 – 0	SIPO		
1 – 0	MSU	>				
		<	1 – 0	SIPO		
TEST	DESCRIPTION					
1.	Check that normal alignment i	s carried out with LPO set at A.				
2.		then aligned, and that A stays in "processor	or outage" state.			
3.	Repeat test with LPO set at B.					

TEST NUMBER: 1.10 PAGE: 1 OF 1			1	
REFERENC	CE: Q.703 Clauses 7, 8 STI	D: Fig. 8		
TITLE: Lin	ak State Control – Expected signa	l units/orders		
SUB TITLE	: Normal alignment with PO set	and clear		
PURPOSE:	To check the response following	g normal alignment when PO has been so	et and cleared	
PRE-TEST (CONDITIONS: Link out of servi	ice		
CONFIGUR	ATION: 1		TYPE OF TE	ST: VAT
EXPECTED	SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: set LPO : clear LPO : start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 – 0	FISU
1 – 0	FISU	>		
TEGE PEG	IN INTERIOR I			
TEST DESCRIPTION				
	ck that normal alignment is carrie			
2. Chec	ck that link aligns and enters "In s	service" state.		

TEST	NUMBER: 1.11		PAGE: 1 OF	1
REFE	RENCE: Q.703 Clauses 7, 8	TD: Fig. 8		
TITLE	E: Link State Control – Expected sign	al units/orders		
SUB T	CITLE: Set RPO when "Aligned not r	eady"		
PURP	OSE: To check the response following	ng normal alignment when PO has been se	et	
PRE-T	EST CONDITIONS: Link out of ser	vice; ability to set PO		
CONF	IGURATION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
	: set LPO			: set LPO : start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 – 0	SIPO
1 – 0	SIPO	>		
TEST	DESCRIPTION			
3.	Check that both LPO and RPO after	alignment completes.		
 2. 3. 	Set LPO at A and B. Start alignment. Check that both LPO and RPO after	alignment completes.		

TEST	NUMBER: 1.12		PAGE: 10	F 1
REFE	RENCE: Q.703 Clauses 7, 8 STI	D: Fig. 8		
TITLE	E: Link State Control – Expected signa	ul units/orders		
SUB 7	TITLE: SIOS received when "Aligned	not ready"		
PURP	OSE: To check the response following	g normal alignment when PO has been so	et	
PRE-T	TEST CONDITIONS: Link out of servi	ice		
CONF	FIGURATION: 1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: set LPO : start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 – 0	SIPO
1 – 0	: stop SIOS	>		
		<	1 – 0	SIOS
TEST	DESCRIPTION			
1.	Soon after alignment completes, A en	ters "Aligned not ready".		
2.	Before alignment completes, stop con	nmand is given at B.		
3.	Check that, on reception of SIOS, A e	enters "Out of service" state.		
4.	Repeat test with LPO set at B.			

TEST	NUMBER: 1.13		PAGE: 10	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8	·			
TITLE	E: Link State Control – Expect	ted signal units/orders				
SUB T	TITLE: SIO received when "A	ligned not ready"				
PURP	OSE: To check the response f	following normal alignment when PO has be	een set			
PRE-T	EST CONDITIONS: Link ou	t of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUE	NCE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: set LPO : start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
		ζ	1 – 0	SIPO		
1 – 0	SIO	>				
		<	1 – 0	SIOS		
TEST	DESCRIPTION					
1.	Soon after alignment complet	es, A enters "Aligned not ready".				
2.	Before alignment completes a	at B, SIO is sent to A.				
3.	Check that, on reception of S	IO, A enters "Out of service" state.				
4.	Repeat test with LPO set at B	3.				

TEST	TEST NUMBER: 1.14			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8				
TITLE	E: Link State Control – Expecte	ed signal units/orders				
SUB T	TTLE: Set and clear LPO when	n "Initial alignment"				
PURP	OSE: To check normal alignment	ent when PO set and clear during "Initial	alignment"			
PRE-T	EST CONDITIONS: Link out	of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
				: set LPO		
1 – 0	SIN	>				
				: clear LPO		
		<	1 – 0	FISU		
1 – 0	FISU	>				
		<	1 – 0	FISU		
TEST DESCRIPTION						
1.	Set LPO at A during "Initial a	lignment" state.				
2.	Check A remains in "Initial ali	gnment" state.				
3.	Clear LPO before alignment co	ompletes at A.				
4.	Check A enters "In service" st	ate after normal alignment.				
5.	Repeat the test at B.					

TEST	NUMBER: 1.1:	5		PAGE: 1 OF	1
REFE	RENCE: Q.703	Clauses 7, 8 STI	D: Fig. 8		
TITLE	E: Link State Co	ontrol – Expected signa	l units/orders		
SUB T	TITLE: Set and	clear LPO when "align	ed ready"		
PURP	OSE: To test the	e response to LPO whe eared	en "aligned ready" and to ensure that the	e aligned ready	state resumes when
PRE-T	EST CONDITIO	ONS: Link out of servi	ice		
CONF	IGURATION:	I		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL 1	UNIT SEQUENCE:			
	SP	В			SP A
Link				Link	
			<	1 – 0	SIOS
1 – 0	SIOS		>		
					: start
			<	1 – 0	SIO
1 – 0	SIO		>		
			<	1 – 0	SIN
1 – 0	SIN		>		
			<	1 – 0	FISU
					: set LPO
			<	1 – 0	SIPO
					: wait 5 secs. : clear LPO
			<	1 – 0	FISU
TEST DESCRIPTION					
1.	Start link at A.				
2.	At "aligned rea (Suppress retur	dy" state set LPO at A n of FISUs at B to mai	intain "aligned ready" state.)		
3.	Clear LPO at A				
4.	Check A resum	es "aligned ready" stat	te.		

TEST	NUMBER: 1.16			PAGE: 1 OF	7 1	
REFEI	RENCE: Q.703 CI	auses 7, 8 STI	D: Fig. 8			
TITLE	E: Link State Contr	ol – Expected signa	l units/orders			
SUB T	TITLE: Timer T1 is	n "aligned not ready	"state			
PURP	OSE: To test the o	peration of Timer T	1 when in the "aligned not ready" state.			
PRE-T	EST CONDITION	S: Link out of servi	ice			
CONF	IGURATION: 1			TYPE OF TH	EST: V	AT
EXPE	CTED SIGNAL UN	IT SEQUENCE:		l		
	SP I	3			SP	A
Link				Link		
			<	1 – 0	SIC	OS
1 – 0	SIOS		>			
					: set : star	
			<	1 – 0	SIC)
1 – 0	SIO		>			
			<	1 – 0	SIN	1
1 – 0	SIN		>			
			<	1 – 0	SIP	0
						Т1
			<	1 – 0	SIC	OS .
TEST	DESCRIPTION					
1.	Set LPO and start	link at A.				
2.	Check A enters th	e "aligned not ready	" state.			
3.	Check A takes the	link out of service a	after time T1.			
4.	Timer T1 shall be	in the range 40 secs	s to 50 secs.			
İ						

TEST	NUMBER: 1.17		PAGE: 10	OF 1	
REFERENCE: Q.703 Clause 7 STD: Fig. 9					
TITLE	: Link State Control – Exp	ected signal units/orders			
SUB T	TTLE: No SIO sent during	normal proving period			
PURP	OSE: To ensure that norma	al alignment still occurs when SIO is omitted			
PRE-T	EST CONDITIONS: Link	out of service			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQU	JENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO not aligned	
1 – 0	SIN	>			
		<	1 – 0	SIN	
1 – 0	SIN	>		T3	
				T4(Pn)	
		<	1 - 0	FISU	
TEST	DESCRIPTION				
1.	Check normal alignment of	ccurs with no SIO sent from SP B.			
	_				

TEST	TEST NUMBER: 1.18 PAGE: 1 OF 1			OF 1		
REFE	RENCE: Q.703 Clause 7 S	TD: Fig. 8				
TITLE	E: Link State Control – Expected	signal units/orders				
SUB 7	FITLE: Set and cease emergency	prior to "start alignment"				
PURP	OSE: To test the normal proving	period is employed having "emergency" set	and cleared			
PRE-T	TEST CONDITIONS: Link out o	f service				
CONF	FIGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENC	CE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: set EM : clear EM : start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
				T4(Pn)		
		<	1 – 0	FISU		
TEST	TEST DESCRIPTION					
1.	Check emergency set and cleare	ed prior to start of alignment.				
2.	Check normal proving period is	carried out.				

TEST	NUMBER: 1.19		PAGE: 1 OF	7 1
REFE	RENCE: Q.703 Clause 7 STD:	Fig. 8; Fig. 9		
TITLE	: Link State Control – Expected signa	ul units/orders		
SUB T	TTLE: Set emergency while in "not al	igned state"		
PURP	OSE: To test that emergency proving	can be set during normal initial alignmen	nt	
PRE-T	TEST CONDITIONS: Link out of serv	ice		
CONF	IGURATION: 1		TYPE OF TH	EST: VAT, CPT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 – 0	SIO
				: set EM
1 – 0	SIO	>		
		<	1 – 0	SIE
1 – 0	SIN	>		T4(Pe)
		,	1 0	
		<	1 – 0	FISU
TEST	DESCRIPTION			
1.	Check that emergency proving period	is used after set EM during normal initi	al alignment.	
2.	The timing of this test is critical, emereceived (i.e. during Timer T2 operations)	rgency must be set once the start comma on).	nd has been giv	ven and before SIO is
3.	At 64 kbit/s Timer T4 shall be in the	range 0.4 sec to 0.6 sec (nominally 0.5 s	ec).	
4.	At 4.8 kbit/s Timer T4 shall be in the	range 6 secs to 8 secs (nominally 7 secs).	

TEST	NUMBER: 1.20		PAGE: 10	OF 1	
REFE	RENCE: Q.703 Clause 7	STD: Fig. 9			
TITLE	: Link State Control – Expec	eted signal units/orders			
SUB T	TTLE: Set emergency when	'aligned''			
PURP	OSE: To test that emergency	proving period is used when emergency se	t prior to receiving	SIN	
PRE-T	EST CONDITIONS: Link or	at of service			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUE	ENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
				: set EM	
		<	1 – 0	SIE	
1 – 0	SIN	>			
				T4 (Pe)	
		<	1 – 0	FISU	
TEST	DESCRIPTION				_
1.	Check that emergency provi	ng period is used after SIE sent during "alig	gned" state.		
2.		ical. Emergency must be set once SIN has be	-	e Timer T3 expires.	

TEST	NUMBER: 1.21		PAGE: 1 OF	1	
REFE	RENCE: Q.703 Clause 7 STD:	Fig. 8; Fig. 9			
TITLE	E: Link State Control – Expected sign	al units/orders			
SUB T	TTLE: Both ends set emergency				
PURP	OSE: To check the emergency alignment	nent procedure and Timer T4 (Pe)			
PRE-T	EST CONDITIONS: Link out of ser	vice			
CONF	IGURATION: 1		TYPE OF TE	EST: V	AT
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP	A
Link			Link		
		<	1 – 0	SIC	os .
1 – 0	SIOS	>			
				: set	
		<	1 – 0	SIC	•
1 – 0	SIO	>			
		<	1 – 0	SIE	
1 – 0	SIE	>			
					T4 (Pe)
		<	1 – 0	FIS	U
TEST	DESCRIPTION				
1.	Check correct emergency alignment	procedure is performed.			

TEST	NUMBER: 1.22		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7 STD:	Fig. 9			
TITLE	E: Link State Control – Expected signa	ul units/orders			
SUB 7	TITLE: Individual end sets emergency				
PURP	OSE: To check emergency alignment	procedure, Emergency set at the other en	nd		
PRE-T	EST CONDITIONS: Link out of serv	ice			
CONF	IGURATION: 1		TYPE OF T	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
1 – 0	SIO	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIE	>			
		<	1 – 0	SIN	
				T4 (Pe)	
		<	1 – 0	FISU	
TEST	DESCRIPTION				
1.	Emergency alignment set at B.				
2.	Start alignment at A.				
3.	Check that alignment occurs with the	emergency proving period.			

TEST NUMBER: 1.23			PAGE: 10	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7	TD: Fig. 9	·			
TITLE	: Link State Control – Expected	signal units/orders				
SUB T	TTLE: Set emergency during no	rmal proving				
PURP	OSE: To test that setting emerge	ency during normal proving stops normal p	proving and starts	the emergency proving		
PRE-T	EST CONDITIONS: Link out of	f service				
CONF	IGURATION: 1		TYPE OF	TYPE OF TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENC	CE:	·			
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
				: set EM		
		<	1 – 0	SIE		
1 – 0	SIN	>				
				T4 (Pe)		
		<	1 – 0	FISU		
TEST DESCRIPTION						
Set emergency during normal proving period at A.						
2.	Check A sends SIE.					
3.						
	-					

TEST NUMBER: 1.24			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7 ST	D: Fig. 9	1		
TITLE	E: Link State Control – Expected si	gnal units/orders			
SUB T	TTLE: No SIO sent during emerge	ncy alignment			
PURP	OSE: to ensure that emergency alig	gnment still occurs when SIE is received follows	lowing SIOS		
PRE-T	EST CONDITIONS: Link out of s	ervice			
CONF	IGURATION: 1		TYPE OF TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENCE	:	1		
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: set EM : start	
		<	1 – 0	SIO	
1 – 0	SIE	>			
		<	1 – 0	SIE	
				T4 (Pe)	
		<	1 – 0	FISU	
TEST DESCRIPTION					
1.	Set emergency and start link at A.				
2.	A receives SIE after sending SIO.				
3.	Check that link aligns OK after en	nergency proving.			

TEST	NUMBER: 1.25		PAGE: 1 OF	1
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9				
TITLE	E: Link State Control – Expected signa	ul units/orders		
SUB T	TITLE: Deactivation during initial alig	nment		
PURP	OSE: To test the response to the receip Not Aligned State)	pt of the stop command while in the initi	al alignment stat	e (initial alignment is
PRE-T	TEST CONDITIONS: Link out of serv	ice		
CONF	IGURATION: 1		TYPE OF TES	ST: VAT, CPT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 – 0	SIO
				: wait 5 secs. : stop
		<	1 – 0	SIOS
TEST DESCRIPTION				
1.	Check that alignment ceases after Sto	p command given.		
2.	The stop command must be issued before timer T2 expires.			
3.	Timer T2 shall be in the range 5 secs to 150 secs.			

TEST NUMBER: 1.26			PAGE: 1 OF 1			
REFEI	RENCE: Q.703	Clause 7 STD:	Fig. 8; Fig. 9			
TITLE	E: Link State Co	ontrol – Expected signa	ll units/orders			
SUB T	TITLE: Deactive	ation during aligned sta	nte			
PURP	OSE: To test th	e response to the receiptate)	pt of the stop command while in the initi	al alignment sta	te (initial alignment is	
PRE-T	EST CONDITIO	ONS: Link out of servi	ice			
CONF	IGURATION:	1		TYPE OF TEST: VAT		
EXPE	CTED SIGNAL	UNIT SEQUENCE:				
	SP	В			SP A	
Link				Link		
			<	1 – 0	SIOS	
1 – 0	SIOS		>			
					: start	
			<	1 – 0	SIO	
1 – 0	SIO		>			
			<	1 – 0	SIN	
					: stop	
			<	1 – 0	SIOS	
TEST DESCRIPTION						
1.	Check that alig	gnment ceases after STO	OP command given.			
2.	The stop command must be issued before timer T3 expires.					
3.	Timer T3 shall be in the range 1 sec to 1.5 secs.					
		-				

TEST	TEST NUMBER: 1.27			PAGE: 1 OF 1	
REFEI	RENCE: Q.703 Clause 7, 8	STD: Fig. 8			
TITLE	: Link State Control – Expect	ed signal units/orders			
SUB T	TTLE: Deactivation during ali	gned not ready			
PURP	OSE: To check the response for	ollowing normal alignment when PO has b	een set		
PRE-T	EST CONDITIONS: Link ou	of service			
CONF	IGURATION: 1		TYPE OF	TYPE OF TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUE	NCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: set LPO : start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
		<	1 – 0	SIPO	
				: stop	
		<	1 – 0	SIOS	
TEST DESCRIPTION					
1.	Soon after alignment completes, A enters "Aligned not ready".				
2.	Before alignment completes at B, stop command is given at A.				
3.	Check that A enters "Out of service" state.				
4.	Repeat test with LPO set at B.				

TEST NUMBER: 1.28	PAGE: 1 OF 1			
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 14				
TITLE: Link State Control – Expected signal units/orders				
SUB TITLE: SIO received during link in service				
PURPOSE: To check the deactivation of a signalling link from the "In Service" state	;			
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B	SP A			
Link	Link			
1 – 0 FISU>				
\	1 – 0 FISU			
1 – 0 SIO	1 – 0 SIOS			
\	1 - 0 3103			
TEST DESCRIPTION				
1. SIO is sent to A during link in service.				
2. Check that an "in service" link can be taken out of service at A.	2. Check that an "in service" link can be taken out of service at A.			

TEST	NUMBER: 1.29		PAGE: 1 OF	7 1	
REFE	RENCE: Q.703 Clause 7 STD	b: Fig. 8; Fig. 14			
TITLE	E: Link State Control – Expected sig	gnal units/orders			
SUB T	TITLE: Deactivation during link in s	ervice			
PURP	OSE: To check the deactivation of a	a signalling link from the "In Service" state	;		
PRE-T	EST CONDITIONS: Link in service	e			
CONFIGURATION: 1 TYPE OF TEST: VAT, CPT			EST: VAT, CPT		
EXPE	EXPECTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
1 – 0	FISU	>			
		<	1 – 0	FISU	
	: stop				
1 – 0	SIOS	>			
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Check that an "In service" link can	be taken out of service by command at B.			
2.	Repeat test, command given at A.				

TEST NUMBER: 1.30			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 8	TD: Fig. 10			
TITLE	E: Link State Control – Expected sign	nal units/orders			
SUB T	TTLE: Deactivation during LPO				
PURP	OSE: To check the response to the s	top command during LPO			
PRE-T	EST CONDITIONS: Link in service	•			
CONFIGURATION: 1 TYPE OF TEST: VAT					
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		S	1 – 0	FISU	
1 – 0	FISU	>	1 – 0	FISU	
				: set LPO	
		<	1 – 0	SIPO	
1 – 0	FISU	>			
				: stop	
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	SIPO sent from A, stop command gi	iven at A, check link enters out of service	state.		
2.	Repeat test, SIPO sent from B, stop	command at B, check link enters out of so	ervice state.		

TEST	NUMBER: 1.31		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 8 ST	D: Fig. 10			
TITLE	E: Link State Control – Expected signa	al units/orders			
SUB 7	TTLE: Deactivation during RPO				
PURP	OSE: To test the response to the stop	command during RPO			
PRE-T	EST CONDITIONS: Link in service				
CONFIGURATION: 1 TYPE OF TEST: VAT					
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
1 – 0	FISU	>			
		<	1 – 0	FISU	
1 – 0	SIPO	>			
				: stop	
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
	DESCRIPTION				
1.		iven at A, check link enters out of service			
2.	Repeat test, SIPO received at B, stop	command given at B, check link enters of	out of service st	ate.	
				į	

TEST	TEST NUMBER: 1.32			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 10	0.3 STD: Fig. 8; Fig. 9				
TITLE	E: Link State Control – Expec	ted signal units/orders				
SUB 7	TITLE: Deactivation during the	ne proving period				
PURP	OSE: To test the response to	the receipt of SIOS during the proving period	ı			
PRE-T	EST CONDITIONS: Link ou	nt of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT, CPT		
EXPE	CTED SIGNAL UNIT SEQUE	ENCE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
	: stop					
1 – 0	SIOS	>				
		<	1 – 0	SIOS		
TEST DESCRIPTION						
1.	Check link enters out of service state when SIOS is received at A during the proving period.					
2.	Repeat test, SIOS received at	B during proving period.				

TEST	NUMBER: 1.33		PAGE: 1	OF 1
REFEI	RENCE: Q.703 Clause 7	STD: Fig. 8		
TITLE	: Link State Control – Expected	d signal units/orders		
SUB T	TTLE: SIO received instead of F	FISUs		
PURP	OSE: To check the response to t	the receipt of SIO instead of FISUs in the alig	gned ready stat	e
PRE-T	EST CONDITIONS: Link out of	of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUEN	CE:		
Link	SP B		Link	SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		: start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
1 – 0	SIO	<>	1 – 0	FISU
1-0	Sio	<	1 – 0	SIOS
TEST DESCRIPTION				
1.	Check link enters out of service	state when SIO is received at A instead of F	ISUs in the ali	gned ready state.

TEST	NUMBER: 1.34		PAGE: 1	OF 1
REFEI	RENCE: Q.703 Clause 7	STD: Fig. 8		
TITLE	: Link State Control – Expec	cted signal units/orders		
SUB T	TTLE: SIO received instead of	of FISUs		
PURP	OSE: To check the response	to the receipt of SIOS instead of FISUs in the ali	gned ready s	tate
PRE-T	EST CONDITIONS: Link or	ut of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUE	ENCE:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>	1 – 0	SIOS
				: start
		<	1 – 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	·>	1 – 0	FISU
	: stop	\	1 – 0	1150
1 – 0	SIOS	>		
		<	1 – 0	SIOS
TEST DESCRIPTION				
1.	Check link enters out of serv	rice state when SIOS is received at A instead of I	FISUs in the a	aligned ready state.

TEST	NUMBER: 1.35		PAGE: 1	PAGE: 1 OF 1		
REFEI	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8				
TITLE	: Link State Control – Expecte	ed signal units/orders				
SUB T	TTLE: SIPO received instead of	of FISUs				
PURP	OSE: To check the response to	the receipt of SIPO instead of FISUs in the	aligned ready st	ate		
PRE-T	EST CONDITIONS: Link out	of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUEN	NCE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
1 – 0	SIN	<>	1 – 0	SIN		
1 0	SILV	<	1 – 0	FISU		
	: set LPO					
1 – 0	SIPO	>				
		<	1 – 0	FISU		
TEST	TEST DESCRIPTION					
1.	Check link enters processor or	atage state when SIPO is received at A inste	ead of FISUs in th	ne aligned ready state.		

TEST	TEST NUMBER: 2.1			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7,	11 STD: Fig. 8				
TITLE	E: Link State Control – Une	expected signal units/orders				
SUB T	TITLE: Unexpected signal u	units/orders in "Out of service" state				
PURP	OSE: To check that the une	expected signal units/orders are ignored				
PRE-T	TEST CONDITIONS: Link	out of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQU	UENCE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
	xxx	>				
				yyy : start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
1 0	GD.	<································	1 – 0	SIN		
1 – 0	SIN	> <	1 – 0	FISU		
1 – 0	FISU	>	1 0	1.50		
TEST DESCRIPTION						
1.	1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIO, SIN, SIE, SIPO, SIB, aberrant LSSU (non-existing status, one and two octets), FISU and MSU.					
2.	Check that the unexpected	orders yyy = Stop from level 3 are ignored with	nout impact on s	ystem (if applicable).		

TEST	NUMBER: 2.2		PAGE:	1 OF 1	
REFE	RENCE: Q.703 Clauses 7	, 11 STD: Fig. 9			
TITLE	E: Link State Control – Un	nexpected signal units/orders			
SUB 7	TITLE: Unexpected signal	units/orders in "Not aligned" state			
PURP	OSE: To check that the un	nexpected signal units/orders are ignored			
PRE-T	TEST CONDITIONS: Link	k out of service			
CONF	IGURATION: 1		TYPE O	F TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQ	QUENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
	XXX	>			
				ууу	
1 – 0	SIO	>			
	an.	<	1 – 0	SIN	
1 – 0	SIN	·	1 0	EXCIT	
1 – 0	FISU	·>	1 – 0	FISU	
1-0	1130				
TEST	DESCRIPTION				
1.	Check that the unexpect successively SIOS, SIPO,	ted signal units xxx received from B are ignored v., SIB, aberrant LSSU, FISU and MSU.	without ii	npact on the system. xxx are	
2.	Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively clear EM and start (if applicable).				

TEST	EST NUMBER: 2.3 PAGE: 1 OF 1			OF 1	
REFE	RENCE: Q.703 Clauses	7, 11 STD: Fig. 9			
TITLE	E: Link State Control – Ui	nexpected signal units/orders			
SUB 7	TITLE: Unexpected signa	l units/orders in "Aligned" state			
PURP	OSE: To check that the u	nexpected signal units/orders are ignored			
PRE-7	EST CONDITIONS: Lin	k out of service			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEC	QUENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>	1 0	GD.	
	XXX	·>	1 – 0	SIN	
				ууу	
1 – 0	SIN	>			
		<	1 – 0	FISU	
1 – 0	FISU	>			
TEST	THE CONTROL OF THE CO				
	1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are				
1.	successively SIO, SIPO,	SIB, aberrant LSSU, FISU and MSU.	a without im	pact on the system. xxx are	
2.	Check that the unexpect successively clear EM ar	eted orders yyy received from level 3 are ignore and start (if applicable).	d without im	pact on the system. yyy are	

TEST	TEST NUMBER: 2.4 PAGE: 1 OF 1			DF 1	
REFE	RENCE: Q.703 Clauses 7, 11	STD: Fig. 9			
TITLE	: Link State Control – Unexpect	ed signal units/orders			
SUB 7	TTLE: Unexpected signal units/o	orders in "Proving" state			
PURP	OSE: To check that the unexpec	ted signal units/orders are ignored			
PRE-T	EST CONDITIONS: Link out o	f service			
CONF	IGURATION: 1		TYPE OF T	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENC	CE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>		2202	
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
1 – 0	SIN	<>	1 – 0	SIN	
1-0	XXX	>			
				ууу	
		<	1 – 0	FISU	
1 – 0	FISU	>			
TEST	DESCRIPTION				
1.	. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIPO, SIB, aberrant LSSU, FISU and MSU.				
2.	Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively clear EM and start (if applicable).				
	NOTE – The reception of SIB in "Initial alignment" state may possibly cause link failure after transferring to "In service" state because of the T6 expiration.				

TEST	TEST NUMBER: 2.5			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause	ses 7, 11 STD: Fig. 8				
TITLE	E: Link State Control –	- Unexpected signal units/orders				
SUB 7	TITLE: Unexpected sig	gnal units/orders in "Aligned ready" state				
PURP	OSE: To check that th	ne unexpected signal units/orders are ignored				
PRE-T	TEST CONDITIONS:	Link out of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT	SEQUENCE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
1 0	SIO	<>	1 – 0	SIO		
1 – 0	SIO	<	1 – 0	SIN		
1 – 0	SIN	>				
		<	1 – 0	FISU		
	XXX	-		Mark		
1 – 0	FISU	>		ууу		
TEST DESCRIPTION						
1.	. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIB and aberrant LSSU.					
2.	Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively set EM, clear EM, clear LPO and start (if applicable).					
	NOTE – The reception of SIB in "Aligned ready" state may possibly cause link failure after transferring to "In service" state because of the T6 expiration.					

TEST NUMBER: 2.6			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 11	STD: Fig. 8	1		
TITLE	E: Link State Control – Unexpect	ed signal units/orders			
SUB 7	FITLE: Unexpected signal units/o	orders in "Aligned not ready" state			
PURP	OSE: To check that the unexpect	ted signal units/orders are ignored			
PRE-T	TEST CONDITIONS: Link out of	service			
CONF	FIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENC	E:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: set LPO : start	
		ζ	1 – 0	SIO	
1 – 0	SIO	>			
1 – 0	SIN	<>	1 – 0	SIN	
1-0	Silv	<	1 – 0	SIPO	
	xxx	>			
				ууу	
1 – 0	FISU	>			
		<	1 – 0	SIPO	
TEST DESCRIPTION					
1.	Check that the unexpected sign successively SIB and aberrant L	nal units xxx received from B are ignored SSU.	without imp	act on the system. xxx are	
2.	Check that the unexpected ord successively set EM, clear EM, c	lers yyy received from level 3 are ignored clear LPO and start (if applicable).	without imp	act on the system. yyy are	
1 – 0 TEST 1.	FISU DESCRIPTION Check that the unexpected sign successively SIB and aberrant LSC. Check that the unexpected ord	nal units xxx received from B are ignored SSU.	1 – 0	SIPO act on the system. xxx are	

TEST	NUMBER: 2.7		PAGE: 1 OF	1
REFE	RENCE: Q.703 Clauses 7, 11	STD: Fig. 8		
TITLE	E: Link State Control – Unexpected si	ignal units/orders		
SUB T	TTLE: Unexpected signal units/order	rs in "In service" state		
PURP	OSE: To check that the unexpected s	ignal units/orders are ignored		
PRE-T	EST CONDITIONS: Link out of ser	vice		
CONF	IGURATION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU	>		
	aberrant LSSU	>		
				ууу
		<	1 – 0	FISU
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Check that an aberrant LSSU receive	ed from B is ignored without impact on the	ne system.	
2.	Check that the unexpected orders successively set EM, clear EM, clear	yyy received from level 3 are ignored : LPO and start (if applicable).	without impac	t on the system. yyy are
	•			

TEST	NUMBER: 2.8	PAGE: 1 OF	7 1
REFEI	RENCE: Q.703 Clauses 7, 11 STD: Fig. 8		
TITLE	: Link State Control – Unexpected signal units/orders		
SUB T	TTLE: Unexpected signal units/orders in "Processor outage" state		
PURP	OSE: To check that the unexpected signal units/orders are ignored		
PRE-T	TEST CONDITIONS: Link in service		
CONF	IGURATION: 1	TYPE OF TE	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:		
	SP B		SP A
Link		Link	
			: set LPO
	<	1 – 0	SIPO
	xxx		
			ууу
1 – 0	FISU		
TEST	DESCRIPTION		
1.	Check that the unexpected signal units xxx received from B are ignored successively SIB and aberrant LSSU.	without impac	t on the system. xxx are
2.	Check that the unexpected orders yyy received from level 3 are ignored successively set EM, clear EM and start (if applicable).	without impac	t on the system. yyy are

TEST NUMBER: 3.1				PAGE: 1 OF 1			
REFE	RENCE: Q.703 Clause 4, sul	oclause10.2	STD: Fig. 8				
TITLE	E: Transmission failure						
SUB 7	TITLE: Link aligned ready (E	Break Tx path)					
PURP	OSE: To test the response to	a transmission fa	nilure – detected by SU	ERM – w	hen in "Alig	ned ready"	state
PRE-T	TEST CONDITIONS: Link or	ut of service					
CONF	IGURATION: 1				TYPE OF	TEST: VA	ΛΤ
EXPE	CTED SIGNAL UNIT SEQUE	ENCE:					
	SP B					SP	A
Link					Link		
		<			1 – 0	SIO	S
1 – 0	SIOS		>				
						: start	:
		<			1 – 0	SIO	
1 – 0	SIO		>				
		<			1 – 0	SIN	
1 – 0	SIN		>				
		<			1 – 0	FISU	J
	: break Tx						
		<			1 – 0	SIO	S
TEST	DESCRIPTION						
1.	Break Tx path at B when in of service.	"Aligned ready"	state, check that the S	SUERM d	etects the fai	lure and the	e link is taken out
2.	Repeat test, break Tx at A.						

TEST NUMBER: 3.2 PAGE: 1 OF 1			1	
REFERENCE:	Q.703 Subclause 5.3 ST	D: Fig. 8		
TITLE: Transm	nission failure			
SUB TITLE: L	ink aligned ready (Corrupt FII	Bs – Basic)		
PURPOSE: To	check the response to a link faigned ready State	ailure after corruption of two FIBs – de	tected by recept	ion control – while in
PRE-TEST CON	NDITIONS: Aligned ready			
CONFIGURATI	ON: 1		TYPE OF TE	ST: VAT
EXPECTED SIG	GNAL UNIT SEQUENCE:			
SF	Р В			SP A
Link			Link	
		<	1 – 0	FISU
	SU corrupt FIB IB + FSN = 7F)	>		
1 – 0 FI	SU corrupt FIB IB + FSN = 7F)	>		
		<	1 – 0	SIOS
TEST DESCRIP	TION			
1. Check the service.	nat receipt of two FISUs at A	with corrupt FIB's at link aligned read	ly state causes t	he link to be taken out of

TEST	NUMBER: 3.3		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 8, subclaus	e 10.3 STD: Fig. 8			
TITLE	: Transmission failure				
SUB T	TTLE: Link aligned not ready (Bre	eak Tx path)			
PURP	OSE: To test the response to a brea	ak in the transmission path – detected by S	UERM – in "A	ligned not ready" state	
PRE-T	EST CONDITIONS: Link out of so	ervice			
CONF	IGURATION: 1		TYPE OF T	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE		1		
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: set LPO	
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
		<	1 – 0	SIPO	
	: break Tx				
		<	1 – 0	SIOS	
TEST DESCRIPTION					
1.	Set LPO at A.				
2.	Start link alignment at A.				
3.	In link aligned not ready state brea	k Tx at B and check link is taken out of ser	vice.		
4.	Repeat test for B with break in Tx	at A, check link is taken out of service.			
5.	The Tx path must be broken before	e Timer T1 expires.			

TEST	NUMBER: 3.4		PAGE: 1 C	PAGE: 1 OF 1	
REFE	RENCE: Q.703 subclauses 5.3, 0	Clause 8 STD: Fig. 8	'		
TITLI	E: Transmission failure				
SUB 7	FITLE: Link aligned not ready (C	Corrupt FIBs – Basic)			
PURP	POSE: To check the response to a "Aligned not ready"	link failure after corruption of two	FIBs – detected by rece	ption control – while in	
PRE-	TEST CONDITIONS: Link out or	f service			
CONI	FIGURATION: 1		TYPE OF T	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENC	E:	1		
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: set LPO	
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 - 0	SIN	
1 – 0	SIN	>			
		<	1 – 0	SIPO	
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
1 – 0	FISU corrupt FIB	>			
1 – 0	(FIB + FSN = 7F)	,			
		<	1 - 0	SIOS	
TEST	DESCRIPTION				
1.	Set LPO at A.				
2.	Start link alignment at A.				
3.	Send two corrupt FISUs (corrup	t FIBs) on link aligned not ready.			
4.	Check link is taken out of service	e at A.			

TEST	NUMBER: 3.5	PAGE: 1 OF 1			
REFE	RENCE: Q.703 Clause 4, subclause 10.2 STD: Fig. 8				
TITLE	: Transmission failure				
SUB T	TTLE: Link in service (Break Tx path)				
PURP	OSE: To test the response to a transmission failure when the link is "In service	3"			
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1	TYPE OF TEST: VAT, CPT			
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B	SP A			
Link		Link			
	<	1 – 0 FISU			
1 – 0	FISU>				
	: break Tx				
	<	SIOS			
TEST	TEST DESCRIPTION				
1.	Break Tx at B, check SIOS returned from A.				
2.	Repeat test, break at A.				

TEST NUMBER: 3.6 PAGE: 1 OF 1				
REFER	ENCE: Q.703 Subclause 5.3 ST	TD: Fig. 8		
TITLE:	Transmission failure			
SUB T	TLE: Link in service (Corrupt FIBs –	Basic)		
PURPO	SE: To check the response to a link f service"	ailure after corruption of two FIBS – de	tected by reception cont	rol – while "In
PRE-TI	EST CONDITIONS: Link in service			
CONFI	GURATION: 1		TYPE OF TEST: VA	ΛT
EXPEC	TED SIGNAL UNIT SEQUENCE:			
	SP B		SP	A
Link			Link	
		<	1 – 0 FISU	J
1 – 0	FISU (FIB + FSN = FF)	>		
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>		
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>		
		<	1 – 0 SIO	S
TEST DESCRIPTION				
1.	Check that receipt of two FISUs at A v	with corrupt FIBs at link in service state	causes the link to be tak	en out of service.

TEST NUMBER: 3.7			PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 8, subclause 1	0.2 STD: Fig. 8			
TITLE	E: Transmission failure				
SUB 7	TITLE: Link in processor outage (Brea	ak Tx path)			
PURP	OSE: To test the response to a transm	nission failure when the link is "Processo	or outage"		
PRE-7	TEST CONDITIONS: Link in service				
CONFIGURATION: 1 TYPE OF TEST: VAT				EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU	
1 – 0	FISU	>			
				: set LPO	
		<	1 – 0	SIPO	
	: break Tx				
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Break Tx path at B when in "Processor outage" state, check that the SUERM detects the failure and the link is taken				
2.					
	<u>.</u> ,				
TEST	: break Tx DESCRIPTION	<	1-0	: set LPO SIPO SIOS	

TEST NUM	MBER: 3.8		PAGE: 1 OF	71	
REFEREN	CE: Q.703 subclauses 5.3, Claus	se 8 STD: Fig. 8			
TITLE: Ti	ransmission failure				
SUB TITL	E: Link in processor outage (Cor	rupt FIBs – Basic)			
PURPOSE:	PURPOSE: To check the response to a link failure after corruption of two FIBs – detected by reception control – while in "Processor outage"				
PRE-TEST	CONDITIONS: Link in service				
CONFIGURATION: 1 TYPE OF TEST: VAT				ST: VAT	
EXPECTE	O SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU	
1 – 0	FISU	>			
				: set LPO	
		<	1 – 0	SIPO	
1 – 0	FISU corrupt FIB	·>	1 0	511 0	
1 – 0	(FIB + FSN = 7F)	/			
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
		<	1 – 0	SIOS	
TEST DESCRIPTION					
Check that receipt of two FISUs at A with corrupt FIBs on processor outage state causes the link to be taken out of service.					

TEST NUMBER: 4.1 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 8 STD: Fig. 10 TITLE: Processor outage control SUB TITLE: Set and clear LPO while link in service PURPOSE: To check the ability to perform correctly when LPO is set and recovered PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)FISU 1 - 0(FSN = 7F, BSN = 7F)accepted 1 - 0MSU (1) (FSN = 0, BSN = 7F)1 - 0MSU (2) (FSN = 1, BSN = 7F): set LPO 1 - 0MSU (FSN = 0, BSN = 0)1 - 0SIPO (FSN = 0, BSN = 7F): clear LPO MSU (3) 1 - 0(FSN = 1, BSN = 5)TEST DESCRIPTION Set LPO at A while link in service. 2. Check that MSU from B is discarded. 3. Clear LPO at A. 4. Check that "old" messages are flushed from level 2 buffers and not transmitted on the link. Check that new MSUs are sent correctly.

TEST	NUMBER: 4.2		PAGE: 1 OF	1
REFEI	RENCE: Q.703 Clause 8 STD:	Fig. 10		
TITLE	Processor outage control			
SUB T	TTLE: RPO during LPO			
PURP	OSE: To test the response to RPO is	set and cleared when "LPO"		
PRE-T	EST CONDITIONS: Link in service	. LPO set at B		
CONF	IGURATION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
				: set LPO
		<	1 – 0	SIPO
1 – 0	SIPO	>		
		<	1 – 0	SIPO
	: clear LPO			
1 – 0	TSR	>		
		<	1 – 0	SIPO
TEST	DESCRIPTION			
1.	Set LPO at A.			
2.	Clear LPO at B.			
3.	Check is SIPO sent from A.			
٥.	Check to our o sont from 11.			

TEST N	NUMBER: 4.3		PAGE: 1 OF	7.1
REFER	REFERENCE: Q.703 Clause 8 STD: Fig. 10			
TITLE:	Processor outage control			
SUB T	ITLE: Clear LPO when "Both proces	sor outage"		
PURPO	OSE: To test the response to LPO, RI	PO recovered when "Both processor outa	age"	
PRE-T	EST CONDITIONS: LPO set at A an	d B		
CONFI	GURATION: 1		TYPE OF TE	EST: VAT
EXPEC	TED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIPO
1 – 0	SIPO	>		
				: clear LPO
		<	1 – 0	FISU
	: clear LPO			
1 – 0	FISU	>		
		<	1 – 0	FISU
TEST I	DESCRIPTION			
1.	Clear LPO at A.			
2.	Clear LPO at B.			
3.	Check is FISU sent from A.			

TEST	NUMBER: 5.1		PAGE: 1 OF 1	
REFEI	RENCE: Q.703 Subclause 4.1 ST	ΓD: Fig. 11		
TITLE	E: SU delimitation, alignment, error det	ection and correction		
SUB T	TTLE: More than seven '1's between I	MSU opening and closing flags		
PURPO	OSE: To test the signal unit delimitation or more consecutive '1's	on, alignment, and error detection action	on receipt of an	MSU containing seven
PRE-T	TEST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF TES	T: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU	>		
1 – 0	corrupt MSU (FIB + FSN = 80) (containing seven consecutive '1's)	>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Send a corrupt MSU at B containing s	even consecutive '1's.		
2.	Check that A discards the signal unit,	and goes into octet counting mode.		
3.	On reception of a correct FISU, check	that A leaves the octet counting mode a	nd remains in the	"in service" state.

TEST	NUMBER: 5.2		PAGE: 1 OF 1	I
REFEI	RENCE: Q.703 Subclause 4.1	STD: Fig. 11		
TITLE	E: SU delimitation, alignment, error de	etection and correction		
SUB T	TTLE: Greater than maximum signal	unit length		
PURP	OSE: To test the signal unit delimitat maximum length	tion, alignment, error detection action on	receipt of signal	unit greater than the
PRE-T	EST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF TES	T: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU	>		
1 – 0	corrupt MSU (FIB + FSN = 80) (signal unit length > max. allowed)	>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Send corrupt MSU at B with maximum	um length plus extra bits and good sumch	neck.	
2.	Check A discards the signal unit, and	d goes into octet counting mode.		
3.	On reception of a correct FISU, chec	k that A leaves the octet counting mode a	nd remains in the	e "in service" state.

TEST	NUMBER: 5.3		PAGE: 1 OF	1
REFE	RENCE: Q.703 Subclause 4.1 ST	D: Fig. 11		
TITLE	: SU delimitation, alignment, error dete	ection and correction		
SUB T	ITLE: Below minimum signal unit leng	gth		
PURP	OSE: To test the signal unit delimitation minimum length	on, alignment and error detection action	on receipt of sig	gnal unit less than the
PRE-T	EST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU (BIB + BSN = FF)
1 – 0	FISU	>		
1 – 0	corrupt MSU (FIB + FSN = 80) (signal unit less than 6 octets)	······>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TECT	DESCRIPTION			
	DESCRIPTION			
1.	-	nan 6 octet (i.e. less than 5 octets between	en flags).	
2.	Check A discards the signal unit, and g			<i></i>
3.	On reception of a correct FISU, check	that A leaves the octet counting mode a	nd remains in th	e "in service" state.

TEST	NUMBER: 5.4		PAGE: 1 OF 1	
REFE	REFERENCE: Q.703 Clause 2 STD: Fig. 11			
TITLE	: SU delimitation, alignment,	error detection and correction		
SUB T	TTLE: Reception of single and	l multiple flags between FISUs		
PURP	OSE: To check that single and	multiple flags between FISUs can be received		
PRE-T	EST CONDITIONS: Link in s	service		
CONF	IGURATION: 1		TYPE OF TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	NCE:		
	SP B		SP A	
Link			Link	
1 – 0	FISU	>		
	case 1	FISU F FISU		
	case 2	FISU F F FISU	F: Flag	
		n(≥ 2)	n = number of flags	
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Check that single and n flags,	case 1 and case 2 respectively, can be received		

TEST	NUMBER: 5.5		PAGE: 1 OF 1	
REFEI	REFERENCE: Q.703 Clause 2 STD: Fig. 11			
TITLE	: SU delimitation, alignment, en	rror detection and correction		
SUB T	ITLE: Reception of single and	multiple flags between MSUs		
PURP	OSE: To check that single and	multiple flags between MSUs can be receive	ed	
PRE-T	EST CONDITIONS: Link in se	rvice		
CONF	IGURATION: 1		TYPE OF TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:		
	SP B		SP A	
Link			Link	
1 – 0	FISU	>		
	case 1	MSU F MSU		
	case 2	MSU F F MSU	F: Flag	
		n(≥ 2)	n = number of flags	
1 – 0	FISU	>		
TEST	DESCRIPTION			
1.	Check that single and n flags, c	ase 1 and case 2 respectively, can be received	ed.	

TEST NUMBER: 6.1 PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 18, Fig. 8

TITLE: SUERM check

SUB TITLE: Error rate of 1 in 256 – Link remains in service

PURPOSE: To check the SUERM at a link error rate of 1 in 256 units

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1 TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

SP B SP A

Link Link

<----- 1 – 0 FISU

1 – 0 FISU

Ct : corrupt 1 in 256

TEST DESCRIPTION

- 1. Check that "In service" state is maintained. The test should run for several minutes.
- 2. Ct = the count of corrupted FISUs.

NOTE -1) The number (x) of corrupt signal units before an SIOS returned is calculated according to the following formula (a = number of correct signal units):

$$x = \frac{1}{1+a} \left(\frac{256 \times 64}{\frac{256}{1+a} - 1} \right)$$
 for $a < 256$

2) In this case as a = 255, so x = infinity.

TEST	NUMBER: 6.2		PAGE: 1 O	F 1	
REFEI	RENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 1	18, Fig. 8			
TITLE	S: SUERM check				
SUB T	TTLE: Error rate of 1 in 254 – Link out of service				
PURP	OSE: To check the SUERM at a link error rate of 1 in 254	units			
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1		TYPE OF T	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		-
	<		1 – 0	FISU	
1 – 0	FISU	>			
Ct	: corrupt 1 in 254				
	ζ		1 – 0	SIOS	
TEST	DESCRIPTION				
1.	SIOS should be returned after approx. 8192 corrupt FISUs	s (e.g. CRC error).			
2.	Ct = the count of corrupted FISUs.				

TEST NUMBER: 6.3		PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 10.2 S	STD: Fig. 11, Fig. 18, Fig. 8		
TITLE: SUERM check			
SUB TITLE: Consecutive corrupted SUs			
PURPOSE: To test the SUERM on consecuti	ive corrupted signal units		
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1		TYPE OF TEST	Γ: VAT
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B		;	SP A
Link		Link	
	ζ	1 – 0	FISU
1 – 0 FISU	>		
Ct : corrupt 1 in 1			
	<	1 – 0	SIOS
TEST DESCRIPTION			
SIOS should be returned after approx.	64 corrupt FISUs (e.g. CRC error).		
2. Ct = the count of corrupted FISUs.			

TEST	NUMBER: 6.4	PAGE: 1 OF 1
REFEI	RENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 18	
TITLE	: SUERM check	
SUB T	TTLE: Time controlled break of the link	
PURP	OSE: To check response to a range of time controlled breaks of Tx or Rx	
PRE-T	EST CONDITIONS: Link in service	
CONF	IGURATION: 1	TYPE OF TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:	
	SP B	SP A
Link		Link
	<	1 – 0 FISU
1 – 0	FISU	
	: break Tx	
	: restore Tx	
	FISU>	
	<	1 – 0 FISU
TEST	DESCRIPTION	
1.	Break the transmission link, and restore before level 2 goes out of service. (E 64 kbit/s).	Break time is less than approx. 128ms for
2.	Check that A enters and leaves the octet counting mode on reception of an FIS	SU.

TEST	NUMBER: 7.1		PAGE: 1 C	OF 1	
REFE	REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9, Fig. 11, Fig. 17				
TITLE	E: AERM check				
SUB 7	FITLE: Error rate below the nor	rmal threshold			
PURP	OSE: To test the AERM on err	or rates below the normal threshold			
PRE-T	TEST CONDITIONS: Link out	of service			
CONF	FIGURATION: 1		TYPE OF T	TYPE OF TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:			
	SP B			SP A	
Link			Link		
		ζ	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	>		T4	
1 – 0	SIN	>			
		<	1 – 0	FISU	
TEST	DESCRIPTION				
1.	Start link at A.				
2.	Generate x number of corrupt	LSSUs (e.g. CRC error) at B.($x < Tin$).			
3.	Check that the proving period	continues and the link aligns successfull	ly.		

TEST	NUMBER: 7.2		PAGE: 10	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Subclause 10.3	STD: Fig. 9, Fig. 11, Fig. 17				
TITLE	: AERM check					
SUB T	TITLE: Error rate at the normal	threshold				
PURP	OSE: To test the AERM at an e	rror rate equal to the normal threshold				
PRE-T	EST CONDITIONS: Link out of	of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUEN	CE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: start		
		<	1 – 0	SIO		
1 – 0	SIO	>				
		<	1 – 0	SIN		
1 – 0	SIN	>				
1 – 0	corrupt LSSUs	>				
	SIN	>		T4		
		<	1 – 0	FISU		
TEST	DESCRIPTION				_	
1.	Start link at A.					
2.	Generate x number of corrupt L	SSUs (e.g. CRC error) at B.($x \ge Tin$).				
3.	Check that the proving period i	s aborted, then restarted and link aligns	successfully.			

TEST NU	JMBER: 7.3		PAGE: 1	OF 1	
REFERE	NCE: Q.703 Subclause 10.3	STD: Fig. 9, Fig. 11, Fig. 17			
TITLE:	AERM check				
SUB TIT	LE: Error rate above the nor	mal threshold			
PURPOS	E: To test the AERM at an e	error rate above the threshold over five	proving periods		
PRE-TES	T CONDITIONS: Link out	of service			
CONFIG	URATION: 1		TYPE OF	TEST: VAT	
EXPECT	ED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
1 – 0	SIOS	<>	1 – 0	SIOS	
1 – 0	SIOS	>		: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 - 0 1 - 0	SIN corrupt LSSUs	> >			
1-0	corrupt L330s	<	1 – 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	>			
1 – 0	SIN	<>	1 – 0	SIN	
1 - 0 1 - 0	corrupt LSSUs	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	> <	1 – 0	SIN	
1 – 0	SIN	>	1 – 0	SIIV	
1 – 0	corrupt LSSUs	>			
		<	1 – 0	SIOS	
TEST DE	SCRIPTION				
1. St	tart link at A.				
2. G	enerate x number of corrupt	LSSUs (e.g. CRC error) at B.($x \ge Tin$)			
3. O	bserve that 5 proving period	attempts are made before link out of ser	rvice state.		

TEST	NUME	BER: 7.4		PAGE: 1 OF 1		
REFE	RENC	E: Q.703 Subclause 10.3	STD: Fig. 9, Fig. 11, Fig. 17			
TITLE	E: AEI	RM check				
SUB T	TITLE:	Error rate at the emergency three	eshold			
PURP	OSE:	To test the AERM at the emerge	ency threshold			
PRE-T	TEST C	CONDITIONS: Link out of servi	ice			
CONF	IGUR/	ATION: 1		TYPE OF TE	ST: VAT	
EXPE	CTED	SIGNAL UNIT SEQUENCE:				
		SP B			SP A	
Link				Link		
			<	1 – 0	SIOS	
1 – 0		SIOS	>			
					: start	
			<	1 – 0	SIO	
1 – 0		SIO	>			
			<	1 – 0	SIN	
1 – 0	ı	SIE	>			
1 – 0		corrupt LSSU	>			
1 - 0		SIE	>			
T4 (Pe)			<	1 – 0	SIN	
			<	1 – 0	FISU	
TEST	DESC	RIPTION				
1.	Start	link at A, check emergency prov	ing started from B.			
2.	Gene	rate x number of corrupt LSSUs	(e.g. CRC error) at B.(5 > $x \ge Tie$).			
3.	Chec	k that link aligns successfully.				

TEST	NUMBER: 8.1	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Subclause 5.2	STD: Fig. 13, Fig. 14		
TITLE	: Transmission and reception cont	rol (Basic)		
SUB T	TTLE: MSU transmission and rece	eption		
PURP	OSE: To check basic MSU transm	ission and reception		
PRE-T	EST CONDITIONS: Link in servi	ce		
CONF	IGURATION: 1		TYPE OF T	EST: VAT, CPT
EXPE	CTED SIGNAL UNIT SEQUENCE	:		
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU	>		
1 – 0	MSU (FIB + FSN = 80) (BIB + BSN = FF)	>		
		<	1 – 0	FISU $(FIB + FSN = FF)$ $(BIB + BSN = 80)$
1 – 0	FISU (FIB + FSN = 80) (BIB + BSN = FF)	>		
		ζ	1 – 0	$\begin{aligned} & \text{MSU} \\ & (\text{FIB} + \text{FSN} = 80) \\ & (\text{BIB} + \text{BSN} = 80) \end{aligned}$
1 – 0	FISU $(FIB + FSN = 80)$ $(BIB + BSN = 80)$	>		
		<	1 – 0	FISU (FIB + FSN = 80) (BIB + BSN = 80)
TEST	DESCRIPTION			
1.	Generate an MSU at B.			
2.	Check that A receives the MSU co	orrectly, and returns a positive acknowledge	ment.	
3.	Generate an MSU at A.	oneedy, and recurso a positive action in edge.		
4.	Check that B receives the MSU co	orrectly, and returns a positive acknowledge	ment.	

TEST NUMBER: 8.2			PAGE:	PAGE: 1 OF 1	
REFE	RENCE: Q.70	3 Subclause 5.3	STD: Fig. 13	,	
TITLE	E: Transmissio	n and reception cor	trol (Basic)		
SUB T	TITLE: Negati	ve acknowledgemen	nt of an MSU		
PURP	OSE: To test	the response to a ne	gatively acknowledged MSU		
PRE-T	EST CONDIT	IONS: Link in serv	ice		
CONF	IGURATION:	1		ТҮРЕ С	OF TEST: VAT
EXPE	CTED SIGNAI	UNIT SEQUENC	∃:	,	
	SP	В			SP A
Link				Link	
			<	1 – 0	FISU
1 – 0	FISU		>		
			<	1 – 0	MSU (FIB + FSN = 80)
			<	1 – 0	MSU (FIB + FSN = 81)
1 – 0	FISU (BIB +	BSN = 7F)	>		
	(313 .	201. 71)	<	1 – 0	MSU (FIB + FSN = 00)
			<	1 – 0	MSU (FIB + FSN = 01)
TEST	DESCRIPTION	N			
1.	Send MSU fro	om A.			
2.	Reply with ne	gative acknowledge	ement from B.		
3.	Check that A	retransmits the MS	U.		

TEST NUMBER: 8.3 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.3 STD: Fig. 13 TITLE: Transmission and reception control (Basic) SUB TITLE: Check RTB full PURPOSE: To check that MSUs are buffered when no acknowledgements are received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** FISU 1 - 0(BIB + BSN = FF)MSU 1 - 0(FIB + FSN = 80)1 - 0MSU (FIB + FSN = FE)(FIB + FSN = FE)1 - 0(BIB + BSN = 7F)1 - 0(FIB + FSN = 00)MSU 1 - 0(FIB + FSN = 7E)TEST DESCRIPTION Generate MSUs at A, at a rate of 100 per second, in order to fill the RTB before the EDA timer T7 expires. 1. No acknowledgements are sent from B until the last message is received, then send negative acknowledgement to the 2. first message received. 3. Check that the complete contents of the RTB are retransmitted.

TEST	NUMBER: 8.4		PAGE: 1 OF	7 1
REFEI	RENCE: Q.703 Subclause 5.2	STD: Fig. 14		
TITLE	E: Transmission and reception contro	l (Basic)		
SUB T	TTLE: Single MSU with erroneous F	TIB		
PURP	OSE: To ensure correct performance	when an MSU with erroneous FIB is reco	eived	
PRE-T	EST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF TH	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU $(BIB + BSN = 7F)$
1 – 0	FISU (FIB + FSN = 7F)	>		
1 – 0	MSU (FIB + FSN = 80)	>		
		<	1 – 0	FISU (BIB + BSN = 7F)
1 – 0	FISU (FIB + FSN = 00)	>		
1 – 0	FISU (FIB + FSN = 00)	>		
		<	1 – 0	FISU (BIB + BSN = FF)
1 – 0	MSU (FIB + FSN = 80)	>		
		<	1 – 0	FISU (BIB + BSN = 80)
TEST	DESCRIPTION			
1.	Generate an MSU at B with FIB invo	erted.		
2.	Check A discards the MSU.			
3.	Generate 2 FISUs at B with correct I	FIB.		
4.	Check A discards the FISU and nega	ative acknowledgement returned.		
5.	Check that B retransmits the MSU c	orrectly, and positive acknowledgement r	eturned.	

TEST	NUMBER: 8.5		PAGE: 1 O	PF 1
REFEI	RENCE: Q.703 Subclause 5.2	STD: Fig. 14		
TITLE	: Transmission and reception contro	ol (Basic)		
SUB T	TTLE: Duplicated FSN			
PURP	OSE: To test the reception control r	response to duplicated FSNs		
PRE-T	EST CONDITIONS: Link in service	e		
CONF	IGURATION: 1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU	>		
1 – 0	MSU $(FIB + FSN = 80)$	>		
		<	1 – 0	FISU (BIB + BSN = 80)
1 – 0	MSU $(FIB + FSN = 80)$	>		
1 – 0	FISU (FIB + FSN = 81)	>		
		<	1 – 0	FISU (BIB + BSN = 00)
1 – 0	MSU (FIB + FSN = 01)	>		
	(PB+131V = 01)	<	1 – 0	FISU (BIB + BSN = 01)
TEST	DESCRIPTION			
1.	Generate an MSU at B, check A rec	ceives the MSU correctly and returns a pos	itive acknowle	edgement.
2.	Duplicate the FSN at B, check that	A responds with a negative acknowledgen	nent.	
3.	Retransmit the MSU with correct F	SN, check that A replies with a positive ac	knowledgeme	nt.

TEST	NUMBER: 8.6		PAGE: 1 OF 1		
REFEI	RENCE: Q.703 Subclause 5.2	STD: Fig. 14			
TITLE	: Transmission and reception cont	rol (Basic)			
SUB T	ITLE: Erroneous retransmission –	Single MSU			
PURP	OSE: To test the reception control	response to retransmission of a single MSU	J		
PRE-T	EST CONDITIONS: Link in servi	ce			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE	:			
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (BIB + BSN = FF)	
1 – 0	FISU (FIB + FSN = FF)	>			
1 – 0	MSU (FIB + FSN = 00)	>			
1 – 0	FISU $(FIB + FSN = 80)$	>			
1 – 0	FISU $(FIB + FSN = 80)$	>			
		<	1 – 0	FISU $(BIB + BSN = 7F)$	
1 – 0	MSU (FIB + FSN = 00)	>			
		<	1 – 0	FISU (BIB + BSN = 00)	
TEST	DESCRIPTION				
1.	A single MSU with FIB inverted in	n error is sent to A, followed by FISUs with	correct FIBs		
2.	Check that A returns a negative ac	cknowledgement for the MSU.			
3.	Retransmit the MSU correctly.				
4.	Check that A receives the MSU co	prrectly and returns a positive acnowledgem	ent.		

TEST NUMBER: 8.7			PAGE: 1 OF 1			
REFE	RENCE: Q.703 Subclause 5.3 ST	D: Fig. 14				
TITLE	E: Transmission and reception control (I	Basic)				
SUB T	TTLE: Erroneous retransmission – Mul	tiple FISUs				
PURP	OSE: To test reception control response	e to retransmission of multiple FISUs				
PRE-T	EST CONDITIONS: Link in service					
CONF	IGURATION: 1		TYPE OF TE	ST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENCE:					
	SP B			SP A		
Link			Link			
		<>	1 – 0	FISU		
1 – 0	FISU $(FIB + FSN = FF)$					
1 – 0	FISU (FIB + FSN = 7F)	>				
1 – 0	FISU $(FIB + FSN = FF)$	>				
1 – 0	FISU $(FIB + FSN = 7F)$	>				
	(IID + I 514 = 71)	<	1 – 0	SIOS		
TEST	TEST DESCRIPTION					
1.	Generate FISUs with the FIB inverted	at B.				
2.	Check that A responds with link out of	service.				

TEST NUMBER: 8.8			PAGE: 1 OF 1		
REFERENC	CE: Q.703 Subclause 5.3	ГD: Fig. 14			
TITLE: Tra	ansmission and reception control ((Basic)			
SUB TITLE	: Single FISU with corrupt FIB				
PURPOSE:	To test the response to receive a	n FISU with a corrupt FIB			
PRE-TEST	CONDITIONS: Link in service				
CONFIGUR	ATION: 1		TYPE OF TE	ST: VAT	
EXPECTED	SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU	
1 – 0	FISU (FIB + FSN = FF)	>			
1 – 0	FISU (FIB + FSN = 7F)	>			
		<	1 – 0	FISU	
1 – 0	FISU	>			
	(FIB + FSN = FF)	<	1 – 0	FISU	
TEST DESC	CRIPTION				
1. Gen	erate one FISU with a corrupt FIE	at B, and check that the link status rem	nains in service.		

TEST	TEST NUMBER: 8,9			PAGE: 1 OF 1	
REFE	RENCE: Q.703 Subclause 5.2 S'	TD: Fig. 10, Fig. 14			
TITLE	: Transmission and reception control	(Basic)			
SUB T	TTLE: Single FISU prior to RPO being	g set			
PURP	OSE: To test the response to RPO wh	ile in the abnormal FIB state			
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1		TYPE OF TH	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU	
1 – 0	FISU	>			
1 – 0	FISU (one only) (FIB + FSN = 7F)	>			
1 – 0	SIPO	>			
1 – 0	MSU (FIB + FSN = 80)	>			
1 – 0	FISU $(FIB + FSN = 80)$	> a)			
1 – 0	FISU (FIB + FSN = 80)	>			
	(1111 + 1314 = 60)	<	1 – 0	FISU	
		>		(BIB + BSN = 7F)	
1 – 0	MSU $(FIB + FSN = 00)$				
		<	1 – 0	FISU $(BIB + BSN = 00)$	
a) RPO at A has recovered, but this FISU is discarded.					
	TEST DESCRIPTION				
1.	Generate one FISU at B with abnorma				
2.	Send SIPO from B, followed by an M				
3.	Check A responds correctly with nega	ative acknowledgement and a retransmiss	sion is received	correctly.	

TEST	NUMBER: 8.10		PAGE: 1 OF	1
REFE	RENCE: Q.703 Subclause 5.3	STD: Fig. 14		
TITLE	E: Transmission and reception control	(Basic)		
SUB T	TITLE: Abnormal BSN – single MSU	ſ		
PURP	OSE: To test the response to an abno	ormal BSN		
PRE-T	TEST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU
1 – 0	FISU $(FIB + FSN = FF)$ $(BIB + BSN = FF)$	>		
1 – 0	MSU (FIB + FSN = 80) (BIB + BSN = BF)	>		
1 – 0	FISU (FIB + FSN = 80) (BIB + BSN = FF)			
1 – 0	FISU (FIB + FSN = 80) (BIB + BSN = FF)	>		
		<	1 – 0	FISU (BIB + BSN = 7F)
1 – 0	MSU $(FIB + FSN = 00)$ $(BIB + BSN = FF)$	>		
	(=== : ===:	<	1 – 0	FISU (BIB + BSN = 00)
a) Th	nough UNB: = 1, abnormal BSNR is no	ot cancelled.		
TEST DESCRIPTION				
1.	Generate a single MSU with abnormal BSN at B, followed by FISUs with correct BSN.			
2.	Check that A responds with a negative	ve acknowledgement.		
3.	Retransmit the MSU correctly at B.			
4.	Check that the MSU is received corre	ectly and positive acknowledgement is gi	ven.	

TEST NU	TEST NUMBER: 8.11 PAGE: 1 OF 1					
REFERE	NCE: Q.703 Subclause 5.3	STD: Fig. 14				
TITLE:	Transmission and reception con	trol (Basic)				
SUB TIT	LE: Abnormal BSN – two cons	secutive FISUs				
PURPOS	E: To test the response to abno	ormal BSNs in two consecutive FISUs				
PRE-TES	ST CONDITIONS: Link in serv	ice				
CONFIG	URATION: 1		TYPE OF	ΓEST: VAT		
EXPECT	ED SIGNAL UNIT SEQUENCI	3:				
	SP B			SP A		
Link			Link			
		<	1 – 0	FISU		
1 – 0	FISU (BIB + BSN = FF)	>				
1 – 0	FISU (BIB + BSN = BF)	>				
1 – 0	FISU $(BIB + BSN = BF)$	>				
1 – 0	FISU (BIB + BSN = FF)	>				
	(=== : ==:,	<	1 – 0	SIOS		
TEST DE	TEST DESCRIPTION					
1. 0	Generate two consecutive FISUs	at B with abnormal BSNs.				
2.	Check that A responds by taking	the link out of service.				

TEST NUMBER: 8.12 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUB TITLE: Excessive delay of acknowledgement PURPOSE: To test the transmission control response to the expiration of EDA timer T7 PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0FISU FISU 1 - 0(BIB + BSN = FF)MSU 1 - 0(FIB + FSN = 80)1 - 0SIOS TEST DESCRIPTION Generate an MSU at A. 1. Discard the received MSU at B and send no acknowledgement to A for more than T7 period. 2. Check that the link is taken out of service by SIOS generated at A after T7 has expired. 3. 4. Timer T7 shall be in the range 0.5 secs to 2.0 secs.

REFERENCE: Q.703 Clause 7 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUB TITLE: Level 3 Stop command PURPOSE: To test the response to a Stop command PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT	TEST NUMBER: 8.13	PAGE: 1 OF 1		
SUB TITLE: Level 3 Stop command PURPOSE: To test the response to a Stop command PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT	REFERENCE: Q.703 Clause 7 STD: Fig. 14			
PURPOSE: To test the response to a Stop command PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT	TITLE: Transmission and reception control (Basic)			
PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT	SUB TITLE: Level 3 Stop command			
CONFIGURATION: 1 TYPE OF TEST: VAT	PURPOSE: To test the response to a Stop command			
	PRE-TEST CONDITIONS: Link in service			
	CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:	EXPECTED SIGNAL UNIT SEQUENCE:			
SP B SP A	SP B	SP A		
Link Link	Link	Link		
< 1 – 0 FISU	<	1-0 FISU		
1 – 0 FISU	1 – 0 FISU			
: stop		: stop		
< 1 – 0 SIOS	<	1-0 SIOS		
TEST DESCRIPTION				
1. Give Stop command at A.	1. Give Stop command at A.			
2. Check that A responds with link out of service.	2. Check that A responds with link out of service.			

TEST	ST NUMBER: 9.1 PAGE: 1 OF 1				
REFE	RENCE: Q.703 Subclause 6.2	STD: Fig. 15, Fig. 16			
TITLE	E: Transmission and reception cont	rol (PCR)			
SUB T	TITLE: MSU transmission and rece	eption			
PURP	OSE: To check basic MSU transm	ission and reception			
PRE-T	EST CONDITIONS: Link in servi	ce			
CONF	IGURATION: 1		TYPE OF	TEST: VAT, CPT	
EXPE	CTED SIGNAL UNIT SEQUENCE	:			
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (FSN = 7F, BSN = 7F)	
1 – 0	FISU (FSN = 7F, BSN = 7F)	>			
		<	1 – 0	MSU $(FSN = 0, BSN = 7F)$	
		<	1 – 0	MSU (FSN = 0, BSN = 7F)	
				•	
1 – 0	FISU $(FSN = 7F, BSN = 0)$	>			
		<	1 – 0	FISU $(FSN = 0, BSN = 7F)$	
1 – 0	MSU $(FSN = 0, BSN = 0)$	>			
		<	1 – 0	FISU $(FSN = 0, BSN = 0)$	
TEST	DESCRIPTION				
1.	Generate an MSU at A.				
2.	Check that B receives the MSU co	prrectly.			
3.	Check that A sends FISUs after re	ceiving an FISU with a positive ackn	nowledgement.		
4.	Generate an MSU at B.				
5.	Check that A receives the MSU co	orrectly and returns a positive acknow	vledgement.		

TEST	EST NUMBER: 9.2 PAGE: 1 OF 1			OF 1
REFEI	RENCE: Q.703 Subclause 6.3	STD: Fig. 15, Fig. 16		
TITLE	: Transmission and reception contro	l (PCR)		
SUB T	TTLE: Priority control			
PURP	OSE: To check the preventive retran	smission procedure		
PRE-T	EST CONDITIONS: Link in service			
CONF	IGURATION: 1		TYPE OF	ΓEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	FISU $(FSN = 7F, BSN = 7F)$
1 – 0	FISU	>		(-2: .:, -2: .:,
	(FSN = 7F, BSN = 7F)	<	1 - 0	MSU
		<	1 – 0	(FSN = 0, BSN = 7F) MSU
		\	1 – 0	(FSN = 1, BSN = 7F)
				•
		<	1 – 0	MSU (FSN = 2, BSN = 7F)
				•
		<	1 - 0	● MSU
		,	1 0	(FSN = 0, BSN = 7F)
		<	1 – 0	MSU $(FSN = 1, BSN = 7F)$
		<	1 – 0	MSU $(FSN = 2, BSN = 7F)$
				•
1 – 0	FISU	>		•
	(FSN = 7F, BSN = 0)			
1 – 0	FISU $(FSN = 7F, BSN = 1)$	>		
1 – 0	FISU (FEN. 7E DEN. 2)	>		
	(FSN = 7F, BSN = 2)	<	1 – 0	FISU
				(FSN = 2, BSN = 7F)
TEST DESCRIPTION				
1.	Generate two MSUs at A.			
2.	No positive acknowledgement is sen	t from B.		
3.	Check that MSUs are retransmitted	at A.		
4.	Generate another MSU at A.			
5.	Check that B receives MSUs correct	ly.		
6.	Reply with positive acknowledgeme	nt at B.		
7	Chack that A stone ratransmission at	ter receiving the positive acknow	uladgament for the last	MSII in DTR and cands FISII

TEST NUMBER: 9.3 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Forced retransmission with the value N₁ PURPOSE: To check that "RTB full" is detected by N₁ and forced retransmission occurs PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)MSU 1 - 0(FSN = 0, BSN = 7F)MSU 1 - 0(FSN = 7E, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)MSU 1 - 0(FSN = X, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 0)MSU (FSN = X + 1, BSN = 7F)1 - 0MSU (FSN = 7F, BSN = 7F)TEST DESCRIPTION 1. Generate 128 MSUs at A, at a rate of 100 per second, in order to fill the RTB before the EDA timer T7 expires. 2. No positive acknowledgement is sent from B until a forced retransmission starts at A. 3. Reply with a positive acknowledgement with BSN = 0 before T7 expires at A. 4. Check that the forced retransmission is cancelled after the transmission of the last MSU in RTB. $NOTE - N_1$ is the maximum number of MSUs which are available for retransmission. (The value of N_1 is normally 127).

TEST NUMBER: 9.4 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Forced retransmission with the value N₂ PURPOSE: To check that "RTB full" is detected by N2 and forced retransmission starts PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = 7F)MSU 1 - 0(FSN = 0, BSN = 7F)MSU 1 - 0(FSN = N - 1, BSN = 7F)1 - 0MSU(FSN = 0, BSN = 7F)1 - 0MSU (FSN = X, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = a - 1)1 - 0MSU (FSN = a, BSN = 7F)MSU 1 - 0(FSN = N, BSN = 7F)(a > X)TEST DESCRIPTION 1. Generate N + 1 MSUs at A (the octet count of N MSUs is larger than N_2). 2. Send no positive acknowledgement at B until a forced retransmission starts at A. 3. Check that B receives the MSUs with FSN = 0 up to FSN = N - 1 but does not receive the MSU with FSN = N. 4. Reply with a positive acknowledgement with BSN = a - 1 at B. 5. Check that the retransmission restarts from the next value of FSN which is acknowledged by B when the retransmission is interrupted. 6. Check that B receives the MSU with FSN = N. NOTE – N_2 is the maximum number of octets which are available for retransmission.

TEST NUMBER: 9.5 PAGE: 1 OF 1 STD: Fig. 15 REFERENCE: Q.703 Subclause 6.4 TITLE: Transmission and reception control (PCR) SUB TITLE: Forced retransmission cancel PURPOSE: To check that the forced retransmission is cancelled when BSN equal to FSNL is received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)• 1 - 0MSU (FSN = 7E, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)MSU 1 - 0(FSN = X, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7E)1 - 0MSU (FSN = 7F, BSN = 7F)TEST DESCRIPTION 1. Generate $N_1 + 1$ MSUs at A (e.g. 128). 2. Send no positive acknowledgement at B until a retransmission occurs at A. Reply with a positive acknowledgement with BSN = 7E at B. 3. 4. Check that a forced retransmission is cancelled and the MSU with FSN = 7F is sent at A. NOTES FSNL is the FSN of the last MSU in RTB. Alternatively, the number of octets threshold (N_2) , instead of the number of MSUs threshold (N_1) , could be used to start forced retransmission.

TEST	TEST NUMBER: 9.6			PAGE: 1 OF 1	
REFEI	RENCE: Q.703 Subclause 6.4 S	TD: Fig. 15			
TITLE	E: Transmission and reception control	(PCR)			
SUB T	TTLE: Repetition of forced retransmis	ssion			
PURP	OSE: To check that the forced retrans	mission repeats when "RTB full" is still	detected after f	inishing a forced	
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1		TYPE OF TE	ST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (FSN = 7F, BSN = 7F)	
1 - 0	FISU $(FSN = 7F, BSN = 7F)$	>			
	(13N = 71, B3N = 71)	<	1 – 0	MSU (FSN = 0, BSN = 7F)	
		<	1 – 0	• MSU (FSN = 7E, BSN = 7F)	
		<	1 – 0	MSU (FSN = 0, BSN = 7F)	
				•	
		<	1 – 0	MSU (FSN = 7E, BSN = 7F)	
		<	1 – 0	MSU (FSN = 0, BSN = 7F)	
				•	
TEST	DESCRIPTION				
1.	Generate MSUs at A at a rate of N pe	er second, in order to make A repeat a for	rced retransmiss	sion.	
	Generate MSUs at A at a rate of N per second, in order to make A repeat a forced retransmission. (N \geq 127 ÷ T, where T = lower limit of T7)				
2.	No acknowledgement is sent from B.				
3.					

TEST	PAGE: 1 OF 1				
REFEI	RENCE: Q.703 Subclause 6.2	STD: Fig. 15			
TITLE	: Transmission and reception contr	rol (PCR)			
SUB T	ITLE: MSU transmission while RF	PO set			
PURP	OSE: To ensure correct performand	ce while RPO is set			
PRE-T	EST CONDITIONS: Link in service	ee			
CONF	IGURATION: 1		TYPE OF T	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (ESN. 7E DEN. 7E)	
1 – 0	FISU	>		(FSN = 7F, BSN = 7F)	
	(FSN = 7F, BSN = 7F)	<	1 – 0	MSU	
		\	1 – 0	(FSN = 0, BSN = 7F)	
	: set LPO			: :	
1 – 0	SIPO	>			
	(FSN = 7F, BSN = 7F)	ζ	1 – 0	FISU	
	1 100			(FSN = 0, BSN = 7F)	
	: clear LPO			: :	
1 – 0	MSU $(FSN = 0, BSN = 7F)$	>			
	(1511 0, 2511 11)	<	1 – 0	FISU	
1 – 0	MSU	>		(FSN = 0, BSN = 0)	
1 0	(FSN = 0, BSN = 7F)				
		<	1 – 0	FISU $(FSN = 0, BSN = 0)$	
TEST	DESCRIPTION				
1.	Generate an MSU at A.				
2.	Instead of sending positive acknow	eledgement, set and keep PO at B.			
3.	Check A stops a retransmission of	the MSU and sends FISUs, and does not do	etect link failu	re by the expiration of T7.	
4.	Cease PO and send an MSU with n	no positive acknowledgement at B.			
5.	Check A flushed its buffer and no				
6.	Generate an MSU at B.				
		mands correctly			
7.	Check A receives the MSU and res	ponus correctiy.			

TEST NUMBER: 9.8	PAGE: 1 OF 1			
REFERENCE: Q.703 Subclause 6.3 STD: Fig. 16				
TITLE: Transmission and reception control (PCR)				
SUB TITLE: Abnormal BSN – Single MSU				
PURPOSE: To test the response to an abnormal BSN				
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B	SP A			
Link <	Link $1 - 0 FISU (FSN = 7F, BSN = 7F)$			
1 - 0 MSU				
<	1-0 FISU (FSN = 7F, BSN = 0)			
TEST DESCRIPTION				
 Generate a single MSU at B with abnormal BSN followed by retransmission of the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and not detect link for the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with a positive acknowledgement and the Check that A responds with the Check that A responds with the	Generate a single MSU at B with abnormal BSN followed by retransmission of that MSU with normal BSN.			
2. Check that A responds with a positive acknowledgement and not detect link i				

TEST	ST NUMBER: 9.9 PAGE: 1 OF 1			1	
REFEI	RENCE: Q.703 Subclause 6.3 ST	TD: Fig. 16			
TITLE	: Transmission and reception control (PCR)			
SUB T	TTLE: Abnormal BSN – Two MSUs				
PURP	OSE: To test the response to two conse	ecutive MSUs with an MSU having norn	nal BSN betwee	n them	
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1		TYPE OF TES	ST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (FSN = 7F, BSN = 7F)	
1 – 0	FISU $(FSN = 7F, BSN = 7F)$	>			
1 – 0	MSU $(FSN = 0, BSN = 7E)$	>			
1 – 0	MSU (FSN = 0, BSN = 7F)	>			
1 – 0	MSU	>			
	(FSN = 0, BSN = 7E)	<	1 – 0	SIOS	
				(FSN = 7F, BSN = 7F)	
TEST	DESCRIPTION				
1.	Generate two consecutive MSUs at B	with abnormal BSN with an MSU havin	g normal BSN b	between them.	
2.	Generate two consecutive MSUs at B with abnormal BSN with an MSU having normal BSN between them. Check that all MSUs are discarded at A.				
3.		Check that A responds by taking the link out of service.			
	1				

TEST NUMBER: 9.10	PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 6.2 STD: Fig. 16		
TITLE: Transmission and reception control (PCR)		
SUB TITLE: Unexpected FSN		
PURPOSE: To check the reception control response to an MSU with unexpected FS	SN	
PRE-TEST CONDITIONS: Link in service		
CONFIGURATION: 1	TYPE OF TEST: VAT	
EXPECTED SIGNAL UNIT SEQUENCE:		
SP B	SP A	
Link	Link	
<	$ \begin{array}{ccc} 1 - 0 & \text{FISU} \\ (\text{FSN} = 7\text{F, BSN} = 7\text{F}) \end{array} $	
1 – 0 FISU		
1 – 0 MSU		
1 – 0 MSU>		
(FSN = 2, BSN = 7F)	1 – 0 FISU	
	(FSN = 7F, BSN = 0)	
TEST DESCRIPTION	-	
Generate an MSU with unexpected FSN at B.		
2. Check A discards the MSU with unexpected FSN and not sends acknowledge	ement for that MSU.	

TEST NUMBER: 9.11			PAGE: 1	PAGE: 1 OF 1	
REFI	ERENCE: Q.703 Subclause 6.3	STD: Fig. 15	<u>'</u>		
TITL	E: Transmission and reception contro	ol (PCR)			
SUB	TITLE: Excessive delay of acknowled	dgement			
PURI	POSE: To test the transmission control	ol response to the expiration of EDA tin	ner T7		
PRE-	TEST CONDITIONS: Link in service)			
CON	FIGURATION: 1		TYPE OF	TEST: VAT	
EXPI	ECTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1 – 0	FISU	>		(FSN = 7F, BSN = 7F)	
1 – 0	(FSN = 7F, BSN = 7F)				
		<	1 – 0	MSU $(FSN = 0, BSN = 7F)$	
				T7 •	
		<	1 – 0	SIOS (FSN = 0, BSN = 7F)	
TEST	DESCRIPTION				
1.	Generate an MSU at A.				
2.	Suspend sending positive acknowled	dgement at B for more than T7 period.			
3.	Check that A sends SIOSs instead of retransmission of MSU after T7 expires.				
4.	Timer T7 shall be in the range 0.5 se	ecs to 2.0 secs.			

TEST	PAGE: 1 OF 1				
REFEI	RENCE: Q.703 Subclause 6.2 STD: Fig. 16				
TITLE	E: Transmission and reception control (PCR)				
SUB T	TTLE: FISU with FSN expected for MSU				
PURP	OSE: To check that the received FISU having FSN expected for MSU is discar	rded			
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1	TYPE OF TE	ST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B		SP A		
Link		Link			
1 – 0	FISU> (FSN = 7F, BSN = 7F)				
	ζ	1 – 0	FISU (FSN = 7F, BSN = 7F)		
1 – 0	FISU> (FSN = 0, BSN = 7F)		,		
	<	1 – 0	FISU (FSN = 7F, BSN = 7F)		
TEST	DESCRIPTION				
1.	Generate an FISU with FSN expected for MSU at B.				
2.	Check that A discards the FISU and responds with an FISU with correct BSN				

TEST NUMBER: 9.13	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 16			
TITLE: Transmission and reception control (PCR)			
SUB TITLE: Level 3 Stop command			
PURPOSE: To test the response to a Stop command			
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B	SP A		
Link	Link		
<	1 – 0 FISU		
1 – 0 FISU			
	: stop		
<	1 – 0 SIOS		
TEST DESCRIPTION			
1. Give Stop command at A.			
2. Check that A responds with link out of service.			

TEST	NUMBER: 10.1		PAGE: 1 O	F 1				
REFE	RENCE: Q.703 Clause 9 STD: Fig. 19							
TITLE: Congestion Control								
SUB TITLE: Congestion abatement								
PURPOSE: To check the congestion abatement procedure								
PRE-TEST CONDITIONS: Link in service								
CONFIGURATION: 1				TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:								
	SP B			SP A				
Link			Link					
				: make congestion state				
	<		1 – 0	SIB				
			Т5					
	<		1 – 0	SIB •				
				: clear congestion				
				state				
	<		1 – 0	FISU				
TEST DESCRIPTION								
1.	Make congestion state at A and check A sends SIB. (Implementation of congestion control is not specified.)							
2.	Check B receives SIBs at the interval of T5.							
3.	Clear congestion state at A and check A stops sending SI	Bs.						
4.	Timer T5 shall be in the range 80 ms to 120 ms.							

TEST	TEST NUMBER: 10.2				PAGE: 1 OF 1		
REFERENCE: Q.703 Subclause 9.2 STD: Fig. 19							
TITLE: Congestion Control							
SUB TITLE: Timer T7							
PURPOSE: To check timer T7 is restarted at the reception of SIB (without expiring of T6)							
PRE-TEST CONDITIONS: Link in service							
CONFIGURATION: 1			TYPE OF TEST: VAT				
EXPE	CTED SIGNAL UNIT S	SEQUENCE:					
	SP B				SP A		
Link				Link			
			<	1 – 0	MSU		
1 - 0	SIB	Ct	>				
1 – 0	SIB •	Ct	>				
	•						
1 – 0	SIB	Bt	>		T6		
1 0	ETG. I						
1 – 0	FISU		>				
TEST DESCRIPTION							
1.	Generate an MSU at A.						
2.	Generate SIBs at B with the time intervals of T5 for Ct, instead of positive acknowledgement.						
3.	Check that link remains in service during Ct.						
4.	Send FISU with positive acknowledgement from B after Bt expires.						
5.	Check that link remains in service.						
6.	Ct = more than T7 and less than T6.						
7.	Bt = less than T7.						
8.	(Ct + Bt) is less than T	Г6.					

TEST NUMBER: 10.3	PAGE: 1 OF 1							
REFERENCE: Q.703 Subclause 9.3 STD: Fig. 19								
TITLE: Congestion Control								
SUB TITLE: Timer T6								
PURPOSE: To check "Remote Congestion" Timer T6								
PRE-TEST CONDITIONS: Link in service								
CONFIGURATION: 1	TYPE OF TEST: VAT							
EXPECTED SIGNAL UNIT SEQUENCE:								
SP B		SP A						
Link	Link							
1 - 0 SIB								
1 – 0 SIB								
1 – 0 SIB>		T6						
1 – 0 SIB								
<	1 – 0	SIOS						
	1 0	5105						
TEST DESCRIPTION								
1. Generate SIB at B until Timer T6 expires.	Generate SIB at B until Timer T6 expires.							
2. Check link becomes out of service.	Check link becomes out of service.							
3. Timer T6 shall be in the range 3 secs to 6 secs (8 to 12 secs for 4.8 kbit/s).	Timer T6 shall be in the range 3 secs to 6 secs (8 to 12 secs for 4.8 kbit/s).							