

Sheet1

- *---A macro to measure range width (before printing for example)
- *---Use the /Range Name Label Down <ENTER> to define the \Z macro name
- *---Use the /Range Name Label Right {End} {Down} <ENTER> to define the range names in this column (starts with RANGWIDE)
- *---Hold the <MACRO> key and press <Z> to activate the macro

!

!

!

!

\Z

RANGWIDE

!

!

!

!

!

!

sum031

!

!

counter031

!

message031

!

total031

!

key031

```
{BREAKON}
{windowsoff}{paneloff}/rncMeasure range ?~/rndmeasure range ?~/rnc{panelon}Measure range ?~{windowson}{?}~
{windowsoff}{paneloff}{goto}measure range ?~
{let total031,0}~
{for counter031,1,@cols(measure range ?),1,sum031}
{let message031,+"The range width is "&@string(total031,0)&" characters long, Press <ESC> to Quit. "}~{panelon}{message031}
/RNDMeasure range ?~

{let total031,total031+@cellpointer("width")}~
{right}
```

The range width is 68 characters long, Press <ESC> to Quit.

```
{ESC}
```