
# **T Series Electrical Testers**

## Now you can get more from a tester





resolution • Displays resistance to 1000 ohms • Easy and accurate Open Jaw™ current measurement

Continuity beeper

breaking the circuit.

• Compact design with neat probe storage

Fluke T5-600 and T5-1000

and Current Testers

Voltage, Continuity/resistance

Fluke T5 electrical testers let you check

voltage, continuity and current with one compact tool. With the T5, all you have

to do is select volts, ohms, or current and

the tester does the rest. Tough test leads stow neatly in the back of the tester,

making it easy to tote the T5 in your tool pouch. The optional H5 holster keeps

the test probes and leads ready to test,

and lets you clip the T5 onto your belt.

Automatically measures Volts AC and

Open Jaw™ current lets you check

current up to 100 amps - without

Volts DC with precise digital

- Rugged enough to withstand a 3 meter (10-foot) drop
- Detachable Slim-Reach™ probe tips are customized for national electrical standards
- Test leads accept Fluke accessory test clips
- Available in 600 Volt and 1000 Volt models
- Can stay connected much longer than solenoid type testers
- Auto off mode to conserve battery life
- Optional holster attaches to a tool belt and neatly stows test leads

## Fluke T2 Voltage and Continuity Tester

The Fluke T2 is a voltage and continuity tester that's designed to work long and hard. There are no settings - just probe the circuit and the T2 will show you whether you're looking at AC volts, DC volts, or an open circuit. You don't even have to turn it on or off! With seven different voltage indicators, it can clearly differentiate between key voltage levels.

FLUKE

- LEDs clearly indicate 7 AC and 7 DC nominal voltage levels
- Indicates DC voltages as low as 6 Volts
- DC polarity indicator
- Compact and rugged fits in a tool pouch or overall pocket
- Automatically selects continuity beeper or voltage measurement
- Can stay connected much longer than solenoid type testers
- Rugged enough to withstand a 3 meter (10-foot) drop
- Protected to 1000 Volts for use in CAT III environments
- Automatically activates and shuts down to conserve battery power
- Heavy-duty test leads for long life

#### Safety Conformance

All inputs of the T2 are protected to IEC 1010-1 category III 1000V rating. All inputs of the T5-600 are protected to IEC 1010-1 CAT III 600V and the T5-1000 to IEC 1010-1 1000V CAT III rating.









## **T2 Voltage Levels**

World-Wide Version		<b>US Version</b>		<b>Canada Version</b>	
Vac	Vdc	Vac	Vdc	Vac	Vdc
12	6	24	6	24	6
24	12	120	12	120	12
48	24	208	24	208	24
110	36	240	36	240	36
230	48	277	48	347	48
400	110	480	110	480	110
690	220	600	220	600	220

## Accessories and Ordering Information

## **Included** Accessories

The T5-1000 and T5-600 come with 4 mm detachable probes and instruction sheet The T2 comes with 4 mm probes and instruction sheet

## Optional Accessories for T5-1000 & T5-600

H5 Custom Holster AC85A Large Jaw Alligator Clips AC20 Industrial Clips

#### **Ordering Information**

T5-1000 1000V Voltage, Continuity and Current Tester T5-600 600V Voltage, Continuity and Current Tester T2 Voltage, Continuity Tester

#### **Fluke Corporation**

P.O. Box 9090 Everett, WA USA 98206

**Fluke Europe B.V.** P.O. Box 1186 5602 BD Eindhoven The Netherlands

For more information call: In the U.S.A. (800) 443-5853 or Fax (425) 356-5116 In Europe/M-East +31 (0)40 2 678 202 or Fax +31 (0)40 2 678 222 In Canada (905) 890-7600 or Fax (905) 890-6866 From other countries +1(425) 356-5500 or Fax +1(425) 356-5116 Web access: http://www.fluke.com

© 1997 Fluke Corporation. All rights reserved. Printed in the Netherlands 12/97 C0168 EEN Rev A

Fluke. Keeping your world up and running.