

---

## ADDENDUM PERIPHERAL EXPANSION SYSTEM ON/OFF SWITCH AND FUSE HOLDER

---

The ON/OFF switch at the lower-left-hand corner of the front of the Peripheral Expansion System has been changed. A rocker-style switch is now used. When the switch is turned off, a small white circle is visible at the top tab of the switch. To turn the switch on, push the top tab of the switch in so that the white circle is no longer visible. To turn the switch off, push the bottom tab in so that the white circle is visible again.

The fuse holder on the back of the Peripheral Expansion System has also been changed. Thus the instructions beginning at step 3 under "Changing the Fuse" on page 6 of your owner's manual should read as follows:

3. Notice that the fuse holder, made of black molded plastic and located just to the left of the power cord connector, looks like a small square with a number at each side of the square. These numbers correspond with the voltage of the wall outlet you are using. (Standard U.S.A. outlets are 115-120 volts). A pointer at the top of the square points to the top number, which must match the voltage of the wall outlet that you are using.

Insert the tip of small standard screwdriver or pocket knife blade into the small notch at the right side of the square. Pry the square back and the fuse will come out of the unit.

4. Next, insert the new fuse. **IMPORTANT:** Make certain that the pointer points to the number which matches the voltage of the wall outlet that you are using. Then push the fuse holder back into the peripheral system.
5. Plug the Peripheral Expansion System cord back into the wall outlet. Turn on the Peripheral Expansion System, monitor, and console.