



# Index



# Index

## A

Adapter Data Space 3-21, 3-22  
 allocate 3-21, 5-6  
 Adapter Option Structure 5-4, 7-31, 7-33,  
 F-31, F-32, F-33, I-7  
 Address conversion  
 LogicalToPhysical 4-3, 4-10  
 PhysicalToLogical 3-16, 4-3, 4-10  
 Assembling 1-7, 2-6, A-2  
 case sensitivity 1-4, 6-2, A-2, C-7

## B

Board service routine 2-3, 5-6, 5-8, 5-16,  
 5-22, 7-13, 8-31, 8-41, E-6, E-10,  
 E-14, E-15  
 Busmaster 2-5, 3-6, 3-7, 4-10, 4-23, 4-24,  
 4-25, 4-26, 4-28, 5-7, 5-13, 5-24,  
 5-26, 6-5, 6-6, 6-10, 7-7, 7-43, 7-44,  
 F-23, F-40, F-41

## C

canonical 3-11, 3-17, 4-9, 4-28, A-8, C-26,  
 C-27, G-2, G-3, G-4, G-5  
 Channel 2-10, 3-10, 3-12, 3-16, 5-5, 5-6,  
 7-31, 7-32, 7-41, A-8, F-34, F-42,  
 I-6  
 Configuration Table 2-4, 3-4, 3-5, 3-9,  
 3-10, 6-12, F-34, I-5, I-6  
 MLIDFlags 3-14, 3-18  
 MLIDModeFlags 3-17  
 MLIDSharingFlags 3-14, 3-15, 3-19  
 Control Procedures 2-4, 5-2, 5-29  
 Custom Keywords 1-8, 3-37, 3-38, 7-26,  
 7-30, A-6

## D

Debugging 1-7, A-4, B-2, B-4, B-12, B-14  
 Direction flag 2-6, F-48  
 DMA 2-5, 3-7, 3-15, 3-17, 3-19, 5-4, 5-5,  
 5-13, 5-24, 7-7, 7-31, 7-33, A-7,  
 C-28, C-29, C-30, C-42, E-9, F-23,  
 F-29, F-41, H-3, H-4  
 Driver Adapter Data Space 3-21, 3-22  
 Driver Configuration File 1-8, 3-37, A-6  
 Driver Configuration Table 2-4, 3-9, 3-10,  
 6-12, F-34  
 Driver Firmware 3-5, 3-35, 6-12

Driver Frame Data Space 3-9  
 Driver Keywords 1-8, 3-5, 3-6, 3-37, 3-38,  
 7-26, 7-30, A-6  
 Driver Parameter Block 2-4, 3-2, 3-3, 3-4,  
 3-5, 3-6, 3-7, 3-8, 3-10, 3-35, 3-36,  
 3-37, 3-38, 3-41, 4-8, 4-26, 5-2, 5-3,  
 5-5, 5-8, 5-19, 5-22, 5-26, 5-29,  
 5-33, 5-35, 5-37, 5-38, 5-42, 6-3,  
 6-12, 6-13, 6-15, 7-5, 7-6, 7-7, 7-10,  
 7-24, 7-26, 7-28, 7-29, 8-31, 8-42,  
 A-8, H-3, I-5, I-8  
 Driver Statistics Table 2-4, 3-21

## Driver Procedures

DriverAESCallback 2-2, 2-4, 2-7, 3-7,  
 5-2, 5-7, 5-9, 5-40, 5-41, 7-48, 7-49  
 DriverDisableInterrupt 2-2, 2-3, 3-4,  
 3-8, 5-2, 5-16, 5-20, 5-27, 5-28,  
 7-14, I-5, I-16, I-21  
 DriverEnableInterrupt 2-2, 2-3, 3-4,  
 3-8, 5-2, 5-16, 5-20, 5-21, 5-27,  
 5-28, 7-9, 7-12, 7-14, I-5, I-16, I-19,  
 I-21  
 DriverInit 2-2, 2-3, 2-6, 2-7, 3-3, 3-5,  
 3-9, 3-11, 3-12, 3-13, 3-14, 3-16,  
 3-21, 3-35, 3-36, 3-37, 4-7, 5-2, 5-3,  
 5-4, 5-5, 5-6, 5-7, 5-8, 5-9, 5-13,  
 5-23, 5-24, 5-31, 6-7, 6-9, 6-12,  
 7-13, 7-24, 7-25, 7-26, 7-29, 7-33,  
 7-38, 7-39, 7-41, 7-42, 7-43, 7-45,  
 7-48, 7-49, 7-52, 7-55, 8-31, 8-41,  
 A-3, A-4, I-8, I-10  
 DriverINTCallback 2-2, 2-4, 2-7, 3-4,  
 3-7, 5-2, 5-7, 5-9, 5-31, 5-40, 5-41,  
 7-18, 7-48, 7-49, I-5, I-10, I-12,  
 I-14, I-15  
 DriverISR 2-2, 2-3, 2-6, 2-7, 3-4, 3-7,  
 4-5, 4-6, 4-7, 4-8, 4-10, 5-2, 5-6,  
 5-11, 5-13, 5-14, 5-16, 5-18, 5-20,  
 5-21, 5-22, 5-23, 5-24, 5-25, 5-26,  
 5-31, 6-3, 6-7, 6-9, 6-13, 7-9, 7-11,  
 7-14, 7-15, 7-50, 7-51, 7-53, 8-31,  
 8-41, F-17, I-5, I-13, I-16, I-19  
 DriverManagement 2-2, 2-4, 2-7, 3-8,  
 5-2, 5-29, 5-39, 8-31, 8-36, 8-41,  
 8-42, 8-43  
 DriverMulticastChange 2-2, 2-4, 2-7,  
 2-11, 3-4, 3-7, 3-18, 5-2, 5-29, 5-33,  
 5-34, 6-15, I-5, I-22, I-23  
 DriverPoll 2-2, 2-3, 2-7, 3-7, 5-2, 5-6,

- 5-16, 5-22, 7-13, 8-31, 8-41
  - DriverPromiscuousChange 2-2, 2-4, 2-7, 2-11, 3-4, 3-8, 5-2, 5-29, 5-35, 6-4, 6-6, 6-8, I-5, I-24
  - DriverRemove 2-2, 2-3, 2-6, 2-7, 3-5, 5-2, 5-42, 7-10, A-3, A-4, E-16, I-27
  - DriverReset 2-2, 2-4, 2-7, 3-4, 3-7, 3-25, 4-9, 5-2, 5-6, 5-9, 5-29, 5-31, 5-32, 6-15, 7-45, I-5, I-10, I-15, I-25
  - DriverRxLookAheadChange 2-2, 2-4, 2-7, 3-8, 3-13, 4-8, 5-2, 5-29, 5-38
  - DriverSend 2-2, 2-3, 2-6, 2-7, 3-4, 3-6, 3-8, 4-5, 4-7, 4-10, 4-26, 5-2, 5-17, 5-21, 5-23, 5-24, 5-26, 5-41, 6-3, 6-8, 6-11, 6-13, 6-14, 6-20, 7-9, 7-14, 7-15, 7-53, 8-31, 8-42, E-6, E-12, E-14, I-5, I-12, I-13, I-15, I-16, I-19
  - DriverShutdown 2-2, 2-4, 2-7, 3-4, 3-8, 5-2, 5-29, 5-31, 5-32, 5-42, 7-10, 7-16, 7-17, I-5, I-26
  - DriverStatisticsChange 2-2, 2-4, 2-7, 3-8, 5-2, 5-29, 5-37
  - DriverTxTimeout 3-8, 5-2, 5-7, 5-40
- E**
- ECB aware 3-6, 4-23, 4-24, 4-25, 4-26, 4-28, 5-13, 5-24, 5-26, 6-6, 6-10, 7-7
  - Event Control Blocks (ECBs) 4-3, 4-11, 8-12
- F**
- File
    - Driver Configuration 1-8, 3-37, A-6
    - Include 1-7, A-2
    - Installation Information 1-8, C-3, C-7, C-11
    - Linker Definition 1-6, 1-7, 2-10, 3-2, 3-12, 3-14, 3-35, 4-10, 5-3, 5-42, 6-12, A-2, A-3, A-6, B-14
    - Source 1-7, A-2
  - Firmware 2-3, 3-5, 3-35, 3-36, 5-3, 5-13, 6-12, A-4, F-38, F-39, H-3, H-4
  - Fragment 2-3, 3-7, 3-33, 4-5, 4-12, 4-13, 4-14, 4-16, 4-17, 4-18, 4-19, 4-20, 4-22, 4-24, 4-29, 5-11, 5-14, 5-21, 5-23, 5-26, 6-4, 6-5, 6-16, 6-17, 6-18, 8-18, D-14, D-15, D-16, D-17, D-18, D-19, D-20, D-21, I-12, I-17, I-18
  - Frame Data Space 3-9
    - allocate 3-9, 6-12
  - Frame Type
    - 802.2 Type I and Type II 3-20, 4-27, 4-28, D-4, D-5, D-8, D-10, D-12
    - default D-5
    - Ethernet 802.2 3-20, 4-4, D-5, D-6
    - Ethernet 802.3 3-20, 4-4, 5-24, D-5
    - Ethernet II 3-20, 4-4, 5-24, C-6, C-27, C-42, D-3, D-5, D-7, E-9
    - Ethernet SNAP 3-20, 4-4, D-5, D-6, D-7
    - FDDI 802.2 3-20, 4-4, D-5, D-10
    - FDDI SNAP 3-20, 4-4, D-5, D-11
    - PCN2 802.2 3-20, 4-4, D-5, D-12
    - PCN2 SNAP 3-20, 4-4, D-5, D-13
    - RX-Net exception packet 4-21, D-14, D-18, D-19
    - RX-Net long packet 4-21, D-14, D-16, D-18
    - RX-Net short packet 4-21, D-14, D-15
    - Token-Ring 802.2 3-20, D-5, D-8
    - Token-Ring SNAP 3-20, D-5, D-9
  - Functional Address 3-18, 5-34, 8-12
- H**
- HSM (Hardware Specific Module) 1-5, 2-1, 3-2, 5-2
    - coding issues 2-6
    - hardware issues 2-5
  - Hub management 2-2, 2-4, 2-11, 3-18, 5-29, 5-39, 8-3, 8-6, 8-7, 8-8, 8-30, 8-33, 8-34, 8-36, 8-38, 8-41, 8-42
    - command ECB 5-39, 8-6, 8-31, 8-33, 8-34, 8-35, 8-36, 8-42
    - command processing 8-33, 8-34, 8-36
    - Group Information Table 8-23, 8-26, 8-28, 8-29
    - Hub Information Table 8-15, 8-21, 8-23, 8-24, 8-25, 8-26, 8-27, 8-38, 8-41
    - Network Management Protocol Agent 8-6, 8-7
    - notification ECB 7-46, 8-8, 8-30, 8-38, 8-39, 8-40
    - notification processing 8-37, 8-40
    - object identifiers 8-14, 8-15, 8-21, 8-35
    - objects 8-7, 8-8, 8-9, 8-10, 8-14, 8-15, 8-19, 8-21, 8-23, 8-26, 8-27, 8-32, 8-33, 8-34, 8-35, 8-44
  - Hub Management NLM 8-6, 8-7, 8-8, 8-30, 8-33, 8-34, 8-36

**I**

Include Files 1-7, A-2  
 Initialization (*see DriverInit*)  
 Install Information File 1-8, C-1  
     Dependency Expressions C-12, C-16,  
     C-17, C-18, C-22, C-25, C-32, C-33,  
     C-34  
     Language Translation C-5, C-9, C-23  
 Intelligent adapters 2-4, 3-19, 3-35, 4-8,  
     4-23, 5-13, 5-29, 5-37, 5-38  
 Interrupt  
     disabling 2-2, 2-3, 3-4, 3-8, 5-2, 5-16,  
     5-20, 5-27, 5-28, 7-14, I-5, I-16, I-21  
     enabling 2-2, 2-3, 3-4, 3-8, 5-2, 5-16,  
     5-20, 5-21, 5-27, 5-28, 7-9, 7-12,  
     7-14, 7-15, I-5, I-16, I-19, I-21

**K**

Keyword, custom 1-8, 3-37, 3-38, 7-26,  
     7-30, A-6

**L**

Linking 1-6, 1-7, 1-8, 2-10, 3-2, 3-12, 3-14,  
     3-35, 4-10, 5-3, 5-42, 6-12, A-2, A-3,  
     A-4, A-5, A-6, B-14, F-38  
     Linker Definition File 1-6, 1-7, 2-10,  
     3-2, 3-12, 3-14, 3-35, 4-10, 5-3,  
     5-42, 6-12, A-2, A-3, A-6, B-14  
     NLMLINK A-2, A-5  
 Loading 1-6, 1-7, 1-8, 2-10, 5-13, 8-32, 9-2,  
     9-15, 9-17, A-2, A-6  
     configuration file 1-8, 3-37, A-6  
     custom keywords 3-5, 3-6, 3-37, 7-30  
     standard keywords A-7  
 Logical boards 2-8, 2-10, 3-11, 3-12, 4-24,  
     4-27, 5-5, 5-7, 8-34, 8-40, D-14, E-5,  
     E-11, E-16, F-31, F-42  
 LogicalToPhysical 4-3, 4-10  
 LookAhead 2-4, 4-8, 5-11, 5-14, 5-15, 5-20,  
     5-29, 5-38, 6-4, 6-5, 6-10, 6-11,  
     6-16, 6-17, I-17  
     DriverRxLookAheadChange 2-2, 2-4,  
     2-7, 3-8, 3-13, 4-8, 5-2, 5-29, 5-38  
     size 3-10, 3-13, 4-3, 4-8, 5-11, 5-20,  
     5-35, 5-38, 6-4, 6-5, 6-10, 6-11,  
     6-16, I-6, I-17  
 LSL (Link Support Layer)  
     general 1-2, 2-5, 3-11, 4-12, 4-14, 4-16,  
     4-17, 5-3, 5-7, 5-10, 6-6, 6-10, 6-13,  
     7-2, 7-43, E-2  
     LSLAddProtocolID E-3, E-4

LSLDeRegisterMLID E-5, E-16  
 LSLFastRcvEvent E-6, E-10, E-15  
 LSLFastSendComplete E-7, E-14, E-15  
 LSLGetMaximumPacketSize E-8, E-9  
 LSLGetSizedRcvECBRTag E-9, E-10  
 LSLHoldRcvEvent E-6, E-10, E-15  
 LSLRegisterMLIDRTag E-11, E-12  
 LSLReturnRcvECB E-13  
 LSLSendComplete E-7, E-14, E-15  
 LSLServiceEvents E-6, E-7, E-10,  
     E-14, E-15, F-17  
 LSLUnBindThenDeRegisterMLID E-5,  
     E-16

**M**

managed objects 8-8, 8-9, 8-14, 8-15, 8-21,  
     8-23, 8-44  
 Maximum Packet Size 3-12, 3-19, 3-20,  
     3-38, 5-4, 6-6, 6-8, 6-12, 7-7, 7-8,  
     7-44, E-8, E-11  
 Media header 2-3, 3-13, 4-8, 4-18, 4-19,  
     4-20, 4-26, 4-27, 4-29, 5-23, 5-26,  
     6-7, 7-8, G-5, I-12  
 Media Support Module (MSM)  
     data structures 4-10  
     equates 4-4  
     procedures 7-1  
     variables 4-9  
 Memory  
     allocate 2-3, 2-7, 3-7, 7-5, 7-6, 7-24,  
     7-25, 8-41, F-4, F-5, F-7, F-39, H-3,  
     H-8  
 MLIDFlags Bit Map 3-18  
 MLIDModeFlags Bit Map 3-17  
 MLIDSharingFlags Bit Map 3-19  
 MSM (Media Support Module)  
     general 1-4  
     AdapterOptionDefinitionStructure 5-4,  
     7-31, 7-33, F-31, F-32, F-33, I-7  
     MSMAlertFatal 7-3, A-3  
     MSMAlertWarning 7-4, I-14  
     MSMAlloc 5-32, 7-5, 7-16, A-3  
     MSMAllocateRCB 4-12, 4-16, 4-25,  
     5-11, 5-13, 6-4, 6-5, 6-6, 6-7, 6-9,  
     7-7, 7-8, 7-44, 7-46, 8-38, 8-39  
     MSMAllocPages 7-6, 7-17  
     MSMDisableHardwareInterrupt 7-9  
     MSMDoEndOfInterrupt 7-11  
     MSMDriverRemove 3-5, 5-42, 7-10,  
     A-3, I-27  
     MSMEnableHardwareInterrupt 7-12  
     MSMEnablePolling 3-7, 5-6, 5-8, 5-22,  
     7-13

- MSMEndCriticalSection 7-14
  - MSMFree 5-32, 7-5, 7-16, 7-24, 7-25, A-3, I-26
  - MSMFreePages 7-6, 7-17, I-26
  - MSMGetCriticalStatus 7-18
  - MSMGetCurrentTime 7-19
  - MSMGetHardwareBusType 7-20
  - MSMGetProcessorSpeedRating 7-21
  - MSMGetRealModeWorkspace 7-22
  - MSMInitAlloc 7-24, 7-25
  - MSMInitFree 7-24, 7-25
  - MSMMaxFrameHeaderSize 3-13, 4-3, 4-8, 5-11, 5-20, 5-35, 5-38, 6-4, 6-5, 6-10, 6-11, 6-16, I-17
  - MSMParseCustomKeywords 5-5, 7-26, 7-27, 7-29
  - MSMParseDriverParameters 2-10, 3-9, 3-37, 3-39, 5-4, 5-5, 5-8, 7-26, 7-29, 7-30, 7-33, 7-42, A-3, A-7, I-7, I-8
  - MSMPhysNodeAddress 3-11, 3-17, 4-3, 4-9, 4-28, G-3, G-4
  - MSMPrintString 5-4, 5-6, 5-9, 6-12, 7-13, 7-30, 7-34, 7-41, 7-42, 7-43, 7-45, 7-48, 7-49, 7-52, A-3, I-10
  - MSMPrintStringFatal 7-35
  - MSMPrintStringWarning 7-36
  - MSMPSemaphore 7-37
  - MSMReadEISAConfig 5-5, 5-8, 7-38
  - MSMReadPhysicalMemory 3-16, 5-5, 7-39, 7-55
  - MSMRealModeInterrupt 7-40
  - MSMRegisterHardwareOptions 3-6, 3-7, 3-8, 3-9, 3-12, 3-13, 3-21, 5-5, 5-6, 5-7, 5-8, 7-24, 7-25, 7-29, 7-30, 7-33, 7-39, 7-41, 7-42, 7-52, 7-55, A-3, I-8
  - MSMRegisterMLID 3-11, 3-12, 3-19, 4-9, 5-7, 5-9, 7-43, A-3, I-10
  - MSMRescheduleLast 7-44
  - MSMReturnDriverResources 5-7, 5-9, 5-32, 7-45, A-3, I-10
  - MSMReturnRCB 7-47
  - MSMScheduleAESCallback 5-7, 5-9, 5-41, 7-48, 7-49
  - MSMScheduleIntTimeCallback 3-7, 5-7, 5-9, 5-41, 7-49, A-3, I-10
  - MSMServiceEvents 7-50
  - MSMServiceEventsAndRet 7-51
  - MSMSetHardwareInterrupt 5-6, 5-8, 7-52, A-3, I-8
  - MSMStartCriticalSection 7-53
  - MSMStatusFlags 4-3, 4-5, 5-17, 5-21, I-15, I-19
  - MSMTxFreeCount 4-3, 4-5, 4-7, 5-6, 5-9, 5-17, 5-18, 5-21, 5-23, 5-24, 5-25, 5-26, 5-31, 5-41, 6-3, H-3, I-10, I-15, I-19
  - MSMVirtualBoardLink 3-9, 4-3, 4-4
  - MSMVSemaphore 7-54
  - MSMWritePhysicalMemory 5-5, 7-39, 7-55
  - Multicast Address 3-18, 5-29, 5-33, 5-34, 6-15, H-3, I-22
  - DriverMaxMulticast 3-4, 3-6, 5-33, 6-15, I-5
  - Multichannel Adapters 2-10, 3-10, 3-12, 3-16, 5-5, 5-6, 7-31, 7-32, 7-41, A-8, F-34, F-42, I-6
  - Multiple Frame Support 1-4, 2-8, 6-2
  - Multiple Link Interface Driver (MLID) 1-3, 1-4, 8-3
  - NetWare Loadable Module (NLM) 1-3, 1-7, A-2
- N**
- Node Address 3-11, 3-17, 3-29, 4-9, 4-28, 5-9, 7-55, 9-14, 9-16, A-8, C-28, C-29, C-30, G-2, G-3, G-4, H-3, H-4, H-7, H-8, H-9
  - canonical 3-11, 3-17, 4-9, 4-28, A-8, C-26, C-27, G-2, G-3, G-4, G-5
  - LSB load keyword 4-28, 8-27, A-8, C-25, C-27, C-37, G-2, G-3, G-4
  - MLIDNodeAddress 3-10, 3-11, 3-17, 4-9, 7-55, G-2, G-3, G-4, I-6
  - MSB load keyword 4-28, A-8, C-25, C-27, G-2, G-3, G-4
  - MSMPhysNodeAddress 3-11, 3-17, 4-3, 4-9, 4-28, G-3, G-4
  - non-canonical 3-11, 3-17, 4-9, 4-28, A-8, C-27, G-2, G-3, G-4, G-5
  - override 3-11, 5-9, A-8, G-4, H-3, H-8
- O**
- Object Identifiers 8-14, 8-15, 8-21, 8-35
  - Address Tracking Objects 8-27
  - Basic Control Objects 8-26, 8-32
  - Open Data-Link Interface (ODI) 1-2
  - OS Support Procedures
  - AddPollingProcedureRtag F-3
  - Alloc F-4, F-5, F-7, F-22, F-39, H-4
  - AllocateMappedPages F-5, F-15
  - AllocateResourceTag F-6
  - AllocBufferBelow16Meg F-7, F-23
  - CancelInterruptTimeCallback F-8
  - CancelNoSleepAESProcessEvent F-9

- CancelSleepAESProcessEvent F-10  
 ClearHardwareInterrupt F-11  
 CPSEmaphore F-12, F-14, F-27, F-28  
 CRscheduleLast F-13  
 CVSEmaphore F-14, F-27, F-28  
 DeAllocateMappedPages F-5, F-15  
 DeRegisterHardwareOptions F-16  
 DisableHardwareInterrupt F-17, F-18, F-21  
 DoEndOfInterrupt F-17, F-18  
 DoRealModeInterrupt F-19, F-20, F-27, F-28  
 EnableHardwareInterrupt F-17, F-21  
 Free 3-33, 4-5, 4-7, 6-3, 7-25, F-15, F-22, H-8, I-15, I-19  
 FreeBufferBelow16Meg F-23  
 GetCurrentTime 7-21, 8-29, F-24  
 GetHardwareBusType F-25  
 GetProcessorSpeedRating F-26  
 GetRealModeWorkSpace F-27, F-28  
 GetServerPhysicalOffset F-29  
 OutputToScreen F-30  
 ParseDriverParameters F-31, F-32, F-34  
 QueueSystemAlert F-35, F-36  
 ReadEISAConfig F-37  
 ReadRoutine F-38  
 RegisterForEventNotification F-40, F-41, F-50  
 RegisterHardwareOptions F-32, F-42  
 RemovePollingProcedure F-43  
 ScheduleInterruptTimeCallBack F-8, F-44, F-45  
 ScheduleNoSleepAESProcessEvent F-9, F-46, F-47  
 ScheduleSleepAESProcessEvent F-10, F-47  
 SetHardwareInterrupt F-11, F-48, F-49  
 UnRegisterEventNotification F-40, F-50
- P**
- PhysicalToLogical 3-16, 4-3, 4-10  
 programmed I/O 2-5, 5-11, 5-14, 5-24, 6-4, 6-16  
 Promiscuous mode 1-5, 2-4, 2-11, 3-8, 3-17, 5-29, 5-35, 5-36, I-24  
 Protocol ID 4-24, 4-25, 4-26, 4-27, 5-39, 8-12, 8-31, 8-33, 8-34, 8-36, 8-38, 8-39, 8-40, 8-42, 8-43, D-3, D-4, E-3, E-4, E-6, E-10, H-3, H-8
- R**
- RCB (Receive Control Block) 3-7, 3-17, 3-23, 4-11, 5-10, 5-11, 5-13, 5-14, 5-21, 5-32, 6-4, 6-5, 6-6, 6-7, 6-8, 6-9, 6-10, 6-11, 6-16, 6-17, 6-18, 6-19, 6-20, 7-7, 7-8, 7-44, 7-47, D-14, H-4, I-17, I-18, I-26  
     fragmented 4-12, 6-4, 6-6, 6-8  
     non-fragmented 4-11, 4-14, 6-6, 6-8  
 Reception 4-12, 5-10, 5-16  
 Reentrancy 2-8, 2-10, 8-36, A-3, A-4  
 Reset 1-5, 2-4, 3-18, 3-25, 5-21, 5-29, 5-31, 5-32, 5-41, 7-34, 8-8, 8-15, 8-18, 8-21, 8-30, 8-36, 8-38, F-45, F-46, H-3, H-5, H-6, H-9, I-7, I-14, I-15, I-22, I-25  
 Returning resources I-10  
 RXNetTSMFastRcvEvent 6-8, 6-20  
 RXNetTSMGetRCB 5-14, 6-4, 6-16, 6-17, 6-18, 6-19, 6-20  
 RXNetTSMRcvEvent 5-14, 6-6, 6-19, 6-20
- S**
- shared interrupts 3-6, 5-6, 5-18, 5-19, 7-50, F-49  
 shared RAM 2-5, 3-16, 4-10, 5-4, 5-5, 5-11, 5-14, 5-24, 6-5, 6-19, 7-39, 7-55, A-7, H-3, H-5, H-6  
 Shutdown (*see DriverShutdown*)  
 Source Files 1-7, A-2  
 Source routing 2-11, 3-13, 3-20, 9-2, 9-3, 9-4, 9-5, 9-8, 9-13, 9-15, 9-16, 9-17, G-5  
     loading ROUTE.NLM 9-15  
 Statistics Table 2-4, 3-21  
     media specific counters 3-21, 3-25, 3-27  
         Ethernet 3-30  
         FDDI 3-31  
         RX-Net 3-33  
         PCN2 3-34  
         Token-Ring 3-27
- T**
- TCB (Transmit Control Block) 3-6, 3-7, 3-17, 4-16, 5-17, 5-23, 5-24, 5-26, 5-32, 5-41, 6-3, 6-13, 6-14, 7-9, 7-14, 7-15, 7-53, G-5, I-12, I-13, I-19, I-26  
     fragment structure 4-18, 4-19, 4-22, 5-26, 6-4, 6-16, I-12, I-17

Timeout Detection 1-5, 2-2, 2-3, 2-4, 4-7,  
5-2, 5-7, 5-9, 5-40, 5-41, 7-19, C-3,  
C-11, C-15, C-41, F-24, I-3, I-10,  
I-12, I-13  
DriverAESCallback 2-2, 2-4, 2-7, 3-7,  
5-2, 5-7, 5-9, 5-40, 5-41, 7-48, 7-49  
DriverINTCallback 2-2, 2-4, 2-7, 3-4,  
3-7, 5-2, 5-7, 5-9, 5-31, 5-40, 5-41,  
7-18, 7-48, 7-49, I-5, I-10, I-12,  
I-14, I-15  
DriverTxTimeout (RX-Net) 3-8, 5-2,  
5-7, 5-40  
Transmission 4-11, 5-23  
TSM (Topology Specific Module)  
  general 1-4, 6-2  
  <TSM>FastProcessGetRCB 4-12, 6-8,  
  6-9, 7-7, 7-50, 7-51  
  <TSM>FastRcvComplete 4-25, 6-5,  
  6-6, 6-11, 6-17, 7-7, 7-50, 7-51  
  <TSM>FastSendComplete 5-24, 5-25,  
  5-26, 6-13, 6-14, 7-9, 7-15, 7-50,  
  7-51  
  <TSM>GetNextSend 4-5, 4-7, 5-17,  
  5-21, 5-41, 6-3  
  <TSM>GetRCB 4-8, 4-12, 5-11, 5-21,  
  5-35, 5-38, 6-4, 6-5, 6-10, 6-11  
  <TSM>ProcessGetRCB 4-12, 5-11,  
  5-13, 5-35, 6-4, 6-6, 6-7, 6-8, 7-7,  
  7-47, 7-50, 7-51  
  <TSM>RcvComplete 4-25, 5-12, 5-13,  
  5-21, 5-35, 6-5, 6-6, 6-10, 6-11,  
  6-17, 6-19, 7-7, 7-47, 7-50, 7-51  
  <TSM>RegisterHSM 3-3, 3-5, 3-6, 3-7,  
  3-9, 3-11, 3-12, 3-14, 3-19, 3-35,  
  3-36, 5-3, 5-4, 5-8, 6-12, 7-29, 7-34,  
  7-35, 7-36, 7-45  
  <TSM>SendComplete 4-10, 5-17, 5-24,  
  5-25, 5-26, 6-13, 6-14, 7-9, 7-15,  
  7-50, 7-51, I-26  
  <TSM>UpdateMulticast 5-31, 6-15  
  RXNetTSMFastRcvEvent 6-8, 6-20  
  RXNetTSMGetRCB 5-14, 6-4, 6-16,  
  6-17, 6-18, 6-19, 6-20  
  RXNetTSMRcvEvent 5-14, 6-6, 6-19,  
  6-20

## U

Unload (*see also DriverRemove*) 2-3, 5-42,  
9-5, 9-7, 9-17, A-4, A-5, F-11, H-8,  
I-27