



Printer Supplies for the Apple ColorLaserWriter

Color LaserWriter supplies

Printer Models

Apple Color LaserWriter 12/600 PS

Supplies

Color LaserWriter Toner Cartridge, Cyan
Color LaserWriter Toner Cartridge, Magenta
Color LaserWriter Toner Cartridge, Yellow
Color LaserWriter Toner Cartridge, Black
Color LaserWriter Photoconductor Replacement Kit
Color LaserWriter Fuser Oil
Color LaserWriter Fuser Replacement Kit

Reorder No.

M3757G/A
M3760G/A
M3758G/A
M3756G/A
M3761G/A
M3755G/A
M3867G/A

Color LaserWriter media

Printer Models

Apple Color LaserWriter 12/600 PS

Media

Color LaserWriter Transparencies, LTR, 50 pk.
Color LaserWriter Transparencies, A4, 50 pk.

Reorder No.

M3876G/A
M3877G/A

Toner cartridges for

Apple Printer Models

LaserWriter IISC, IINT, IINTX, IIf, and IIg
LaserWriter and LaserWriter Plus
Personal LaserWriter LS, SC, NT, and NTR
Personal LaserWriter 300, 320 and LaserWriter 4/600 PS
LaserWriter Select 300, 310, and 360
LaserWriter Pro 600, 630, and LaserWriter 16/600 PS
LaserWriter Pro 810, Extended-Capacity Cartridge Kit

Page/Yield @ 5%

4,000
4,000
3,000
3,000
4,000
6,000
13,000

Reorder No.

M6002 or M2795G/A
M0180
M0089LL/A
M2045G/A
M1960G/A
M2473G/A
M3602G/A

Canon Printer Models

LBP-SX, LBP-200V, LBP-8 II, LBP-8 II R, and LBP-8 II T
LBP-8 III, LBP-8 III R, LBP-8 III T, LBP-RX, and LBP-TX
LBP-CX, LBP-8 A1, LBP-8 A2, and LBP-8 D A1
LBP-LX, LBP-4, LBP-4+, LBP-4 III+, and P 110
LBP-EX, LBP-8 IV, and P 270

Toner Cartridge

EP-S
EP-S
EP
EP-L
EP-X

Compatible Apple Toner Cartridge

M6002 or M2795G/A
M6002 or M2795G/A
M0180
M0089LL/A
M2473G/A

Hewlett-Packard Printer Models

LaserJet II, IID, III, and IIID
LaserJet, LaserJet Plus, and LaserJet 500 Plus
1686 TA, 2686 LaserJet, and 2686TA LaserJet
33471 A, LaserJet IIP, IIP Plus, IIIP, and III P/MAC
LaserJet 4L and LaserJet 4ML 92274A M2045G/A
LaserJet 4, LaserJet 4M, 4M Plus, and 4 Plus

Toner Cartridge

92295A
92285A
92285A
92275A
92298A

Compatible Apple Toner Cartridge

M6002 or M2795G/A
M0180
M0180
M0089LL/A
M2473G/A

Product specifications are subject to change.

Check with your Apple reseller for the most current information about product specifications and configurations.

Apple Computer, Inc.
1 Infinite Loop
Cupertino, CA 95014
(408) 996-1010
TLX 171-576

© 1995 Apple Computer, Inc. All rights reserved. Apple, the Apple logo, and LaserWriter are trademarks of Apple Computer, Inc., registered in the U.S.A. and other countries. Mention of non-Apple products or services is for informational purposes only and constitutes neither an endorsement nor a recommendation. Apple assumes no responsibility with regard to the selection, performance, or use of these products. All understandings, agreements, and warranties, if any, take place directly between the vendors and the prospective users.
June 1995. Product specifications are subject to change without notice. Printed in the United States of America.
L01398A



Printer Supplies for the Apple Color LaserWriter

Congratulations on your investment in an Apple Color LaserWriter 12/600 PS. To achieve the best results with this high-quality printer, Apple recommends that you use only Apple replacement toner cartridges as well as photo-conductor and fuser supplies.

Apple also offers Color LaserWriter Transparencies designed specifically for creating photographic-quality overheads for your presentations.

Toner cartridges

Apple Color LaserWriter 12/600 PS

Toner Cartridges

These replacement toner cartridges are designed to print on plain paper as well as Apple Color LaserWriter Transparencies. And they'll save you money because you need to replace only the cartridge that's run out. Each cartridge prints up to 4,000 pages at 5 percent coverage.

- Cyan Toner Cartridge
Reorder No. M3757G/A
- Magenta Toner Cartridge
Reorder No. M3760G/A
- Yellow Toner Cartridge
Reorder No. M3758G/A
- Black Toner Cartridge
Reorder No. M3756G/A

Printable media

Color LaserWriter Transparencies

Now your Color LaserWriter can help you prepare your presentations. With this transparency film, you can use your Color LaserWriter to turn out brilliantly colored overhead presentation transparencies.

- Letter-Size Color LaserWriter Transparencies
Reorder No. M3876G/A
- A4-Size Color LaserWriter Transparencies
Reorder No. M3877G/A

Preventive maintenance supplies

Your Color LaserWriter was designed to be easy to use and maintain. To keep it in top condition, Apple recommends that you replace the photoconductor after 40,000 continuous or 10,000 intermittent black-and-white pages, or after 13,000 continuous or 6,500 intermittent color pages.

Your printer's fuser oil should be replenished after each 10,000 pages, and the Fuser Replacement Kit—including air filter, ozone filter, and fuser unit transfer drum cleaning unit—should be installed after 60,000 pages.

- Photoconductor Replacement Kit
Reorder No. M3761G/A
- Fuser Oil
Reorder No. M3755G/A
- Fuser Replacement Kit
Reorder No. M3867G/A