

Intel EtherExpress PRO/10+ PCI LAN Adapter

874264_PixelRule.tiff ↗

94627_network.tiff ↗ Network Devices

This PCI bus device driver is designed to run on an Intel-based computer running OPENSTEP for Mach Release 4.1.

Supported Hardware

- Intel EtherExpress PRO/10+ PCI (PILA8500) (AUI, BNC, RJ-45)
- Intel EtherExpress PRO/10+ PCI (PILA8520) (RJ-45)

This driver supports the Intel EtherExpress PRO/10+ PCI LAN Adapter which is based on the Intel 82557 LAN co-processor. The driver is capable of automatically determining the correct network connector in use.

Installing the Adaptor

- Install the adapter in the system. Refer to the Intel EtherExpress PRO/10+ Adapter Installation Guide for complete information.

Configuration

- Log in as root and run Configure to add the adapter to the system.
- Click on the Network Devices icon at the top of Configure's "Summary of Devices" window. In the Add Network Devices panel that opens, select the radio button labeled "Show Drivers for Detected Devices" if it is not already highlighted.
- Select "Intel EtherExpress PRO/10+ PCI LAN Adapter" from the list, and click Add.
- Click Done, then click Save, then quit Configure.

See also

- "Add a Device" in Configure's on-line help.
- See NeXTanswer 1824 for general information on installing and configuring device drivers.