

WaveLAN AT/MC Adapters

Use this dialog box to configure settings for the WaveLAN ISA and MCA adapters.

When using the WaveLAN ISA adapter, the setting selected in the setup dialog box must match the value selected in the SETCONF.EXE configuration program. You must also run the SETCONF.EXE and complete the card configuration.

When using the WaveLAN MCA adapter, the slot number selected in the setup dialog box must match the actual hardware setting.

Base I/O Address (for ISA adapter only)

It defines the I/O base address that the adapter will use.

0x300, 0x390, 0x3C0, 0x3E0 The driver will set the I/O address to the assigned value.

Slot Number (for micro channel adapter only)

It defines the micro channel slot in which the adapter was installed.

