

# Guide to 'Overnight Test' Errors

f

## I. OS ERRORS

2

2 OS Errors are Macintosh Operating System Result Codes. The complete list can be found in Inside Macintosh Vol. V pp. 597-591. Errors 2 through 10 are SCSI Manager Errors. They are taken from Inside Macintosh vols. IV and V and are listed here as follows

- 2 Communications error (no device connected or improper termination of bus);
- 3 Arbitration failed during SCSIGet; bus busy or hung;
- 4 Bad parameter in Command Descriptor Block or Transfer Instruction Block opcode;
- 5 SCSI bus not in correct phase for attempted operation;
- 6 Data comparison error during read;
- 7 SCSI Manager busy with another operation when SCSIGet was called;
- 8 Attempted operation is performed out of sequence;
- 9 Bus timeout before data ready on SCSI Blind transfers (the drive and computer may not support blind data transfers);
- 10 SCSIComplete failed;

### Summary of OS Errors

The most common OS Errors are 2 and 10. They are often an indication of defective cabling, improperly configured termination, or bad power supply in an external hard drive. Do not try and reassign a block based upon an OS Error.

## II. SENSE KEY ERRORS

2

- 20 No Sense (Command successfully executed.)
- 1 Recovered Error (Drive experienced errors but still completed command.)
- 2 Not Ready (Drive is either not spinning or not spinning at operational speed.)
- 3 Medium Error (Probable bad block on drive.)
- 4. Hardware Error (Drive is experiencing problems with its own hardware; bad block is only a remotely possible cause.)
- 5. Illegal Request (Drive received and instruction it either does not recognize or cannot execute. You should never get this on the Overnight

test)

6. Unit Attention (Drive has just been powered on, experienced a reset, or a 45 Removable has just changed cartridges.)
7. Data Protect (Most likely you have inserted a locked 45RM cartridge.)

#### ADDITIONAL SENSE DATA

The only Additional Sense Data which you may need to know are those two which correspond to a Sense Key 3 error (bad media). Those two are Additional Sense 17 for an error which occurred while the drive was attempting to read data from the media, and Additional Sense 12 for an error which occurred while the drive was attempting to write data to the media.

#### Summary of Sense Key Errors

If you get an error with Sense Key = 3 and an Additional Sense = 12 or 17, then you may wish to use the "Reassign Block" feature. Please read the online help entry for the "Reassign Block" before using it!