

DASYLab 2 Data-Acquisition and Analysis

Demonstration Disk - without Interface to AD-Boards

This Demo-Software does not require any data-acquisition-hardware. Analog and digital inputs are simulated by software-generated sine and square waves with various frequencies and amplitudes. It's only purpose is to demonstrate the great functionality of **DASYLab**.

How to install the *DASYLab* Demo

Required hardware: AT-compatible PC with at least 2 MByte RAM,
Intel 80486 or better CPU.
Harddisk with 3 MByte of free disk space
Mouse.

Required software: MS-DOS or PC-DOS version 3.3 or higher
Microsoft Windows 3.1.
DASYLab runs under the graphical user interface Windows 3.1
If You do not have a Windows license, please feel free to order a runtime
version for this demonstration

Installation: To install the **DASYLab** Demo under Windows 3.1 execute the following steps :

- ☐ insert the demo disk into your floppy drive
- ☐ start Windows and execute the install .exe file using the capabilities of the program manager
- ☐ **DASYLab** will be installed
- ☐ Windows creates the subdirectory "DLABDEMO" , which contains all files, necessary to run the demo version. If you don't need them anymore you can easily remove the whole directory. Moreover the installation program creates a new program group
- ☐ To start **DASYLab** just double click the **DASYLab** ICON

DEMO-setups Using the FILE and OPEN commands you can load the Demo-setups, which are included in this demo-package. Furthermore you can start and modify them. Every setup is shortly explained. You can read the information about the setup using the information button in the control bar

Help Use the integrated help system to get information about all Icons and modules.

P.S.: Please feel free to copy this disk and give it to colleagues and friends, which might also be interested.