

## Driver Definitions

**Note:** Drivers are specialized programs designed to act as an interface between the computer and a particular device

[Text] = Item only exists under given circumstance

- Driver# = Reference number of the driver
  - ◊ Name = Driver name, always preceded by a period
  - ◊ Version = Version of driver ['vers' Resource]
  - ◊ Unit# = Position which the device occupies in the unit table
  - ◊ SCSI# = Number of SCSI device [SCSI Driver]
  - ◊ Type = Type of driver [Type Known]
  - ◊ Status = Open/Closed
  - ◊ Nubus/PDS Slot# = Slot Number [SCSI Slot Card]
  - ◊ Nubus/PDS sResource# = sResource Number [SCSI Slot Card]
  - ◊ Nubus/PDS Device# = Device Number [SCSI Slot Card]
  - ◊ Location = ROM/RAM
  - ◊ Address = Hex address of driver
  - ◊ Original Flags Enabled = Flags which were active when the driver was loaded. These flags provide information about how the operating system should interact with the driver
  - ◊ Current Flags Enabled = Flags which are currently active