


## UPDATING THE FIRMWARE FOR THE DD0201/DD0401 DRIVE IN WINDOWS

The instructions below is an example of how to update the firmware using the DD0401 drive.

1. Go to [http://www.optorite.com/english/web/2\\_service/2\\_firmwares.php](http://www.optorite.com/english/web/2_service/2_firmwares.php) download the firmware files. You will need to scroll down the page to SECTION B: Windows.
2. Download the executable firmware program file.
3. Run the program. It should open as follows:



4. Verify that the correct drive (ID String) is selected. If it is not, then select the drive from the drop down menu. Also verify that the firmware versions are correct.
5. Click "OK". You should see blue bars run across the "Send data to device" and the "verify data".
6. After this, the "Flashing" blue bars should appear. When the drive has finish flashing, a message should appear to restart the computer.