

Q: What are the frontporch (fp) and the backporch (bp) shown in disktab?

A: The front and back porches are for "non-file-system stuff." The front porch has:

- the disk label
- two copies of the boot program

The backporch is currently unused by the SCSI hard disk driver.

QA435

Valid for 1.0, 2.0, 3.0, 3.1