

**PITTSBURGH PAINTS**A new generation of paint company  
for a new generation.**SPEEDHIDE®****6-162****HPC/Industrial Maintenance****SPEEDHIDE® Interior Dry-Fog Spray Paint Semi-Gloss****Generic Type**

Alkyd Resin

**Tinting and Base Information**

Use PITTSBURGH Paints Custom Colorants and refer to THE VOICE OF COLOR electronic CD or formula book for tinting instructions.

6-162

White

**General Description**

This product is an economical alkyd dry fog coating suitable for spray applications on interior surfaces. Ideally suited for the refinishing of large industrial or commercial ceiling or wall areas by spray painting techniques. This product produces a minimum amount of overspray which may be wiped or swept away with a dry cloth or brush.

**Recommended Uses**

Beams  
Corrugated Metal  
Trusses  
Ceilings  
Girders

**Features / Benefits**

Dry fall overspray allows for minimal masking and preparation.  
Dry fall in 7-10 feet at 70°F at 50% relative humidity.

**Limitations of Use**

Apply when air, surface and product temperatures are above 50 deg F (10 deg C). Intended for interior spray application only. Dry fogging properties are affected by color selection, product and application temperature, humidity and degree of air movement. Test free fall drying distance (dry fogging distance) before proceeding. Swept up dry overspray may ignite spontaneously. Wet and dispose of all collected dry overspray immediately. Sweep up dry overspray before rolling scaffold or allowing foot traffic into area. Some types of machinery and equipment may still require protection against possible damage to working parts such as bearings. Not recommended for use on floors, machinery, or in direct contact with corrosive chemicals. All oil based alkyd products change color with age. The yellow discoloration is most visible in white and light colors. PITTSBURGH Paints latex products are recommended when yellowing is a concern.

**Product Data**

**Gloss:** Semi-Gloss: 15 to 25 (60°Gloss Meter)  
**VOC\*:** 3.31 lbs/gal 396.00 g/L  
**Coverage:** 225 to 323 sq ft/gal (21 to 30 sq. m/3.78L)  
*Note: Does not include loss due to varying application method, surface porosity, or mixing.*  
**DFT:** 2.3 minimum to 3.4 maximum  
**Weight/Gallon\*:** 10.8 lbs. (4.9 kg) +/- 0.2 lbs. (91 g)  
**Volume Solids\*:** 47.7% +/- 2%  
**Weight Solids\*:** 69.6% +/- 2%  
**Clean-up:** VM & P Naphtha

Results will vary by color, thinning and other additives.

\*Product data calculated on 6-162.

**Drying Time:**

To Touch: 15 minutes  
To Handle: 2 hours  
To Recoat: 18 hours

Dry Time @77°F (25°C); 50% relative humidity

**Flash Point:** 43°F, (6°C)

## HPC/Industrial Maintenance

## SPEEDHIDE® Interior Dry-Fog Spray Paint Semi-Gloss

## General Surface Preparation

Surface must be clean, dry, and free from dirt, grease, powdery or peeling paint, and other surface contaminants. All cracks and other surface imperfections must be repaired using high quality patching compounds, then allowed to dry thoroughly. Repaired areas should be sanded smooth and then spot-primed. Slick or glossy surfaces of previously applied paint, in sound condition, must be dulled by sanding. Prime all bare wood, plaster, masonry, metal, patched and porous surfaces with the appropriate primer. If unsure of the suitability of the substrate for painting, first spot that product to check for adhesion performance.

**NEW WOOD:** New wood should be sanded smooth and wiped clean. Any knots or resinous areas should be sealed before painting.

Countersink all nails. Putty flush with surface, then prime.

**NEW PLASTER:** Fresh plaster, hardcoat, skim coat, or other alkaline surfaces should be allowed to cure for at least 30 days prior to priming with an alkali resistant primer.

**CONCRETE BLOCK, CINDER BLOCK, VERTICAL MASONRY:** New concrete should cure for at least 30 days and preferably 90 days prior to priming. Fill block with an appropriate block filler. Surfaces previously coated with water thinned cement-base paint must be prepared with extra care. Such coatings must be completely removed for best results. If the coatings appear to be adhering tightly, a masonry sealer may be applied to seal the surface prior to topcoating. One way to check adhesion is by applying a piece of masking tape. If it peels off easily and has loose particles adhering to it, remove all the chalking or crumbling material before repainting.

**METAL:** Rust and other surface contaminants must be removed from ferrous metals, aluminum, copper, brass, and galvanized steel. Then the surface cleaned thoroughly to remove any dust.

**GALVANIZED STEEL:** Caution must be used when selecting coatings for use on all galvanized metal surfaces. These substrates may have a factory-applied stabilizer, which is used to prevent white rusting during storage and shipping. Such stabilizers must be removed by either brush blasting or chemical treatment.

## Recommended Primers

Wood	17-21, 6-6, 6-855
Galvanized Steel	6-209, 90-712
Ferrous Metal	6-208, 6-212, 90-712
Aluminum	6-204, 90-712
Gypsum Wallboard-Drywall	17-21, 6-2
Plaster	6-603
Brass	6-204, 90-712
Copper	6-204, 90-712
Concrete Masonry Units, Masonry (Block Fillers)	6-12, 6-7
Concrete, Masonry (Primers, Sealers)	6-603, 6-808

## Directions for Use

Mix thoroughly before using. **FREE FALL:** 7 to 10 ft. (2.1 - 3.0 m). Dry fog paint dries at varying distances from the area being sprayed, dependent upon the color selection, degree of air movement, temperature, and humidity conditions. At higher relative humidities, it will dry more slowly. Test free falling drying distance before proceeding. Read all label and Material Safety Data Sheet (MSDS) information prior to use. MSDS are available through our website or by calling 1-800-441-9695.

## Permissible temperatures during application:

Material:	50 to 90°F	10 to 32°C
Ambient:	50 to 100°F	10 to 38°C
Substrate:	50 to 100°F	10 to 38°C

PPGAF believes the technical data presented in this bulletin is currently accurate; however, no guarantee of accuracy, comprehensiveness, or performance is given or implied. Improvements in coatings technology may cause future technical data to vary from what is in this bulletin. For complete, up-to-date information visit our web site or call 1-800-441-9695

## Application Information

## Recommended Spread Rates:

Wet Mils :	4.9	minimum to	7.1	maximum
Wet Microns:	124.5	minimum to	180.0	maximum
Dry Mils :	2.3	minimum to	3.0	maximum
Dry Microns:	58.4	minimum to	86.4	maximum

**Application Equipment:** Changes in application equipment, pressures and/or tip sizes may be required depending on ambient temperatures and application conditions.

**Conventional Spray:** Not recommended

**Airless Spray:** Pressure 1500-3000 psi, tip 0.017"-0.019"

**Brush:** Not Recommended

**Roller:** Not Recommended.

## Thinning:

DO NOT THIN.

## Packaging: 5-Gallon (18.9L)

Not all products are available in all sizes.



**PITTSBURGH® PAINTS**  
A new generation of paint company  
for a new generation.

PPG Architectural Finishes, Inc.  
One PPG Place  
Pittsburgh, PA 15272

www.pittsburghpaints.com

Technical Services:  
1-800-441-9695  
Architect/Specifier:  
1-888-774-7732  
International Sales:  
(412) 434-2049

PPG Coatings, Inc.  
Coatings and Resins Group  
5546 Timberlea Blvd.  
Mississauga, Ontario L4W2T7  
(905) 238-6441