

Changes the sharpness of the image. Higher values sharpen images and lower values smooth them.

Changes the brightness of the image. Higher values brighten images and lower values darken them.


Increases or decreases the size of the image, or a selected area.

Increases the speed of the scanner head. Use this option when previewing images to cut down on scan time.

Returns all of the slider bars to their original positions of 128.

Sets all of the slider bars to their last stored positions. The positions of the slider bars are stored each time you exit from Corel TWAIN.

Making image adjustments



Adjusting images

The Adjust page lets you modify the sharpness, and brightness of the scanned image. Changes to these settings affect both the final scan and preview image.

You can adjust any of the sliders on the page, or choose Default to restore the sliders to their default values. Restore resets all the slider bars to their last stored positions. The positions of the slider bars are stored each time you exit from Corel TWAIN.



Adjusting sharpness and brightness

The Sharpness slider bar lets you define the amount of sharpening applied to the image during a scan. The Brightness slider bar allows you lighten or darken an image.

To adjust sharpness

1. Choose the Adjust page.
2. Set the Sharpness slider to the desired value.



Tip

- To see the result of your changes, click Prescan.

To adjust brightness

1. Choose the Adjust page.
2. Set the Brightness and slider to the desired values.



Tip

- To see the result of your changes, click Prescan.

{button ,AL("PRC Making image adjustments;",0,"Defaultoverview",)} [Related Topics](#)



Adjusting image size

The Zoom slider lets you increase or decrease the size of the scanned image. Follow this procedure to increase or reduce the size of the scanned image.

To adjust the image size


1. Choose the Adjust page.
2. Adjust the Zoom slider to set the desired image size. Zoom is measured as a percentage of the original image. For example, to increase the size of the image set the slider to a value greater than 100.



Tip

- To increase the size of an area of the image, select the area using the selection box in the preview window.

{button ,AL('PRC Making image adjustments;',0,"Defaultoverview",)} [Related Topics](#)



Increasing scanning speed

Follow this procedure to increase the scanning of the preview image.

To increase the scanning speed

1. Choose the Adjust page.
2. Enable the High speed scanning option.

{button ,AL('PRC Making image adjustments;',0,"Defaultoverview",)} [Related Topics](#)

