

PCL 5 Printer Driver Help Index

Use the scroll bar to see index entries not visible in the Help window describing this driver.

If you would like to print this or any other help topic, choose Print Topic from the "File" title bar above.

Help Topics

[Cartridges](#)

[Compatible Fonts and Typefaces](#)

[Copies](#)

[Defining Printer Memory](#)

[Fonts Button](#)

[Graphics Resolution](#)

[Gray Scale Settings](#)

[Ordering Accessories for HP LaserJet Printers](#)

[Orientation](#)

[Page Protection](#)

[Paper Source and Paper Sizes](#)

[Selecting a Printer Model](#)

[Special Options -- Duplex Printing](#)

Copyright © 1991 by Hewlett-Packard Company

Compatible Fonts and Typefaces

The basic HP Font Installer allows you to install the following:

- * Bitmapped printer fonts -- cartridge or disk-based (soft)
- * Scalable printer fonts -- through AutoFont Support utilities
- * Printer Cartridge Metric (.PCM) files

If you have *HP Intellifont-for-Windows 3.0*, you can also use the HP Font Installer to install:

- * Scalable typefaces

NOTE: Disk-based (soft) bitmapped printer fonts must be in PCL format for HP LaserJet printers. Scalable typeface products must be in AGFA Compugraphic's FAIS format. All other font products require AutoFont Support files or .PCM files. Scalable typefaces require *HP Intellifont-for-Windows 3.0* or an AutoFont Support utility to use them with the HP Font Installer.

To access the **HP Font Installer** from the PCL 5 Printer Driver window, click on the **Fonts** button.

Cartridges

Support is already included for many of Hewlett-Packard's scalable typeface and bitmapped cartridges with the PCL 5 Printer Driver. Be sure to select a cartridge **before** you format your documents. The cartridge you select includes a list of fonts and point sizes that you will be able to use in your Windows applications.

You will not need to use the **Fonts** button or the HP Font Installer if your cartridge is listed (unless you need to install matching screen fonts for the *HP Intellifont-for-Windows 3.0* program).

Unlisted Cartridges

If you have a font cartridge that is unlisted, you must install AutoFont Support files (.TFM) or a Printer Cartridge Metric (.PCM) file which supports the fonts through the HP Font Installer.

If you do not have AutoFont Support diskettes for HP font products, you can order them by calling Hewlett-Packard at 303-353-7650. If you purchased a font cartridge from a company other than HP, call that company to see if a Windows 3.0 .PCM file or AutoFont Support file is available.

For specific instructions on the procedures to install new (unlisted) cartridges, view the Help file in the HP Font Installer window.

Ordering Typefaces

Copies

The **Copies** selection tells Windows how many uncollated copies you want to print from a software application. This setting is independent of the "copies selection" that may be available within the print menus of your software application.

Do not use the two selections simultaneously.

As a general rule: Set the number of copies in the PCL 5 Printer Driver window when you want to print uncollated copies. When you want sets of collated copies, select the number of copies from within your software application.

You should experiment to determine which selection works best for the kinds of jobs you print.

Defining Printer Memory

The **Memory** selection, which defines the amount of memory installed in a printer, should be configured to match your HP LaserJet printer. Windows uses this information to determine the amount of memory you have available for printing.

The HP LaserJet III and IIID printers come with a minimum of 1 megabyte of memory, standard, and can be expanded to 5 megabytes. If you are unsure how much memory is installed in your printer, you can run a Self Test printout using your HP LaserJet printer's front panel.

Ordering Additional Printer Memory

Additional printer memory can eliminate memory overflows (Error 21) if you print complex forms, full-page graphics and/or download many fonts.

Fonts Button

By clicking on the **Fonts** button you can access the **HP Font Installer** where you can install new printer fonts or, if you have *HP Intellifont-for-Windows 3.0* scalable typefaces. Step-by-step procedures for installing fonts can be found in the HP Font Installer help screens.

You can install any PCL compatible printer fonts with the HP Font Installer.

The following are the three separate methods that can be used to access the HP Font Installer:

1. If you have *HP Intellifont-for-Windows 3.0*, double-click on the **Intellifont** icon, then click on the **Fonts** button.
2. From the Program Manager's **Main** group, double-click on **Control Panel**, double-click on the **Printers** icon, click on the **Configure** button, click on the **Setup** button, then click on the **Fonts** button.
3. Within most software applications, click on the **File** title bar, click on **Printer** setup, click on the **Setup** button, then click on the **Fonts** button.

Ordering Scalable Typefaces and Fonts

Graphics Resolution

The Graphics Resolution settings in the printer setup dialog box affect the resolution of graphic images only, not text.

Graphics resolution is measured in **dots per inch** (dpi). Choosing 300 dpi will produce finer, higher-quality output. The output quality decreases as the resolution decreases to 150 and 75 dpi. However, on most printers, higher resolution output will take longer to print.

The amount of resident memory in your HP LaserJet printer determines the amount of graphics you can print on one page at higher resolutions (such as 300 dpi). The more memory your printer has, the more of a graphic image you can print at higher resolutions.

If the printer does not print the entire graphic image on one page and displays an "Error 20" message, then most likely the printer has run out of memory. You either need to install more memory in your printer or choose a lower graphics resolution setting.

Ordering Memory

Gray Scale Settings

Gray scale refers to a type of pattern that is applied to printed images. Though HP LaserJet printers print only black, these patterns produce a "gray" appearance on the printed page.

The best way to choose a setting for your graphic image is to **experiment**. Print a graphic at each setting and choose the one you like best.

To help you decide which selection to choose, the three settings are described here:

Photographic Images

Choose this setting for printed images that you want to have smooth, realistic and photographic appearance. The **Photographic Images** setting provides soft contrasts between various shades of gray. This setting also works well for images originally designed with color. The PCL 5 Printer Driver uses an 8 bit-by-8 bit "clustered dot" method to emulate 60 different levels of gray at this setting.

Line Art Images

Choose this setting for graphic images with intricate lines and fine detail, like "clip art" graphics. The **Line Art Images** setting provides solid lines and sharp contrasts between shaded areas. The PCL 5 Printer Driver uses 32 different 8 bit-by-8 bit "dispersed dot" patterns to produce gray tones.

HP ScanJet Images

Choose this setting if you graphic images were originally scanned in through an HP ScanJet. The **HP ScanJet Images** setting is specially tuned to provide exceptional quality and clarity to printed images originally scanned with an HP ScanJet. The PCL 5 Printer Driver uses a variation of the 8 bit-by-8 bit "clustered dot" method used in the Photographic Images setting. This method also produces 60 different levels of gray.

Orientation

Print orientation can be Portrait or Landscape. Portrait orientation means the page is taller than it is wide when you view the printed text upright. Landscape orientation means the page is wider than it is tall when you view the printed text upright.

NOTE: For HP LaserJet IID printer, when printing in duplex (double-sided) mode, orientation is an important consideration that effects the binding setup of your documents.

Page Protection

"Page Protection" refers to a HP LaserJet III or IIID printer setting that reserves additional memory for the creation of page images. Page protection is only available if you have installed at least 1 megabyte of optional memory in your HP LaserJet printer.

The selections, which are related to the size of the paper source you usually use, should match the selection on your printer's control panel settings.

The default is **off**. Other selections are **LTR** (letter-size paper), **A4**, or **LGL** (legal-size paper). To verify how your printer is configured, you can run a Self Test on your HP LaserJet printer.

The page protection feature allows the printer to create an entire page image in memory before physically moving the paper through the printer. This process ensures that the entire page will be printed and helps eliminate the "21 PRINT OVERRUN" error that can sometimes appear on the display of your HP LaserJet printer.

NOTE: This setting does not change any settings within your HP LaserJet printer. In order to set Page Protection you must configure your HP LaserJet printer using the printer's control panel. Refer to your HP LaserJet printer user's manual for more information.

Ordering Additional Memory

Paper Source and Paper Size

If you are unsure about which paper source and paper size is used in your printer, you can run a Self Test printout on your HP LaserJet printer.

Paper Source

For a **HP LaserJet III** printer, which has one paper tray, you can choose

- * Upper tray
- * Envelope
- * Manual Feed

For a **HP LaserJet IIID** printer, which has two paper trays and an optional envelope feeder, you can choose:

- * Upper tray
- * Lower tray
- * Envelope
- * Manual Feed
- * Auto Select

If you choose Manual or Envelope for the paper source, the PCL 5 Printer Driver will use this selection only until you exit Windows. The next time you start Windows, the paper source selection will revert to the default paper tray.

Paper Size

The PCL 5 Printer Driver lets you select four sizes of paper and four sizes of envelopes.

Letter	8.5 x 11 inches
Legal	8.5 x 14 inches
A4	210 x 297 mm
Executive	7.25 x 10.5 inches

Envelopes	
COM-10	4 1/8 x 9 1/2 inches
Monarch	3 7/8 x 7 1/2 inches
DL	110 x 220 mm
C5	162 x 229 mm

Ordering Paper Trays

Selecting a Printer Model

The PCL 5 Printer Driver supports the HP LaserJet III and IIID printers.

NOTE: The title shown in many Windows menus simply lists "LaserJet III printer" driver. The HP LaserJet III driver also includes support for the HP LaserJet IIID printer. You will not see the HP LaserJet IIID printer listed separately.

Special Options -- Duplex Printing

Special options are available supporting duplex (two-sided) printing for the HP LaserJet IID printer. The default selection is "None" for single-sided printing. If you want to print in duplex mode, you should determine how your finished document will be bound:

"Long-edge" binding setup in portrait orientation is used for conventional layouts in book binding. Long-edge in landscape orientation is often used in accounting and spreadsheet applications because pages can be flipped through as on a clipboard.

"Short-edge binding setup in portrait orientation is often used for calendar-like books. Short-edge in landscape orientation is another variation of conventional book layouts.

Ordering Accessories for Your HP LaserJet Printer

To order additional printer memory boards, paper trays and font or typeface products, check with your authorized HP dealer.

To locate your nearest HP dealer or to receive additional product sales information, or to order a accessory catalog, call Hewlett-Packard's Customer Information Center at:

USA 1-800-752-0900

Canada 1-800-387-3867

Other countries Contact a Hewlett-Packard sales office

If your dealer is temporarily out of stock, call Hewlett-Packard for fast-ship service:

USA 1-800-538-8787

Canada

Toronto 416-671-8383

Ontario/Quebec 1-800-387-3417

Other provinces 1-800-387-3154

Free copies of *HP Intellifont-for-Windows 3.0* can be obtained by calling 303-353-7650 (offer good in USA and Canada).

To run a Self Test printout on your HP LaserJet III or IIID printer, take your printer off-line (light out), press and hold down the TEST button on your printer's control panel until 05 SELF TEST appears. A printout will be generated in a few moments.

AutoFont Support files are provided with all HP font and typeface products. These files contain font metric (width) information used by the HP Font Installer. AutoFont Support files are usually shipped with special installation utilities that must be run prior to using the HP Font Installer.

Binding refers to the process of joining a stack of printed sheets with stitches (staples), three-hole, glue or some other means.

An acronym for "What You See Is What Your Get." The screen fonts that appear on your display match the fonts used in your printer.

The term **scalable** describes products that can be reduced or enlarged (scaled) to virtually any point size from 4 to 127 (or even greater). CG Times and Univers are examples of scalable typefaces.

Conversely, **bitmapped** fonts are limited to an exact point size. A bitmapped font can not be reduced or enlarged (non-scalable). Courier 10 point is an example of a bitmapped fonts.

A **driver** is a portion of software code that controls commands sent to a device such as a printer or screen. Drivers work automatically so that you don't have to enter in programming codes. Drivers allow you to select fonts, set margins, number of copies, etc.

In multiple page jobs that are **uncollated** several copies of page One are printed followed by several copies of page Two, followed by several copies of page Three, etc.

In multiple page jobs that are **collated**, a complete set of pages in a job are printed followed by another complete set of pages. For example: One copy of Page 1, then Page 2, then Page 3; followed by another copy of Page 1, then Page 2, then Page 3.

HP Intellifont-for-Windows 3.0 is a software program from Hewlett-Packard that includes a special screen font driver in addition to the PCL 5 Printer Driver and HP Font Installer. With *HP Intellifont-for-Windows 3.0* loaded, scalable typeface products can be directly installed to produce both printer fonts and screen fonts.

HP Intellifont-for-Windows 3.0, requires an IBM PC-AT or compatible (286 and above) and a minimum of 1 megabyte of extended RAM. Call 303-353-7650 to order a free copy (USA and Canada only).

Manual feed is often used for printing non-standard sizes of paper, envelopes, labels and transparencies. Also, when an occasional page of special paper, such as letter-head or color paper, is wanted without having to open and load a paper tray.

If **Auto Select** is used for a HP LaserJet IIID printer and both paper trays have the same size of paper, the printer will automatically print from the top tray until it is empty, then continue printing from the lower tray.

Auto Select can also be used if you store different size paper (for example, letter-size paper in one tray and legal-size paper in the other).

